



EN

# Operation & Maintenance Manual

## Compact Excavator



E60 S/N: B4HV11001 & Above



# OPERATOR SAFETY WARNINGS



- Never operate without instructions. Read machine signs (decals), Operation & Maintenance Manual, and Operator's Handbook.
- Operator must have instructions before operating the machine. Untrained operators can cause injury or death.

## SAFETY EQUIPMENT

The Bobcat® excavator must be equipped with safety items necessary for each job. Ask your Bobcat dealer for information on the availability and safe use of attachments and accessories.

- **SEAT BELT:** Check belt fasteners and check for damaged webbing or buckle.
- **OPERATOR CAB / CANOPY:** Check condition and mounting hardware.
- **OPERATOR'S HANDBOOK:** Must be in the cab / canopy.
- **LEFT HAND CONSOLE:** When raised must deactivate the travel and hydraulic functions.
- **SAFETY SIGNS (DECALS):** Replace if damaged.
- **GRAB HANDLES:** Replace if damaged.
- **INTEGRATED SLEW LOCK BRAKE.**
- **SAFETY TREAD:** Replace if damaged.



This check mark means: "Follow instructions for proper operations." Carefully read the message that follows.



- Fasten seat belt securely.
- Operate controls only from operator's seat.



- To leave excavator, lower the work equipment and the blade to the ground.
- Stop the engine.


# OPERATOR SAFETY WARNINGS




This Safety Alert Symbol means: "Attention! Be Alert! Your Safety is Involved!" Carefully read the message that follows.



- Do not grasp controls when entering cab / canopy.
- Be sure controls are in neutral before starting.
- Sound horn and check behind machine before starting.



- Never operate without approved cab / canopy.
- Never modify equipment.
- Never use attachments not approved by Bobcat Company.



- Never exceed a 15° slope to the side.
- Never travel up a slope that exceeds 15°.
- Never exceed 25° when going down or backing up a slope.



- Keep bystanders out of maximum reach area.
- Do not travel or turn with bucket extended.
- Look in the direction of rotation and make sure no bystanders are in the work area.



- Use caution to avoid tipping. Do not swing a heavy load over side of track.
- Operate on flat, level ground.



- Never carry riders.



- Avoid steep areas or banks that could break away.



<b>FOREWORD</b> .....	9
<b>DECLARATION OF CONFORMITY (MACHINE)</b> .....	9
<b>DECLARATION OF CONFORMITY (TOUCH DISPLAY)</b> .....	10
<b>DECLARATION OF CONFORMITY (RADIO)</b> .....	11
<b>DECLARATION OF CONFORMITY (HYDROFLUOROCARBON)</b> .....	13
<b>INTRODUCTION</b> .....	14
Bobcat Company Is ISO 9001 Certified .....	14
<b>MANUFACTURING LOCATIONS</b> .....	14
North America .....	14
Czech Republic .....	14
<b>SERIAL NUMBER LOCATIONS</b> .....	15
Machine Serial Number Location .....	15
Engine Serial Number Location .....	15
<b>DELIVERY REPORT</b> .....	15
<b>EXCAVATOR IDENTIFICATION</b> .....	16
Front View .....	16
Rear View .....	16
<b>FEATURES, ACCESSORIES, AND ATTACHMENTS</b> .....	17
Standard Items .....	17
Options And Accessories .....	17
Attachments .....	17
Buckets Available.....	17
Falling-Object Protective Structure (FOPS).....	18
Top Guard (FOPS II) Kit .....	18
Front Guard Kit.....	18
Inspecting And Maintaining The Front Guard Kit .....	18
<b>SAFETY AND TRAINING RESOURCES</b> .....	19
<b>SAFETY INSTRUCTIONS</b> .....	19
Before Operation .....	19
Safe Operation Is The Operator’s Responsibility .....	19
Safe Operation Needs A Qualified Operator.....	19
A Qualified Operator Must Do The Following.....	19
Silica Dust Exposure.....	20
<b>FIRE PREVENTION</b> .....	20
Maintenance .....	20
Operation .....	20
Electrical .....	20
Hydraulic System.....	20
Fuelling.....	21
Starting.....	21
Exhaust System.....	21
Welding And Grinding .....	21
Fire Extinguishers .....	21
<b>PUBLICATIONS AND TRAINING RESOURCES</b> .....	22
<b>PICTORIAL ONLY SAFETY SIGNS</b> .....	22
<b>MACHINE SIGNS (DECALS)</b> .....	23
<b>OPERATING INSTRUCTIONS</b> .....	32
<b>INTENDED USE</b> .....	32
<b>INSTRUMENTS AND CONSOLES</b> .....	33
Left Console .....	33
Right Console .....	34
Standard Display .....	36
Touch Display .....	38

Jog Shuttle (Standard Display).....	40
Using The Jog Shuttle With Standard Display.....	40
Jog Shuttle (Touch Display).....	41
Using The Jog Shuttle With Touch Display .....	41
<b>REAR VIEW CAMERA SYSTEM</b> .....	42
Operating Rear View Camera .....	42
Cleaning And Maintaining Rear View Camera .....	42
Adjusting Rear View Camera Position .....	43
<b>RADIO</b> .....	44
Radio Identification.....	44
Operating Radio Timer .....	44
Adjusting Radio Settings.....	45
Operating The Radio Clock .....	45
<b>RAISING AND LOWERING THE CONSOLE</b> .....	46
<b>TWO-SPEED TRAVEL</b> .....	46
Engaging Two-Speed Travel (Without Angle Blade Option).....	46
Engaging Two-Speed Travel (With Angle Blade Option) .....	47
Auto Shift Drive Motors.....	47
<b>AUTO IDLE</b> .....	48
Auto Idle Description.....	48
Activating Auto Idle.....	48
<b>OPERATOR CAB (ROPS / TOPS / FOPS)</b> .....	48
Operating The Cab Door.....	48
Operating The Front Window .....	49
Operating The Right Windows .....	50
Operating The Cab Interior Light .....	50
Window Washer Reservoir.....	51
Heating, Ventilation, And Air Conditioning Ducting .....	51
<b>EMERGENCY EXITS</b> .....	51
Emergency Exit Locations.....	51
Making An Emergency Exit Through The Front Window .....	51
Making An Emergency Exit Through The Right Side Window.....	51
<b>TRAVEL MOTION ALARM</b> .....	52
Travel Motion Alarm Description.....	52
Disabling The Travel Motion Alarm .....	52
<b>TRAVEL CONTROLS</b> .....	52
Forward And Reverse Travel .....	52
<b>HYDRAULIC CONTROLS</b> .....	54
Hydraulic Controls Description .....	54
ISO Control Pattern .....	55
<b>QUICK COUPLERS</b> .....	55
Connecting Quick Couplers.....	56
<b>PRIMARY AUXILIARY HYDRAULICS</b> .....	56
Operating Attachments With Primary Auxiliary Hydraulics.....	56
Setting Auxiliary Hydraulics Flow Rate.....	57
Releasing Hydraulic Pressure in Excavator.....	58
Releasing Hydraulic Pressure In Attachments .....	58
<b>SECONDARY AUXILIARY HYDRAULICS</b> .....	59
Operating Attachments With Secondary Auxiliary Hydraulics.....	59
Releasing Secondary Auxiliary Hydraulic Pressure In Excavator .....	60
Releasing Secondary Auxiliary Hydraulic Pressure In Attachments.....	60
<b>FOURTH AUXILIARY HYDRAULICS</b> .....	60
Location Of Fourth Auxiliary Hydraulics Lines.....	60
Operating Attachments With Primary, Secondary, And Fourth Auxiliary Hydraulics.....	60
Auxiliary Hydraulics Settings Sequence .....	62
<b>THIRD AUXILIARY HYDRAULICS</b> .....	63
Operating Attachments With Third Auxiliary Hydraulics .....	63

<b>OVERLOAD WARNING DEVICE</b> .....	64
Operating The Overload Warning Device .....	64
<b>BLADE CONTROL LEVER</b> .....	65
Raising And Lowering The Blade .....	65
<b>ANGLE BLADE</b> .....	65
Operating The Angle Blade .....	65
<b>DIESEL PARTICULATE FILTER (DPF) SYSTEM</b> .....	66
DPF Description .....	66
DPF Regeneration Tables .....	67
DPF Regeneration Status Icons .....	68
Automatic Regeneration Operation .....	68
Forced Regeneration Operation .....	69
Forced Parked Regeneration Operation .....	70
Inhibit Mode Operation .....	71
<b>ENGINE SPEED CONTROL</b> .....	72
Setting Engine Speed (RPM) .....	72
Eco Mode .....	72
<b>BOOM SWING</b> .....	73
Enabling Boom Swing .....	73
<b>DAILY INSPECTION</b> .....	74
Daily Inspection And Maintenance List .....	74
<b>PRE-STARTING PROCEDURE</b> .....	75
Entering The Excavator .....	75
Operation & Maintenance Manual And Operator's Handbook Locations .....	75
Seat Adjustment .....	76
Adjusting Mirrors .....	76
Fastening The Seat Belt .....	76
<b>STARTING THE ENGINE</b> .....	77
Quick Start Description .....	77
Starting The Engine .....	77
Lowering The Control Console .....	78
Warming The Hydraulic System .....	78
Cold Temperature Starting Tips .....	78
<b>MONITORING THE DISPLAY</b> .....	79
Monitoring The Standard Display During Operation .....	79
Monitoring The Touch Display During Operation .....	79
Derate And Shutdown Conditions .....	80
<b>OPERATING PROCEDURE</b> .....	80
Inspect The Work Area .....	80
Basic Operating Instructions .....	80
Operating Near An Edge Or Water .....	80
Lowering The Work Group If The Engine Stops .....	80
Driving The Excavator .....	81
Operating On Slopes .....	81
Operating In Water .....	83
Protecting The Track From Damage .....	84
<b>STOPPING THE ENGINE AND LEAVING THE MACHINE</b> .....	85
Stopping The Engine And Leaving The Machine .....	85
<b>INSTALLING ATTACHMENTS (PIN-ON ATTACHMENT)</b> .....	86
<b>REMOVING ATTACHMENTS (PIN-ON ATTACHMENT)</b> .....	87
<b>INSTALLING ATTACHMENTS (QUICK COUPLER, KLAC SYSTEM)</b> .....	88
<b>REMOVING ATTACHMENTS (QUICK COUPLER, KLAC SYSTEM)</b> .....	90
<b>INSPECTING AND ADJUSTING THE QUICK COUPLER LATCH</b> .....	91
<b>INSTALLING ATTACHMENTS (GERMAN STYLE COUPLER)</b> .....	92
<b>REMOVING ATTACHMENTS (GERMAN STYLE COUPLER)</b> .....	94
<b>INSTALLING ATTACHMENTS (MECHANICAL PIN GRABBER COUPLER)</b> .....	95
<b>REMOVING ATTACHMENTS (MECHANICAL PIN GRABBER COUPLER)</b> .....	97

<b>INSTALLING ATTACHMENTS (HYDRAULIC QUICK COUPLER)</b> .....	99
<b>REMOVING ATTACHMENTS (HYDRAULIC QUICK COUPLER)</b> .....	102
<b>HYDRAULIC CLAMP</b> .....	104
Hydraulic Clamp Operation.....	104
Using Primary Auxiliary Hydraulics To Activate Clamp.....	104
Using Secondary Auxiliary Hydraulics to Activate Clamp.....	104
<b>HANDLING OBJECTS</b> .....	105
Handling Objects With The Lifting Device.....	105
<b>LIFT CAPACITY</b> .....	107
Lift Capacity Description.....	107
Calculating Lift Capacity.....	107
Attachment Mounting System And Clamp Weights.....	108
<b>BOOM LOAD HOLDING VALVE</b> .....	108
Location Of Boom Load Holding Valve.....	108
Lowering Boom With Load Holding Valve With Base End Hose Failure.....	109
Lowering Boom With Load Holding Valve With Rod End Hose Failure – With Accumulator Pressure.....	109
Lowering Boom With Load Holding Valve With Rod End Hose Failure And No Accumulator Pressure Or Loss Of Hydraulic Pressure.....	109
<b>ARM LOAD HOLDING VALVE</b> .....	110
Location Of Arm Load Holding Valve.....	110
Lowering Arm with Load Holding Valve With Base End Hose Failure.....	111
Lowering Arm With Load Holding Valve With Rod End Hose Failure – With Accumulator Pressure.....	111
Lowering Arm With Rod End Hose Failure And No Accumulator Pressure Or Loss Of Hydraulic Pressure.....	111
<b>DEPTH CHECK (STANDARD DISPLAY)</b> .....	112
Depth Check Description.....	112
Depth Check Screen.....	112
Changing The Depth Check Screen.....	113
Calibrating The Boom.....	113
Calibrating The Arm.....	115
Calibrating The Attachment.....	117
Setting Target Depth.....	119
Description Of Grade And Warning Zones.....	120
Setting The Warning Zone.....	120
Setting The Grade Zone.....	121
Digging To A Target Depth.....	121
Repositioning The Excavator And Continuing To Dig To The Original Depth.....	122
Setting Up A Laser With Depth Check.....	123
Benching With A Laser System.....	124
<b>DEPTH CHECK (TOUCH DISPLAY)</b> .....	125
Depth Check Description.....	125
Depth Check Screen.....	126
Setting The Default Depth Check Screen.....	126
Switching Unit Scale.....	127
Calibrating The Boom.....	127
Calibrating The Arm.....	130
Calibrating The Attachment.....	131
Setting Target Depth.....	133
Description Of Grade And Warning Zones.....	134
Setting The Warning Zone.....	134
Setting The Grade Zone.....	134
Digging To A Target Depth.....	135
Repositioning The Excavator And Continuing To Dig To The Original Depth.....	136
Digging To A Target Depth And Width.....	136
Setting Up A Laser With Depth Check.....	137
Benching With A Laser System.....	138
<b>TROUBLESHOOTING THE DEPTH CHECK SYSTEM</b> .....	140
Checking The Bucket Sensor.....	140

Checking The Arm Sensor .....	141
Checking The Boom Sensor .....	141
<b>TOWING THE MACHINE</b> .....	142
Towing The Machine .....	142
<b>LIFTING THE MACHINE</b> .....	143
Lifting The Machine .....	143
<b>TRANSPORTING THE MACHINE</b> .....	144
Fastening The Machine To A Trailer .....	145
<b>MAINTENANCE SAFETY WARNINGS</b> .....	147
<b>MAINTENANCE SAFETY WARNINGS</b> .....	148
<b>PREVENTIVE MAINTENANCE</b> .....	149
<b>SERVICE SCHEDULE</b> .....	149
Maintenance Intervals .....	149
Service Schedule .....	149
Inspection Checkbook .....	153
<b>CONTROL CONSOLE LOCKOUTS</b> .....	153
Inspecting And Maintaining The Control Console Lockouts .....	153
<b>SEAT BELT</b> .....	154
Inspecting And Maintaining The Seat Belt .....	154
<b>TRAVEL MOTION ALARM</b> .....	155
Travel Motion Alarm Description .....	155
Inspecting The Travel Motion Alarm System .....	155
Maintaining The Travel Motion Alarm Switch .....	156
<b>TAILGATE</b> .....	157
Opening And Closing The Tailgate .....	157
<b>RIGHT SIDE COVER</b> .....	158
Opening And Closing The Right Side Cover .....	158
<b>RIGHT SIDE PANEL</b> .....	158
Removing And Installing The Right Side Panel .....	158
<b>RIGHT SIDE GRILLE</b> .....	159
Removing And Installing The Right Side Grille .....	159
<b>CAB FILTERS</b> .....	159
Cleaning And Maintaining The Recirculation Filter .....	159
Cleaning And Maintaining The Fresh Air Filter .....	160
<b>HEATING, VENTILATION, AND AIR CONDITIONING (HVAC)</b> .....	160
Cleaning HVAC Filters .....	160
<b>ENGINE AIR CLEANER</b> .....	161
Replacing The Outer Filter Of The Air Cleaner .....	161
Replacing The Inner Filter Of The Air Cleaner .....	162
<b>FUEL SYSTEM</b> .....	163
Fuel Specifications .....	163
Biodiesel Blend Fuel .....	163
Filling The Fuel Tank .....	163
Using The Fuel Fill Pump .....	164
Removing Water From The Fuel Filter .....	165
Replacing The Fuel Filter .....	165
Replacing The Fuel Pre-Filter .....	166
Replacing The Fuel Tank Vent Filter .....	167
Draining The Fuel Tank .....	167
<b>ENGINE LUBRICATION SYSTEM</b> .....	168
Checking And Adding Engine Oil .....	168
Engine Oil Chart .....	168
Replacing Engine Oil And Filter .....	168
<b>ENGINE COOLING SYSTEM</b> .....	169
Cleaning The Engine Cooling System .....	169
Checking Coolant Level .....	170

Replacing Coolant (Cab Models) .....	170
<b>ELECTRICAL SYSTEM</b> .....	172
Electrical System Description .....	172
Fuse And Relay Identification .....	172
Battery Disconnect Switch .....	174
Battery Maintenance .....	174
Maintaining Battery Charge Level .....	175
Battery Service During Machine Storage .....	175
Testing The Battery .....	175
Battery Charging .....	175
Using A Booster Battery (Jump Starting) .....	175
Removing And Installing The Battery .....	176
<b>HYDRAULIC SYSTEM</b> .....	177
Checking And Adding Hydraulic Fluid .....	177
Hydraulic Fluid Chart .....	178
Replacing The Hydraulic Filter .....	178
Replacing The Case Drain Filter .....	179
Replacing Hydraulic Fluid .....	179
<b>DIESEL PARTICULATE FILTER (DPF) SYSTEM</b> .....	181
DPF Service Description .....	181
DPF Service Regeneration .....	181
DPF Cleaning .....	181
<b>TRACK TENSION</b> .....	182
Track Tension Description .....	182
Types of Track Tensioning Systems .....	182
Adjusting Track Tension Manually .....	182
Adjusting Track Tension Automatically .....	184
Adjusting The Hydraulic Pressure Reducing Valve .....	184
Returning The Hydraulic Pressure Reducing Valve To Factory Setting .....	185
<b>TRAVEL MOTOR</b> .....	185
Checking And Adding Travel Motor Fluid .....	185
Replacing Travel Motor Fluid .....	185
<b>BELTS</b> .....	186
Adjusting Alternator Belt .....	186
Replacing Alternator Belt .....	186
Adjusting Air Conditioning Belt .....	188
Replacing Air Conditioning Belt .....	188
<b>QUICK COUPLER</b> .....	188
Inspecting And Maintaining The Bucket Link And Coupler .....	188
<b>BUCKET TEETH</b> .....	189
Replacing Bucket Teeth .....	189
<b>CUTTING EDGE (ANGLE BLADE ONLY)</b> .....	189
Reversing Or Replacing The Angle Blade .....	189
<b>MACHINE LUBRICATION</b> .....	190
Grease Fitting Locations .....	190
Lubricate Every 8 – 10 Hours .....	190
Lubricate Every 50 Hours .....	192
<b>PIVOT PINS</b> .....	192
Pivot Pin Inspection And Maintenance .....	192
<b>STORAGE AND RETURN TO SERVICE</b> .....	193
Extended Storage Procedure .....	193
Returning Machine To Service .....	193
<b>SYSTEM SETUP AND ANALYSIS</b> .....	194
<b>NAVIGATION (STANDARD DISPLAY)</b> .....	194
Opening Navigation Bar .....	194
Active Shortcuts .....	194

<b>VITALS (STANDARD DISPLAY)</b> .....	195
Accessing Vital Detail And Machine Performance .....	195
<b>SERVICE (STANDARD DISPLAY)</b> .....	196
Recording A Service .....	196
Viewing Service Codes .....	196
<b>SETTINGS (STANDARD DISPLAY)</b> .....	197
Adjusting Display Brightness .....	197
Managing Operators .....	197
Machine Lockout And Quick Start .....	197
Password Description .....	197
Enabling Machine Lockout And Quick Start .....	197
Setting The System Language .....	198
Switching Between English / Metric Units .....	198
Software Version .....	198
<b>GAUGES (TOUCH DISPLAY)</b> .....	199
Notification Drawer .....	199
Accessing Vital Detail And Machine Performance .....	199
<b>CAMERA (TOUCH DISPLAY)</b> .....	200
Operating Rear View Camera .....	200
Adjusting Rear View Camera Settings .....	201
<b>PHONE (TOUCH DISPLAY)</b> .....	201
<b>AUDIO (TOUCH DISPLAY)</b> .....	202
<b>SERVICE (TOUCH DISPLAY)</b> .....	202
Viewing Service Codes .....	202
Viewing And Adjusting Service Schedule .....	203
Recording A Service .....	203
Removing Service Records .....	204
<b>ATTACHMENTS (TOUCH DISPLAY)</b> .....	205
Accessing Attachment Information .....	205
<b>SETTINGS (TOUCH DISPLAY)</b> .....	206
Setting Date And Time .....	206
Adjusting Display Brightness .....	206
Releasing Hydraulic Pressure In Excavator .....	207
Setting The Auxiliary Hydraulics Flow .....	208
Activating Auto Idle .....	209
Password Description .....	209
Changing The Owner And Operator Passwords .....	209
Adding An Operator .....	210
Removing An Operator .....	210
Machine Lockout And Quick Start .....	211
Enabling Machine Lockout and Quick Start .....	211
Auto Lock Time At Key OFF .....	211
System Sleep Time At Key OFF .....	212
Enabling Password Error Lockout .....	212
Accessing Operator Statistics .....	212
Using The Job Clock .....	213
Setting The System Language .....	214
Switching Between English / Metric Units .....	214
Dealer Information .....	214
Software Version .....	214
<b>DIAGNOSTIC SERVICE CODES</b> .....	215
Service Codes List .....	215
<b>SPECIFICATIONS</b> .....	226
<b>MACHINE DIMENSIONS</b> .....	226
<b>RATED LIFT CAPACITY – LONG ARM AND ADD ON COUNTERWEIGHT</b> .....	232
<b>RATED LIFT CAPACITY – LONG ARM AND HEAVY COUNTERWEIGHT</b> .....	233

<b>RATED LIFT CAPACITY – STANDARD ARM AND HEAVY COUNTERWEIGHT</b> .....	234
<b>EXCAVATOR SPECIFICATIONS</b> .....	235
Performance Specifications.....	235
Controls Specifications.....	235
Engine Specifications.....	235
Hydraulic System Specifications.....	236
Hydraulic Cylinders .....	237
Hydraulic Cycle Times .....	237
Electrical System Specifications.....	237
Drive System Specifications .....	238
Slew System Specifications.....	238
Undercarriage Specifications.....	238
Capacities Specifications.....	238
Track Specifications .....	238
Ground Pressure Specifications .....	238
Environmental Specifications.....	239
Temperature Range .....	239
<b>WARRANTY</b> .....	240
<b>BOBCAT® EXCAVATORS WARRANTY</b> .....	240

## DECLARATION OF CONFORMITY (MACHINE)

<b>Contents of EC Declaration of Conformity</b>					
<p>This information is provided in the operators manual to comply with clause 1.7.4.2(c) of Annex I of Machinery Directive 2006/42/EC.</p> <p>The official EC Declaration of Conformity is supplied in a separate document.</p>					
<p><b>Manufacturer</b></p>  <p>Bobcat Company World Headquarters 250 East Beaton Drive West Fargo, ND 58078-6000 United States of America</p>	<p><b>Directive 2000/14/EC: Noise Emission in the Environment by Equipment For Use Outdoors</b></p> <p><b>Notified Body</b></p> <p>Technical and Test Institute for Construction Prague Czech Republic Notified Body Number: 1020</p> <p><b>EC Certificate No.</b></p> <p>1020-090-022395</p>				
<p><b>Technical Documentation</b></p> <p>Homologation Manager Doosan Bobcat EMEA s.r.o U Kodetky 1810 26312 Dobris Czech Republic</p>	<p><b>Conformity Assessment Procedure(s)</b></p> <p>2000/14/EC, Annex VIII, Full Quality Assurance</p> <p><b>Sound Power Levels [Lw(A)]</b></p> <table style="width: 100%; border: none;"> <tr> <td style="width: 80%;">Measured Sound Power</td> <td style="text-align: right;"><b>96.3 db(A)</b></td> </tr> <tr> <td>Guaranteed Sound Power</td> <td style="text-align: right;"><b>97 db(A)</b></td> </tr> </table>	Measured Sound Power	<b>96.3 db(A)</b>	Guaranteed Sound Power	<b>97 db(A)</b>
Measured Sound Power	<b>96.3 db(A)</b>				
Guaranteed Sound Power	<b>97 db(A)</b>				
<p><b>Description of Equipment</b></p> <p>Type of Equipment: Excavator Model Name: E60 Model Code: B4HV</p> <p>Engine Manufacturer: Bobcat Company Engine Model: DM02VB DM02-MFE01 Engine Power: 41.0 kW @ 2200 rpm</p>	<p><b>Equipment conforms to CE Directive(s) Listed Below</b></p> <p>2006/42/EC: Machinery Directive 2014/30/EU: Electromagnetic Compatibility Directive</p>				
<p><b>Declaration of Conformance</b></p> <p>This equipment conforms to the requirements specified in all the EC Directives listed in this declaration.</p>					
<p><b>Effective From:</b></p> <p>26 March 2021</p>					

## DECLARATION OF CONFORMITY (TOUCH DISPLAY)

*EU Declaration of Conformity under the terms of Directive No. 2014/53/EU (RED directive)*

1. No ... (unique identification of the product)  
**Multiview Media Display**
2. Name and address of the manufacturer or his authorised representative:  
**Continental Automotive GmbH  
Heinrich-Hertz-Str. 45  
78052 Villingen-Schwenningen  
Germany**
3. This declaration of conformity is issued under the sole responsibility of the manufacturer (or installer):  
**Continental Automotive GmbH declares as a manufacturer that the above-mentioned product complies with the necessary requirements of Directive 2014/53/EU (RED Directive) when used for its intended purpose.**
4. Object of the declaration (identification of product allowing traceability. It may include a colour image of sufficient clarity to enable the identification of the product, where appropriate.)  
**Not applicable.**
5. The object of the declaration described in point 4 is in conformity with the relevant Union harmonisation legislation:  
**Directive 2014/53/EU**  
  
Additional relevant Union harmonisation legislation:  
**None.**
6. References to the relevant harmonised standards used, or references to the specifications in relation to which conformity is declared:
  - **EN 300 328 V2.1.1**
  - **DRAFT EN 301 489-1 V2.2.0; DRAFT EN 301 489-17 V3.2.0**
  - **EN 62311:2008**
  - **EN 62368-1:2014 / AC:2015 / A11:2017 / AC:2017**
7. The notified body **CTC advanced, 0682** has performed Tests and has issued the EC approval certificate **T818817M-01-TEC**.
8. If available, a description of the accessories and the components, including the software that enables the operation of the radio system and which is covered by the EU Declaration of Conformity:  
**Not applicable.**
9. Additional information:  
**None.**

Signed for and on behalf of:  
**Continental Automotive GmbH  
Heinrich-Hertz-Str. 45  
78052 Villingen-Schwenningen  
Germany**

Place and date of issue:  
**Villingen-Schwenningen, 21 January 2021**

**Dr. Marion Grüner (Homologation)**  
(Name, function)

## DECLARATION OF CONFORMITY (RADIO)

*EU Declaration of Conformity under the terms of Directive No. 2014/53/EU (RED directive)*

1. No ... (unique identification of the product)  
**Bobcat Radio**  
**Hardware Version: A2C 399933**
2. Name and address of the manufacturer or his authorised representative:  
**Continental Automotive GmbH**  
**Heinrich-Hertz-Str. 45**  
**78052 Villingen-Schwenningen**  
**Germany**
3. This declaration of conformity is issued under the sole responsibility of the manufacturer ~~(or installer)~~:  
**Continental Automotive GmbH declares as a manufacturer that the above-mentioned product complies with the necessary requirements of Directive 2014/53/EU (RED Directive) when used for its intended purpose.**
4. Object of the declaration (identification of product allowing traceability. It may include a colour image of sufficient clarity to enable the identification of the product, where appropriate.)  
**Not applicable.**
5. The object of the declaration described in point 4 is in conformity with the relevant Union harmonisation legislation:  
**Directive 2014/53/EU**  
  
Additional relevant Union harmonisation legislation:  
**None.**
6. References to the relevant harmonised standards used, or references to the specifications in relation to which conformity is declared:
  - **EN 62368-1:2014/AC:2015/A11:2017/AC:2017**
  - **EN 62479:2010**
  - **Draft EN 301 489-1 V2.2.0**
  - **Draft EN 301 489-17 V3.2.0**
  - **EN 300 328 V2.1.1**
  - **Draft EN 303 345 v.1.1.7**
  - **EN 303 345-2 V1.1.1**
7. The notified body **CTC advanced, 0682 has performed Tests** and has issued the EC approval certificate **T818837N-01-TEC**.
8. If available, a description of the accessories and the components, including the software that enables the operation of the radio system and which is covered by the EU Declaration of Conformity:  
**Not applicable.**
9. Additional information:  
**None.**

Signed for and on behalf of:  
**Continental Automotive GmbH**  
**Heinrich-Hertz-Str. 45**  
**78052 Villingen-Schwenningen**  
**Germany**

Place and date of issue:  
**Villingen-Schwenningen, 11 February 2021**

**Dr. Marion Grüner (Homologation)**  
(Name, function)

A handwritten signature in cursive script, appearing to read 'Grüner', positioned to the right of the text block.

**DECLARATION OF CONFORMITY (HYDROFLUOROCARBON)**

**DOOSAN BOBCAT EMEA**  
U Kodetky 1810  
Dobris, 263 12  
Czech Republic  
T: +420 318 532 444

www.doosanbobcat.com

**Declaration of conformity with Article 14 of Regulation (EU) No 517/2014 of the  
European Parliament and of the Council**

We Doosan Bobcat s.r.o. with VAT number CZ26489201, acting in its capacity as EU representative for the import of goods from CLARK EQUIPMENT COMPANY doing business as BOBCAT COMPANY, a corporation organized under the laws of the State of Delaware, USA with its registered address located at 250 East Beaton Drive, West Fargo, North Dakota, USA, declare under our sole responsibility that when placing on the market pre-charged equipment, which we import to or manufacture in the Union, the hydrofluorocarbons contained in that equipment are accounted for within the quota system referred to in Chapter IV of Regulation (EU) No 517/2014 as:

A. we hold authorisation(s) issued in accordance with Article 18(2) of Regulation (EU) No 517/2014 and registered in the registry referred to in Article 17 of that Regulation, at the time of release for free circulation to use the quota of a producer or importer of hydrofluorocarbons subject to Article 15 of Regulation (EU) No 517/2014 that cover(s) the quantity of hydrofluorocarbons contained in the equipment.

B. *[for importers of equipment only]* the hydrofluorocarbons contained in the equipment have been placed on the market in the Union, subsequently exported and charged into the equipment outside the Union, and the undertaking that placed the hydrofluorocarbons on the market made a declaration stating that the quantity of hydrofluorocarbons has been or will be reported as placed on the market in the Union and that it has not been and will not be reported as direct supply for export in the meaning of Article 15(2)(c) of Regulation (EU) No 517/2014 pursuant to Article 19 of Regulation (EU) No 517/2014 and Section 5C of the Annex to Commission Implementing Regulation (EU) No 1191/2014 (2).

C. *[for equipment manufactured in the Union only]* the hydrofluorocarbons charged into the equipment were placed on the market by a producer or importer of hydrofluorocarbons subject to Article 15 of Regulation (EU) No 517/2014.

Miguel Mallo Marcos

27th March, 2019

A handwritten signature in black ink, appearing to be "Miguel Mallo Marcos", written over a horizontal line.

## INTRODUCTION

This Operation & Maintenance Manual was written to give the owner / operator instructions on the safe operation and maintenance of the Bobcat machine. Read and understand this Operation & Maintenance Manual before operating your Bobcat machine. If you have any questions, see your Bobcat dealer. This manual may illustrate options and accessories not installed on your machine.

### Bobcat Company Is ISO 9001 Certified



ISO 9001 is an international standard that specifies requirements for a quality management system that controls the processes and procedures that we use to design, develop, manufacture, and distribute Bobcat products.

British Standards Institute (BSI) is the Certified Registrar that Bobcat Company chose to assess the company's compliance with ISO 9001 at Bobcat's manufacturing facilities in Gwinner, North Dakota (U.S.A.), Pontchâteau (France), and the Bobcat corporate offices (Gwinner, Bismarck, and West Fargo) in North Dakota. TÜV Rheinland is the Certified Registrar that Bobcat Company chose to assess the company's compliance with ISO 9001 at Bobcat's manufacturing facility in Dobříš (Czech Republic). Only certified assessors, like BSI and TÜV Rheinland, can grant registrations.

ISO 9001 means that as a company we say what we do and do what we say. In other words, we have established procedures and policies, and we provide evidence that the procedures and policies are followed.

## MANUFACTURING LOCATIONS

### North America

Bobcat Company  
250 E. Beaton Drive  
West Fargo, ND 58078  
USA

### Czech Republic


Doosan Bobcat EMEA s.r.o.  
U Kodetky 1810  
263 12 Dobříš  
Czech Republic

## SERIAL NUMBER LOCATIONS

Always use the serial number of the machine when requesting service information or when ordering parts. Earlier or later models (identification made by serial number) may use different parts, or it may be necessary to use a different procedure to do a specific service operation.

### Machine Serial Number Location


Figure 1



The machine serial number plate (Item 1) [Figure 1] is located on the frame of the machine in the location shown.

### Engine Serial Number Location

Figure 2



The engine serial number (Item 1) [Figure 2] is located on the side of the engine under the oil fill cap.

## DELIVERY REPORT

Figure 3




The delivery report contains a list of items that must be explained or shown to the owner or operator by the dealer when the machine is delivered.

The delivery report must be reviewed and signed by the owner or operator and the dealer.

**EXCAVATOR IDENTIFICATION**

**Front View**

**Figure 4**



NA18172F


REF.	DESCRIPTION
1	Arm Cylinder
2	Lift Point
3	Boom
4	Joysticks
5	Operator's Seat with Seat Belt (location of Operation & Maintenance Manual)
6	Upperstructure
7	Tie-Downs (both sides)
8	Blade Cylinder
9	Tie-Downs / Lift Points
10	Boom Cylinder
11	Auxiliary Hydraulic Couplers
12	Arm
13	Bucket [A]
14	Attachment Mounting System [B] (if equipped)
15	Bucket Cylinder

[A] Several different buckets and other attachments are available.

[B] Optional attachment couplers are available.

**Rear View**

**Figure 5**



NA18172B

REF.	DESCRIPTION
1	Right Side Cover
2	Right Side Panel
3	Blade
4	Track Frame
5	Right Side Grille
6	Tie-Downs (both sides)
7	Tracks [A] (both sides)
8	Counterweight
9	Tailgate
10	Operator's Handbook (in right console)
11	Canopy [B] / Cab (ROPS / TOPS / FOPS) [C]

[A] Optional tracks are available.

[B] Canopy is not available in all areas. Contact your local Bobcat dealer for more information.

[C] Roll-Over Protective Structure (ROPS) per ISO 12117-2 / Tip-Over Protective Structure (TOPS) per ISO 12117. Falling Object Protective Structure (FOPS) per ISO 10262 (Level I).

## FEATURES, ACCESSORIES, AND ATTACHMENTS

### Standard Items

The following items are standard for this model:

- Advanced Diagnostics
- Arm-Mounted Auxiliary Hydraulics and Quick Couplers
- Auto-Shift Drive Motors
- Battery Disconnect Switch
- Cab with ROPS / TOPS / FOPS Approval
- Counterweight (Heavy)
- Deluxe Cloth Suspension Heated Seat With Headrest
- Dozer Blade (1960 mm (77.2 in))
- Engine and Hydraulic System Monitor with Shut Down
- Engine Speed Control Dial with Auto Idle Feature
- Fuel Filter with Water Bowl
- Horn
- Hydraulic and Travel Control Lockouts
- Hydraulic Joystick Controls
- Keyless Start
- Long Arm
- Pin-On X-Change
- Retractable Seat Belt
- Rubber Tracks (400 mm (15.7 in))
- Standard Display
- Two-Speed Travel
- Upperstructure Lights

### Options And Accessories

Below is a list of some equipment available from your Bobcat dealer as Dealer and/or Factory Installed Accessories and Factory Installed Options. See your Bobcat dealer for other available options, accessories, and attachments.

- Angle Blade
- Attachment Quick Coupler – German Style
- Attachment Quick Coupler – Hydraulic Pin Grabber
- Attachment Quick Coupler – Hydraulic Quick Coupler
- Attachment Quick Coupler – Klac™ System
- Attachment Quick Coupler – Mechanical Pin Grabber
- Beacon Kit
- Cab With Heater and HVAC
- Case Drain Kit
- Counterweight (Add On)
- Depth Check Kit
- Direct to Tank Kit
- Engine Louvre
- Front Guard Kit

- Fuel Transfer Pump
- Hydraulic (Automatic) Track Tensioning
- Load Holding Valve - Arm
- Load Holding Valve - Boom
- Overload Warning Device
- Radio
- Rear Mounted Lights
- Rearview Camera
- Secondary, Third, and Fourth Auxiliary Hydraulics
- Segmented Tracks
- Side Mirror
- Standard Arm
- Steel Tracks
- Strobe Light
- Touch Screen Display
- Travel Motion Alarm

### Attachments

These and other attachments are approved for use on this model Bobcat excavator. Do not use unapproved attachments. Attachments not manufactured by Bobcat Company may not be approved.

The versatile Bobcat excavator quickly turns into a multi-job machine with a variety of attachments.

See your Bobcat dealer for information about approved attachments and attachment Operation & Maintenance Manuals.

- Auger
- Breaker
- Flail Mower
- Hydraulic Clamp
- Plate Compactor
- Rotary Grinder

### Buckets Available


Increase the versatility of your excavator with a variety of bucket sizes.

Many bucket styles, widths, and different capacities are available for a variety of different applications. They include trenching, digging, grading, and tilt, to name a few. See your Bobcat dealer for the correct bucket for your Bobcat excavator and application.

Specifications subject to change without notice and standard items may vary.

## Falling-Object Protective Structure (FOPS)

Figure 6



C133105c


The top window (Item 1) [Figure 6] is a Falling-Object Protective Structure (FOPS) that meets the top guard requirements of FOPS Level 1 per ISO 10262.

There is a kit available that meets FOPS Level 2 per ISO 10262. (See Top Guard (FOPS II) Kit on Page 18)

See your Bobcat dealer for more information.

## Top Guard (FOPS II) Kit

Figure 7




NA13738b

The excavator must have the Top Guard kit installed to meet the top guard requirements in ISO 10262 – Level II.

The kit includes an overhead guard (Item 1) [Figure 7]. See your Bobcat dealer for more information.

## Front Guard Kit

Figure 8



NA13738a

The Front Guard Kit is available for applications that require protection from objects entering the front of the excavator.

The excavator must have the front guard installed to meet the front guard requirements in ISO 10262 – Level II.

The kit includes a front guard (Item 1) [Figure 8]. See your Bobcat dealer for more information.

## Inspecting And Maintaining The Front Guard Kit

The Front Guard Kit must be regularly inspected and maintained. Inspect the screen for damage. Replace parts as necessary.

## SAFETY INSTRUCTIONS

### Before Operation

Carefully follow the operating and maintenance instructions in this manual.

The Bobcat machine is highly manoeuvrable and compact. It is rugged and useful under a wide variety of conditions. This presents an operator with hazards associated with off motorway, rough terrain applications, common with Bobcat machine usage.

The Bobcat machine has an internal combustion engine with resultant heat and exhaust. All exhaust gases can kill or cause illness so use the machine with adequate ventilation.

The dealer explains the capabilities and restrictions of the Bobcat machine and attachment for each application. The dealer demonstrates the safe operation according to Bobcat instructional materials, which are also available to operators. The dealer can also identify unsafe modifications or use of unapproved attachments. The attachments and buckets are designed for a Rated Lift Capacity. They are designed for secure fastening to the machine. The user must check with the dealer, or Bobcat literature, to determine safe loads of materials of specified densities for the machine - attachment combination.

The following publications and training materials provide information on the safe use and maintenance of the Bobcat machine and attachments:

- The Delivery Report is used to assure that complete instructions have been given to the new owner and that the machine and attachment are in safe operating condition.
- The Operation & Maintenance Manual delivered with the machine or attachment gives operating information as well as routine maintenance and service procedures. It is a part of the machine and can be stored in a container provided on the machine. Replacement Operation & Maintenance Manuals can be ordered from your Bobcat dealer.
- Machine signs (decals) instruct on the safe operation and care of your Bobcat machine or attachment. The signs and their locations are shown in the Operation & Maintenance Manual. Replacement signs are available from your Bobcat dealer.
- An Operator's Handbook is fastened to the operator cab of the machine. Its brief instructions are convenient for the operator. See your Bobcat dealer for more information on translated versions.

The dealer and owner / operator review the recommended uses of the product when delivered. If the owner / operator will be using the machine for a different application(s) he or she must ask the dealer for recommendations on the new use.

### Safe Operation Is The Operator's Responsibility



## Safety Alert Symbol

This symbol with a warning statement means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.



### WARNING

#### INSUFFICIENT INSTRUCTIONS HAZARD

**Untrained operators or failure to follow instructions can cause serious injury or death.**

**Operators must have adequate training and instruction before operating.** ◀

W-2001



### IMPORTANT

**This notice identifies procedures which must be followed to avoid damage to the machine.** ◀

I-2019



### WARNING

**The signal word WARNING on the machine and in the manuals indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.** ◀

W-2044



### DANGER

**The signal word DANGER on machine signs and in the manuals indicates a hazardous situation which, if not avoided, will result in death or serious injury.** ◀

D-1022

The machine and attachment must be in good operating condition before use.

Check all of the items on the Service Schedule decal in the Every 10 Hours section or as shown in the Operation & Maintenance Manual.

### Safe Operation Needs A Qualified Operator

For an operator to be qualified, he or she must not use drugs or alcoholic drinks which impair alertness or coordination while working. An operator who is taking prescription drugs must get medical advice to determine if he or she can safely operate a machine.

### A Qualified Operator Must Do The Following

- Understand the written instructions, rules, and regulations.
  - ▷ The written instructions from Bobcat Company include the Delivery Report, Operation & Maintenance Manual, Operator's Handbook, and machine signs (decals).
  - ▷ Check the rules and regulations at your location. The rules may include an employer's work safety requirements. For driving on public roads, the machine must be equipped as stipulated by the

local regulations authorising operation on public roads in your specific country. Regulations may identify a hazard such as a utility line.

- Have training with actual operation.
  - ▷ Operator training must consist of a demonstration and verbal instruction. This training is given by your Bobcat dealer before the product is delivered.
  - ▷ The new operator must start in an area without bystanders and use all the controls until he or she can operate the machine and attachment safely under all conditions of the work area. Always fasten seat belt before operating.
- Know the work conditions.
  - ▷ Know the weight of the materials being handled. Avoid exceeding the Rated Lift Capacity of the machine. Material that is very dense will be heavier than the same volume of less dense material. Reduce the size of load if handling dense material.
  - ▷ The operator must know any prohibited uses or work areas, for example, he or she needs to know about excessive slopes.
  - ▷ Know the location of any underground lines.
  - ▷ Wear tight fitting clothing. Always wear safety glasses when doing maintenance or service. Safety glasses, respiratory equipment, hearing protection, or Special Applications Kits are required for some work. See your Bobcat dealer about Bobcat safety equipment for your model.

### Silica Dust Exposure



Cutting or drilling concrete containing sand or rock containing quartz may result in exposure to silica dust. Use a respirator, water spray, or other means to control dust.

### FIRE PREVENTION



#### Maintenance

The machine and some attachments have components that are at high temperatures under normal operating conditions. The primary source of high temperatures is the engine and exhaust system. The electrical system, if damaged or incorrectly maintained, can be a source of arcs or sparks.

Flammable debris (leaves, straw, etc.) must be removed regularly. If flammable debris is allowed to accumulate, it can cause a fire hazard. Clean often to avoid this accumulation. Flammable debris in the engine compartment is a potential fire hazard.

The operator's area, engine compartment, and engine cooling system must be inspected every day and cleaned if necessary to prevent fire hazards and overheating.

All fuels, most lubricants, and some coolants mixtures are flammable. Flammable fluids that are leaking or spilled onto hot surfaces or onto electrical components can cause a fire.

#### Operation

Do not use the machine where exhaust, arcs, sparks, or hot components can contact flammable material, explosive dust, or gases.

#### Electrical



Check all electrical wiring and connections for damage. Keep the battery terminals clean and tight. Repair or replace any damaged part or wires that are loose or frayed.

Battery gas can explode and cause serious injury. Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting. Do not jump start or charge a frozen or damaged battery. Keep any open flames or sparks away from batteries. Do not smoke in battery charging area.

#### Hydraulic System

Check hydraulic tubes, hoses and fittings for damage and leakage. Never use open flame or bare skin to check for leaks. Hydraulic tubes and hoses must be properly routed and have adequate support and secure clamps. Tighten or replace any parts that show leakage.

Always clean fluid spills. Do not use petrol or diesel fuel for cleaning parts. Use commercial non-flammable solvents.

### Fuelling



P200084

Stop the engine and let it cool before adding fuel. No smoking! Do not refuel a machine near open flames or sparks. Fill the fuel tank outdoors.

Ultra Low Sulfur Diesel (ULSD) poses a greater static ignition hazard than earlier diesel formulations with higher sulfur content. Avoid death or serious injury from fire or explosion. Consult with your fuel or fuel system supplier to ensure the delivery system is in compliance with fuelling standards for proper earthing and bonding practices.

### Starting

Do not use ether or starting fluids on any engine that has glow plugs or air intake heater. These starting aids can cause explosion and injure you or bystanders.

Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting.

### Exhaust System

The exhaust system consisting of spark arrester, DOC (Diesel Oxidation Catalyst), or DPF (Diesel Particulate Filter) is designed to control the emission of hot particles from the engine and exhaust system, but the muffler and the exhaust gases are still hot.

Check the spark arrester exhaust system regularly to make sure it is maintained and working properly. Use the procedure in the Operation & Maintenance Manual for cleaning the spark arrester muffler (if equipped).

### Welding And Grinding

Always clean the machine and attachment, disconnect the battery, and disconnect the wiring from the Bobcat controllers before welding. Cover rubber hoses, battery, and all other flammable parts. Keep a fire extinguisher near the machine when welding.

Have good ventilation when grinding or welding painted parts. Wear a dust mask when grinding painted parts. Toxic dust or gas can be produced.

Dust generated from repairing non-metallic parts such as hoods, fenders, or covers can be flammable or explosive. Repair such components in a well ventilated area away from open flames or sparks.

### Fire Extinguishers




P200083

Know where fire extinguishers and first aid kits are located and how to use them. Inspect the fire extinguisher and service the fire extinguisher regularly. Obey the recommendations on the instructions plate.

## PUBLICATIONS AND TRAINING RESOURCES


The following publications are also available for your Bobcat excavator. You can order them from your Bobcat dealer.



### OPERATION & MAINTENANCE MANUAL

Complete instructions on the correct operation and the routine maintenance of your Bobcat excavator.

7427957enGB



### SERVICE MANUAL

Complete maintenance instructions for your Bobcat excavator.

7427958enUS



### OPERATOR'S HANDBOOK

Gives basic operation instructions and safety warnings.

7407666enUS



### TOUCH DISPLAY USER GUIDE


Gives instructions for pairing a cellular phone with the touch display and for operating the sound system on the touch display.

7326266enUS

## PICTORIAL ONLY SAFETY SIGNS

Safety signs are used to alert the equipment operator or maintenance person to hazards that may be encountered in the use and maintenance of the equipment. The location and description of the safety signs are detailed in this section. Please become familiarised with all safety signs installed on the machine / attachment.

**Figure 9**



The format consists of the hazard panel(s) (Item 1) [Figure 9] and the avoidance panel(s) (Item 2) [Figure 9].

**Hazard Panels:** Depict a potential hazard enclosed in a safety alert triangle.


**Avoidance Panels:** Depict actions required to avoid the hazards.

A safety sign may contain more than one hazard panel and more than one avoidance panel.

## MACHINE SIGNS (DECALS)

Follow the instructions on all Machine Signs (Decals) that are on the machine. Replace any damaged machine signs and be sure they are in the correct locations. Machine signs are available from your Bobcat dealer.


Figure 10



NA19172k

REF	DECAL	WARNING (IF APPLICABLE)
-----	-------	----------------------------


1 Stay Clear (6713507)




**WARNING**

**GENERAL HAZARD**  
Failure to follow instruction can cause serious injury or death.  
Keep away from the operating machine. ◀

2 Lift Point (7195361) (2)



3 ISO Control Pattern for Right Joystick (7307931 or 7350091)



**WARNING**


**UNINTENDED MOVEMENT HAZARD**  
Failure to follow instructions can cause serious injury or death. Know the control pattern before operating.  
Read and understand the Operation & Maintenance manual before operating the machine. ◀

4 Engine Speed Control Dial / Angle Blade Control Lever (7240698 or 7240699)



REF	DECAL	WARNING (IF APPLICABLE)
-----	-------	----------------------------

5 Motion Alarm (7136738) (if equipped)



**! WARNING**

**CRUSHING HAZARD**  
Failure to maintain a clear view in the direction of travel can cause serious injury or death.

- This machine is equipped with a motion alarm. **ALARM MUST SOUND!** when operating forward or backward.
- The operator is responsible for the safe operation of this machine. ◀

W-2788

6 General Warnings (7148158)



**! WARNING**

**GENERAL HAZARD**  
Failure to follow instructions can cause serious injury or death.  
Read and understand the Operation & Maintenance Manual and Handbook before operating excavator.

- Keep away from drop-offs, steep areas or banks that could break away.
- Explosion or electrocution can occur if machine contacts utility lines or pipes. Check for overhead or underground lines before operating.
- Keep bystanders away. No riders. Check location of blade for direction of travel before moving steering controls.
- Operate machine from operators position only.

To Leave Excavator

1. Lower attachment and blade to ground.
2. Stop engine and remove the key (if equipped.)
3. Raise control console. ◀




W-2518

7 Operator's Handbook (7236492)




8 Start Switch (7186708)



REF	DECAL	WARNING (IF APPLICABLE)
9	<p data-bbox="199 264 845 324">ISO Control Pattern for Left Joystick (7307932 for E50z and E55z) or (7427699 for E60)</p> 	<div data-bbox="877 291 1484 347" style="background-color: black; color: white; padding: 5px; text-align: center;">  <b>WARNING</b> </div> <p data-bbox="877 358 1484 548"><b>UNINTENDED MOVEMENT HAZARD</b> Failure to follow instructions can cause serious injury or death. Know the control pattern before operating. Read and understand the Operation &amp; Maintenance manual before operating the machine. ◀</p> <p data-bbox="877 548 909 560"><small>W-3022</small></p>
10	<p data-bbox="295 896 750 929">Ultra Low Sulfur Diesel Fuel (7238123)</p> 	
11	<p data-bbox="311 1176 726 1209">Transporting and Lifting (7178215)</p> 	<div data-bbox="877 1209 1484 1265" style="background-color: black; color: white; padding: 5px; text-align: center;">  <b>WARNING</b> </div> <p data-bbox="877 1276 1484 1444"><b>GENERAL HAZARD</b> Improper loading, transporting, and lifting procedures can cause serious injury or death. Read and understand the Operation &amp; Maintenance Manual prior to transporting or lifting the machine. ◀</p> <p data-bbox="877 1444 909 1456"><small>W-2517</small></p>
12	<p data-bbox="311 1500 726 1534">Remote grease location (7238017)</p> 	

REF	DECAL	WARNING (IF APPLICABLE)
-----	-------	----------------------------

13 High Pressure Grease (7168039) (2)




**! WARNING**

**INJECTION HAZARD**  
 High pressure grease can penetrate skin and eyes, causing serious injury.  
 Do not loosen the track tension fitting more than 1 - 1/2 turns.\*

14 Tie-Down (6595014) (9)



15 Battery Shut-Off Switch (7342035)



16 Emergency Exit (7169014) (cab models only)



17 Not a Lift Point (7359393) (cab models only)






REF	DECAL	WARNING (IF APPLICABLE)
-----	-------	----------------------------

21 Not a Lift Point (7282101)



22 Lift Point / Tie-Down (6815993) (2)




23 Hot Surface Warning (7185935)



**! WARNING**

**BURN HAZARD**  
 Failure to follow instructions can cause serious burns.  
 Stop the engine and allow it to cool before removing the radiator cap or adding coolant. ◀

24 Check Hydraulic Level (7186931)




REF	DECAL	WARNING (IF APPLICABLE)
-----	-------	-------------------------

25 Hydraulic Oil (7120570)




7120570

26 Fuse / Relay (7435001 for E50z and E55z) or (7451008 for E60)




7435001

27 Tow Point Only (7350261)



7350261

28 Stay Clear (7169009)



7169009

**! WARNING**

**CRUSHING HAZARD**  
 Contact with machine can cause property damage, serious injury or death.

- Keep out of swing area or travel path.
- Always look in the direction of travel.
- Make sure swing area is clear of bystanders and objects.

W-2775

29 High Pressure Gas (7169291) (3)



7169291

**! WARNING**

**IMPACT HAZARD**  
 Opening cylinder can release rod and cause serious injury or death.


- Contents under high pressure.
- Do not open.
- See Service Manual for additional information.

W-2523

REF	DECAL	WARNING (IF APPLICABLE)
-----	-------	----------------------------

30

Engine Coolant (7120573)



31

Rotating Parts and Hot Surfaces (7243563)



**! WARNING**

**CUTTING AND BURN HAZARD**


Keep away from the operating machine.

- Keep away from fan and moving parts. Do not operate with guard removed.
- Do not touch hot surfaces. Allow to cool before servicing. ◀

W-2521

32

Operator's Manual Location (6732148)



**! WARNING**

**INSUFFICIENT INSTRUCTIONS HAZARD**

Untrained operators or failure to follow instructions can cause serious injury or death. Read and understand the Operation & Maintenance Manual before operating the machine. ◀



W-3021

**INTENDED USE**

This machine is classified as an Excavator as defined in ISO 6165. This machine has tracks and commonly a mounted bucket for the principle intended functions of excavating, loading, and backfilling loose materials such as earth, gravel, or crushed rock.

Additional Bobcat approved attachments allow this machine to perform other tasks described in the attachment Operation & Maintenance Manuals.

Some examples of intended use include:

Excavating	
Excavating	
Boom Swing	
Rotating the Upperstructure	

Loading Material



Backfilling



**⚠ WARNING**

**INSTABILITY HAZARD**

Excessive load can cause tipping or loss of control leading to serious injury or death. Do not exceed rated lift capacity. ◀

W-2374

**⚠ DANGER**

**EXPLOSION AND ELECTROCUTION HAZARDS**  
Contact with underground utility lines will cause death, serious injury, or property damage.

- Check the work area for buried electrical, gas, utility, or other service lines before excavating or operating ground engaging equipment.
- Follow all local rules and regulations regarding digging or working in areas around underground utilities. Have all underground utility lines clearly marked before operating. ◀

1221-78FCF-438

**⚠ WARNING**

**ENTANGLEMENT AND IMPACT HAZARD**

Contact with moving parts, a trench cave-in or flying objects can cause serious injury or death. Keep all bystanders 6 m (20 ft) away from equipment when operating. ◀

W-2119

**⚠ IMPORTANT**

**MACHINE DAMAGE HAZARD**


Failure to follow instructions could result in damage to the blade and undercarriage components. Avoid impacting objects with the blade. ◀

I-2256


**INSTRUMENTS AND CONSOLES**

**Left Console**

**Figure 11**




**Figure 12**



REF	DESCRIPTION	FUNCTION
1	Left Joystick	Operates the hydraulic controls. (See Hydraulic Controls on Page 54)
2	Left Joystick Switch	Controls boom swing and auxiliary hydraulics. (See Enabling Boom Swing on Page 73) (See Operating Attachments With Secondary Auxiliary Hydraulics on Page 59)
3	Left Joystick Button	Toggles between boom swing and auxiliary hydraulics (if equipped). (See Enabling Boom Swing on Page 73) (See Operating Attachments With Secondary Auxiliary Hydraulics on Page 59)
4	Horn	Sounds the horn.
5	Windshield Wiper	Operates windshield wiper.
6	Rear Windshield Heat	Operates rear windshield heater.
7	Hydraulic Quick Coupler On / Off Switch (if equipped)	Retracts and extends hydraulic pins. (See Installing Attachments (Hydraulic Quick Coupler) on Page 99)
8	Beacon / Strobe Light (if equipped)	Turns beacon / strobe light on and off.
9	Windshield Washer	Operates windshield washer.
10	Boom Swing Switch (if equipped)	Push to select boom swing offset for either the left or right joystick. (See Operating Attachments With Primary, Secondary, And Fourth Auxiliary Hydraulics on Page 60)
11	Overload Warning Device Switch (if equipped)	Operates the overload warning device. (See Overload Warning Device on Page 64)
12	Hydraulic Quick Coupler Intent Switch (if equipped)	Initiates quick coupler install or remove mode. (See Installing Attachments (Hydraulic Quick Coupler) on Page 99)

Right Console

Figure 13



C206171a


REF.	DESCRIPTION	FUNCTION
1	Right Joystick Switch	Controls auxiliary hydraulics. (See Operating Attachments With Primary Auxiliary Hydraulics on Page 56) (See Operating Attachments With Primary, Secondary, And Fourth Auxiliary Hydraulics on Page 60)
2	Right Joystick Button	Toggles between rear view camera (if equipped) and current screen on the display. (See Operating Rear View Camera on Page 200) Used to bench the Depth Check system (if equipped). (See Depth Check (Standard Display) on Page 112) (See Depth Check (Touch Display) on Page 125)
3	Right Joystick	Operates the hydraulic controls. (See Hydraulic Controls on Page 54)
4	Blade Control Lever	Raises and lowers the blade. (See Blade Control Lever on Page 65)
5	Two-Speed Button (With Angle Blade Option)	Engages and disengages high range travel speed (if angle blade is equipped). (See Engaging Two-Speed Travel (With Angle Blade Option) on Page 47)
6	Angle Blade Switch (With Angle Blade Option) Two-Speed Button (Without Angle Blade Option)	Operates the angle blade (if angle blade is equipped). (See Angle Blade on Page 65) Engages and disengages high range travel speed (if angle blade is not equipped). (See Engaging Two-Speed Travel (Without Angle Blade Option) on Page 46)
7	Engine Speed Control Dial	Controls engine rpm. (See Engine Speed Control on Page 72)
8	Travel Motion Alarm Cancel Switch	Temporarily disables the travel motion alarm. (See Disabling The Travel Motion Alarm on Page 52)
9	Wait To Start Light	When light turns off, the engine can be started. (See Starting The Engine on Page 77)
10	Auxiliary Power Outlet	12 volt receptacle for accessories.

REF.	DESCRIPTION	FUNCTION
11	USB Port (if equipped)	See the Touch Display User Guide for more information about the sound system.
12	3,5 mm (1/8 in) Auxiliary Input Jack (if equipped)	
13	Hands-Free Microphone (if equipped)	Used for hands-free talking with the touch display phone feature.
14	Key Switch or Keyless Start Switch	Used to start the engine. (See Starting The Engine on Page 77)
15	Jog Shuttle	Used to navigate the display. (See Jog Shuttle (Standard Display) on Page 40) (See Jog Shuttle (Touch Display) on Page 41)
16	Fan Motor Dial (if equipped)	Controls fan speed.
17	Air Conditioning Switch (if equipped)	Turns air conditioner on / off.
18	Temperature Control Dial (if equipped)	Controls temperature in cab.
19	Standard Display Screen	(See Standard Display on Page 36)
	Touch Display Screen	(See Touch Display on Page 38)

**NOTE:** Always turn key switch and all accessories to off when the engine is stopped, the battery will discharge if the key is left on.

Standard Display

Figure 14




The standard display is a visual interface that provides control of certain machine settings and operating information through the use of a jog shuttle. The standard display is scratch resistant and weather resistant.

REF	DESCRIPTION	FUNCTION
1	Machine Hours	Shows machine operating hours.
2	Direct To Tank	Indicates Direct To Tank feature has been activated.
3	Auxiliary Hydraulics	Indicates Auxiliary Hydraulics are activated. The icon changes when detent flow is activated. (See Operating Attachments With Primary Auxiliary Hydraulics on Page 56)
4	General Warning	Indicates a malfunction of one or more machine functions.
5	High Range	Indicates high range is activated. (See Two-Speed Travel on Page 46)
6	Seat Belt Reminder	Illuminates as a reminder to fasten the seat belt.
7	Control Console Raised	Indicates the left console is raised and hydraulic controls are locked out. (See Raising And Lowering The Console on Page 46)

REF	DESCRIPTION	FUNCTION
8	Boom Swing or Auxiliary Hydraulics (if equipped)	Indicates what control the left joystick switch is operating. (See Boom Swing on Page 73) (See Operating Attachments With Secondary Auxiliary Hydraulics on Page 59) (See Operating Attachments With Primary, Secondary, And Fourth Auxiliary Hydraulics on Page 60)
9	Boom Swing or Auxiliary Hydraulics (if equipped)	Indicates what control the right joystick switch is operating. (See Boom Swing on Page 73) (See Operating Attachments With Primary Auxiliary Hydraulics on Page 56) (See Operating Attachments With Primary, Secondary, And Fourth Auxiliary Hydraulics on Page 60)
10	Engine Coolant Temperature Gauge	Shows the engine coolant temperature.
11	Diesel Particulate Filter (DPF)	Indicates inhibit mode has been selected. DPF icon will blink when forced regeneration is required. DPF icon will be ON during regeneration. (See Diesel Particulate Filter (DPF) System on Page 66)
12	Emissions Error	Indicates emissions regulating system malfunction. (See Diesel Particulate Filter (DPF) System on Page 66)
13	Fuel Gauge	Shows the amount of fuel in the tank. Icon illuminates to indicate a malfunction.
14	Eco Mode	Indicates Eco Mode is activated. (See Eco Mode on Page 72)
15	High Exhaust System Temperature (HEST)	Indicates the exhaust temperature is higher than normal operation temperature. (See Diesel Particulate Filter (DPF) System on Page 66)
16	Battery Warning	Indicates battery voltage is low.
17	Engine Warning	Indicates the engine has malfunctioned.
18	Service Due	Indicates scheduled maintenance is due.
19	Engine RPM	Shows engine RPM.
20	Throttle Indicator	Manual throttle icon changes to Auto icon when Auto Idle is activated. (See Auto Idle on Page 48)
21	Hydraulic Warning	Indicates hydraulic fluid temperature is high.
22	Glow Plugs	Indicates glow plugs are active.
23	Secondary Auxiliary Hydraulics	Indicates Secondary Auxiliary Hydraulics are activated. (See Operating Attachments With Secondary Auxiliary Hydraulics on Page 59)
24	Navigation Handle	Brings up the navigation bar. (See Opening Navigation Bar on Page 194) Any active shortcuts will be displayed. (See Active Shortcuts on Page 194)
25	Fuel Priming	Indicates fuel priming is in process.

Touch Display

Figure 15



The touch display is a visual interface that provides control of certain machine settings, operating information, and entertainment through the use of a touch screen or jog shuttle control. The touch display is scratch resistant and weather resistant.

See the Touch Display User Guide for phone and sound system instructions.


REF	DESCRIPTION	FUNCTION
1	Operator Name	Shows the user that is currently logged into the system.
2	Connected Device Signal Strength	Indicates the signal strength of a connected device.
3	Connected Device Battery Strength	Indicates the battery strength of a connected device.
4	Bluetooth® Device	Indicates a Bluetooth Device has been connected.
5	Job Clock	Indicates one of the job clocks is running. (See Using The Job Clock on Page 213)
6	Notifications	Indicates that Notifications are available.

REF	DESCRIPTION	FUNCTION
7	Time / Notification Drawer	Displays current time. During machine start up, "COLD" or "WAIT" may also be displayed in this area to indicate that the machine can not be started until the message is off. Provides access to Notification Drawer. (See Notification Drawer on Page 199)
8	Direct To Tank	Indicates Direct To Tank feature has been activated.
9	Auxiliary Hydraulics	Indicates Auxiliary Hydraulics are activated. The icon changes when detent flow is activated. (See Operating Attachments With Primary Auxiliary Hydraulics on Page 56)
10	General Warning	Indicates a malfunction of one or more machine functions.
11	High Range	Indicates high range is activated. (See Two-Speed Travel on Page 46)
12	Seat Belt Reminder	Illuminates as a reminder to fasten the seat belt.
13	Control Console Raised	Indicates the left console is raised and hydraulic controls are locked out. (See Raising And Lowering The Console on Page 46)
14	Volume	Press to access volume slider bar.
15	Vitals (Digital Information)	Accesses the gauge information in digital format. (See Accessing Vital Detail And Machine Performance on Page 199)
16	Machine Settings	Accesses various machine settings.
17	Machine Hours	Shows machine operating hours.
18	Engine Oil Pressure Gauge	Shows the engine oil pressure.
19	Battery Voltage Gauge	Shows the battery voltage.
20	Diesel Particulate Filter (DPF)	Indicates inhibit mode has been selected. DPF icon will blink when forced regeneration is required. DPF icon will be on during regeneration. (See Diesel Particulate Filter (DPF) System on Page 66)
21	Emissions Error	Indicates emissions regulating system malfunction. (See Diesel Particulate Filter (DPF) System on Page 66)
22	Boom Swing or Auxiliary Hydraulics (if equipped)	Icon indicates what the left joystick switch is operating (boom swing, Aux 2, or Aux 4). (See Boom Swing on Page 73) (See Operating Attachments With Secondary Auxiliary Hydraulics on Page 59) (See Operating Attachments With Primary, Secondary, And Fourth Auxiliary Hydraulics on Page 60)
23	Fuel Gauge	Shows the amount of fuel in the tank.
24	High Exhaust System Temperature (HEST)	Icon is on when the exhaust temperature is higher than normal operation. (See Diesel Particulate Filter (DPF) System on Page 66)
25	Eco Mode	Indicates Eco mode is activated. (See Eco Mode on Page 72)
26	Hydraulic Fluid Temperature Gauge	Shows the hydraulic fluid temperature.
27	Boom Swing or Auxiliary Hydraulics (if equipped)	Icon indicates what the right joystick switch is operating (boom swing, Aux 1, or Aux 4). (See Boom Swing on Page 73) (See Operating Attachments With Primary Auxiliary Hydraulics on Page 56) (See Operating Attachments With Primary, Secondary, And Fourth Auxiliary Hydraulics on Page 60)
28	Engine Coolant Temperature Gauge	Shows the engine coolant temperature.

REF	DESCRIPTION	FUNCTION
29	Fuel Level Bar Graph	Visually shows the fuel level.
30	Fuel Priming	Indicates fuel priming is in process.
31	Hydraulic Warning	Indicates hydraulic fluid temperature is high.
32	Battery Warning	Indicates battery voltage is low.
33	Secondary Auxiliary Hydraulics	Indicates secondary auxiliary hydraulics are activated. (See Operating Attachments With Secondary Auxiliary Hydraulics on Page 59)
34	Engine RPM	Shows engine rpm.
35	Throttle Indicator	Manual throttle icon changes to Auto when Auto Idle is activated. (See Auto Idle on Page 48)
36	Service Due	Indicates scheduled maintenance is due.
37	Glow Plugs	Indicates glow plugs are active.
38	Engine Warning	Indicates the engine has malfunctioned.
39	Front Lights	Indicates front lights are on.
40	Gauges	Accesses <b>GAUGES</b> screen.
41	Camera (if equipped)	Accesses <b>CAMERA</b> screen.
42	Phone	Accesses <b>PHONE</b> screen.
43	Audio	Accesses <b>AUDIO</b> screen.
44	Service	Accesses <b>SERVICE</b> screen.
45	Attachment	Accesses <b>ATTACHMENT</b> screen.
46	Settings	Accesses <b>SETTINGS</b> screen.

**Jog Shuttle (Standard Display)**

**Figure 16**



C206625a

Navigate the display with the jog shuttle [Figure 16].

See the User Guide included with the machine's literature packet for more information.

REF.	DESC.	FUNCTION
1	Not Used	
2	Auxiliary Hydraulics	Activates auxiliary hydraulics. (See Operating Attachments With Primary Auxiliary Hydraulics on Page 56)
3	Gauges	Opens <b>GAUGES</b> screen.
4	Back	Returns to previous screen.
5	Lights	Turns front lights on and off.
6	Rotary Knob	Used to navigate between available icons on display. Press knob to select highlighted icon.


**Using The Jog Shuttle With Standard Display**

- Turn the rotary knob (Item 6) [Figure 16] to move between the icons on the screen.  
Only icons that highlight on the screen can be selected.

- Press the rotary knob (Item 6) [Figure 16] to select a highlighted icon or to turn a feature on / off.
- Press the Back button (Item 4) [Figure 16] to return to the previous screen.
- If a slider is used for changing a setting, highlight the slider and turn the rotary knob to change the slider position.

**Jog Shuttle (Touch Display)**

**Figure 17**



Navigate the display with the jog shuttle [Figure 17].

See the User Guide included with the machine’s literature packet for more information.

**Using The Jog Shuttle With Touch Display**

- Press the Volume / Navigation button (Item 4) [Figure 17] to highlight the first selectable icon on the display screen.
- Turn the rotary knob (Item 6) [Figure 17] to move between the icons on the screen.  
  
Only icons that highlight on the screen can be selected.
- Press the rotary knob (Item 6) [Figure 17] to select the highlighted icon.
- To turn a feature on / off, press the rotary knob.
- If a slider is used for changing a setting, highlight the slider and turn the rotary knob to change the slider position.

REF.	DESC.	FUNCTION
1	Audio / Phone	Toggles between <b>PHONE</b> screen and <b>AUDIO</b> screen. Also accepts and ends calls.
2	Auxiliary Hydraulics	Activates auxiliary hydraulics. (See Operating Attachments With Primary Auxiliary Hydraulics on Page 56)
3	Gauges / Vital Detail	Toggles between <b>GAUGES</b> screen and <b>VITAL DETAIL</b> screen.
4	Volume / Navigation	Toggles the function of the Rotary Knob between adjusting volume and navigating through the screens on the display.
5	Lights	Turns front lights on / off.
6	Rotary Knob (Volume / Navigation)	In navigation mode, used to navigate through items on the page.  In volume mode, used to adjust volume. Pressing the rotary knob will mute and unmute audio.

**REAR VIEW CAMERA SYSTEM**


This machine may be equipped with a rear view camera system. The view from the camera is displayed on the display screen.

The rear view camera system is not a substitute for keeping bystanders away from the work area. You must remain fully aware of your surroundings using direct visibility and the rear view camera system. You must service and maintain the camera system to ensure proper function.

**NOTE:** Objects viewed on the display are closer than they appear.

**Operating Rear View Camera**

**Figure 18**



**Figure 19**



- To navigate to the camera, select **[NAVIGATION HANDLE]** → **[CAMERA]** (Item 1) [Figure 18] on the standard display.
- OR
- Select **[CAMERA]** on the touch display (Item 1) [Figure 19].

**Figure 20**



You can also press the right joystick button (Item 1) [Figure 20] to toggle between the camera and the current screen.

**Figure 21**



The rotating spinner icon (Item 1) [Figure 21] indicates you are viewing a live broadcast from the camera.

See touch display section for additional features available on that display. (See Camera (Touch Display) on Page 200)

**Cleaning And Maintaining Rear View Camera**

Perform the following daily or as needed:


- Clean the lens of the camera using a soft cloth and clean water.
- Remove mud, snow, ice, or other debris that could affect the clear view provided by the camera system.
- Verify proper camera adjustment. Adjust camera if needed. (See Adjusting Rear View Camera Position on Page 43)

- Replace damaged rear view camera system components. See your Bobcat dealer for service and parts.

### Adjusting Rear View Camera Position

1. Make a mark on the ground 1,25 m (4 ft) behind the machine.


Figure 22



2. Loosen the screws (Item 1) [Figure 22] of the clamp holding the camera.
3. Turn the start switch to ON, but do not start the engine.
4. Turn the camera ON.  
(See Operating Rear View Camera on Page 42)
5. Compare the camera display with the view through the rear window of the machine. The image should be as a mirror, with an object to the left of the machine appearing on the left of the display.

See display menu to adjust if needed.

Figure 23




6. Adjust the camera as follows.
  - a. The mark on the ground (Item 1) [Figure 23] should be visible on the display.
  - b. The tailgate (Item 2) [Figure 23] should be just visible on the display.
  - c. The camera should be centred left and right.
7. Tighten the screws to 0,8 – 1,0 N•m (7 – 8.8 in-lb) torque.
8. Turn the key switch to off.

**RADIO**

**Radio Identification**

**Figure 24**




REF	DESC.	FUNCTION
1	POWER	Turns the radio unit ON / OFF.
2	MUTE	Mutes audio output.
3	DISP	Switches between display operation functions of the radio. (See Operating The Radio Clock on Page 45)
4	AM/FM	Switches between AM (MW) bands and three FM bands.
5	AUX	Switches to Auxiliary Input mode. Portable audio device (MP3 player, etc.) must be attached to auxiliary input jack.
6	WB	Selects weather band. The weather alert feature, if activated, will automatically switch from the current function to the weather band if a weather warning is received. (See Adjusting Radio Settings on Page 45)
7	TIMER	Accesses timer mode. (See Operating Radio Timer on Page 44)
8	DISPLAY SCREEN	Displays the time, frequency, and activated functions.
9	VOL+ / VOL-	Adjusts volume up and down. Current volume (0 – 40) will appear briefly in display screen.

REF	DESC.	FUNCTION
10	AUDIO / MENU	Adjusts radio settings. (See Adjusting Radio Settings on Page 45)
11	TUN- / TUN+	Manually tunes the radio frequency up and down.
12	SEEK- / SEEK+	Automatically tunes frequency up or down to next strong station.
13	PRESET STATIONS	Stores and recalls stations for each AM and FM band. Press button and hold to store current station. Press button to recall station.
14	AUX IN	Connect line output of portable audio device (MP3 player, etc.) to 3,5 mm (1/8 in) jack and press AUX button.

**Operating Radio Timer**


**Figure 25**



- Press the TIMER (Item 1) [Figure 25] button to start the timer function.
- Press TIMER (Item 1) [Figure 25] again to stop timer.
- Press and hold TIMER (Item 1) [Figure 25] to reset timer and exit from timer mode.

## Adjusting Radio Settings

Figure 26



- Press the AUDIO / MENU button (Item 1) [Figure 26] to cycle through bass, treble, and balance settings.
  - ▷ Use the VOL+ (Item 2) and VOL- (Item 3) buttons [Figure 26] to adjust the desired option displayed.


Normal operation will resume automatically.

- Press and hold the AUDIO / MENU button (Item 1) [Figure 26] for three seconds to enter menu adjustment settings.
  - ▷ Press the AUDIO / MENU button (Item 1) [Figure 26] to cycle through the following settings:
    - Beep Confirm:** Determines if beep will sound with each button press.
    - Operation Region:** Selects the appropriate region (USA or Europe).
    - Clock Display:** Selects a 12 hour or 24 hour clock display.
    - Display Brightness:** Set display screen brightness level (low, medium, or high).
    - Backlight Colour:** Set display screen backlight colour (amber or green).
    - Power On Volume:** Sets default volume setting when radio is turned on.
    - WB Alert:** Determines if weather band alert features is activated.
  - ▷ Use the VOL+ (Item 2) and VOL- (Item 3) buttons [Figure 26] to adjust the active setting.

Normal operation will resume automatically.

## Operating The Radio Clock

Figure 27



- Press and hold the DISP (Item 1) button [Figure 27] to enter clock setting mode.
- Use TUN – button (Item 2) [Figure 27] to adjust hours.
- Use TUN + button (Item 3) [Figure 27] to adjust minutes.

Normal operation will resume automatically.

## RAISING AND LOWERING THE CONSOLE

Figure 28



P134071a


- Before operating the excavator, lower the left console [Figure 28].  
Push down on the handle until the latch is engaged.
- Before exiting the cab, raise the left console by pulling up on the handle.  
The lift spring will assist in raising the console.

**NOTE:** When the console is raised, the hydraulic and traction system functions are locked and will not operate. If the engine stops, the boom / bucket (attachments) can be lowered to the ground using hydraulic pressure in the accumulator. The control console must be in the locked down position, and the key switch in the ON position.

## TWO-SPEED TRAVEL

### Engaging Two-Speed Travel (Without Angle Blade Option)

Figure 29



P200052b

- Press the button (Item 1) [Figure 29] to engage the high range.

Figure 30




NA3774

Two beeps will be heard and the high range icon (Item 1) [Figure 30] will illuminate.

- Press the button (Item 1) [Figure 29] again to disengage.  
One beep will be heard.

## Engaging Two-Speed Travel (With Angle Blade Option)


Figure 31



C201031a

- Press the button (Item 1) [Figure 31] to engage the high range.

Figure 32



NA3774

Two beeps will be heard and the high range icon (Item 1) [Figure 32] will illuminate.

- Press the button (Item 1) [Figure 31] again to disengage.

One beep will be heard.

### Auto Shift Drive Motors

The travel motors are equipped with an auto shift feature that senses hydraulic pressure. When in high range, the travel motors will automatically shift to low range when more torque is required and return to high range when hydraulic pressure decreases.

**NOTE:** Always set the travel speed to low range when loading or unloading the excavator onto a transport vehicle.

## AUTO IDLE

### Auto Idle Description


When auto idle is activated, engine speed will be reduced to low idle when the control levers (joystick, blade, travel, etc.) are in neutral and have not been used for the auto idle delay time. The engine rpm will return to the set position as soon as any control lever is activated.

**NOTE:** Always disengage auto idle when loading or unloading the excavator onto a transport vehicle.

### Activating Auto Idle

1. Select [SETTINGS] → [MACHINE SETTINGS].

Figure 33



2. Select [AUTO-IDLE] to turn it on / off (Item 1) [Figure 33].

The Auto-Idle Delay Time can be changed on the touch display. (See Activating Auto Idle on Page 209)

## OPERATOR CAB (ROPS / TOPS / FOPS)

The Bobcat excavator may be equipped with an operator cab (Roll-Over Protective Structure (ROPS) / Tip-Over Protective Structure (TOPS) / FOPS) to protect the operator if the excavator is tipped over or from falling objects. The seat belt must be worn for ROPS / TOPS / FOPS protection.

Check the ROPS / TOPS / FOPS cab, mounting, and hardware for damage. Never modify the ROPS / TOPS / FOPS cab. Replace the cab and hardware if damaged. See your Bobcat dealer for parts.

### **⚠ WARNING**

#### MODIFICATION HAZARD


**Cab changes can cause loss of operator protection from rollover and falling objects resulting in serious injury or death.**

**Never modify operator cab by welding, grinding, drilling holes or adding attachments unless instructed to do so by Bobcat Company. ◀**

W-2069

### Operating The Cab Door

Figure 34




C206626a

- Pull on the latch to open the door.

The cab door can be locked (Item 1) [Figure 34] with the same key as the starter switch.


Figure 35



C206627a

- Push the door all the way open until the latch post (Item 1) engages in the latch (Item 2) to hold the door in the open position [Figure 35].


Figure 36



C206628a

- When the door is in the open position, push the latch (Item 1) [Figure 36] to release the door.

Figure 37




C206629a

- From inside the cab, open the door using the handle (Item 1) [Figure 37].

**Operating The Front Window**


Figure 38



P20095a

1. Push the window latch buttons (Item 1) [Figure 38] on both sides.


**Figure 39**



C206630a

2. Use both window grab handles (Item 1) [Figure 39] to pull the top of the window in.

**Figure 40**




P200096a

3. Continue moving the window in and up over your head until the window is fully raised.  
When the window is fully raised, the latch (Item 1) (both sides) [Figure 40] will close on the bracket in the latched position.
4. Pull down and forward slightly on the window to make sure it is fully latched.
5. To close the window, use both window grab handles to support the window while pressing the window latch button (Item 2) [Figure 40] (both sides).  
Use both window grab handles (Item 1) [Figure 39] to pull the window down fully.
6. Press the top of the window in until the latch locks into the latched position (both sides) [Figure 38].

7. Pull inward and upward slightly on the window to make sure it is fully latched in the closed position.

**Operating The Right Windows**

**Figure 41**




C206651a

1. Pinch the latch together (Item 1) [Figure 41] and pull the window open.
2. Release the lever (Item 1) [Figure 41] into the slot to secure the window open in one of the available positions.
3. To close the window, pinch the latch together and push the window shut. Make sure the lever releases into the slot to secure the window shut.

**Operating The Cab Interior Light**

**Figure 42**




C208425b

- Use the switch (Item 1) [Figure 42] to the turn the light ON and OFF.

**Window Washer Reservoir**

**Figure 43**




P200100a

The window washer reservoir (Item 1) [Figure 43] is located under the right side cover.

**Heating, Ventilation, And Air Conditioning Ducting**

**Figure 44**



P141329a

The HVAC louvers (Item 1) [Figure 44] can be positioned as needed to direct the air flow to various areas in the cab.

**EMERGENCY EXITS**

**Emergency Exit Locations**

The door, the right window, and the front window provide exits in case of an emergency.

**Making An Emergency Exit Through The Front Window**

**Figure 45**



C206830

You can make an emergency exit through the front window. (See Operating The Front Window on Page 49)

**NOTE:** If the excavator has a Front Guard Kit installed, the front window can not be used as an emergency exit.

**Making An Emergency Exit Through The Right Side Window**

**Figure 46**



C206832

You can make an emergency exit through the right window. (See Operating The Right Windows on Page 50)

## TRAVEL MOTION ALARM

### Travel Motion Alarm Description

This excavator may be equipped with a travel motion alarm. The travel motion alarm is located underneath the rear of the excavator.

The travel motion alarm will sound when the operator moves the travel control levers in either the forward or reverse direction.

If the alarm does not sound, see inspection instructions. (See Inspecting The Travel Motion Alarm System on Page 155)

### **⚠ WARNING**

#### CRUSHING HAZARD


Failure to maintain a clear view in the direction of travel can cause serious injury or death.

- This machine is equipped with a motion alarm. **ALARM MUST SOUND!** when operating forward or backward.
- The operator is responsible for the safe operation of this machine. ◀

W-2788

### Disabling The Travel Motion Alarm

Figure 47



C200865c

- Press the travel motion alarm switch (Item 1) [Figure 47] on the right console while the machine is moving to temporarily disable the travel motion alarm.
- Enable the travel motion alarm by returning the travel levers back to the neutral position.


## TRAVEL CONTROLS

### Forward And Reverse Travel

The following procedures describe forward, reverse, left, and right as seated in the operator's seat.

1. Rotate the upperstructure, if necessary, to ensure the blade is at the front of the machine (as you sit in the operator's seat).

Figure 48



C20849a

2. Slowly move both steering levers (Item 1) [Figure 48] forward for forward travel, backward for reverse travel.  
OR  
Control travel with the foot pedals (Item 2) [Figure 48].

### **⚠ WARNING**

#### UNINTENDED MOVEMENT HAZARD


Failure to follow instructions can cause serious injury or death.

- Check the blade location before travelling. When the blade is to the rear, operate the steering levers / foot pedals in the opposite direction to when the blade is in the front.
- Move the steering levers / foot pedals slowly. Abrupt lever motion will cause the machine to jerk. ◀

W-2235

*Making A Right Turn*


**Figure 49**



NA15007B

- Push the left steering lever forward to turn right while travelling forward [Figure 49].

**Figure 50**




NA15010B

- Pull the left steering lever backward to turn right while travelling backward [Figure 50].

*Making A Counter-Rotation Right Turn*

**Figure 51**




NA15007A

- Push the left steering lever forward and pull the right steering lever backward [Figure 51].

*Making A Left Turn*


**Figure 52**



NA15008A

- Push the right steering lever forward to turn left while travelling forward [Figure 52].

Figure 53




NA15009A

- Pull the right steering lever backward to turn left while travelling backward [Figure 53].

#### Making A Counter-Rotation Left Turn

Figure 54



NA15010A

- Push the right steering lever forward and pull the left steering lever backward [Figure 54].

## HYDRAULIC CONTROLS

### Hydraulic Controls Description

Operate the work equipment (boom, arm, bucket, and upperstructure slew) by using the left and right joysticks.

### **⚠ WARNING**

#### GENERAL HAZARD

Failure to follow instructions can cause serious injury or death.

Before leaving the machine:

- Lower the work equipment to the ground.
- Lower the blade to the ground.
- Stop the engine and remove the key.
- Raise the control console. ◀

W-2780

ISO Control Pattern

**Left Joystick**

P134139e

Joystick Position	Function
1	Arm out
2	Arm out and slew right
3	Slew right
4	Arm in and slew right
5	Arm in
6	Arm in and slew left
7	Slew left
8	Arm out and slew left

**Right Joystick**

P134140e

Joystick Position	Function
1	Boom lower
2	Boom lower and bucket dump
3	Bucket dump
4	Boom raise and bucket dump
5	Boom raise
6	Boom raise and bucket curl
7	Bucket curl
8	Boom lower and bucket curl

QUICK COUPLERS

**⚠ WARNING**

**BURN HAZARD**  
Hydraulic fluid, tubes, fittings and quick couplers can get hot when running machine and attachments. Be careful when connecting and disconnecting quick couplers. ◀


W-2220

**⚠ WARNING**

**INJECTION HAZARD**  
Pressurised diesel fuel or hydraulic fluid can penetrate skin and eyes, causing serious injury or death. Fluid leaks under pressure may not be visible. Use a piece of cardboard or wood to find leaks. **DO NOT** use your bare hand. Wear safety goggles. If fluid enters skin or eyes, get immediate medical attention from a doctor familiar with this injury. ◀

W-3072

Figure 55




C208415a

The excavator and attachments are supplied with flush faced couplers. The couplers are mounted on the arm of the excavator (Item 1) [Figure 55].

### Connecting Quick Couplers

1. Remove any dirt or debris from the surface of both the male and female couplers, and from the outside diameter of the male coupler.
2. Visually check the couplers for corroding, cracking, damage, or excessive wear.  
  
If any of these conditions exist, the coupler(s) must be replaced.
3. Install the male coupler into the female coupler.  
  
Full connection is made when the ball release sleeve slides forward on the female coupler.

Figure 56



4. To disconnect, hold the male coupler (Item 1) and retract the sleeve (Item 2) on the female coupler until the couplers disconnect [Figure 56].

### PRIMARY AUXILIARY HYDRAULICS

#### Operating Attachments With Primary Auxiliary Hydraulics


**! WARNING**

#### MODIFICATION HAZARD

Unapproved attachments can cause serious injury or death.

Buckets and attachments for safe loads of specified densities are approved for each model. Never use attachments or buckets that are not approved by Bobcat Company. ◀

Figure 57



1. Press the AUX button (Item 1) [Figure 57] on the jog shuttle.

Figure 58




The auxiliary hydraulics icon (Item 1) [Figure 58] will turn ON.

2. For auxiliary hydraulics, continue to the next step.

OR

To activate detent mode, press and hold the AUX button (Item 1) [Figure 57] on the jog shuttle again for at least one second.

Figure 59



A beep will be heard and the detent icon (Item 1) [Figure 59] will appear. Detent mode will be active.

3. Adjust the hydraulic flow to best meet the needs of the attachment.  
(See Setting Auxiliary Hydraulics Flow Rate on Page 57)
4. To operate the attachment with primary auxiliary hydraulics, see the following table:

Figure 60



C206172b


ACTION	RESULT
Move right joystick switch (Item 1) to the right.	Supply hydraulic flow to female coupler.
Move right joystick switch (Item 1) to the left.	Supply hydraulic flow to male coupler.
Move right joystick switch (Item 1) halfway.	Auxiliary functions move at approximately one-half speed.
Press front joystick button (Item 2).	Supply continuous flow to female coupler.
Move right joystick switch (Item 1) to the left while pressing front joystick button (Item 2).	Supply continuous flow to male coupler.
Press front joystick button (Item 2) a second time.	Stop auxiliary flow to couplers.

5. To turn off auxiliary hydraulics, press the AUX button (Item 1) [Figure 57] on the jog shuttle.

**Setting Auxiliary Hydraulics Flow Rate**

1. Select [SETTINGS]→ [MACHINE SETTINGS]→ [AUXILIARY SETTINGS].

Figure 61



- Adjust the flow rate of the auxiliary hydraulics to best match the attachment / operator requirements [Figure 61].

RECOMMENDED FLOW RATES FOR COMMON ATTACHMENTS	
FLOW	ATTACHMENT
100%	Breaker, Vibratory Plate Compactor, Auger
65 – 75%	Clamp, Grapple
25 – 35%	Tilt Coupler

The touch display, if equipped, offers additional settings. (See Setting The Auxiliary Hydraulics Flow on Page 208)

**NOTE:** If the auxiliary hydraulics are enabled when the engine is turned off, they will stay enabled at engine restart. If detent flow was enabled at engine off, it will be disabled at engine restart.

**Releasing Hydraulic Pressure in Excavator**

The engine must have been recently started to release hydraulic pressure.

- Put the attachment flat on the ground.
- Stop the engine and then turn the start switch to ON, but do not start the engine.
- Make sure the left console is fully lowered.

Figure 62



- Press the AUX button (Item 1) [Figure 62] on the jog shuttle to enable auxiliary hydraulics.
- Move the right joystick switch (Item 1) [Figure 60] to the right and left several times to release pressure.

The touch display, if equipped, offers an additional option for releasing pressure. (See Releasing Hydraulic Pressure In Excavator on Page 207)

**Releasing Hydraulic Pressure In Attachments**

Hydraulic pressure in the auxiliary hydraulic system can make it difficult to engage quick couplers to an attachment.

- Release hydraulic pressure in the excavator.
- Connect the male coupler from the attachment to the female coupler of the excavator, then repeat the procedure above.

This will relieve pressure in the attachment.

- Connect the female coupler from the attachment.

**SECONDARY AUXILIARY HYDRAULICS**


**Operating Attachments With Secondary Auxiliary Hydraulics**

**⚠ WARNING**

**MODIFICATION HAZARD**  
 Unapproved attachments can cause serious injury or death.  
 Buckets and attachments for safe loads of specified densities are approved for each model. Never use attachments or buckets that are not approved by Bobcat Company. ◀


Secondary auxiliary hydraulics have a lower flow rate than primary auxiliary hydraulics. Attachment performance may be affected.

**Figure 63**




1. Press the AUX button (Item 1) [Figure 63] on the jog shuttle to activate auxiliary hydraulics.

**Figure 64**




The auxiliary hydraulics icon (Item 1) [Figure 64] will turn ON.

**Figure 65**



2. Press and hold the button (Item 1) [Figure 65] on the left joystick until a beep is heard to switch from boom swing function to secondary auxiliary hydraulics.

**Figure 66**



- The second auxiliary hydraulics icon (Item 1) [Figure 66] will appear on the screen.
3. Adjust the secondary hydraulic flow to best meet the needs of the attachment. (See Setting Auxiliary Hydraulics Flow Rate on Page 57)
  4. Use the left joystick switch (Item 2) [Figure 65] to operate the attachment as follows:
    - Move the left joystick switch to the left to supply hydraulic flow to the female coupler.
    - Move the left joystick switch to the right to supply hydraulic flow to the male coupler.
    - Move the switch halfway, and the auxiliary functions will move at approximately one-half speed.
  5. To turn off auxiliary hydraulics, press the AUX button (Item 1) [Figure 63] on the jog shuttle.

### Releasing Secondary Auxiliary Hydraulic Pressure In Excavator

The engine must have been recently started to release hydraulic pressure.

1. Put the attachment flat on the ground.
2. Stop engine and then turn the start switch to ON, but do not start the engine.
3. Make sure the left console is fully lowered.
4. Press and hold the left joystick button (Item 1) [Figure 65] until a beep is heard to switch to the secondary auxiliary hydraulics.

The secondary auxiliary hydraulic icon (Item 1) [Figure 66] will be ON when activated.

5. Move the left joystick switch (Item 2) [Figure 65] to the right and left several times to release pressure.

### Releasing Secondary Auxiliary Hydraulic Pressure In Attachments


Hydraulic pressure in the auxiliary hydraulic system can make it difficult to engage quick couplers to an attachment.

1. Follow the procedure to relieve hydraulic pressure in the excavator.
2. Connect the male coupler from the attachment to the female coupler of the excavator, then repeat the procedure above. This will release pressure in the attachment.
3. Connect the female coupler from the attachment.

## FOURTH AUXILIARY HYDRAULICS

### Location Of Fourth Auxiliary Hydraulics Lines

Figure 67



C133922a

When the excavator is equipped with fourth auxiliary hydraulics, the fourth auxiliary hydraulics lines will be mounted on top of the arm in the outside position (Item 1) [Figure 67] and connect to the port block on the arm.

### Operating Attachments With Primary, Secondary, And Fourth Auxiliary Hydraulics

On machines equipped with primary, secondary, and fourth auxiliary hydraulics, you can switch control of boom swing offset and Aux 4 between the left and right joysticks. Select the joystick control configuration that best suits your attachment and operation.

**NOTE:** Use only approved attachments for your model excavator. Attachments are approved for each model based on various factors. Using unapproved attachments could cause damage to the attachment or to the excavator.


Figure 68



1. Push the Boom Swing switch (Item 1) [Figure 68] on the left console to the left to operate boom swing with the left joystick.


This switch can later be pushed to the right to transfer boom swing control to the right joystick.

Figure 69




2. Press the AUX button (Item 1) [Figure 69] on the jog shuttle to activate auxiliary hydraulics.

Figure 70



The display will indicate the left joystick controls boom swing and the right joystick controls primary auxiliary hydraulics [Figure 70].

Figure 71



3. Press the joystick buttons to toggle to the desired joystick control configuration.
  - Press the left joystick button (Item 1) [Figure 71] until two beeps are heard to select Boom Swing, Aux 2, or Aux 4.
  - Press the right joystick button (Item 2) [Figure 71] until two beeps are heard to select Boom Swing, Aux 1, or Aux 4.

**NOTE:** Boom swing will only be available for the joystick that is set with the Boom Swing switch (Item 1) [Figure 68]. Aux 4 will be available only for the other joystick.

**NOTE:** The joystick switches must be in the neutral position before you press a joystick button to change to a different auxiliary.



4. Operate the attachment with the joysticks.

- Use the left joystick switch (Item 3) [Figure 71] to control the hydraulics indicated on the left side of the display panel (Boom Swing, Aux 2, or Aux 4).
  - Use the right joystick switch (Item 4) [Figure 71] to control the hydraulics indicated on the right side of the display panel (Boom Swing, Aux 1, or Aux 4).
5. When necessary, press the Boom Swing switch (Item 1) [Figure 68] to the right to transfer boom swing control to the right joystick.

After you push the Boom Swing switch, auxiliary hydraulics will deactivate. Press the AUX button (Item 1) [Figure 69] again to reactivate auxiliary hydraulics.

To set auxiliary hydraulics flow rate, see the following for standard display:  
 (See Setting Auxiliary Hydraulics Flow Rate on Page 57)  
 See the following for touch display:  
 (See Setting The Auxiliary Hydraulics Flow on Page 208)

**Auxiliary Hydraulics Settings Sequence**


Boom Swing Switch	Action	Display
	1. Initial setting with Boom Swing switch set to left joystick.	
	2. Activate auxiliary hydraulics.	
	3. Press right joystick button.	
	4. Press left joystick button.	
	5. Press right joystick button.	
	6. Press Boom Swing switch to right.	
	7. Activate auxiliary hydraulics.	
	8. Press right joystick button.	
	9. Press left joystick button.	

**NOTE:** The combination Aux 2 and Boom Swing is not a possible setting.

### THIRD AUXILIARY HYDRAULICS

#### Operating Attachments With Third Auxiliary Hydraulics

Figure 72



P153923b

When the excavator is equipped with third auxiliary hydraulics, two manually operated diverter valves (Item 1) [Figure 72] will be installed into the bucket hydraulic circuit.

**NOTE:** Both levers (Item 1) must be fully rotated in either the bucket position (Item 4) or the third auxiliary position (Item 3) to operate correctly [Figure 72].

1. Move both levers inward (Item 3) [Figure 72] to select third auxiliary hydraulics.
2. Connect the attachment to the third auxiliary quick couplers (Item 2) [Figure 72].

Figure 73



C206172a

3. Move the right joystick (Item 1) [Figure 73] right and left to supply hydraulic flow to the third auxiliary ports (Item 2) [Figure 72].

### ⚠ IMPORTANT

**UNINTENDED MOVEMENT HAZARD**  
If attachments are left connected, hydraulic system pressure can cause unexpected attachment movement.

Disconnect attachments from the auxiliary hydraulic diverter valve quick couplers when the levers are in the bucket position. ◀

1-2389

## OVERLOAD WARNING DEVICE

### Operating The Overload Warning Device

The excavator must be equipped with the boom load holding valve to install the overload warning device.

When the overload warning device (if equipped) is engaged, a warning buzzer will sound and the general warning icon will flash on the display if the work group is overloaded.

### WARNING

#### CRUSHING HAZARD

Falling equipment can cause serious injury or death. **DO NOT** work or stand under raised work equipment or attachment. ◀

W-2793


Figure 74



C208239c

1. Press the switch (Item 1) [Figure 74] to the right to enable the overload warning device.

Figure 75




NA3734f

2. If overload occurs, the general warning icon (Item 1) [Figure 75] will illuminate and a buzzer will sound.
  - a. Immediately bring the arm toward the machine, lower the boom, and reduce the load before continuing operation.
3. Disengage the overload warning device by pressing the switch (Item 1) [Figure 74] to the left.

## BLADE CONTROL LEVER

### Raising And Lowering The Blade

Figure 76



P200125a

The blade lever shown here [Figure 76] is for machines without an angle blade. For machines with an angle blade, the blade lever is shown in [Figure 77].

- Pull the lever backward (Item 1) [Figure 76] to raise the blade.
- Push the lever forward (Item 2) [Figure 76] to lower the blade.
- Push the lever forward until the lever is in the locked position (Item 3) [Figure 76] to put the blade in the float position.
  - ▷ Pull the lever backward to unlock from the float position.


Keep blade lowered for increased digging performance.

## ANGLE BLADE

### Operating The Angle Blade


If your machine is equipped with an angle blade:

Figure 77



P2000092a

Figure 78



NA3529

- Move the switch (Item 1) [Figure 77] to the left to angle the blade to the left [Figure 78].
- Move the switch (Item 1) [Figure 77] to the right to angle the blade to the right [Figure 78].

Always have the blade straight for excavating or lifting the excavator.

## DIESEL PARTICULATE FILTER (DPF) SYSTEM

### DPF Description


The engine exhaust system is equipped with a diesel particulate filter (DPF).

The DPF is an emissions reduction device that removes diesel particulate matter (soot) from the exhaust gases of the diesel engine. The DPF will trap and collect the soot until it is burned off.

The process of burning off the collected soot is called regeneration. There are five types of regeneration: passive, automatic, forced, forced parked, and service. An inhibit mode is also available to the operator.

Term	Description
Passive Regeneration	The engine provides adequate exhaust temperature during operation for regeneration.
Automatic Regeneration	The engine control unit (ECU) automatically controls active regeneration. Active regeneration can occur any time the engine is operating once the soot accumulated in the DPF reaches a certain level. (See Automatic Regeneration Operation on Page 68)
Forced Regeneration	The operator activates a forced regeneration. This selection requires confirmation after certain machine conditions are met. (See Forced Regeneration Operation on Page 69)
Forced Parked Regeneration	The operator activates a forced parked regeneration. This selection requires confirmation after certain machine conditions are met.
Service Regeneration	Your Bobcat dealer uses specialised equipment to perform a service regeneration. (See DPF Service Regeneration on Page 181)
Inhibit Mode	Active regeneration will not occur. This selection requires confirmation. (See Inhibit Mode Operation on Page 71)

DPF Regeneration Tables

Soot Level	0 – 75%	75 – 100%	100 – 105%	105 – 110%	110 – 120%	120 – 150%	> 150%
<b>Active Regeneration Status</b>	Not Required	Not Required	Regenerating	Regenerating	Regenerating	Not Regenerating	Not Regenerating
<b>Inhibit Allowed</b> 	Yes	Yes	Yes	Yes	Yes	Yes	Yes
<b>Forced Allowed</b> 	No	Yes	Yes	Yes	Yes	No	No
<b>Forced Parked Allowed</b> 	No	Yes	Yes	Yes	Yes	No	No
<b>DPF Icon</b> 	Off	Off	On	Flashing Slowly	Flashing Slowly	Flashing Quickly	Off
<b>HEST Icon</b> 	Off	Off	On	On	On	Off	Off
<b>Check Engine Icon</b> 	Off	Off	Off	Off	On	On	On
<b>Regeneration Type</b>	Passive	Passive	Automatic	Automatic	Automatic	Service	None
<b>Soot Load Bar Colour</b>	Grey	Blue	Blue	Red	Red	Red	Red
<b>Service Code</b>	None	None	None	None	P2463	P24A3	P24A3
<b>Torque Derate</b>	None	None	None	None	Mild	Severe	Severe
<b>Operator Action</b>	None	None	None	Activate Forced or Forced Parked Regeneration when possible	Activate Forced or Forced Parked Regeneration when possible	Dealer Service Regeneration Required (See DPF Service Regeneration on Page 181)	Contact your Bobcat dealer to replace the DPF

NOTE: The general warning icon on the display will also turn on to alert operator of active service codes.

**DPF Regeneration Status Icons**

Icon	Definition
	DPF - Appears on the display during regeneration. Machine is requesting that operator activate a forced or forced parked regeneration when flashing.
	Hot Exhaust System Temperature (HEST) - Appears on the display during regeneration to indicate that exhaust and exhaust gases can be hot.
	Inhibit - Appears on the display when the operator has selected inhibit mode. Machine is indicating it would like to do regeneration when flashing.
	Emissions Error - Appears on the display to indicate a problem with the emission regulating system.

**Automatic Regeneration Operation**

Automatic regeneration mode is selected by default every time the machine is started.


The DPF management screen is available on the display, where you can check the status of the DPF and select the required regeneration mode.

**Figure 79**




1. Select the **[NAVIGATION HANDLE]** icon (Item 1) [Figure 79].
2. Select **[SETTINGS]** (Item 2) [Figure 79].

**Figure 80**




3. Select **[MACHINE SETTINGS]** (Item 1) [Figure 80].

**Figure 81**




4. Scroll down and select **[DPF MANAGEMENT]** [Figure 81].

**Figure 82**



5. Select the automatic regeneration icon (Item 1) [Figure 82].

Figure 83



6. Select **[ACTIVATE]** [Figure 83] if not already active.

The ECU will monitor soot load and perform a regeneration automatically. The operator will be informed that an automatic regeneration has started by the HEST icon.

The machine should be operated during this regeneration.

**NOTE: The regeneration process can last for 30 minutes or longer.**

It is recommended to increase engine speed to high idle during an automatic regeneration and operate the machine under load if possible.


It is recommended to allow the regeneration cycle to finish before turning the machine off.

### Forced Regeneration Operation

A forced regeneration can be activated by the operator using the DPF management screen. The machine should be operated as normal during this regeneration.


**NOTE: The regeneration process can last for 30 minutes or longer.**

Figure 84




1. Select the **[NAVIGATION HANDLE]** icon (Item 1) [Figure 84].
2. Select **[SETTINGS]** (Item 2) [Figure 84].

Figure 85




3. Select **[MACHINE SETTINGS]** (Item 1) [Figure 85].

Figure 86



4. Scroll down and select **[DPF MANAGEMENT]** [Figure 86].

Figure 87




5. Select the forced regeneration icon (Item 1) [Figure 87].

The following machine conditions must be met before forced regeneration is allowed:

- No active DPF related service codes
- Engine coolant temperature higher than 40°C (104°F)
- Soot load between 75 percent and 120 percent
- More than 25 percent fuel in the tank

6. Increase engine speed to high idle.

Figure 88



7. Select **[ACTIVATE]** [Figure 88] to start regeneration.

It is recommended to allow the regeneration cycle to finish before turning the machine off.

**Forced Parked Regeneration Operation**

A forced parked regeneration can be activated by the operator using the DPF management screen. The machine cannot be operated during this regeneration.

**NOTE: The regeneration process can last for 40 minutes or longer.**


Figure 89



1. Select the **[NAVIGATION HANDLE]** icon (Item 1) [Figure 89].


2. Select **[SETTINGS]** (Item 2) [Figure 89].

Figure 90




3. Select **[MACHINE SETTINGS]** (Item 1) [Figure 90].

Figure 91



4. Scroll down and select **[DPF MANAGEMENT]** [Figure 91].

Figure 92



5. Select the forced parked regeneration icon (Item 1) [Figure 92].

**⚠ IMPORTANT**

**MACHINE DAMAGE HAZARD**

Failure to follow directions may cause damage to the DPF.

Never stop the engine during the regeneration cycle. This will by-pass the programmed cool down cycle required after a high temperature regen. ◀


I-2382

The following machine conditions must be met before forced parked regeneration is allowed:

- Engine coolant temperature higher than 40°C (104°F)
- Hydraulic functions disabled
- Engine speed at low idle
- More than 25 percent fuel in the tank
- Soot load between 75 percent and 120 percent
- No active DPF related service codes

6. Decrease engine speed to low idle.

Figure 93



NA3993

7. Select **[ACTIVATE]** [Figure 93] to start regeneration.

The ECU will control engine speed until the regeneration cycle is finished.

**Inhibit Mode Operation**

Regeneration can be prevented from occurring by selecting inhibit mode. The machine should be operated under load when inhibit mode is selected.

**⚠ IMPORTANT**

**MACHINE DAMAGE HAZARD**

Operating the machine in inhibit mode for extended periods may cause severe damage to the DPF. ◀

I-2409

The DPF will be inhibited from actively regenerating until a regeneration mode is selected or the machine is turned OFF. The machine will revert to automatic mode the next time the machine is turned ON.


Figure 94



NA3865A

1. Select the **[NAVIGATION HANDLE]** icon (Item 1) [Figure 94].
2. Select **[SETTINGS]** (Item 2) [Figure 94].


Figure 95



NA3865A

3. Select **[MACHINE SETTINGS]** (Item 1) [Figure 95].


Figure 96



NA3865


4. Scroll down and select **[DPF MANAGEMENT]** [Figure 96].

Figure 97



5. Select the inhibit mode icon (Item 1) [Figure 97].

Figure 98




6. Select **[ACTIVATE]** [Figure 98] to inhibit regeneration.
7. After running the machine in inhibit mode, take one of the below actions as soon as possible:
  - Place the machine in automatic regeneration mode
  - Perform a forced regeneration if possible (The soot load bar must be blue or red.)
  - Perform a forced parked regeneration if possible (The soot load bar must be blue or red.)

**ENGINE SPEED CONTROL**

**Setting Engine Speed (RPM)**

Figure 99



The engine speed control dial (Item 1) [Figure 99] controls engine rpm.

- Rotate the engine speed control dial counterclockwise to reduce engine rpm.
- Rotate the engine speed control dial clockwise to increase engine rpm.


**Eco Mode**

Eco mode, when enabled, will reduce the high idle engine rpm and cycle times to help conserve fuel in certain operating conditions.

*Activating Eco Mode*


1. Select **[SETTINGS]** → **[MACHINE SETTINGS]**.

Figure 100



2. Select **[ECO MODE]** (Item 1) [Figure 100] to turn Eco mode on / off.

Figure 101




C132900g

The Eco mode icon (Item 1) [Figure 101] will be displayed on the **GAUGES** screen when Eco mode is on.

## BOOM SWING

### Enabling Boom Swing


Figure 102



NA1432b

The purpose of the boom swing is to offset the boom with respect to the upperstructure for digging close to a structure [Figure 102]. Adjust the mirrors if necessary before beginning.

Figure 103



C206181a

1. If no auxiliary hydraulics are enabled, control the boom swing with the left joystick switch (Item 2) [Figure 103].

OR

If auxiliary hydraulics are enabled, press and hold the button (Item 1) [Figure 103] on the left joystick until a beep is heard to switch between the boom swing function and the secondary auxiliary hydraulics.

(See Operating Attachments With Secondary Auxiliary Hydraulics on Page 59)


2. Use the switch (Item 2) [Figure 103] on the left joystick to control boom swing.

- a. Move the switch to the left to swing the boom to the left.
- b. Move the switch to the right to swing the boom to the right.

## DAILY INSPECTION

### Daily Inspection And Maintenance List

Figure 104



P200106a

Maintenance work must be done at regular intervals. Failure to do so will result in excessive wear and early failures. The Service Schedule is a guide for correct maintenance of the Bobcat excavator. The decal (Item 1) [Figure 104] is located inside the right cover. (See Service Schedule on Page 149)

Do the following before each day of operation:

- Check operator canopy or cab (ROPS / TOPS / FOPS) and mounting hardware. Lubricate door hinges if necessary.
- Check seat belt and mounting hardware. Replace seat belt if damaged.
- Check for damaged decals, replace as needed.
- Check control console lockout.
- Check attachment mounting system for damage or loose parts.
- Check air cleaner and intake hoses / clamps.
- Check engine oil level and engine for leaks.
- Check engine coolant level in both the coolant recovery tank and radiator and check system for leaks.
- Check engine area for flammable materials.
- Check hydraulic fluid level and system for leaks.
- Check indicator lights for correct operation.
- Grease all pivot points.
- Check cylinder and attachment pivot points.
- Check the track tension.

- Repair broken and loose parts.
- Check or clean cab heater filters (if equipped).
- Check front horn and motion alarm (if equipped) for proper function.

Fluids such as engine oil, hydraulic fluid, coolants, etc. must be disposed of in an environmentally safe manner. Some regulations require that certain spills and leaks on the ground must be cleaned in a specific manner. See local regulations for correct disposal.

**⚠ WARNING**

**INSUFFICIENT INSTRUCTIONS HAZARD**  
 Untrained operators or failure to follow instructions can cause serious injury or death. Operators must have adequate training and instruction before operating. ◀

W-2001

**⚠ IMPORTANT**

**MACHINE DAMAGE HAZARD**  
 Improper pressure washing may lead to damage of the decal.

- Direct the stream at a 90 degree angle and at least 300 mm (12 in) from the decal.
- Wash from the centre of the decal toward the edges. ◀

I-2226

**⚠ WARNING**

**GENERAL HAZARD**  
 Failure to follow instructions can cause serious injury or death.

- Keep door / cover closed except for service.
- Keep engine clean of flammable material.
- Keep body, loose objects, and clothing away from electrical contacts, moving parts, hot parts, and exhaust.
- Do not use the machine in space with explosive dusts or gases or with flammable material near exhaust.
- Never use ether or starting fluid on diesel engine with glow plugs or air intake heater. Use only starting aids as approved by engine manufacturer.
- Leaking fluids under pressure can enter skin and cause serious injury.
- Battery acid causes severe burns; wear goggles. If acid contacts eyes, skin, or clothing, flush with water. For contact with eyes, flush and get medical attention.
- Battery makes flammable and explosive gas. Keep arcs, sparks, flames, and lighted tobacco away.
- For jump start, connect negative cable to the machine engine last (never at the battery). After jump start, remove negative connection at the engine first.
- Exhaust gases can kill. Always ventilate. ◀

W-2782

**PRE-STARTING PROCEDURE**

**Entering The Excavator**

**Figure 105**




P132086

Use the grab handles and tracks to enter the canopy / cab [Figure 105].

**Operation & Maintenance Manual And Operator's Handbook Locations**

**Figure 106**



C206182a

- Read and understand the Operation & Maintenance Manual before operating the machine.

The Operation & Maintenance Manual is located inside the storage box on the back of the operator's seat (Item 1) [Figure 106].

Figure 107



P200107a

- Read and understand the Operator's Handbook before operating the machine.

The Operator's Handbook is located in the back of the right console (Item 1) [Figure 107].

**⚠ WARNING**

**INSUFFICIENT INSTRUCTIONS HAZARD**  
Untrained operators or failure to follow instructions can cause serious injury or death.


- Read and understand the Operation & Maintenance Manual, Operator's Handbook and decals on machine.
- Follow warnings and instructions in the manuals when making repairs, adjustments or servicing.
- Check for correct function after adjustments, repairs or service. ◀

W2003

**Seat Adjustment**

*Adjusting The Suspension Seat*

Figure 108




C113009a

1. Release the seat lever (Item 1) [Figure 108] to adjust the seat forward or back.
2. Turn the handle (Item 2) to change the adjustment for operator weight. Turn the handle until your weight is shown in the window (Item 3) [Figure 108].
3. Release the lever (Item 4) [Figure 108] to change the incline of the seat back.
4. Turn the knob (Item 5) [Figure 108] to adjust the height of the seat.

**Adjusting Mirrors**

Figure 109



P113541a

Adjust mirrors (Item 1) [Figure 109] (if equipped).

**Fastening The Seat Belt**

Figure 110



P113010

Fasten the seat belt [Figure 110].

**STARTING THE ENGINE**

**Quick Start Description**

The Sleep Time is the time during which the display is in sleep cycle after the machine is turned off. The Sleep Time is fixed for the standard display.

If your machine is equipped with a touch display, the Sleep Time can be adjusted.  
(See System Sleep Time At Key OFF on Page 212)

- If you turn the start switch to on during the sleep cycle, the **GAUGES** or **PASSWORD** screen will be displayed.
- If you turn the start switch to on after the sleep cycle expires, one set of icons in the following table will be displayed.

<p>Machine Lockout Off / Quick Start On</p>  <p><small>NA3515</small></p>	<ul style="list-style-type: none"> <li>• Password is not required.</li> <li>• Engine can be started after glow plugs have cycled and wait to start light is off.</li> <li>• Machine functions are active immediately after engine is started.</li> </ul>
<p>Machine Lockout On / Quick Start On</p>  <p><small>NA3516</small></p>	<ul style="list-style-type: none"> <li>• Password is required.</li> <li>• Engine can be started after glow plugs have cycled and wait to start light is off.</li> <li>• Machine functions are disabled until a password is entered.</li> <li>• Machine will shut down if a valid password is not entered within 10 minutes.</li> </ul>
<p>Machine Lockout On / Quick Start Off</p>  <p><small>NA3517</small></p>	<ul style="list-style-type: none"> <li>• Password is required.</li> <li>• Engine cannot be started until a password is entered.</li> </ul>

**Starting The Engine**

**⚠ WARNING**


**GENERAL HAZARD**  
Failure to follow instructions can cause serious injury or death.

- **Fasten seat belt, start, and operate only from the operator's seat.**
- **Never wear loose clothing when working near machine.** ◀

W-2135

1. Perform the Pre-Starting Procedure.  
(See Pre-Starting Procedure on Page 75)

**Figure 111**



P200582a

2. Set the engine speed control (Item 1) [Figure 111] to low idle.

**⚠ IMPORTANT**


**MACHINE DAMAGE HAZARD**  
Damage to the starter motor can occur with prolonged use.

- **Do not engage the starter for longer than 15 seconds at a time.**
- **Allow the starter motor to cool for 1 minute before using again.** ◀

I-2034

3. Turn the start switch (or key) to on (Item 2) [Figure 111].
4. Enter the password if prompted.

**Figure 112**



C200593b

5. Wait while the machine cycles the glow plugs.

The glow plugs icon (Item 1) will show on the display and the Wait To Start light (Item 2) [Figure 112] on the right console will illuminate while the glow plugs are on.

**NOTE:** It is recommended in cold weather to cycle the glow plugs twice before attempting to start the engine. This will allow for additional heating time for cold weather starting.

6. When the Wait To Start light turns off, turn the start switch (or key) to the start position (Item 3) [Figure 111].

Release the start switch (or key) when the engine starts.

7. Stop the engine if the warning lights and alarm do not go off. Check for the cause before starting the engine again.
8. Turn the start switch (or key) to off to stop the engine.

**⚠ WARNING**

**INHALATION HAZARD**

Exhaust fumes contain odorless, invisible gases that can kill without warning. Fresh air must be added to avoid concentration of exhaust fumes when an engine is running in an enclosed area. If the engine is stationary, vent the exhaust outside. ◀

W-2050

**⚠ WARNING**

**FIRE AND EXPLOSION HAZARDS**

Engines can have hot parts and hot exhaust gas that can cause serious injury or death.

- Keep flammable material away.
- DO NOT use machines in an atmosphere containing explosive dust or gases. ◀

W-2051

**Lowering The Control Console**

**Figure 113**



P134071a

- Lower the left control console [Figure 113].

The console must be in the locked down position for the hydraulic joysticks and traction system to operate.

The hydraulic joysticks and traction system are deactivated when the control console is raised. If the joysticks and traction system fail to deactivate when the console is raised, see your Bobcat dealer for service.

**Warming The Hydraulic System**

If the temperature is below freezing, let the engine run for at least 15 minutes to warm the engine and hydraulic fluid before operating the excavator.

**Cold Temperature Starting Tips**

**⚠ WARNING**

**EXPLOSION HAZARD**

Failure to follow instructions can cause serious injury, death or severe engine damage. DO NOT use ether or starting fluid with glow plug or air intake heater systems. ◀

W-2071

**NOTE:** The display screen may not be at full intensity when the temperature is below -26°C (-15°F). The display screen may take 30 seconds to several minutes to warm up. All systems remain monitored even when the display screen is off.

If the temperature is below freezing, perform the following to make starting the engine easier:

- Replace the engine oil with the correct type and viscosity for the anticipated starting temperature. (See Engine Oil Chart on Page 168)
- Make sure the battery is fully charged.


If the battery is discharged (but not frozen), a booster battery can be used to jump start the excavator. (See Using A Booster Battery (Jump Starting) on Page 175)

- Install an engine heater.


**MONITORING THE DISPLAY**

**Monitoring The Standard Display During Operation**

**Figure 114**



**Figure 115**



Frequently monitor the **GAUGES** [Figure 114] and **VITAL DETAIL** [Figure 115] screens for machine condition.

These icons (Item 1) [Figure 114] indicate machine conditions that may require service. (See Standard Display on Page 36)

**Figure 116**




Active shortcuts (Item 1) [Figure 116] that appear also indicate a need for service. (See Active Shortcuts on Page 194)

A red dot next to the **[SERVICE]** icon indicates an active service code. (See Viewing Service Codes on Page 196)

The fuel and engine coolant gauges will turn red when there is a problem with these systems.

**Monitoring The Touch Display During Operation**

**Figure 117**



**Figure 118**



Frequently monitor the **GAUGES** [Figure 117] and **VITAL DETAIL** [Figure 118] screens for machine condition.

These icons (Item 1) [Figure 117] indicate machine conditions that may require service.

A red dot next to the **[SERVICE]** icon indicates an active service code. (See Viewing Service Codes on Page 202)

The fuel and engine coolant gauges will turn red when there is a problem with these systems.

For more information see touch display section. (See Accessing Vital Detail And Machine Performance on Page 199)

## Derate And Shutdown Conditions

Certain machine conditions can result in a derate condition until the fault is corrected. These derates are designed to protect the machine systems from damage while a fault condition exists.

An engine shutdown can occur during certain system malfunctions. The engine can be restarted to move the machine.

## OPERATING PROCEDURE

### Inspect The Work Area

Before beginning operation, inspect the work area and check ground conditions for unsafe conditions:

- Look for sharp drop-offs or rough terrain.
- Have underground utility lines (gas, electrical, water, sewer, irrigation, etc.) located and marked.
- Work slowly in areas of underground utilities.
- Remove objects or other construction material that could damage the machine or cause personal injury.
- Inspect for signs of instability such as cracks or settlement.
- Be aware of weather conditions that can affect ground stability.
- Check for adequate traction if working on a slope.

### Basic Operating Instructions

When operating on a public road or motorway, always follow local regulations. For example, a slow moving vehicle (SMV) emblem or direction signals may be required.

Run the engine at low idle speed to warm the engine and hydraulic system before operating the machine.

**NOTE:** Machines warmed up with moderate engine speed and light load have longer life.

New operators must operate the machine in an open area without bystanders. Operate the controls until the machine can be handled at an efficient and safe rate for all conditions of the work area.

### Operating Near An Edge Or Water

Keep the machine as far back from the edge as possible and the machine base perpendicular to the edge so that if part of the edge collapses, the machine can be moved back.

Always move the machine back at any indication the edge may be unstable.

### Lowering The Work Group If The Engine Stops

If the engine stops, you can lower the boom and attachment to the ground using hydraulic pressure in the accumulator.

Figure 119




P134071a

1. Ensure the left console is down [Figure 119].
2. Turn the start switch to ON.
3. Use the joystick to lower the boom.

**Driving The Excavator**

- When operating on uneven ground, operate as slow as possible and avoid sudden changes in direction.
- Avoid travelling over objects such as rocks, trees, stumps, etc.

Figure 120




NA1440a

- When working on wet or soft ground, put planks (Item 1) [Figure 120] on the ground to provide a solid base to travel on and prevent the excavator from getting stuck.
- If one or both tracks have become stuck in soft or wet ground, raise one track at a time by turning the upperstructure and pushing the bucket against the ground.

- ▷ Put planks under the tracks and drive the excavator to dry ground.

Figure 121



NA1422a

- The bucket may also be used to pull the excavator [Figure 121].
  - ▷ Raise the blade.
  - ▷ Extend the arm and lower the boom.
  - ▷ Operate the boom in a digging manner.

**Operating On Slopes**

**⚠ WARNING**

**INSTABILITY HAZARD**


Machine tipping or rollover can cause serious injury or death.

- Do not travel across or up slopes that are over 15 degrees.
- Do not travel down or back up slopes that exceed 25 degrees.
- Look in the direction of travel.
- Check for adequate traction. ◀

W-2497

- When going down a slope, control the speed with the steering levers and the speed control lever.

Figure 122



NA1448e

- When going down grades that exceed 15 degrees (Item 2), put the machine in the position shown, with the attachment no higher than 304 mm (12 in) (Item 1) off the ground [Figure 122]. Run the engine slowly.
- Do not travel down or back up slopes that exceed 25 degrees (Item 2) [Figure 122].
- Operate as slow as possible.
- Avoid sudden changes in lever directions.
- Avoid travelling over objects such as rocks, trees, stumps, etc.
- Stop the machine before moving the upper equipment controls.
- Never allow the blade to strike a solid object.

Damage to the blade or hydraulic cylinder can result.


**⚠ WARNING**

**INSTABILITY HAZARD**  
Machine tipping or rollover can cause serious injury or death.

- Always fasten seat belt.
- Avoid steep areas or banks that could break away.
- Keep boom centred and attachments as low as possible when travelling on slopes or in rough conditions.
- Look in the direction of travel.
- Keep feet and hands on controls. ◀


W-2498

Figure 123



NA1447e


Figure 124



NA1449c

- When travelling up slopes (Item 1) [Figure 123], or on side slopes that are 15 degrees or less (Item 1) [Figure 124], position the machine as shown and run the engine slowly.

Figure 125




NA1450a

- When operating on a slope, level the work area before beginning [Figure 125].

If this is not possible, the following procedure should be used:

- Do not work on slopes that are over 15 degrees (Item 1) [Figure 124].
- Use a slow work cycle.
- Avoid working with the tracks across the slope. This will reduce stability and increase the tendency for the machine to slide.
- Position the excavator with the blades downhill and lowered.
- Avoid swinging or extending the bucket more than necessary in a downhill direction.
- When you must swing the bucket downhill, keep the arm low and skid the bucket downhill.
- When working with the bucket on the uphill side, keep the bucket as close to the ground as possible.
- Dump the spoil far enough away from the trench or hole to prevent the possibility of a cave in.

Figure 126



P200102a

- To brake the machine when going down a slope, move the steering levers (Item 1) to the NEUTRAL position (Item 2) [Figure 126].

This will engage the hydrostatic braking.


- When the engine stops on a slope, move the steering levers to the NEUTRAL position. Lower the boom / bucket to the ground.

If the engine stops, the boom / bucket (attachments) can be lowered to the ground using the hydraulic pressure that is stored in the accumulator.

- Ensure the console is in the locked down position, and the key is switched to the ON position.
- Use the joystick to lower the boom.
- Start the engine and resume operation.

### Operating In Water

Figure 127



NA1446a

- Do not operate or immerse the excavator in water higher than the bottom of the swing bearing (Item 1) [Figure 127].
- Remove mud and water from the machine before parking.
- In freezing temperatures, park the machine on boards or concrete to prevent the track or undercarriage from freezing to the ground and preventing machine movement.
- Grease the excavator when it has been operated or immersed in water for a period of time. Greasing forces the water out of the lubrication areas.
- Remove water from the cylinder rods.

If water freezes to the cylinder rod, the cylinder seals can be damaged when the rod is retracted.

**Protecting The Track From Damage**

- In freezing temperatures, park the machine on boards or concrete.

If you park the machine on the ground, the track or undercarriage might freeze to the ground and prevent the machine from moving.


- Remove mud and water from the machine before parking.

If moisture invades through cuts on the track, the embedded steel cords will corrode. The deterioration of the design strength may cause the steel cords to break.

- Remove any stones or foreign objects that may be clogging the rubber track.


Stones and foreign objects can become wedged between the sprocket / rollers and cause detracting and track stress.

**Figure 128**



NA20189

**Figure 129**




NA20190

- Maintain proper track tension. (See Track Tension on Page 182)

When the rubber track detracts due to improper track tension, the idler or sprocket rides on the projections of the embedded metal causing the embedded metal to be exposed to corrosion ([Figure 128] or [Figure 129]).

**Figure 130**



NA20248


- Avoid driving over sharp objects.

When rubber tracks drive over sharp projections:

- Intensive stress is applied to the lug side of the rubber surface, especially at the edges of embedded metals, causing cracks and cuts in the area around the embedded metals.
- Concentrated forces cause cuts [Figure 130] on the lug side of the rubber surface.
- If avoiding a sharp object is impossible, do not make a turn while driving over a sharp object.

If you make a turn on a projection, the lug side rubber surface will have an even higher chance of being cut. If the cuts run through the embedded steel cords, it might result in the steel cords breaking due to corrosion.

Figure 131



NA20247a

- Avoid driving over stumps and ridges.  
This may apply extensive stress to the lug root where metals are embedded [Figure 131].
- Avoid making quick turns on bumpy and rocky fields.

## STOPPING THE ENGINE AND LEAVING THE MACHINE

### Stopping The Engine And Leaving The Machine

Figure 132



C200402a

1. Stop the machine on level ground.
2. Lower the work equipment and the blade to the ground [Figure 132].


Figure 133



C208107a

3. Rotate the engine speed control dial counterclockwise to low idle [Figure 133].
4. Run the engine at idle speed for about 5 minutes to allow it to cool.

Figure 134



5. Turn the switch to Stop (Item 1) [Figure 134].
6. Disconnect the seat belt.
7. Remove the key from the switch (if equipped) to prevent operation of machine by unauthorised personnel.
8. Raise the control console.
9. Exit the machine.

INSTALLING ATTACHMENTS (PIN-ON ATTACHMENT)

**⚠ WARNING**

**MODIFICATION HAZARD**

Unapproved attachments can cause serious injury or death.

Buckets and attachments for safe loads of specified densities are approved for each model. Never use attachments or buckets that are not approved by Bobcat Company. ◀

W-2052

**⚠ WARNING**

**GENERAL HAZARD**


Failure to follow instructions can cause serious injury or death.

Stop the machine on a firm flat surface. When removing or installing attachments always have a second person in the operator's seat, give clear signals and work carefully. ◀

W-2140

1. Start the engine.


Figure 135



NA20306b

2. Move the arm toward the bucket and align the mounting hole (Item 1) [Figure 135].
3. Stop the engine and exit the excavator.
4. Install the O-rings by rolling them onto the interior bucket bushing groove.
5. Install the snap ring (Item 2) and washer (Item 3) onto the pin (Item 4) [Figure 135].
6. Push the pin (Item 4) through the bucket bushings and pivot [Figure 135].
7. Align link with bucket bushing (Item 5) [Figure 135] and washers.
8. With washer and snap ring installed, push the second pin (Item 6) through bucket bushing and link [Figure 135].

Figure 136




9. Install screws (Item 1) and double nuts (Item 2), ensuring that the screws rotate freely [Figure 136].
10. Add grease to the grease fittings.

**REMOVING ATTACHMENTS (PIN-ON ATTACHMENT)**


1. Park the excavator on a flat surface and lower the bucket fully.
2. Stop the engine and exit the excavator.

Figure 137



3. Remove the screws (Item 1) and double nuts (Item 2) [Figure 137].

Figure 138



4. Remove the pins, washers, and snap rings (Items 1, 2, and 3) [Figure 138].
5. Do not damage the O-rings in the arm.

**INSTALLING ATTACHMENTS (QUICK COUPLER, KLAC SYSTEM)**

Installation of the bucket is shown. The procedure is the same for other attachments. Disconnect any hydraulic lines that are operated by hydraulic power before removing any attachments (breaker, auger, etc.).

**⚠ WARNING**

**MODIFICATION HAZARD**

Unapproved attachments can cause serious injury or death.

Buckets and attachments for safe loads of specified densities are approved for each model. Never use attachments or buckets that are not approved by Bobcat Company. ◀

W-2052

**⚠ WARNING**

**ENTANGLEMENT AND IMPACT HAZARD**

Contact with moving parts, a trench cave-in or flying objects can cause serious injury or death.


Keep all bystanders 6 m (20 ft) away from equipment when operating. ◀

W-2119

A coupler equipped with the lifting device can only be used on machines on which the overload warning device and boom and arm load holding valves are installed. See your Bobcat dealer for available kits.

1. Fully retract the bucket cylinder.
2. Stop the engine and exit the excavator.


**Figure 139**



p-72272b

3. Inspect the quick coupler [Figure 139].

**Figure 140**



p-72273a


4. If the coupler is in the unlatched position (Item 1) [Figure 139], proceed to Step 5.

OR

If the coupler is in the latched position (Item 2) [Figure 139], install the tool (Item 1) [Figure 140] and pull the handle. The latch will move completely forward and lock in the unlatched position.

5. Enter the excavator, fasten the seat belt, and start the engine.


**Figure 141**



p-72274b

6. Position the quick coupler near the attachment [Figure 141].

Figure 142




7. Extend the arm out until there is at least 100° (Item 1) between the quick coupler surface (Item 2) and the attachment mounting surface (Item 3) [Figure 142].

There must be proper clearance (Item 1) between the hook (Item 4) and the quick coupler (Item 5) [Figure 142].


Extend the arm out to get the required angle (Item 1) [Figure 142]. Damage could occur to the attachment hooks or the quick coupler without proper clearance.

Figure 143




8. Raise the boom and extend the arm until the hooks of the attachment (Item 1) engage the pins (Item 2) of the quick coupler [Figure 143].

Figure 144



9. Raise the boom until there is approximately 500 mm (20.0 in) (Item 1) [Figure 144] of clearance between the bottom of the attachment and the ground.

Figure 145



10. Extend the bucket cylinder (Item 1) [Figure 145] fully.
11. Lower the attachment until it is flat on the ground.
12. Stop the engine and exit the excavator.

Inspect the quick coupler latch. Check if it has properly locked. (See Inspecting And Adjusting The Quick Coupler Latch on Page 91)

**REMOVING ATTACHMENTS (QUICK COUPLER, KLAC SYSTEM)**

Removal of the bucket is shown. The procedure is the same for other attachments. Disconnect any hydraulic lines that are operated by hydraulic power before removing any attachments (breaker, auger, etc.).

**⚠ WARNING**

**PINCHING HAZARD**


Failure to follow instructions can cause serious injury.

Keep fingers and hands out of pinch points when latching and unlatching the attachment quick coupler. ◀

W2541

1. Position the attachment flat on the ground.


**Figure 146**



p-72286

2. Install the quick coupler tool (Item 1) into the hole (Item 2) in the quick coupler [Figure 146].
3. Push down on the tool (Item 1) [Figure 146] to unlock the latch.
4. Remove the tool.
5. Enter the excavator, fasten the seat belt, and start the engine.


**Figure 147**



p-72282a

6. Retract the bucket cylinder fully and lower the boom until the attachment is on the ground [Figure 147].

**Figure 148**



p-72274c

7. Continue to lower the boom and move the arm towards the excavator until the quick coupler is clear of the attachment [Figure 148].

**INSPECTING AND ADJUSTING THE QUICK COUPLER LATCH**


**⚠ WARNING**

**PINCHING HAZARD**

Failure to follow instructions can cause serious injury.

Keep fingers and hands out of pinch points when latching and unlatching the attachment quick coupler. ◀


**Figure 149**



Visually inspect the quick coupler latch to the bucket mount [Figure 149]. The latch must be fully engaged (Item 1) [Figure 149].

If the latch is not fully engaged (Item 2) [Figure 149], proceed with the following instructions:

**Figure 150**



1. Install the tool (Item 1) in the hole (Item 2) of the quick coupler [Figure 150].

2. Push the tool (Item 1) [Figure 150] down to unlatch the quick coupler.
3. Remove the tool (Item 1) [Figure 150].
4. Enter the excavator, fasten the seat belt, and start the engine.
5. Raise the boom 500 mm (20.0 in) off the ground and fully extend the bucket cylinder [Figure 145].
6. Lower the attachment until it is flat on the ground.
7. Stop the engine and exit the excavator.
8. Again, visually inspect the quick coupler to make sure the latch is fully engaged (Item 1) [Figure 149].
9. If it is not fully engaged, remove the attachment and inspect both the quick coupler and the attachment for damage or debris.

## INSTALLING ATTACHMENTS (GERMAN STYLE COUPLER)

Installation of the bucket is shown. The procedure is the same for other attachments. Disconnect any hydraulic lines that are operated by hydraulic power before removing any attachments (breaker, auger, etc.).

### **⚠ WARNING**

#### **MODIFICATION HAZARD**

Unapproved attachments can cause serious injury or death.

Buckets and attachments for safe loads of specified densities are approved for each model. Never use attachments or buckets that are not approved by Bobcat Company. ◀

W2052

### **⚠ WARNING**

#### **ENTANGLEMENT AND IMPACT HAZARD**

Contact with moving parts, a trench cave-in or flying objects can cause serious injury or death.


Keep all bystanders 6 m (20 ft) away from equipment when operating. ◀

W2119

A coupler equipped with the lifting device can only be used on machines on which the overload warning device and boom and arm load holding valves are installed. See your Bobcat dealer for available kits.

1. Start the engine.
2. If your machine is equipped with a hydraulic clamp, fully retract the hydraulic clamp cylinder so the clamp is out of the way for installing the attachment.

Figure 151



C113895a


3. Position the arm and quick coupler to the attachment [Figure 151].

Figure 152



C206172c


Figure 153



C113902c

4. Move the right joystick (Item 1) [Figure 152] to the right (OUT) to curl the coupler (Item 1) [Figure 153] back, fully away from the cab.
5. Lower the coupler onto the attachment.

Figure 154




- Engage the coupler hooks (Item 1) onto the attachment shaft (Item 2) [Figure 154].

Figure 155



- Move the right joystick to the left (IN) and curl the coupler (Item 1) [Figure 155] in toward the cab fully.
- Stop the engine and exit the machine.

Figure 156




- Use the supplied wrench (Item 1) [Figure 156] and turn the wrench clockwise until the locking pins fully engage.

**⚠ WARNING**

**CRUSHING HAZARD**

Failure to fully engage quick coupler locking pins can allow attachment to come off and can cause serious injury or death. The locking pins must be fully engaged and locked to the attachment pins. <sup>W-3023</sup>

Figure 157



- Visually check that the locking pins (Item 1) [Figure 157] are extended through the holes in the attachment mounting frame, securely fastening the attachment to the coupler.

If both locking pins do not engage in the locked position, see your Bobcat dealer for service.

11. Enter the excavator, fasten the seat belt, and start the engine.  
(See Pre-Starting Procedure on Page 75)
12. With the attachment as low to the ground as possible, curl the attachment out and in several times to ensure the attachment is secured to the coupler.
13. Lower the attachment flat to the ground.

The type of quick coupler installed on the excavator may affect the excavator's lift capacity and the availability of attachments.

See the lift capacity decal on your machine for the specific lift capacities of your machine. If this decal is missing or damaged, see your Bobcat dealer.  
(See Lift Capacity on Page 107)

See your Bobcat dealer for a list of approved attachments for the type of quick coupler installed on the machine.

### REMOVING ATTACHMENTS (GERMAN STYLE COUPLER)

Removal of the bucket is shown. The procedure is the same for other attachments. Disconnect any hydraulic lines that are operated by hydraulic power before removing any attachments (breaker, auger, etc.).

#### **⚠ WARNING**

**ENTANGLEMENT AND IMPACT HAZARD**  
Contact with moving parts, a trench cave-in or flying objects can cause serious injury or death.  
Keep all bystanders 6 m (20 ft) away from equipment when operating. ◀

W-2119

1. Enter the excavator, fasten the seat belt, and start the engine.
2. Raise the boom.


Figure 158



C113899

3. Move the right joystick to the left (IN) and curl the coupler in toward the cab fully [Figure 158].
4. Stop the engine and exit the excavator.


Figure 159



p113803b

5. Use the supplied wrench (Item 1) [Figure 159] and turn the wrench anticlockwise until the locking pins are fully disengaged.
6. Enter the excavator, fasten the seat belt, and start the engine.
7. With the attachment slightly off the ground, roll the quick coupler back until the coupler starts to disengage from the attachment.

Figure 160



p113896b

8. Roll the quick coupler back fully and lower the boom and arm until the attachment is on the ground and the quick coupler is disengaged from the attachment pins [Figure 160].
9. Move the arm away from the attachment.

**INSTALLING ATTACHMENTS (MECHANICAL PIN GRABBER COUPLER)**

Figure 161



C207444

You have been supplied with the release tool [Figure 161] that is required to disengage and engage the safety lock. Do not use alternative tools, as they may damage the coupler.

Installation of the bucket is shown. The procedure is the same for other attachments. Disconnect any hydraulic lines that are operated by hydraulic power before removing any attachments (breaker, auger, etc.).

**⚠ WARNING**

**MODIFICATION HAZARD**  
 Unapproved attachments can cause serious injury or death.  
 Buckets and attachments for safe loads of specified densities are approved for each model. Never use attachments or buckets that are not approved by Bobcat Company. ◀

W-2052

**⚠ WARNING**


**ENTANGLEMENT AND IMPACT HAZARD**  
 Contact with moving parts, a trench cave-in or flying objects can cause serious injury or death.  
 Keep all bystanders 6 m (20 ft) away from equipment when operating. ◀

W-2119

A coupler equipped with the lifting device can only be used on machines on which the overload warning device and boom and arm load holding valves are installed. See your Bobcat dealer for available kits.

1. If your machine is equipped with a hydraulic clamp, fully retract the hydraulic clamp cylinder so the clamp is out of the way for installing the attachment.

Figure 162



2. Inspect the quick coupler. If the wedge and the trigger are in the primed position (Item 1) [Figure 162], proceed to Step 4.

OR

If the wedge is in the engaged position (Item 2) [Figure 162], see Step 3.

**⚠ WARNING**


**PINCHING HAZARD**

Failure to follow instructions can cause serious injury.

Keep fingers and hands out of pinch points when latching and unlatching the attachment quick coupler.

W-2541


Figure 163



3. To prepare the quick coupler, do the following:
- Stop the engine and exit the excavator.
  - Install the release tool (Item 1) [Figure 163].


- Rotate the release tool clockwise and hold [Figure 163].
- Push the release tool down [Figure 163].
- The bottom part of the wedge will withdraw from the rear pin slot and the trigger will drop down.
- Remove the release tool and return it to a secure position.
- Enter the excavator, fasten the seat belt, and start the engine.

Figure 164




4. Guide the coupler front hooks onto the attachment front pin [Figure 164].
5. Raise the boom until there is approximately 500 mm (20 in) of clearance between the bottom of the attachment and the ground.

Figure 165



6. Extend the bucket cylinder and curl in the bucket [Figure 165] until you hear the wedge engage on the attachment back pin.

Figure 166



7. Visually inspect the indication bar to see if the coupler is fully engaged (Item 1) [Figure 166].

If the visual indicator bar is not fully engaged (Item 2) [Figure 166], the attachment must not be operated. Turn off the excavator and examine the coupler for dirt build up or damage. Refer to the service manual for further information.


**⚠ WARNING**

**CRUSHING HAZARD**

Failure to fully engage quick coupler locking clasps / pins can allow attachment to come off and can cause serious injury or death. The locking clasps / pins must be fully engaged and locked to the attachment pins. ◀

W-3024

Figure 167



8. Shake the attachment vigorously and / or carry out a bump test to ensure the attachment is secured to the coupler [Figure 167].

**REMOVING ATTACHMENTS (MECHANICAL PIN GRABBER COUPLER)**

Removal of the bucket is shown. The procedure is the same for other attachments. Disconnect any hydraulic lines that are operated by hydraulic power before removing any attachments (breaker, auger, etc.).

**⚠ WARNING**

**MODIFICATION HAZARD**

Unapproved attachments can cause serious injury or death.

Buckets and attachments for safe loads of specified densities are approved for each model. Never use attachments or buckets that are not approved by Bobcat Company. ◀

W-2052

**⚠ WARNING**

**ENTANGLEMENT AND IMPACT HAZARD**

Contact with moving parts, a trench cave-in or flying objects can cause serious injury or death.

Keep all bystanders 6 m (20 ft) away from equipment when operating. ◀

W-2119

Figure 168




C207452a

1. Position the attachment close to ground level at the angle shown [Figure 168].

The bucket / attachment pins should be approximately parallel to the ground.

Figure 169




**DO NOT RELEASE AN ATTACHMENT WITH THE COUPLER CURLED OPEN. [Figure 169]**

2. Stop the engine and exit the excavator.

**⚠ WARNING**

**PINCHING HAZARD**  
Failure to follow instructions can cause serious injury. Keep fingers and hands out of pinch points when latching and unlatching the attachment quick coupler. ◀

Figure 170




3. Firmly insert the release tool (Item 1) [Figure 170].

**⚠ WARNING**

**PINCHING HAZARD**  
Failure to follow instructions can cause serious injury. Keep fingers and hands out of pinch points when latching and unlatching the attachment quick coupler. ◀

4. Rotate the release tool clockwise and hold [Figure 170].
5. Press the release tool down against the wedge to disengage the attachment back pin [Figure 170].
6. Remove the release tool and return it to a secure position.
7. Enter the excavator, fasten the seat belt, and start the engine.
8. Lower the attachment to the ground.
9. Roll the coupler back until the coupler disengages from the attachment.

Figure 171



10. Move the arm away from the attachment [Figure 171].

**INSTALLING ATTACHMENTS (HYDRAULIC QUICK COUPLER)**

Installation of the bucket is shown. The procedure is the same for other attachments. Disconnect any hydraulic lines that are operated by hydraulic power before removing any attachments (breaker, auger, etc.).

**⚠ WARNING**

**MODIFICATION HAZARD**

Unapproved attachments can cause serious injury or death.

Buckets and attachments for safe loads of specified densities are approved for each model. Never use attachments or buckets that are not approved by Bobcat Company. ◀

W-2052

**⚠ WARNING**

**ENTANGLEMENT AND IMPACT HAZARD**

Contact with moving parts, a trench cave-in or flying objects can cause serious injury or death.


Keep all bystanders 6 m (20 ft) away from equipment when operating. ◀

W-2119

A coupler equipped with the lifting device can only be used on machines on which the overload warning device and boom and arm load holding valves are installed. See your Bobcat dealer for available kits.

1. Start the engine.
2. If your machine is equipped with a hydraulic clamp, fully retract the hydraulic clamp cylinder so the clamp is out of the way for installing the attachment.

**Figure 172**



C113895a


3. Position the arm and quick coupler to the attachment [Figure 172].

**Figure 173**



C206172a

**Figure 174**



C113902b

4. Move the right joystick (Item 1) [Figure 173] to the left (IN) to curl the coupler (Item 1) [Figure 174] fully in toward the cab.

**Figure 175**




5. Press the coupler ON / OFF switch (Item 1) [Figure 175] to the left (ON) position to enable the quick coupler feature.

The switch will illuminate in the ON position and a buzzer will sound.

6. Within five seconds after pressing the coupler ON / OFF switch (Item 1), press and release the INTENT switch (Item 2) [Figure 175] while continuing to hold the right joystick to the left (IN).

The buzzer will continue to sound and the switch will stay ON.

**Figure 176**




p113904b

7. For the Pin Grabber Coupler – Continue holding the right joystick to the left (IN) until the locking clasp (Item 1) [Figure 176] is fully retracted.

OR

For the Hydraulic Quick Coupler – Continue holding the right joystick to the left (IN) until the pins (Item 2) [Figure 176] are fully retracted.

**Figure 177**



p113986c

8. Roll the coupler out and move the arm toward the attachment. Position the boom, arm, and coupler so the coupler (Item 1) is positioned over the attachment pin (Item 2) [Figure 177].
9. Raise the attachment up slightly.

**Figure 178**



C113859

10. Curl the quick coupler in fully [Figure 178].
11. Press the coupler ON / OFF switch (Item 1) [Figure 175] to the right, (OFF) position.


The switch light and buzzer will turn OFF.

12. For the Pin Grabber Coupler – Continue to curl the bucket in for an additional 10 seconds to allow the locking clasp to move and lock to the bucket pins.

OR


For the Hydraulic Quick Coupler – The locking pins will extend and engage the attachment mount locking the attachment to the coupler.

Figure 179



C113664a

Figure 180



C113600a

13. For the Pin Grabber Coupler – Visually check that the locking clasp (Item 1) [Figure 179] is fully engaged and locked, securely fastening the attachment to the coupler.

OR

For the Hydraulic Quick Coupler – Visually check that the locking pins (Item 2) [Figure 180] are extended through the holes in the attachment mounting frame, securely fastening the attachment to the coupler.

14. With the attachment as low to the ground as possible, curl the attachment out and in several

times to ensure the attachment is secured to the coupler.

If the locking clasps do not engage in the locked position, see your Bobcat dealer for service.

15. Lower the attachment flat to the ground.

**⚠ WARNING**

**CRUSHING HAZARD**

Failure to fully engage quick coupler locking clasps / pins can allow attachment to come off and can cause serious injury or death. The locking clasps / pins must be fully engaged and locked to the attachment pins. ◀

W-3024

The type of quick coupler installed on the excavator may affect the excavator's lift capacity and the availability of attachments.

See the lift capacity decal on your machine for the specific lift capacities of your machine. If this decal is missing or damaged, see your Bobcat dealer. (See Lift Capacity on Page 107)

See your Bobcat dealer for a list of approved attachments for the type of quick coupler installed on the machine.

**REMOVING ATTACHMENTS (HYDRAULIC QUICK COUPLER)**


Removal of the bucket is shown. The procedure is the same for other attachments. Disconnect any hydraulic lines that are operated by hydraulic power before removing any attachments (breaker, auger, etc.).

**⚠ WARNING**

**ENTANGLEMENT AND IMPACT HAZARD**  
 Contact with moving parts, a trench cave-in or flying objects can cause serious injury or death. Keep all bystanders 6 m (20 ft) away from equipment when operating. ◀

1. Enter the excavator and start the engine.
2. Raise the attachment slightly off the ground.

**Figure 181**




**Figure 182**



3. Move the right joystick (Item 1) [Figure 181] to the left (IN) to curl the coupler fully in toward the cab [Figure 182].

**Figure 183**




4. Press the coupler ON / OFF switch (Item 1) [Figure 183] to the left (ON) position to enable the quick coupler feature.

The switch will illuminate when in the ON position and a buzzer will sound.

5. Within five seconds after pressing the coupler ON / OFF switch (Item 1) [Figure 183], press and release the INTENT switch (Item 2) [Figure 183] while continuing to hold the right joystick to the left (IN).

The buzzer will continue to sound and the light will stay ON.

Figure 184



6. For the Pin Grabber Quick Coupler – Continue holding the right joystick to the left (IN) until the locking clasp (Item 1) [Figure 184] retracts and unlocks the attachment from the quick coupler.

OR

For the Hydraulic Quick Coupler – Continue holding the right joystick to the left (IN) until the pins (Item 2) [Figure 184] are fully retracted to unlock the attachment from the quick coupler.

7. With the attachment slightly off the ground, roll the quick coupler back.  
The coupler will start to disengage from the attachment.
8. Roll the quick coupler back fully.
9. Lower the boom and arm until the attachment is on the ground and the quick coupler is disengaged from the attachment pins.

Figure 185





Figure 186




10. Move the arm away from the excavator until the quick coupler is clear of the attachment [Figure 185] or [Figure 186].
11. Press the coupler ON / OFF switch (Item 1) [Figure 183] to the right, (OFF) position.  
The switch light and buzzer will turn OFF.

## HYDRAULIC CLAMP

### Hydraulic Clamp Operation

Figure 187



N15513a

The optional lifting clamp attachment (if equipped) gives the excavator a wider range of use and mobility for debris removal [Figure 187].

The lifting clamp cylinder must be fully retracted when the machine is being used for excavating.

The lift capacities are reduced for machines equipped with the optional lifting clamp. (See Lift Capacity on Page 107)

### **⚠ IMPORTANT**

**MACHINE DAMAGE**  
Improper use of the clamp, such as prying, will result in clamp damage.  
Clamp is for lifting purposes only. ◀

1382-AF18701D

**NOTE:** Use care when operating the bucket and clamp functions on machines equipped with an attachment mounting system and without a bucket or attachment installed. Cylinder damage can occur due to contact between the attachment mounting system and the clamp when both cylinders are fully extended.

#### Using Primary Auxiliary Hydraulics To Activate Clamp

1. Engage the primary auxiliary hydraulics by pressing the AUX button on the jog shuttle.

Set the hydraulics flow to 60 – 70%.  
(See Setting Auxiliary Hydraulics Flow Rate on Page 57) Adjust auxiliary flow as needed for optimal job performance.

Figure 188




C206172a

2. Move the switch (Item 1) [Figure 188] on the right joystick to the right to open the clamp.
3. Move the switch (Item 1) [Figure 188] to the left to close the clamp.

#### Using Secondary Auxiliary Hydraulics to Activate Clamp

1. Engage the secondary auxiliary hydraulics by pressing the AUX button on the jog shuttle.

Figure 189



C206181a

2. Press and hold the button (Item 1) [Figure 189] on the left joystick until a beep is heard to switch from boom swing to secondary auxiliary hydraulics.
3. Move the switch (Item 2) [Figure 189] on the left joystick to the left to open the clamp.
4. Move the switch (Item 2) [Figure 189] on the left joystick to the right to close the clamp.

**HANDLING OBJECTS**

Do not exceed the Rated Lift Capacity when handling objects.

See the lift capacity decal on your machine for the specific lift capacities of your machine in different configurations. If this decal is missing or damaged, see your Bobcat dealer.

(See Calculating Lift Capacity on Page 107)

**⚠ WARNING**

**INSTABILITY HAZARD**

**Excessive load can cause tipping or loss of control leading to serious injury or death.**

**Do not exceed rated lift capacity. ◀**


W-2374

**Handling Objects With The Lifting Device**

The machine must be equipped with a lifting device, boom and arm load hold valves, and the overload warning device. See your Bobcat dealer for available kits.


Do not exceed the machine's Rated Lift Capacity or the Rated Lift Load (RLL) of the lifting device (lift eye).

**Figure 190**



C135342a

**Figure 191**



P200410a

The maximum Rated Lift Capacity is shown on the lifting device (Item 1) [Figure 190] or [Figure 191].

**⚠ WARNING**

**INSTABILITY AND CRUSHING HAZARD**


**Excessive load can cause tipping, loss of control or failure of the lift eye resulting in serious injury or death.**

**Do not exceed rated lift capacity. ◀**

W-2991

1. Extend the bucket cylinder completely and lower the boom to the ground.
2. Stop the engine and exit the excavator.

**Figure 192**




P200408a

3. For clevis lift eyes only, install the clevis (Item 2) through the lift eye (Item 1) [Figure 192].


Visually check the lift eye and secondary lifting system (chain and clevis) for any damage. Replace any damaged components before lifting. See your Bobcat dealer for replacement lift eye and clevis.

Figure 193



C135344a

Figure 194




P200407a

4. Install a lift chain (Item 1) (or other type of lifting device) through the lift eye (Item 2) [Figure 193] or clevis (Item 2) [Figure 194] and connect to the object being lifted.

Always use chains or other types of lifting devices that are intended for this type of use and that are of adequate strength for the object being lifted.

5. Enter the excavator, fasten the seat belt, and start the engine.  
(See Pre-Starting Procedure on Page 75)

Figure 195



C20829c

6. Press the overload warning device switch (Item 1) [Figure 195] on the left console to the left to activate the overload warning device.

Figure 196



P113708

7. Make sure the load is evenly weighted and centred on the lifting chain (or other type of lifting device), and is secured to prevent the load from shifting [Figure 196].
8. Operate the controls slowly and smoothly to avoid suddenly swinging the lifted load.
9. Lift and position the load.

- When the load is placed in a secured position and tension is removed from the lift chain, remove the chain from the load and from the lifting device.

## LIFT CAPACITY

### Lift Capacity Description



### WARNING

#### INSTABILITY AND CRUSHING HAZARD

Excessive load can cause tipping, loss of control or failure of the lift eye resulting in serious injury or death.

Do not exceed rated lift capacity. ◀

W-2991


The standard lift capacities listed on the lift capacity decal are calculated for a machine equipped with no attachment mounting system and no attachment.

To obtain the actual lift capacity, subtract the weights of any optional equipment on your machine, such as bucket, coupler, or hydraulic clamp.  
(See Calculating Lift Capacity on Page 107)

The weights for attachment mounting systems and hydraulic clamps can be found in documentation, including serial number plates. This manual also contains a list of weights.  
(See Attachment Mounting System And Clamp Weights on Page 108)

### Calculating Lift Capacity

Figure 197




- Find the standard lift capacity for your working conditions on your machine's lift capacity decal [Figure 197].

Working conditions include:

- Blade down (Item 1) [Figure 197]
- Blade Up (Item 2) [Figure 197]
- Boom Over Tracks (Item 3) [Figure 197]
- Lift Point Height (A) (Item 4) [Figure 197]
- Lift Radius (B) (Item 5) [Figure 197]
- Tracks Expanded / Retracted (not shown here)

Figure 198



C209385b

2. Find the weight of your attachment mounting system, which is printed on the plate as shown here (Item 1) [Figure 197].
3. Calculate the actual lift capacity for your conditions by subtracting the weights of optional equipment from the standard lift capacity on the decal.

**NOTE:** For bucket weights, see your Bobcat dealer. For attachment weights, see the attachment Operation & Maintenance Manual. For hydraulic clamp weights, (See Attachment Mounting System And Clamp Weights on Page 108)

**EXAMPLE:** Standard lift capacity on decal (1485 kg (3274 lb)) – Attachment Mounting System (30 kg (66 lb)) – Hydraulic Clamp and Cylinder (86 kg (190 lb)) – Bucket (117 kg (258 lb)) = 1252 kg (2760 lb)

**Attachment Mounting System And Clamp Weights**


Description	Weight
Hydraulic Clamp and Cylinder	
DX17z, E17, E17z	39 kg (85 lb)
E19, E20, E20z (Pin-On)	29 kg (64 lb)
E19, E20, E20z (Klac System)	81 kg (179 lb)
E32, E35	52 kg (114 lb)
E42, E50, E55, E60	97 kg (214 lb)
E50z, E55z, E60 (Europe)	95 kg (210 lb)
E88	166 kg (366 lb)
Pin-On X-Change	
E42, E50, E60	58 kg (128 lb)

**BOOM LOAD HOLDING VALVE**

**Location Of Boom Load Holding Valve**

The boom load holding valve (if equipped) will hold the boom in its current position in the event of hydraulic pressure loss.


Figure 199



P132112a

If the excavator is equipped with a boom load holding valve (Item 1) [Figure 199], it will be attached to the boom cylinder at the base end.

Figure 200



P132113a

**NOTE:** The cover (Item 2) [Figure 199] is removed for photo clarity in [Figure 200].

Do not remove or adjust the two valves (Item 1) [Figure 200]. If these valves have been tampered with, see your Bobcat dealer for service.

**⚠ WARNING**

**CRUSHING HAZARD**

Falling equipment can cause serious injury or death. **DO NOT** work or stand under raised work equipment or attachment. ◀


W-2763

**Lowering Boom With Load Holding Valve With Base End Hose Failure**

**NOTE:** If possible, first remove the load from the work group and support the boom before proceeding.

1. Place a container under the valve and base end hose to catch any hydraulic fluid that is leaking.

**Figure 201**



P132108a

2. Remove the plastic cap (Item 1) [Figure 201] from the valve.

**⚠ WARNING**


**BURN HAZARD**

Hydraulic fluid, tubes, fittings and quick couplers can get hot when running machine and attachments.

**Be careful when connecting and disconnecting quick couplers.** ◀

W-2220

**Figure 202**



P132109a

3. Loosen the locknut (Item 1) [Figure 202].
4. Install a hex wrench into the valve screw (Item 2) [Figure 202] and slowly rotate the screw clockwise 1/8 to 1/4 turn and allow the boom to lower to the ground.
5. After the boom is fully lowered, rotate the screw (Item 2) counterclockwise 1/8 to 1/4 turn and tighten the locknut (Item 1) [Figure 202].

**Lowering Boom With Load Holding Valve With Rod End Hose Failure – With Accumulator Pressure**

**NOTE:** If possible, first remove the load from the work group and support the boom before proceeding.


1. Place a container under the valve and hose end to catch any hydraulic fluid that is leaking.
2. Enter the excavator and turn the key on.  
Do not start the engine.
3. Lower the left console.
4. Slowly move the joystick boom lower function to lower the boom to the ground.

**Lowering Boom With Load Holding Valve With Rod End Hose Failure And No Accumulator Pressure Or Loss Of Hydraulic Pressure**

**NOTE:** If possible, first remove the load from the work group and support the boom before proceeding.

1. Place a container under the valve and rod end hose to catch any hydraulic fluid that is leaking.

Figure 203



C132113b


2. Remove the boom base end hose (Item 1) [Figure 203] from the boom load holding valve.
3. Loosen the locknut (Item 1) [Figure 202].
4. Install a hex wrench into the valve screw (Item 2) [Figure 202].
5. Slowly rotate the screw clockwise 1/8 to 1/4 turn and allow the boom to lower to the ground.
6. After the boom is fully lowered, rotate the screw (Item 2) [Figure 202] counterclockwise 1/8 to 1/4 turn and tighten the locknut (Item 1) [Figure 202].
7. Reinstall the base end hose.

## ARM LOAD HOLDING VALVE

### Location Of Arm Load Holding Valve

The arm load holding valve (if equipped) will hold the arm in its current position in the event of hydraulic pressure loss.


Figure 204



C206633a

If the excavator is equipped with an arm load holding valve (Item 1) [Figure 204], it will be attached to the arm cylinder base end as shown.

Figure 205



C206634a

Do not remove or adjust the two port relief valves (Item 1) [Figure 205]. If the port relief valves have been tampered with, see your Bobcat dealer for service.

## **⚠ WARNING**

### **CRUSHING HAZARD**

**Falling equipment can cause serious injury or death. DO NOT work or stand under raised work equipment or attachment. ◀**

W275

**Lowering Arm with Load Holding Valve With Base End Hose Failure**

1. Place a container under the valve and hose end to catch any hydraulic fluid that is leaking.


**⚠ WARNING**

**BURN HAZARD**

Hydraulic fluid, tubes, fittings and quick couplers can get hot when running machine and attachments. Be careful when connecting and disconnecting quick couplers. ◀

W-2220

Figure 206




2. Loosen the locknut (Item 1) [Figure 206].
3. Install a hex wrench into the valve screw (Item 2) [Figure 206].
4. Slowly rotate the screw clockwise 1/8 to 1/4 turn and allow the arm to lower.
5. After the arm is lowered, rotate the screw (Item 2) [Figure 206] counterclockwise the same 1/8 to 1/4 turn.
6. Tighten the locknut (Item 1) [Figure 206].

**Lowering Arm With Load Holding Valve With Rod End Hose Failure – With Accumulator Pressure**

1. Place a container under the valve and hose end to catch any hydraulic fluid that is leaking.
2. Enter the excavator and turn the key on.  
Do not start the engine.
3. Lower the left console.
4. Slowly move the joystick arm retract function to lower the arm.

**Lowering Arm With Rod End Hose Failure And No Accumulator Pressure Or Loss Of Hydraulic Pressure**

Figure 207



C206636

1. Remove the arm end hose (Item 1) [Figure 207] from the arm load holding valve.
2. Place a container under the valve and base end hose to catch any hydraulic fluid that is leaking.
3. Loosen the locknut (Item 1) [Figure 206].
4. Install a hex wrench into the valve screw (Item 2) [Figure 206].
5. Slowly rotate the screw clockwise 1/8 to 1/4 turn and allow the arm to lower.
6. After the arm is lowered, rotate the screw (Item 2) [Figure 206] counterclockwise 1/8 to 1/4 turn.
7. Tighten the locknut (Item 1) [Figure 206].
8. Reinstall the base end hose.

**DEPTH CHECK (STANDARD DISPLAY)**

**Depth Check Description**

**⚠ WARNING**

**INHALATION HAZARD**

Exhaust fumes contain odorless, invisible gases that can kill without warning. Fresh air must be added to avoid concentration of exhaust fumes when an engine is running in an enclosed area. If the engine is stationary, vent the exhaust outside. ◀

The Depth Check system provides audible and visual guidance to achieve and / or sustain a user-assigned depth target. Depth Check will display the vertical position of the bucket tip based on your initial starting point or bench point.

When the Depth Check kit was initially installed, the setup / calibration procedure should have been performed. But with usage of any attachment, the components and the cutting surfaces wear. The accuracy of the Depth Check system is affected by the wear of these components. If loss of accuracy is noticed, re-calibrate the attachment to reset the dimensions needed for the Depth Check system to operate correctly.

Two magnetic mounted tools are included with the kit for positioning the boom, arm, and bucket for calibration. These magnetic tools must be kept with the machine, as the Depth Check system should be re-calibrated on a yearly basis or sooner if slight changes in accuracy are noticed.

The Depth Check system sensors are designed for high angle stability and temperature ranges. However, with the use of any mechanical components (boom, arm, bucket, etc.), there is wear on the components and this will affect the accuracy of the Depth Check system over time. Also, if any structural changes are made, components replaced, or a new attachment is installed on the excavator, the setup / calibration procedure must be performed again.

The calibration procedure is a two-person task. One person must remain in the cab to enter data into the display while a second person takes measurements from outside the machine. Make sure the second person is away from the machine when moving any of the work group components (boom, arm, bucket, etc.).

See the correct section for the type of screen equipped on your machine.  
(See Depth Check (Standard Display) on Page 112)  
(See Depth Check (Touch Display) on Page 125)

**NOTE:** The machine shown in the photos may be different than your machine and this manual, but the procedure is the same for all models.

**⚠ WARNING**


**GENERAL HAZARD**

Contact with equipment can cause serious injury or death. Keep all bystanders 6 m (20 ft) away from equipment when operating. ◀

**Depth Check Screen**

Access the **DEPTH CHECK** screen by selecting **[NAVIGATION HANDLE] → [DEPTH CHECK]**.

**Figure 208**



NA3915b

REF.	DESC.	FUNCTION
1	Depth (Dimension)	The current depth of the attachment cutting edge.
2	Target (Dimension)	Depth to dig from an established starting point set by the operator. (Example: Desired dig depth from a surveyor's elevation pin.)
3	Difference (Dimension)	The difference between the current depth and the target depth.
4	Depth (Bar Graph)	Moves up and down to show the position of the attachment to the target.
5	Target (Bar Graph)	Shows where the target is in relationship to the attachment position.
6	Attachment Rotation	A bucket is used to represent the attachment. The bucket image will rotate to represent the position of the attachment as the attachment is curled out or curled in.
7	Attachment	Displays currently selected attachment.


REF.	DESC.	FUNCTION
8	Arrow	Used to move between depth check screens. (See Changing The Depth Check Screen on Page 113)
9	Alarm	Turns target depth alarm on / off. (See Setting The Warning Zone on Page 120)
10	Laser	Accesses <b>LASER SETUP</b> screen where you can add the laser position dimension or turn the laser on / off. When laser is on, the icon is illuminated. (See Setting Up A Laser With Depth Check on Page 123)
11	Depth Check Settings	Accesses <b>DEPTH CHECK SETTINGS</b> screen.
12	Rebench	Press to Rebench. (See Digging To A Target Depth on Page 121)
13	Set Target	Accesses <b>SET TARGET DEPTH</b> screen. (See Setting Target Depth on Page 119)
14	Set Attachment	Accesses <b>SET ATTACHMENT</b> screen.

**Changing The Depth Check Screen**


There are two **DEPTH CHECK** screens:

- Dig Depth [Figure 209]
- Distance to Target [Figure 210]

**Figure 209**



**Figure 210**



Press the arrow (Item 1) to toggle between these two screens at any time.

**Calibrating The Boom**

The following items are needed to complete this task:


- Tape measure.
- Two magnetic tools that are included with the kit.

The task is a two-person job. One person must remain in the cab to enter data into the display while a second person takes measurements from outside the machine.

**NOTE:** The owner password is needed to access the Setup and Calibration settings.

1. Move the machine to an open area where the boom and arm can be repositioned and there is fresh air, as you will need to operate the engine during this procedure.
2. Park the machine on a flat, level surface.


**Figure 211**



3. Position the excavator with the bucket fully rolled out and the arm fully extended [Figure 211].


- On the standard display select **[NAVIGATION HANDLE]** → **[DEPTH CHECK]**.

Figure 212




- Select the Settings icon (Item 1) [Figure 212].

Figure 213




- Select **[SETUP AND CALIBRATION]** (Item 1) [Figure 213].

Figure 214




- Select **[BOOM CALIBRATION]** (Item 1) [Figure 214].

Figure 215




- Install one of the magnetic tools (Item 1) on the boom pivot pin (Item 2) [Figure 215]. Position the magnetic tool as close as possible to the centre of the boom pivot pin.

Figure 216



- Install the second magnetic tool (Item 1) on the arm pivot pin (Item 2) [Figure 216]. Position the magnetic tool as close as possible to the centre of the arm pin.


Figure 217



C200403b

10. Position the work group so the distance from the ground to the two magnetic sensors (Items 1 and 2) [Figure 217] is identical.

Figure 218




P131857a

11. Measure the distance from the centre of the boom magnetic tool (Item 1) [Figure 218] to the ground.

Measure as close to the boom as possible without interference from components between the boom and the ground. The closer to the boom the measurement is taken, the more accurate the measurement should be. You can also use a laser level to locate the centerlines of the magnetic tools as this will eliminate any possible variation in the measurements to the ground.

Figure 219




P131858a

12. Measure the distance from the centre of the arm magnetic tool (Item 1) [Figure 219] to the ground.
13. Adjust the boom up or down as needed and remeasure until both distances are the same.

**NOTE:** Make sure there is no cylinder drift that could affect the calibration accuracy. The person in the cab needs to enter the information into the display in a timely manner.

Figure 220



NA3910

14. Follow the instructions on the screen and select **[DONE]** [Figure 220].
15. Proceed to calibrating the arm. (See Calibrating The Arm on Page 115)

### Calibrating The Arm

The following items are needed to complete this task:


- Plumb bob.
- Magnetic tool that is included with the kit.

The task is a two-person job. One person must remain in the cab to enter data into the display while a second person takes measurements from outside the machine.

**NOTE:** The owner password is needed to access the Setup and Calibration settings.


1. Select [NAVIGATION HANDLE] → [DEPTH CHECK] → [SETTINGS] → [SETUP AND CALIBRATION].

Figure 221



2. Select [ARM CALIBRATION] (Item 1) [Figure 221].


Figure 222



3. Select the arm that your machine is equipped with [Figure 222].


**NOTE:** Some models only have one arm option available.

Figure 223



4. Install the magnetic tool on the arm pin (Item 1) [Figure 223].
5. Place the plumb bob on the magnetic tool that is installed on the arm pin (Item 1) [Figure 223].


Figure 224



6. Move the arm until the plumb bob line (Item 1) is centred on the pivoting bucket pin (Item 2) [Figure 224].

The accuracy of the arm being vertical affects the accuracy of the Depth Check system.

Figure 225



7. With the arm vertical, select **[DONE]** (Item 1) [Figure 225] to store this information.
8. Proceed to calibrating the attachment. (See Calibrating The Attachment on Page 117)

### Calibrating The Attachment

The following items are needed to complete this task:


- Tape measure.
- Magnetic tool that is included with the kit.

The task is a two-person job. One person must remain in the cab to enter data into the display while a second person takes measurements from outside the machine.

**NOTE:** The owner password is needed to access the Setup and Calibration settings.


1. Select **[NAVIGATION HANDLE]** → **[DEPTH CHECK]** → **[SETTINGS]** → **[SETUP AND CALIBRATION]**.

Figure 226




2. Select **[ATTACHMENTS]** (Item 1) [Figure 226].

Figure 227



3. Select one of the attachments [Figure 227].


Figure 228



4. On the **ATTACHMENT CALIBRATION** screen, select **[NAME]** (Item 1) [Figure 228].


**NOTE:** A bucket is used as an example here, but this setup is similar for all attachments. The accuracy of these dimensions affects the accuracy of the Depth Check.

Figure 229




5. Select type of attachment [Figure 229].

Figure 230




6. Enter a number to identify your attachment and select the enter icon [Figure 230].

Figure 231



7. Select [INNER LENGTH] (Item 1) [Figure 231].

Figure 232



8. Measure the distance from the tip of the attachment (Item 1) to the centre of the inner pin (Item 2) [Figure 232] and enter this value.

Choose the correct pin (Item 2) [Figure 232] based on the type of attachment mounting system on your machine.


9. Select [OUTER LENGTH] (Item 2) [Figure 231].

**NOTE:** The cutting surfaces of any attachments will wear over time. For example, the cutting edge (tooth) wears with the use of the bucket. The accuracy of the Depth Check system is affected by the wear of these components. If you notice any loss in accuracy, recalibrate the Depth Check system to reset the attachment dimensions.

10. Measure the distance from the tip of the attachment (Item 1) to the centre of the outer pin (Item 3) [Figure 232] and enter this value.


Choose the correct pin (Item 3) [Figure 232] based on the type of attachment mounting system on your machine.

Figure 233




- If you are using a non-standard bucket or attachment and want the display to more accurately reflect its rotation, select **[ATTACHMENT ANGLE SETUP]** (Item 1) [Figure 233].

Figure 234



- Follow the instructions on the screen [Figure 234] and select **[DONE]**.

Figure 235



- Select **[CALIBRATE]** (Item 1) [Figure 235].

Figure 236



- Follow the instructions on the screen [Figure 236] and select **[DONE]**.

Use the plumb bob and pin extender to vertically align the inner pin (Item 2) and the attachment tip (Item 1) [Figure 232].

The Depth Check system will not be as accurate with augers as with solid mounted attachments because all components are not rigidly mounted. The auger bit has extra movement and rotation, but the Depth Check system is designed for fixed positions. Follow these tips:

- Enter zero for both attachment dimensions.
- Try to keep the attachment mounting system horizontal to the ground during the dig cycle and monitor the screen depth.


If more than one attachment is being set up, the attachments can be changed on the arm and the additional attachment dimensions can also be entered. Always measure to the cutting / work tip on the attachment when measuring the dimensions to add to the inside and outside length screens for each new attachment. The Depth Check system uses these dimensions along with the other setup points to calculate the tip position for Depth Check.

This finishes the calibration procedure, except if you are also installing a laser. (See Setting Up A Laser With Depth Check on Page 123)

### Setting Target Depth


Several different target depths can be pre-set and stored in the system.

Figure 237




- To select one of the preset target depths, select **[NAVIGATION HANDLE]** → **[DEPTH CHECK]** → **[SET TARGET]** and select a Target [Figure 237].
- To change a preset target depth, select **[NAVIGATION HANDLE]** → **[DEPTH CHECK]** → **[SETTINGS]**.

Figure 238



3. Select **[EDIT DEPTH TARGETS]** (Item 1) [Figure 238].


Figure 239



4. Select one of the Targets [Figure 239] and enter the new target depth on the keypad.

Description Of Grade And Warning Zones

Figure 240



The following three values can be set on the display:

ITEM	DESCRIPTION
1	Target Depth
2	Warning Zone
3	Grade Zone

After you set the target depth, warning zone, and grade zone, you will hear the following audible signals when the attachment is at each depth:

ITEM	DESCRIPTION
A	Operator hears slow beeps.
B	Operator hears solid beep.
C	Operator hears fast beeps.


**EXAMPLE:** Operator sets Target Depth to 610 mm (24 in), Warning Zone to 100 mm (4 in), and Grade Zone to 50 mm (2 in). Operator will hear slow beeps from 508 – 584 mm (20 – 23 in), a solid beep from 584 – 635 mm (23 – 25 in), and fast beeps below 635 mm (25 in).

Setting The Warning Zone

The Warning Zone is the upper distance from the target depth when the warning alarm will start to beep. The closer the attachment gets to the target, the faster the beeps will be. When the attachment reaches the target depth, the alarm will be a continuous sound. If the attachment goes below the target depth, the beeps will be very fast.

1. Select **[NAVIGATION HANDLE]** → **[DEPTH CHECK]** → **[SETTINGS]** → **[PREFERENCES]**.

Figure 241



2. Select **[SET WARNING ZONE]** (Item 1) [Figure 241] and enter the dimension.
3. Select the **[ENTER]** icon to save your changes.


**Setting The Grade Zone**

The Grade Zone is the distance above and below the target depth at which the alarm will be a continuous beep.

**EXAMPLE:** If the grade zone is 200 mm (8 in), it will start 100 mm (4 in) above the target depth and end 100 mm (4 in) below the target depth.

1. Select **[NAVIGATION HANDLE]** → **[DEPTH CHECK]** → **[SETTINGS]** → **[PREFERENCES]**.

Figure 242



2. Select **[SET GRADE ZONE]** (Item 1) [Figure 242] and enter the dimension.
3. Select the **[ENTER]** icon to save your changes.

**Digging To A Target Depth**




**EXPLOSION AND ELECTROCUTION HAZARDS**  
Contact with underground utility lines will cause death, serious injury, or property damage.

- Check the work area for buried electrical, gas, utility, or other service lines before excavating or operating ground engaging equipment.
- Follow all local rules and regulations regarding digging or working in areas around underground utilities. Have all underground utility lines clearly marked before operating.
- DO NOT depend on the Depth Check system for digging close to known utilities. The system accuracy is dependent upon calibration, slope of the ground, and other variables.
- Reported utility locations, such as the depth of the line, can also vary due to soil erosion, grading, and other factors. ◀


**NOTE:** If you are not digging with a laser, make sure the laser icon is not illuminated on the **DEPTH CHECK** screen.

Figure 243




1. Set the bucket (Item 1) [Figure 243] on the ground surface where you are going to start the dig or on the surveyor mark to establish the starting ground position.
2. Select **[NAVIGATION HANDLE]** → **[DEPTH CHECK]**.

Figure 244



3. Select **[REBENCH]** (Item 1) [Figure 244] on the display.  
OR  
Press the right joystick button to rebench.  
At rebench, the depth dimension (Item 2) will set to 0.0. As the bucket is raised or lowered, the depth dimension (Item 2) will change [Figure 244].
4. Select **[SET TARGET]** (Item 3) [Figure 244] to select one of the preset depth targets.  
OR  
Select the **[SETTINGS]** icon (Item 4) [Figure 244] to change one of the preset depth targets.  
(See Setting Target Depth on Page 119)

Figure 245



- As the hole is being dug, the position of the bucket (Item 1) [Figure 245] is dimensionally shown (Item 2) [Figure 244] and shown on the bar graph at (Item 5) [Figure 244].
- The distance to target depth is shown dimensionally (Item 6) and on the bar graph (Item 7) [Figure 244].

- When the bucket is getting close to the target depth (Item 8) [Figure 244], a warning alarm (if activated) will start to slowly beep. The beeps will increase in frequency the closer the bucket gets to the target depth or grade zone. When the target depth or grade zone is reached, the alarm will sound continuously. (See Setting The Warning Zone on Page 120) (See Setting The Grade Zone on Page 121)


**EXAMPLE:** The Target is 2 m (6.5 ft) and the Depth is 1,5 m (4.9 ft), the Difference will be 0,5 m (1.6 ft).

$$2 \text{ m} - 1,5 \text{ m} = 0,5 \text{ m} \quad (6.5 \text{ ft} - 4.9 \text{ ft} = 1.6 \text{ ft}).$$

**Repositioning The Excavator And Continuing To Dig To The Original Depth**

After repositioning the excavator, choose one of the following options to continue to dig to the original depth.

Figure 246




- Reposition the excavator so the bucket can be rebench off the original bench point (Item 1) [Figure 246].
- Position the excavator so the bucket will reach to the bottom of the hole (Item 2) [Figure 246] at an area that is known to be the correct depth. When rebenching at the bottom of the trench, set the target depth to zero to continue digging at the original depth.

**NOTE:** Set the distance from the target depth to the point at which the alarm starts to beep on the **WARNING ZONE** screen.

**Setting Up A Laser With Depth Check**


**Figure 247**



P132078b

1. Install the laser receiver (Item 1) as close as possible in line with the arm pin (Item 2) and the bucket pivot pin (Item 3) [Figure 247].


**Figure 248**



C204959b

2. If your machine is equipped with options that make it difficult to install the laser receiver in the centre of the arm, install it in an alternative location such as shown here (Item 1) [Figure 248].
3. If your excavator is equipped with a clamp or arm that may interfere with the laser, make sure there is no hose-to-laser interference.
  - a. Fully curl the arm and bucket and make sure the hoses do not interfere with the laser receiver during any arm or bucket movement.
  - b. Adjust the position of the laser receiver if necessary to avoid any contact with the hoses.
4. Select **[NAVIGATION HANDLE]** → **[DEPTH CHECK]** → **[SETTINGS]** → **[LASER SETUP]**.


**Figure 249**



NA3912a

5. Select **[SET LASER DISTANCE]** (Item 1) [Figure 249].
6. Measure from the centre of the laser receiver to the bucket pivot pin (Item 1) [Figure 250]

Figure 250



p132079d

7. Enter this distance as the Laser Distance.

To dig a hole using the laser, see the following:  
(See Benching With A Laser System on Page 124)


**Benching With A Laser System**

Read and understand the information supplied with the laser receiver for correctly setting up the laser system.

**When the laser feature is turned on, the target depth is the distance from the laser beam to grade point. Grade must be known prior to benching with a laser system. See (Item 3) [Figure 252].**

1. Make sure the laser receiver location on the arm has been entered into the Depth Check system.  
(See Setting Up A Laser With Depth Check on Page 123)
2. Select **[NAVIGATION HANDLE]** → **[DEPTH CHECK]** → **[SETTINGS]** → **[LASER SETUP]**.


Figure 251



NA3912b

3. Select **[ENABLE LASER]** (Item 1) [Figure 251].

Figure 252



P200245a

4. With the excavator arm vertical, raise or lower the boom and arm as needed until the laser (Item 1) strikes the receiver (Item 2) [Figure 252].


If necessary, curl the bucket fully for increased bucket ground clearance, or dig a hole so that the bucket can be lowered to allow the laser to strike the receiver with the arm vertical.

5. When the laser strikes the receiver and the receiver light turns green, select **[REBENCH]**.

OR

Rebench by pressing the right joystick button.

Figure 253



If the arm is not vertical when you try to rebench, the **ARM ALIGNMENT** screen [Figure 253] will remind you to make the arm vertical before rebenching is possible. Adjust the arm to the vertical position and select **[REBENCH]** [Figure 253].

6. Select **[SET TARGET]**.
7. Enter the distance from the laser to the target depth (Item 3) [Figure 252].
8. Adjust the Warning Zone and Grade Zone as needed. (See Setting The Grade Zone on Page 121) (See Setting The Warning Zone on Page 120)
9. Proceed to dig, referencing the display and listening for audible alerts to maintain the correct depth.

## DEPTH CHECK (TOUCH DISPLAY)

### Depth Check Description

#### **⚠ WARNING**

#### **INHALATION HAZARD**

Exhaust fumes contain odorless, invisible gases that can kill without warning.

Fresh air must be added to avoid concentration of exhaust fumes when an engine is running in an enclosed area. If the engine is stationary, vent the exhaust outside. ◀

W-2050

The Depth Check system provides audible and visual guidance to achieve and / or sustain a user-assigned depth target. Depth Check will display the vertical position of the bucket tip based on your initial starting point or bench point.

When the Depth Check kit was initially installed, the setup / calibration procedure should have been performed. But with usage of any attachment, the components and the cutting surfaces wear. The accuracy of the Depth Check system is affected by the wear of these components. If loss of accuracy is noticed, re-calibrate the attachment to reset the dimensions needed for the Depth Check system to operate correctly.

Two magnetic mounted tools are included with the kit for positioning the boom, arm, and bucket for calibration. These magnetic tools must be kept with the machine, as the Depth Check system should be re-calibrated on a yearly basis or sooner if slight changes in accuracy are noticed.

The Depth Check system sensors are designed for high angle stability and temperature ranges. However, with the use of any mechanical components (boom, arm, bucket, etc.), there is wear on the components and this will affect the accuracy of the Depth Check system over time. Also, if any structural changes are made, components replaced, or a new attachment is installed on the excavator, the setup / calibration procedure must be performed again.

The calibration procedure is a two-person task. One person must remain in the cab to enter data into the display while a second person takes measurements from outside the machine. Make sure the second person is away from the machine when moving any of the work group components (boom, arm, bucket, etc.).

See the correct section for the type of screen equipped on your machine.

(See Depth Check (Standard Display) on Page 112)  
(See Depth Check (Touch Display) on Page 125)

**NOTE:** The machine shown in the photos may be different than your machine and this manual, but the procedure is the same for all models.

**⚠ WARNING**


**GENERAL HAZARD**

Contact with equipment can cause serious injury or death.  
Keep all bystanders 6 m (20 ft) away from equipment when operating.

**Depth Check Screen**

Access the **DEPTH CHECK** screen by selecting **[ATTACHMENTS]**→ **[DEPTH CHECK]**.

**Figure 254**



P132925c

REF.	DESC.	FUNCTION
1	Target (Dimension)	Depth to dig from an established starting point set by the operator. (Example: Desired dig depth from a surveyor's elevation pin.)
2	Target (Bar Graph)	Shows where the target is in relationship to the attachment position.
3	Depth (Dimension)	The current depth of the attachment cutting edge.
4	Depth (Bar Graph)	Moves up and down to show the position of the attachment to the target.
5	Difference (Dimension)	The difference between the current depth and the target depth.
6	Units	The current selected unit of measure (meters / millimeters or feet / inches).
7	Attachment Rotation	A bucket is used to represent the attachment. The bucket image will rotate to represent the position of the attachment as the attachment is curled out or curled in.


REF.	DESC.	FUNCTION
8	Laser	Accesses <b>LASER SETUP</b> screen where you can add the laser position dimension or turn the laser on / off. When laser is on, the icon is illuminated. (See Setting Up A Laser With Depth Check on Page 137)
9	Depth Check Settings	Accesses <b>DEPTH CHECK SETTINGS</b> screen.
10	Tips	Accesses <b>TOOL TIPS</b> screen.
11	Rebench	Press to Rebench. (See Digging To A Target Depth on Page 135)
12	Set Target	Accesses <b>SET TARGET DEPTH</b> screen. (See Setting Target Depth on Page 133)
13	Alarm	Turns target depth alarm on / off. (See Setting The Warning Zone on Page 134)
14	Screen Indicator	Dots indicate which of the three screens is being displayed.
15	Arrow	Used to move between screens. You can also swipe between screens with your finger. (See Setting The Default Depth Check Screen on Page 126)

**Setting The Default Depth Check Screen**

The **DEPTH CHECK** screen can be set to default to one of the following screens:

- Dig Depth [Figure 255]
- Distance to Target [Figure 256]
- Grade Check [Figure 257]

Figure 255




P132925b

Figure 256



NA3432b

Figure 257



NA3431b

1. To select one of the three depth check screens as the default screen, select **[ATTACHMENTS]**→**[DEPTH CHECK]**→**[SETTINGS]**→**[PREFERENCES]**→**[DEFAULT SCREEN]**.

Press the arrow (Item 1) to toggle between these three screens at any time. The three dots (Item 2) change to represent which **DEPTH CHECK** screen is active: [Figure 255], [Figure 256], or [Figure 257].

### Switching Unit Scale

1. Select **[ATTACHMENTS]**→**[DEPTH CHECK]**→**[SETTINGS]**→**[PREFERENCES]**.

Figure 258



P132911a

2. Select **[UNITS]** (Item 1) to switch between meters / millimeters or feet / inches (Item 2) [Figure 258].

You can also switch between metric and English units. (See Switching Between English / Metric Units on Page 214)

### Calibrating The Boom


The following items are needed to complete this task:

- Tape measure.
- Two magnetic tools that are included with the kit.

The task is a two-person job. One person must remain in the cab to enter data into the display while a second person takes measurements from outside the machine.

1. Move the machine to an open area where the boom and arm can be repositioned and there is fresh air, as you will need to operate the engine during this procedure.
2. Park the machine on a flat, level surface.


Figure 259



C200403a

3. Position the excavator with the bucket fully rolled out and the arm fully extended [Figure 259].
4. On the touch display select **[ATTACHMENTS]** → **[DEPTH CHECK]**.


Figure 260



NA3429b

5. Select the **[SETTINGS]** icon (Item 1) [Figure 260].

Figure 261



C132910d

6. Select **[SETUP AND CALIBRATION]** (Item 1) [Figure 261].


Figure 262



P132909a

7. Read the message on the screen and press **[CONTINUE]** (Item 1) [Figure 262] to proceed.


Figure 263



P132909b

8. Select **[BOOM CALIBRATION]** (Item 1) [Figure 263].


Figure 264



P131855a

9. Install one of the magnetic tools (Item 1) on the boom pivot pin (Item 2) [Figure 264]. Position the magnetic tool as close as possible to the center of the boom pivot pin.


Figure 265



P131856a

10. Install the second magnetic tool (Item 1) on the arm pivot pin (Item 2) [Figure 265]. Position the magnetic tool as close as possible to the center of the arm pin.


Figure 266



C200403b

11. Position the work group so the distance from the ground to the two magnetic tools (Items 1 and 2) [Figure 266] is identical.

Figure 267




P131857a

12. Measure the distance from the center of the boom magnetic tool (Item 1) [Figure 267] to the ground.

Measure as close to the boom as possible without interference from components between the boom and the ground. The closer to the boom the measurement is taken, the more accurate the measurement should be. You can also use a laser level to locate the centerlines of the magnetic tools as this will eliminate any possible variation in the measurements to the ground.

Figure 268




P131856a

13. Measure the distance from the center of the arm magnetic tool (Item 1) [Figure 268] to the ground.
14. Adjust the boom up or down as needed and remeasure until both distances are the same.

**NOTE:** Make sure there is no cylinder drift that could affect the calibration accuracy. The person in the cab needs to enter the information into the display in a timely manner.

Figure 269



15. Follow the instructions on the screen and select **[DONE]** (Item 1) [Figure 269].
16. Proceed to calibrating the arm.  
(See Calibrating The Arm on Page 130)

**Calibrating The Arm**

The following items are needed to complete this task:


- Plumb bob.
- Magnetic tool that is included with the kit.

The task is a two-person job. One person must remain in the cab to enter data into the display while a second person takes measurements from outside the machine.

**NOTE:** The owner password is needed to access the Setup and Calibration settings.

1. Select **[ATTACHMENTS]** → **[DEPTH CHECK]** → **[SETTINGS]** → **[SETUP AND CALIBRATION]**.

Figure 270



2. Select **[ARM CALIBRATION]** (Item 1) [Figure 270].


Figure 271



3. Select the arm that your machine is equipped with (Item 1 or 2) [Figure 271].


**NOTE:** Some models only have one arm option available.

Figure 272



4. Install the magnetic tool on the arm pin (Item 1) [Figure 272].
5. Place the plumb bob on the magnetic tool that is installed on the arm pin (Item 1) [Figure 272].

Figure 273



6. Move the arm until the plumb bob line (Item 1) is centered on the pivoting bucket pin (Item 2) [Figure 273].

The accuracy of the arm being vertical affects the accuracy of the Depth Check.

Figure 274



7. With the arm vertical, select **[DONE]** (Item 1) [Figure 274] to store this information.

8. Proceed to calibrating the attachment.  
(See Calibrating The Attachment on Page 131)

**Calibrating The Attachment**

The following items are needed to complete this task:

- Tape measure.
- Magnetic tool that is included with the kit.

The task is a two-person job. One person must remain in the cab to enter data into the display while a second person takes measurements from outside the machine.

**NOTE:** The owner password is needed to access the Setup and Calibration settings.

1. Select **[ATTACHMENTS]**→ **[DEPTH CHECK]**→ **[SETTINGS]**→ **[SETUP AND CALIBRATION]**.

Figure 275



2. Select **[ATTACHMENTS]** (Item 1) [Figure 275].


Figure 276



3. Select **[ADD ATTACHMENT]** (Item 1) [Figure 276].  
OR  
Select one of the existing attachments (Item 2) [Figure 276] from the list.

**NOTE:** When switching between attachments, just select the desired attachment and, as long as it was correctly set up, the Depth Check system will have the information needed for that attachment.

Figure 277




4. On the **CALIBRATION** screen, select **[ENTER A NAME]** (Item 1) [Figure 277].

Enter a name for the attachment such as 24" Bucket, 30" Bucket, Auger, etc.

**NOTE:** A bucket is used as an example here, but this setup is similar for all attachments. The accuracy of these dimensions affects the accuracy of the Depth Check.

5. Select **[ENTER A LENGTH]** (Item 2) [Figure 277] for the Attachment Inner Length.

Figure 278



6. Measure the distance from the tip of the attachment (Item 1) to the center of the inner pin (Item 2) [Figure 278] and enter this value.

Choose the correct pin (Item 2) [Figure 278] based on the type of attachment mounting system on your machine.


7. Select **[ENTER A LENGTH]** (Item 3) [Figure 277] for the Attachment Outer Length.

**NOTE:** The cutting surfaces of any attachments will wear over time. For example, the cutting edge (tooth) wears with the use of the bucket. The accuracy of the Depth Check system is affected by the wear of these components. If you notice any loss in accuracy, recalibrate the Depth Check system to reset the attachment dimensions.

8. Measure the distance from the tip of the attachment (Item 1) to the center of the outer pin (Item 3) [Figure 278] and enter this value.

Choose the correct pin (Item 3) [Figure 278] based on the type of attachment mounting system on your machine.

Figure 279



9. If you are using a non-standard bucket or attachment and want the display to more accurately reflect its rotation, select **[ATTACHMENT ANGLE SETUP]** (Item 1) [Figure 279].

Figure 280



- Follow the instructions on the screen [Figure 280] and select **[DONE]**.

**Figure 281**



- Follow the instructions on the screen to align the attachment for sensor calibration.

Use the plumb bob and pin extender to vertically align the inner pin (Item 2) and the attachment tip (Item 1) [Figure 278].

- Select **[DONE]** (Item 1) [Figure 281] to store the calibration information.

The Depth Check system will not be as accurate with augers as with solid mounted attachments because all components are not rigidly mounted. The auger bit has extra movement and rotation, but the Depth Check system is designed for fixed positions. Follow these tips:

- Enter zero for both attachment dimensions.
- Try to keep the attachment mounting system horizontal to the ground during the dig cycle and monitor the screen depth.

If more than one attachment is being set up, the attachments can be changed on the arm and the additional attachment dimensions can also be entered. Always measure to the cutting / work tip on the attachment when measuring the dimensions to add to the inside and outside length screens for each new attachment. The Depth Check system uses these dimensions along with the other setup points to calculate the tip position for Depth Check.


This finishes the calibration procedure, except if you are also installing a laser.  
(See Setting Up A Laser With Depth Check on Page 137)

**Setting Target Depth**

**NOTE:** Twenty different target depths can be pre-set and stored in the system.

- Select **[ATTACHMENTS]** → **[DEPTH CHECK]**.

**Figure 282**




- Select **[SET TARGET]** (Item 1) [Figure 282].

**Figure 283**



- Select one of the existing target depths.  
OR  
Select **[ADD TARGET]** (Item 2) [Figure 283] to add a new target depth.  
  
A check mark will appear (Item 1) [Figure 283] by the selected target depth.


**Figure 284**



4. To remove an existing target depth, select **[EDIT]** (Item 3) [Figure 283].
  - a. Select the **[REMOVE]** icon (Item 1) [Figure 284] in front of a target depth to remove it.  
The active target depth can not be removed.
  - b. Select **[SAVE]** (Item 2) [Figure 284] to confirm removal.

**Description Of Grade And Warning Zones**

**Figure 285**



The following three values can be set on the display:

ITEM	DESCRIPTION
1	Target Depth
2	Warning Zone
3	Grade Zone

After you set the target depth, warning zone, and grade zone, you will hear the following audible signals when the attachment is at each depth:

ITEM	DESCRIPTION
A	Operator hears slow beeps.
B	Operator hears solid beep.
C	Operator hears fast beeps.


**EXAMPLE:** Operator sets Target Depth to 610 mm (24 in), Warning Zone to 100 mm (4 in), and Grade Zone to 50 mm (2 in). Operator will hear slow beeps from 508 – 584 mm (20 – 23 in), a solid beep from 584 – 635 mm (23 – 25 in), and fast beeps below 635 mm (25 in).

**Setting The Warning Zone**

The Warning Zone is the upper distance from the target depth when the warning alarm will start to beep. The closer the attachment gets to the target, the faster the beeps will be. When the attachment reaches the target depth, the alarm will be a continuous sound. If the attachment goes below the target depth, the beeps will be very fast.

1. Select **[ATTACHMENTS]** → **[DEPTH CHECK]** → **[SETTINGS]** → **[PREFERENCES]**.

**Figure 286**



2. Select **[SET WARNING ZONE]** (Item 1) [Figure 286] and enter the dimension.
3. Select **[ENTER]** to save your changes.


**Setting The Grade Zone**

The Grade Zone is the distance above and below the target depth at which the alarm will be a continuous beep.

**EXAMPLE:** If the grade zone is 200 mm (8 in), it will start 100 mm (4 in) above the target depth and end 100 mm (4 in) below the target depth.

1. Select **[ATTACHMENTS]** → **[DEPTH CHECK]** → **[SETTINGS]** → **[PREFERENCES]**.

Figure 287



2. Select **[SET GRADE ZONE]** (Item 1) [Figure 287] and enter the dimension.
3. Select **[ENTER]** to save your changes.

### Digging To A Target Depth


#### **⚠ DANGER**

**EXPLOSION AND ELECTROCUTION HAZARDS**  
Contact with underground utility lines will cause death, serious injury, or property damage.

- Check the work area for buried electrical, gas, utility, or other service lines before excavating or operating ground engaging equipment.
- Follow all local rules and regulations regarding digging or working in areas around underground utilities. Have all underground utility lines clearly marked before operating.
- **DO NOT** depend on the Depth Check system for digging close to known utilities. The system accuracy is dependent upon calibration, slope of the ground, and other variables.
- Reported utility locations, such as the depth of the line, can also vary due to soil erosion, grading, and other factors. ◀


**NOTE:** If you are not digging with a laser, make sure the laser icon is not illuminated on the **DEPTH CHECK** screen.

Figure 288




1. Set the bucket (Item 1) [Figure 288] on the ground surface where you are going to start the dig or on the surveyor mark to establish the starting ground position.
2. Select **[ATTACHMENTS]** → **[DEPTH CHECK]**.

Figure 289



3. Select **[REBENCH]** (Item 1) [Figure 289] on the display.  
OR  
Press the right joystick button to rebench.  
At rebench, the depth dimension (Item 2) will set to 0.0. As the bucket is raised or lowered, the depth dimension (Item 2) will change [Figure 289].
4. Select **[SET TARGET]** (Item 3) [Figure 289] to set the new depth target.

Figure 290



NA1437d

- As the hole is being dug, the position of the bucket (Item 1) [Figure 290] is dimensionally shown (Item 2) [Figure 289] and shown on the bar graph (Item 4) [Figure 289].
- The distance to target depth is shown dimensionally (Item 5) and on the bar graph (Item 6) [Figure 289].
- When the bucket is getting close to the target depth (Item 7) [Figure 289], a warning alarm (if activated) will start to slowly beep. The beeps will increase in frequency the closer the bucket gets to the target depth or grade zone. When the target depth or grade zone is reached, the alarm will sound continuously. (See Setting The Warning Zone on Page 134) (See Setting The Grade Zone on Page 134)


**EXAMPLE:** The Target is 2 m (6.5 ft) and the Depth is 1,5 m (4.9 ft), the Difference will be 0,5 m (1.6 ft).

$$2\text{ m} - 1,5\text{ m} = 0,5\text{ m} \quad (6.5\text{ ft} - 4.9\text{ ft} = 1.6\text{ ft}).$$

**Repositioning The Excavator And Continuing To Dig To The Original Depth**

After repositioning the excavator, choose one of the following options to continue to dig to the original depth.

Figure 291



P200242b


- Reposition the excavator so the bucket can be rebenched off the original bench point (Item 1) [Figure 291].
- Position the excavator so the bucket will reach to the bottom of the hole (Item 2) [Figure 291] at an area that is known to be the correct depth. When rebenching at the bottom of the trench, set the target depth to zero to continue digging at the original depth.

**NOTE:** Set the distance from the target depth to the point at which the alarm starts to beep on the **WARNING ZONE** screen.

**Digging To A Target Depth And Width**

Follow the same procedure as for digging a hole to a target depth except as follows. (See Digging To A Target Depth on Page 135)

Figure 292




P200241a

1. When rebenching the bucket for setting to 0.0, position the bucket (Item 1) [Figure 292] at the starting point of the side of the hole.

This gives the Depth Check system the starting position of the hole.

Figure 293



2. Press the **[ARROW]** icon (Item 1) [Figure 293] to scroll to the **GRADE CHECK** screen [Figure 293].

On this example screen, Zero (Item 2) is the rebench starting point, 36.0 in (Item 3) is the target depth, and 78.0 in (Item 4) is the reach (the width of the hole) [Figure 293].

The warning alarm (if activated) will start to beep when you are getting close to the target depth, will progressively beep faster until the target depth is reached, and then will sound continuously.

The alarm only activates for the depth, not for the reach (width of hole). For this, monitor the reach dimension on the screen (Item 4) [Figure 293].

## **⚠ DANGER**


**EXPLOSION AND ELECTROCUTION HAZARDS**  
Contact with underground utility lines will cause death, serious injury, or property damage.

- Check the work area for buried electrical, gas, utility, or other service lines before excavating or operating ground engaging equipment.
- Follow all local rules and regulations regarding digging or working in areas around underground utilities. Have all underground utility lines clearly marked before operating.
- **DO NOT** depend on the Depth Check system for digging close to known utilities. The system accuracy is dependent upon calibration, slope of the ground, and other variables.
- Reported utility locations, such as the depth of the line, can also vary due to soil erosion, grading, and other factors. ◀

1222-78F-D3B03

## Setting Up A Laser With Depth Check


Figure 294



P152078b

1. Install the laser receiver (Item 1) as close as possible in line with the arm pin (Item 2) and the bucket pivot pin (Item 3) [Figure 294].


Figure 295



C204995b


2. If your machine is equipped with options that make it difficult to install the laser receiver in the center of the arm, install it in an alternative location such as shown here (Item 1) [Figure 295].
3. If your excavator is equipped with a clamp or arm that may interfere with the laser, make sure there is no hose-to-laser interference.
  - a. Fully curl the arm and bucket and make sure the hoses do not interfere with the laser receiver during any arm or bucket movement.
  - b. Adjust the position of the laser receiver if necessary to avoid any contact with the hoses.
4. Select **[ATTACHMENTS]** → **[DEPTH CHECK]** → **[SETTINGS]** → **[LASER SETUP]**.

Figure 296



5. Select **[SET LASER DISTANCE]** (Item 1) [Figure 296].
6. Measure from the center of the laser receiver to the bucket pivot pin (Item 1) [Figure 297].

Figure 297



7. Enter this distance as the Laser Distance.

To dig a hole using the laser, see the following:  
(See *Benching With A Laser System* on Page 138)


### Benching With A Laser System

Read and understand the information supplied with the laser receiver for correctly setting up the laser system.

**When the laser feature is turned on, the target depth is the distance from the laser beam to grade point. Grade must be known prior to benching with a laser system. See (Item 3) [Figure 299].**


1. Make sure the laser receiver location on the arm has been entered into the Depth Check system.  
(See *Setting Up A Laser With Depth Check* on Page 137)
2. Select **[ATTACHMENTS]** → **[DEPTH CHECK]** → **[SETTINGS]** → **[LASER SETUP]**.

Figure 298



3. Enable the laser by moving the slider (Item 1) [Figure 298].

Figure 299



4. With the excavator arm vertical, raise or lower the boom and arm as needed until the laser (Item 1) strikes the receiver (Item 2) [Figure 299].

If necessary, curl the bucket fully for increased bucket ground clearance, or dig a hole so that the bucket can be lowered to allow the laser to strike the receiver with the arm vertical.

5. When the laser strikes the receiver and the receiver light turns green, select **[REBENCH]**.

OR

Rebench by pressing the right joystick button.

Figure 300



If the arm is not vertical when you try to rebench, the **ARM ALIGNMENT** screen [Figure 300] will remind you to align the arm vertically before rebenching. Adjust the arm and select **[REBENCH]**.

6. Select **[SET TARGET]**.
7. Enter the distance from the laser to the target depth (Item 3) [Figure 299].
8. Adjust the Warning Zone and Grade Zone as needed. (See Setting The Grade Zone on Page 134) (See Setting The Warning Zone on Page 134)
9. Proceed to dig, referencing the display and listening for audible alerts to maintain the correct depth.

**TROUBLESHOOTING THE DEPTH CHECK SYSTEM**

Depth Check system measures inaccurately, shows the incorrect depth on the display, or gives an error code.

Cause(s)	Solution(s)
Improper calibration of boom, arm, or attachment.	Recalibrate boom, arm, and attachment. (See Depth Check (Standard Display) on Page 112) (See Depth Check (Touch Display) on Page 125)
One or more sensors are not working correctly.	Determine which sensor is not working correctly and replace. (See Checking The Bucket Sensor on Page 140) (See Checking The Arm Sensor on Page 141) (See Checking The Boom Sensor on Page 141)
Attachment was measured incorrectly.	Remeasure attachment and input new values.  For standard display (See Calibrating The Attachment on Page 117)  For touch display (See Calibrating The Attachment on Page 131)
Laser feature is activated but laser isn't being used.	Turn laser off.  For standard display (See Benching With A Laser System on Page 124)  For touch display (See Benching With A Laser System on Page 138)

Cause(s)	Solution(s)
Laser feature isn't activated, but a laser is being used to Rebench.	Turn laser feature on.  For standard display (See Benching With A Laser System on Page 124)  For touch display (See Benching With A Laser System on Page 138)
Rebenching isn't working correctly.	If you are not using a laser, make sure the laser feature is turned off.  If you are using a laser, make sure the laser feature is turned on and you are benching off the laser beam, not the ground.


**Checking The Bucket Sensor**

The following item is required for this task:

- Tape measure.

The task is a two-person job. One person must remain in the cab to enter data into the display while a second person takes measurements from outside the machine.


**Figure 301**



C209270

1. Place the bucket teeth on the ground with the teeth at the lowest point in the bucket movement arc [Figure 301].
2. Select **[REBENCH]**.

Figure 302



3. Move only the bucket up to nearly the fully curled position [Figure 302].  
Do not move the boom or arm.
4. Measure how high the bucket teeth are off the ground [Figure 302].
5. Compare the measurement to the Depth value on the display.

If the display isn't showing the correct Depth, contact your Bobcat dealer.

#### Checking The Arm Sensor


The following item is required for this task:

- Tape measure.

The task is a two-person job. One person must remain in the cab to enter data into the display while a second person takes measurements from outside the machine.

1. First verify that the bucket sensor is working correctly.  
(See Checking The Bucket Sensor on Page 140)

Figure 303



2. Place the bucket teeth on the ground with the teeth at the lowest point in the bucket movement arc [Figure 303].
3. Select **[REBENCH]**.

Figure 304



4. Move only the arm out, extending it as much as possible [Figure 304].  
Do not move the boom.
5. Measure how high the bucket teeth are off the ground [Figure 304].
6. Compare this result to the Depth value on the display.

If the display isn't showing the correct Depth, contact your Bobcat dealer.

#### Checking The Boom Sensor

The following item is required for this task:

- Tape measure.

The task is a two-person job. One person must remain in the cab to enter data into the display while a second person takes measurements from outside the machine.


1. First verify that the bucket and arm sensors are working correctly.  
(See Checking The Bucket Sensor on Page 140)  
(See Checking The Arm Sensor on Page 141)

**Figure 305**



2. Set the bucket flat on the ground [Figure 305].
3. Select **[REBENCH]**.
4. Move the boom up.

**Figure 306**



5. Measure how high the bucket teeth are off the ground [Figure 306].
6. Compare the measurement with the Depth value on the display.

If the display isn't showing the correct Depth, contact your Bobcat dealer.

## TOWING THE MACHINE


### Towing The Machine

There is not a recommended towing procedure for the excavators.

- The excavator can be lifted onto the transport vehicle. (See Lifting The Machine on Page 143)
- The excavator can be skidded a short distance for service (for example, moving it onto a transport vehicle) without damaging the hydraulic system. (The tracks will not turn.)

There might be slight wear to the tracks when the excavator is skidded.

**Figure 307**



- Secure the towing chain to the loop located at the rear of the excavator (Item 1) [Figure 307].

The towing chain (or cable) must be rated at 1.5 times the weight of the excavator.

## LIFTING THE MACHINE

### Lifting The Machine

Figure 308



P200405a

1. Fully extend the cylinders of the bucket, arm, and boom.
2. Raise the blade fully.
3. Turn the upperstructure so the boom and blade are at opposite ends of the excavator as shown in [Figure 308].
4. Put all the control levers in NEUTRAL and stop the machine.

### **⚠ WARNING**


#### **CRUSHING HAZARD**

Falling machine can cause serious injury or death.

- Use chains and lifting equipment with sufficient capacity for the weight of the excavator plus any added attachments.
- Keep machine level and balanced when lifting.
- Do not swing boom or upperstructure.
- Never lift with operator on machine.
- Never lift with the blade angled (if equipped).

W-2800

Figure 309




P200406a

5. Fasten chains to the ends of the blade (Item 1) [Figure 309] and up to a lifting fixture above the canopy / cab.

The lifting fixture must extend over the sides of the canopy / cab to prevent the chains from hitting the canopy / cab.


Figure 310



P200404a

6. Fasten a chain from the boom (Item 1) [Figure 310] to the lift fixture.

Figure 311



NA15059a

Keep the following in mind:

- The excavator should remain as close to horizontal as possible.
- To prevent damage, the chains should not contact any part of the canopy / cab.
- The chains should be at an angle of 45° (Item 1) [Figure 311].

## TRANSPORTING THE MACHINE

When transporting the machine, observe the rules, motor vehicle laws, and vehicle limit ordinances. Use a transport and towing vehicle of adequate length and capacity.

1. Secure the parking brakes and block the wheels of the transport vehicle.
2. Align the ramps with the centre of the transport vehicle.
3. Secure the ramps to the truck bed and be sure ramp angle does not exceed 15 degrees.

Use metal loading ramps with a slip-resistant surface. Use ramps that are the correct length and width and that can support the weight of the machine.

4. Block and support the rear of the trailer during loading and unloading to prevent the front of the transport vehicle from raising.
5. Determine the direction of the track movement before moving the machine (blade forward).
6. Disengage the auto idle feature and move the two-speed travel to the low range position.

### WARNING

#### INSTABILITY HAZARD

**Wood ramps can break and cause personal injury. Use adequately designed ramps of sufficient strength to support the weight of the machine loading onto a transport vehicle. ◀**

W-2058

Figure 312



C-97223d


7. Move the machine forward onto the transport vehicle [Figure 312].
8. Do not change the direction of the machine while it is on the ramps.

9. Lower the boom, arm, bucket, and blade to the transport vehicle.
10. Stop the engine and remove the key (if equipped).
11. Put blocks at the front and rear of the tracks.

### Fastening The Machine To A Trailer


Tie down the excavator to prevent it from moving when going up or down slopes or during sudden stops. Use chain binders to tighten the chains and then safely tie the chain binder levers to prevent loosening.

**Figure 313**




P134185a

**Figure 314**



C206170a


**Figure 315**



C206170a


1. At the front of the machine, fasten chains to the corners of the blade (Item 1) [Figure 313].  
OR  
Fasten chains to the tie-down loops on the outside of the tracks (Item 1) [Figure 314].  
OR  
Fasten chains to the tie-down loops on the front of the upperstructure (Item 1) [Figure 315].

**Figure 316**



P134186a

Figure 317



C200607a

2. At the rear of the machine, fasten chains to the tie-down loops on the exterior of the track (Item 1) [Figure 316]  
OR  
Fasten chains to the tie-down loops in the interior of the track (Item 1) [Figure 317].

# MAINTENANCE SAFETY WARNINGS



- Never service the Bobcat® machine without instructions. Read and understand the Operation & Maintenance Manual, Operator's Handbook, and signs (decals) on machine. Follow warnings and instructions in manuals when making repairs, adjustments, or servicing. Check for correct function after adjustments, repairs, or service.
- Untrained operators and failure to follow instructions can cause injury or death.

Maintenance procedures that are given in the Operation & Maintenance Manual can be performed by the owner/operator without any specific technical training. Maintenance procedures that are not in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL**. Always use genuine Bobcat replacement parts. The Service Safety Training Course is available from your Bobcat dealer.



This check mark means: "Follow instructions for proper operations." Carefully read the message that follows.



- Have good ventilation when welding or grinding painted parts.
- Wear dust mask when grinding painted parts. Toxic dust and gas can be produced.


# MAINTENANCE SAFETY WARNINGS



This Safety Alert Symbol means: "Attention! Be Alert! Your Safety is Involved!" Carefully read the message that follows.



- Use the correct procedure to lift and support the machine.



- Cleaning and maintenance are required daily.



- Vent exhaust to outside when engine must be run for service.
- Exhaust system must be tightly sealed. Exhaust fumes can kill without warning.




- Stop, cool, and clean engine of flammable materials before checking fluids.
- Never service or adjust machine with the engine running unless instructed to do so in the manual.
- Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate the skin or eyes.
- Never fill fuel tank with engine running, while smoking, or when near open flame.



- Keep body, jewelry, and clothing away from moving parts, electrical contact, hot parts, and exhaust.
- Wear eye protection to guard from battery acid, compressed springs, fluids under pressure, and flying debris when engines are running or tools are used. Use eye protections approved for type of welding.
- Keep tailgate closed except for service. Close and latch tailgate before operating machine.



- Lead-acid batteries produce flammable and explosive gases.
- Keep arcs, sparks, flames, and lighted tobacco away from batteries.
- Batteries contain acid that burns eyes or skin on contact.
- Wear protective clothing. If acid contacts body, flush well with water. For eye contact, flush well and get immediate medical attention.



- Always lower the bucket and blade to the ground before doing any maintenance.
- Never modify equipment or add attachments not approved by Bobcat Company.

## SERVICE SCHEDULE

### Maintenance Intervals

Maintenance work must be done at regular intervals. Failure to do so will result in excessive wear and early failures.


The service schedule decal is a guide for correct maintenance of the Bobcat excavator.

The maintenance items listed under the maintenance intervals on the following pages are the required tasks to be performed. Those items provide additional details and include maintenance that is not shown on the decal.

All maintenance intervals are for machines operating in general environmental conditions. Keep in mind that filter and oil life can be reduced:

- When machines are operating in high dust environments or extreme temperature applications,
- When fuel is taken from uncontrolled storage tanks,
- When other non-standard conditions exist.

For more details, contact your Bobcat dealer.



### ⚠ WARNING

#### INSUFFICIENT INSTRUCTIONS HAZARD

Untrained operators or failure to follow instructions can cause serious injury or death.

- Read and understand the Operation & Maintenance Manual, Operator's Handbook and decals on machine.
- Follow warnings and instructions in the manuals when making repairs, adjustments or servicing.
- Check for correct function after adjustments, repairs or service. ◀

W-2003

#### Service Schedule

Explanation of the service intervals:

- **10:** Every 10 hours or daily (before starting the machine).
- **50:** Every 50 hours.
- **250:** Every 250 hours or every 12 months, whichever comes first.
- **500:** Every 500 hours or every 12 months, whichever comes first.
- **1000:** Every 1000 hours or every 12 months, whichever comes first.
- **1500:** Every 1500 hours or every 24 months, whichever comes first.

Service Schedule							
O	Check condition / proper operation. Adjust or replace as needed	V	Refill as needed.				
D	Check the display. Service only when required.	C	Clean.				
W	Service every 10 hours when operating in water.	R	Replace.				
F	First time only.	G	Grease.				
Item	Service Required	Service Interval (hours)					
		10	50	250	500	1000	1500
Engine Air Filters and Air System 	(See Page 161) <ul style="list-style-type: none"> <li>Outer Air Filter (6666375)</li> <li>Inner Air Filter (6666376)</li> </ul>	D O			O		
Engine Oil 	(See Page 168) <ul style="list-style-type: none"> <li>Engine Oil (Packaging: A = 5 L can, B = 25 L container, C = 209 L drum, D = 1000 L tank):                             <ul style="list-style-type: none"> <li>SAE 15W-40 (-20°C – +40°C) (7395725)</li> <li>SAE 10W-30 (-25°C – +30°C) (7341377)</li> </ul> </li> <li>Engine Oil Filter (7343102)</li> </ul>	V			R		
Hydraulic Fluid 	(See Page 177) <ul style="list-style-type: none"> <li>Hydraulic Fluid (Packaging: A = 5 L can, B = 20 L container, C = 210 L drum, D = 1000 L tank):                             <ul style="list-style-type: none"> <li>Bobcat Superior SH Hydraulic (-35°C – +50°C) (6987791)</li> <li>Bobcat Biodegradable Hydraulic (-35°C – +50°C) (6987792)</li> </ul> </li> </ul>	V				R	
Engine Coolant 	Coolant level (check cold) (See Page 169) <ul style="list-style-type: none"> <li>Coolant (Packaging: A = 5 L can, B = 20 L container, C = 210 L drum, D = 1000 L tank):                             <ul style="list-style-type: none"> <li>Bobcat PG Coolant Premix (6987793)</li> </ul> </li> </ul>	V				R	
Tracks 	Tension (See Page 182)	O					
Operator Cab and HVAC	Filters (See Page 160) <ul style="list-style-type: none"> <li>HVAC Air Filter (If Equipped):                             <ul style="list-style-type: none"> <li>Fresh Air (7176099)</li> <li>Recirculation (7222791)</li> </ul> </li> </ul>	C					
Safety Signs (decals)		C O					
Seat Belt	Seat belt, mounting hardware, and seat belt retractors (See Page 154)	C O					

Service Schedule							
O	Check condition / proper operation. Adjust or replace as needed			V	Refill as needed.		
D	Check the display. Service only when required.			C	Clean.		
W	Service every 10 hours when operating in water.			R	Replace.		
F	First time only.			G	Grease.		
Item	Service Required	Service Interval (hours)					
		10	50	250	500	1000	1500
Control Console Lockout	(See Page 153)	O					
X-Change / Attachment Coupler	(See Quick Coupler on Page 188)	O					
Motion Alarm and Horn	(See Page 155)	O					
Operator Canopy / Cab	Canopy / cab, mounting hardware	O					
Indicators and Lights		O					
Pivot Points 	Pivot points, clamp (if equipped) (See Machine Lubrication on Page 190) <ul style="list-style-type: none"> <li>Grease (Packaging: 400 g tube):                             <ul style="list-style-type: none"> <li>Bobcat Multipurpose Grease (Drop Point from 260°C) (6987888)</li> <li>Bobcat Supreme HD Grease (Drop Point from 280°C) (6987889)</li> <li>Bobcat Extreme HP Grease (Drop Point from 260°C) (6987890)</li> </ul> </li> </ul>	G					
Swing Bearing 	Swing bearing, swing pinion (See Machine Lubrication on Page 190) <ul style="list-style-type: none"> <li>Grease (Packaging: 400 g tube):                             <ul style="list-style-type: none"> <li>Bobcat Multipurpose Grease (Drop Point from 260°C) (6987888)</li> <li>Bobcat Supreme HD Grease (Drop Point from 280°C) (6987889)</li> <li>Bobcat Extreme HP Grease (Drop Point from 260°C) (6987890)</li> </ul> </li> </ul>	W	G				
Travel Motors (Final Drive) 	Fluid (See Page 185) <ul style="list-style-type: none"> <li>Transmission Fluid (Packaging: A = 5 L, B = 20 L, C = 210 L)                             <ul style="list-style-type: none"> <li>80W-90 API GL-5 LS (6987805)</li> </ul> </li> </ul>		FR	V		R	
Hydraulic Filters 	Hydraulic filter and case drain filter (See Page 177) <ul style="list-style-type: none"> <li>Primary Hydraulic Filter (6670207)</li> <li>Case Drain Filter (6516722)</li> </ul>		FR		R		
Alternator and Starter	Electrical connections		FO		O		

Service Schedule							
O	Check condition / proper operation. Adjust or replace as needed			V	Refill as needed.		
D	Check the display. Service only when required.			C	Clean.		
W	Service every 10 hours when operating in water.			R	Replace.		
F	First time only.			G	Grease.		
Item	Service Required	Service Interval (hours)					
		10	50	250	500	1000	1500
Battery 	Cables and electrical connections (See Page 174) • Battery (7306047)			O			
Engine Oil Filter 	(See Page 168) • Engine Oil (Packaging: A = 5 L can, B = 25 L container, C = 209 L drum, D = 1000 L tank): > SAE 15W-40 (-20°C – +40°C) (7395725) > SAE 10W-30 (-25°C – +30°C) (7341377) • Engine Oil Filter (7343102)				R		
Hydraulic Reservoir 	Breather cap (See Page 177) • Hydraulic Breather Cap (6692836)				R		
Engine Cooling System 	Radiator, fuel cooler, hydraulic fluid cooler, air conditioning condenser (if equipped) (See Page 169) • Radiator Cap (7337382)				C		
Alternator 	Belt (See Page 186)				O		
Air Conditioning (if equipped)	Belt (See Page 186)				O		
HVAC	Housing and coils (See Page 160)				C		
Fuel Filter and Pre-Filter 	Fuel Filter (See Page 165) • Fuel Filter (7336334)  Fuel Pre-Filter (See Page 166) • Fuel Pre-Filter (7348032)					R	
Fuel Tank	Vent filter (See Page 167) • Fuel Tank Vent Filter (7340277)					R	

## Inspection Checkbook

Maintenance work must be done at regular intervals. Failure to do so will result in excessive wear and early failures.

The service schedule is a guide for the correct maintenance of the Bobcat machine.

The Inspection Checkbook contains the following information:

- Doosan Bobcat EMEA s.r.o. Warranty Policy
- Doosan Bobcat EMEA s.r.o. Extended Warranty Policy

The inspection checkbook has to be filled in by the dealer for any maintenance and service work of your Bobcat machine. This book may be required anytime by an authorised dealer or by Bobcat Europe, should a breakdown occur on the Bobcat equipment.

Your Bobcat dealer can order the Inspection Checkbook. The part number is 7296478.

## CONTROL CONSOLE LOCKOUTS

### Inspecting And Maintaining The Control Console Lockouts

Figure 318



When the left console is raised [Figure 318], the hydraulic joysticks and traction system must not function.

1. Sit in the operator's seat, fasten the seat belt, and start the engine.
2. Raise the left console [Figure 318].
3. Move the joysticks.

There should be no movement of the boom, arm, slew, or bucket.

4. Move the steering control levers.

There should be no movement of the excavator tracks.

If these controls do not deactivate when the left console is raised, see your Bobcat dealer for service.

**SEAT BELT**

**Inspecting And Maintaining The Seat Belt**


**⚠ WARNING**

**GENERAL HAZARD**

**Failure to properly inspect and maintain the seat belt can cause lack of operator restraint resulting in serious injury or death. ◀**

W2466

**Figure 319**



Check the seat belt daily for correct function. Inspect the seat belt system thoroughly at least once each year or more often if the machine is exposed to severe environmental conditions or applications.

The items below are referenced in [Figure 319].

1. Check the webbing. If the system is equipped with a retractor, pull the webbing completely out and inspect the full length of the webbing. Look for cuts, wear, fraying, dirt, and stiffness.
2. Check the buckle and latch for correct operation. Make sure latch plate is not excessively worn or deformed, buckle is not damaged, and casing is not broken.
3. Check the retractor web storage device (if equipped) by extending webbing to determine if it looks correct and that it spools out and retracts webbing correctly.

4. Check webbing in areas exposed to ultraviolet (UV) rays from the sun or extreme dust or dirt. If the original colour of the webbing in these areas is extremely faded and / or the webbing is packed with dirt, the webbing strength may have deteriorated.
5. Check the hardware on both sides of the seat. Hardware should be tight. Hardware must not be missing, rusted, corroded, or damaged.

Any seat belt system that shows cuts, fraying, extreme or unusual wear, significant discolourations due to ultraviolet UV exposure, dusty / dirty conditions, abrasion to the seat belt webbing, or damage to the buckle, latch plate, retractor (if equipped), hardware or any other obvious problem should be replaced immediately.

See your Bobcat dealer for seat belt system replacement parts for your machine.

## TRAVEL MOTION ALARM

### Travel Motion Alarm Description

This excavator may be equipped with a travel motion alarm. The travel motion alarm is located underneath the rear of the excavator.

The travel motion alarm will sound when the operator moves the travel control levers in either the forward or reverse direction.

If the alarm does not sound, see inspection instructions. (See Inspecting The Travel Motion Alarm System on Page 155)

### **⚠ WARNING**

#### CRUSHING HAZARD

Failure to maintain a clear view in the direction of travel can cause serious injury or death.

- This machine is equipped with a motion alarm. **ALARM MUST SOUND!** when operating forward or backward.
- The operator is responsible for the safe operation of this machine. ◀

W-2786

### Inspecting The Travel Motion Alarm System

You will need to move the machine slightly in the forward and reverse directions to test the travel motion alarm. Keep all bystanders away from machine during test.

### **⚠ WARNING**

#### CRUSHING HAZARD


Failure to maintain a clear view in the direction of travel can cause serious injury or death.

- This machine is equipped with a motion alarm. **ALARM MUST SOUND!** when operating forward or backward.
- The operator is responsible for the safe operation of this machine. ◀

W-2786


1. Sit in the operator's seat and fasten the seat belt. (See Pre-Starting Procedure on Page 75)

Figure 320



P200105a


Figure 321



C206837a

2. Inspect for damaged or missing travel motion alarm decal (Item 1) [Figure 320] (cab machine) or [Figure 321] (canopy machine).  
Replace if required.
3. Start the engine. (See Starting The Engine on Page 77)
4. Move the travel control levers (one lever at a time) in the forward direction.  
The motion alarm must sound.
5. Move the travel control levers (one lever at a time) in the reverse direction.  
The travel motion alarm must sound.

**Figure 322**



6. Slightly move both travel control levers in the forward direction (until the machine is slowly moving forward) and then press the travel motion alarm cancel switch (Item 1) [Figure 322].


The travel motion alarm will shut off.

7. Slightly move both travel control levers in the reverse direction (until the machine is slowly moving backward) and then press the travel motion alarm cancel switch (Item 1) [Figure 322].

The travel motion alarm will shut off.

8. Return both levers to neutral and turn excavator key to off position.
9. Exit the excavator.  
(See Stopping The Engine And Leaving The Machine on Page 85)


**Figure 323**



10. Locate the travel motion alarm, which is mounted in the bottom rear of the excavator to the front of the engine oil pan [Figure 323].

11. Inspect the travel motion alarm electrical connections and wire harness (Item 1) [Figure 323] for tightness and damage.
  - a. Repair or replace any damaged components.

**Figure 324**




12. Locate the travel motion alarm switch, which is in the travel control valve under the floorplate [Figure 324].
  - a. Remove the floor mat and the floorplate to access the switch.
13. Inspect the wire harness (Item 1) and travel motion alarm switch (Item 2) for tightness and damage [Figure 324].

If the travel motion alarm switch requires service, see your Bobcat dealer.

**Maintaining The Travel Motion Alarm Switch**

**Figure 325**



The travel motion alarm switch (Item 1) [Figure 325] is located in the travel control valve located under the

floorplate. In the event the travel motion alarm is not sounding, inspect the switch.

1. Remove the floor mat and the floorplate to access the switch.
2. Check that the switch is fully installed into the travel control valve housings and tightened.  
Tighten the switch to 18 – 20 N•m (13 – 15 ft-lb).
3. Recheck the travel motion alarm.  
(See Inspecting The Travel Motion Alarm System on Page 155)

If the travel motion alarm still does not sound, replace the switch.

## TAILGATE

### Opening And Closing The Tailgate

#### **⚠ WARNING**

#### **GENERAL HAZARD**

**Failure to follow instructions can cause serious injury or death.**

**Never service or adjust the machine when the engine is running unless instructed to do so in the manual. ◀**

W-2012

#### **⚠ WARNING**


#### **IMPACT HAZARD**

**Swinging rear door can seriously injure a bystander. Keep the rear door closed when operating the machine. ◀**

W-2020

The tailgate can be locked and unlocked using the start key.

**Figure 326**



P200085a

- Push the button (Item 1) [Figure 326] and pull the tailgate open.
- Push firmly to close the tailgate.

## RIGHT SIDE COVER

### Opening And Closing The Right Side Cover

Figure 327



P20011a

1. Open the tailgate to access the right side cover latch (Item 1) [Figure 327].

Figure 328



P141325


2. Pull the latch (Item 1) [Figure 327] toward the cover and allow the cover to rise slowly [Figure 328].
3. To close the right side cover, rotate the cover back until it is in the fully closed position and you hear the latch snap into place.

## RIGHT SIDE PANEL

### Removing And Installing The Right Side Panel

1. Open the tailgate. (See Tailgate on Page 157)
2. Open the right side cover. (See Right Side Cover on Page 158)

Figure 329



C200143a


3. Loosen the five bolts (Item 1) on the right side panel (Item 2) and remove the panel [Figure 329].
4. To reinstall the panel, fit the panel back onto the bolts (Item 1) [Figure 329] and tighten the bolts.

## RIGHT SIDE GRILLE

### Removing And Installing The Right Side Grille

1. Open the tailgate. (See Tailgate on Page 157)
2. Open the right side cover. (See Right Side Cover on Page 158)

Figure 330




P200101a

3. Turn the two fasteners (Item 1) [Figure 330] a quarter turn.
4. Remove the right side grille (Item 2) [Figure 330].
5. To install the grille, position it in place and turn the two fasteners (Item 1) [Figure 330] a quarter turn.

## CAB FILTERS

### Cleaning And Maintaining The Recirculation Filter


Figure 331



C206256a

The recirculation filter is located to the right of the operator seat (Item 1) [Figure 331]. It must be cleaned regularly.

Figure 332




C206256a

1. Pull up on the filter (Item 1) [Figure 332] until it is removed from the housing.
2. Shake the filter or use low pressure air to clean the filter.  
  
Replace the filter if it is very dirty or damaged.
3. To reinstall the filter, position the bottom of the filter on the housing and slowly push the filter down fully.

## Cleaning And Maintaining The Fresh Air Filter

Figure 333



P20114a

The fresh air filter (Item 1) is located behind the hydraulic tank (Item 2) [Figure 333] (view from the top). It must be cleaned regularly.

1. Open the right side cover.  
(See Right Side Cover on Page 158)
2. Pull out on the tab (Item 1) [Figure 333] and remove the cover.
3. Pull the filter out of the housing.
4. Gently tap the sides of the filter and / or use low pressure compressed air from the back side of the filter to remove debris.

Do not use solvents. Do not use a brush on the filter as it can push debris into the filter.

Replace the filter if it is very dirty or damaged.

5. To reinstall the filter, position the filter on the housing and slowly push the filter in fully.
6. Place the bottom tabs of the filter cover into the frame and push the top in until the tab locks to the frame.

## HEATING, VENTILATION, AND AIR CONDITIONING (HVAC)


### Cleaning HVAC Filters

The inside of the HVAC housing needs to be cleaned regularly. Dust will accumulate over time inside the housing. A dusty heater and evaporator coil will reduce heating and cooling efficiency.  
(See Service Schedule on Page 149)

The HVAC housing is located to the right of the operator seat.

1. Rotate the upperstructure 90° to the right to allow water to drain from the housing during the cleaning process.
2. Use the blade to raise the front of the excavator so that water can run out of the housing.
3. Use jackstands to support the front of the undercarriage.
4. Remove the floor mat.


Figure 334



P200301a

5. Pull back on the two latches (Item 1) [Figure 334] and remove the HVAC side cover.

Figure 335



6. Use a lower pressure air or low pressure water stream to remove debris and clean the coils (Item 1) [Figure 335].
7. After the housing has been cleaned and flushed, remove the jackstands and raise the blade so the front of the excavator is flat on the ground.
8. Stop the engine.
9. Access two of the rubber drain valves by opening the right side cover. The drain valves are located below the HVAC housing on the right side.
10. Clean the rubber drain valves by pinching the drain valves on the flat sides to open the valves and allow dirt and moisture to exit from the end of the valves.
11. Remove the center floorplate to access the third rubber drain valve that is located below the left rear corner of the HVAC housing.
12. Clean the rubber drain valve by pinching the drain valve on the flat side to open the valve and allow dirt and moisture to exit from the end of the valve.  
  
The rubber drain valves allow condensation to drain from the housing during normal usage. These drain valves can get clogged with dirt and should be cleaned at the same time the housing is cleaned.
13. Reinstall the center floorplate and close the right cover.
14. Fit the three retainers (Item 3) of the HVAC side cover into the three tabs on the bottom of the HVAC housing (Item 2) [Figure 335].
15. Press on the front of the cover to secure the front latch (Item 1) [Figure 334].
16. Press on the top edge of the side cover and work back to the rear of the cover and secure the rear latch.
17. Reinstall the floor mat.

## ENGINE AIR CLEANER

### Replacing The Outer Filter Of The Air Cleaner


The engine air cleaner is located in the engine compartment.

See the Service Schedule for the correct service interval. (See Service Schedule on Page 149)

The general warning icon and service code “M-0117 – Air Filter Plugged” will appear on the screen when air filter replacement is necessary.

1. Open the tailgate. (See Tailgate on Page 157)

Figure 336



2. Release the three fasteners (Item 1) [Figure 336].
3. Remove and clean the dust cup (Item 2) [Figure 336].

Figure 337



4. Pull the outer filter (Item 1) [Figure 337] from the air cleaner housing.


5. Check the housing for damage.
6. Clean the housing and the seal surface. Do not use compressed air.
7. Install a new filter.
8. Install the dust cup (Item 2) and engage the three fasteners (Item 1) [Figure 336].
9. Check the air intake hose and the air cleaner housing for damage. Make sure all connections are tight.
10. Close the tailgate.

### Replacing The Inner Filter Of The Air Cleaner

Replace the inner filter only under the following conditions:

- Replace the inner filter every second time the outer filter is replaced.
  - After the outer filter has been replaced, start the engine and operate at full rpm. If service code “M-0117 – Air Filter Plugged” is still displayed, replace the inner filter.
1. Open the tailgate. (See Tailgate on Page 157)
  2. Remove the dust cup and the outer filter. (See Replacing The Outer Filter Of The Air Cleaner on Page 161)

**Figure 338**



3. Remove the inner filter (Item 1) [Figure 338].
4. Check the housing for damage.
5. Clean the housing and the seal surfaces. Do not use compressed air.
6. Install a new inner filter.
7. Install the outer filter and dust cup.

**FUEL SYSTEM**

**Fuel Specifications**

**NOTE:** Contact your local fuel supplier to receive recommendations for your region.

*U.S. Standard (ASTM D975)*

Use only clean, high quality diesel fuel, grade number 2-D or grade number 1-D.

Ultra-low sulfur diesel fuel must be used in this machine. Ultra-low sulfur is defined as 15 mg/kg (15 ppm) sulfur maximum.

The following is one suggested blending guideline that should prevent fuel gelling during cold temperatures:

TEMPERATURE	GRADE 1-D	GRADE 2-D
Above -9°C (+15°F)	0%	100%
Down to -21°C (-5°F)	50%	50%
Below -21°C (-5°F)	100%	0%

**NOTE:** Biodiesel blend fuel may also be used in this machine. Biodiesel blend fuel must contain no more than five percent biodiesel mixed with ultra-low sulfur petroleum based diesel. This biodiesel blend fuel is commonly marketed as B5 blended diesel fuel. B5 blended diesel fuel must meet ASTM specifications.

*E.U. Standard (EN590)*

Use only clean, high quality diesel fuel that meets the EN590 specifications listed below:

- Sulfur-free diesel fuel defined as 10 mg/kg (10 ppm) sulfur maximum.
- Diesel fuel with cetane number of 51.0 and above.

**NOTE:** Biodiesel blend fuel may also be used in this machine. Biodiesel blend fuel must contain no more than seven percent biodiesel mixed with sulfur-free petroleum based diesel. This biodiesel blend fuel is commonly marketed as B7 blended diesel fuel. B7 blended diesel fuel must meet EN590 specifications.

**Biodiesel Blend Fuel**

Biodiesel blend fuel has unique qualities that should be considered before using in this machine:

- Cold weather conditions can lead to plugged fuel system components and hard starting.
- Biodiesel blend fuel is an excellent medium for microbial growth and contamination, which can cause corrosion and plugging of fuel system components.
- Use of biodiesel blend fuel may result in premature failure of fuel system components, such as plugged fuel filters and deteriorated fuel lines.

- Shorter maintenance intervals may be required, such as cleaning the fuel system and replacing fuel filters and fuel lines.
- Using biodiesel blended fuels containing more than the recommended amount of biodiesel can affect engine life and cause deterioration of hoses, tubelines, injectors, injector pump, and seals. (See Fuel Specifications on Page 163)

Apply the following guidelines if biodiesel blend fuel is used:

- Ensure the fuel tank is as full as possible at all times to prevent moisture from collecting in the fuel tank.
- Ensure that the fuel tank cap is securely tightened.
- Biodiesel blend fuel can damage painted surfaces. Remove all spilled fuel from painted surfaces immediately.
- Drain all water from the fuel filter daily before operating the machine.
- Do not exceed engine oil change interval. Extending oil change intervals can cause engine damage.
- Before vehicle storage, drain the fuel tank, refill with 100% petroleum diesel fuel, add fuel stabiliser, and run the engine for at least 30 minutes.

**NOTE:** Biodiesel blend fuel does not have long-term stability and should not be stored for more than three months.

**Filling The Fuel Tank**



**WARNING**

**FIRE AND EXPLOSION HAZARDS**  
 Failure to follow instructions can cause serious injury or death.  
 Stop and cool the engine before adding fuel. **NO SMOKING!**

W-2063




**WARNING**

**FIRE AND EXPLOSION HAZARD**  
 Failure to use care around combustibles can cause serious injury or death.  
 Always clean up spilled fuel or oil. Keep heat, flames, sparks or lighted tobacco away from fuel and oil.

W-2103

1. Use the start key to unlock the fuel cap.

Figure 339



P200118a

2. Remove the fuel fill cap (Item 1) [Figure 339].
3. Use a clean, approved safety container to add fuel.
4. Add fuel only in an area that has a free movement of air and no flames or sparks. Do not smoke.
5. Install and tighten the fuel fill cap.
6. Clean up any spilled fuel.

See the Service Schedule for the service interval for removing water from the filter or replacing the filter. (See Service Schedule on Page 149)

**Using The Fuel Fill Pump**

**⚠ WARNING**

**FIRE AND EXPLOSION HAZARDS**  
 Failure to follow instructions can cause serious injury or death.  
 Stop and cool the engine before adding fuel. **NO SMOKING!** ◀


W2063

**⚠ WARNING**

**FIRE AND EXPLOSION HAZARD**  
 Failure to use care around combustibles can cause serious injury or death.  
 Always clean up spilled fuel or oil. Keep heat, flames, sparks or lighted tobacco away from fuel and oil. ◀

W2103


Figure 340



C206812a

Your machine may be equipped with a battery-operated fuel fill pump (Item 1) [Figure 340] located in the upperstructure under the operator door.

Figure 341



P200118a


1. Loosen the fuel fill cap (Item 1) [Figure 341] using the start key.
2. Open the left upperstructure access cover (Item 2) [Figure 340] that is located under the operator door.
3. Pull out the suction hose (Item 3) [Figure 340].
4. Ensure the suction hose (Item 3) [Figure 340] is clean.

If necessary, wipe the suction hose with a clean, dry cloth to remove any contaminants.

5. Put the end of the hose into an external fuel resupply container.

- Add fuel only in an area that has a free movement of air and no flames or sparks.
- Do not smoke.

**Figure 342**



6. Briefly push the button (Item 1) [Figure 342] on the fuel pump to wake the system from stand-by mode.  
The green light (Item 2) [Figure 342] will turn on.
7. Push the button (Item 1) [Figure 342] on the fuel pump to start fuel transfer.  
The red light (Item 3) [Figure 342] will turn on.
8. The yellow light (Item 4) [Figure 342] will turn on when the fuel tank is full and fuel transfer will stop automatically.  
OR  
Push the button (Item 1) [Figure 342] for several seconds to stop fuel transfer at any time.
9. When fuel transfer is done, place the suction hose back into its holder (Item 3) [Figure 340].
10. Close the left upperstructure access cover (Item 2) [Figure 340].
11. Tighten the fuel fill cap (Item 1) [Figure 341].


**Removing Water From The Fuel Filter**

Monitor your display for notifications. See the Service Schedule for the correct service interval. (See Service Schedule on Page 149)

1. Rotate the upperstructure 90°.
2. Turn off the engine and exit the excavator.
3. Open the tailgate. (See Tailgate on Page 157)
4. Open the right side cover. (See Right Side Cover on Page 158)

5. Remove the right grille. (See Right Side Grille on Page 159)

**Figure 343**



6. Locate the hose (Item 1) under the fuel filter (Item 2) and put a container underneath the upperstructure (hose should be routed down through the frame) [Figure 343].
7. Loosen the drain (Item 3) [Figure 343] at the bottom of the filter to remove trapped water from the filter.
8. Tighten the drain.
9. Reinstall the right side grille and close the right side cover and tailgate.

**⚠ WARNING**


**FIRE AND EXPLOSION HAZARD**  
Failure to use care around combustibles can cause serious injury or death. Always clean up spilled fuel or oil. Keep heat, flames, sparks or lighted tobacco away from fuel and oil. ◀

**Replacing The Fuel Filter**

Monitor your display for notifications. See the Service Schedule for the correct service interval. (See Service Schedule on Page 149)

1. Stop the engine.
2. Open the tailgate. (See Tailgate on Page 157)
3. Open the right side cover. (See Right Side Cover on Page 158)
4. Remove the right side grille. (See Right Side Grille on Page 159)

Figure 344



5. Disconnect the electric connector (Item 1) [Figure 344] from the bottom of the fuel filter.
6. Unscrew and remove the water separator (Item 2) [Figure 344].
7. Remove the fuel filter (Item 3) [Figure 344].
8. Screw the water separator onto the replacement filter.  
Do not fill the new fuel filter with fuel at this time.
9. Put clean oil on the two new fuel filter O-rings.
10. Install the replacement filter and torque to 13,5 N•m (10 ft-lb).
11. Connect the electrical connector (Item 1) [Figure 344].
12. Turn the starter switch to ON to let the electronic fuel pump purge the air.
13. Start the engine and let it run for a few minutes.
14. Stop the engine and check for leaks at the filter.
15. Reinstall the right side grille, close the right side cover and tailgate.

**⚠ WARNING**

**INJECTION HAZARD**

Pressurised diesel fuel or hydraulic fluid can penetrate skin and eyes, causing serious injury or death.

Fluid leaks under pressure may not be visible. Use a piece of cardboard or wood to find leaks. **DO NOT** use your bare hand. Wear safety goggles. If fluid enters skin or eyes, get immediate medical attention from a doctor familiar with this injury. ◀


W-2072

**Replacing The Fuel Pre-Filter**

See the Service Schedule for the correct service interval. (See Service Schedule on Page 149)

1. Stop the engine.
2. Open the tailgate. (See Tailgate on Page 157)
3. Open the right side cover. (See Right Side Cover on Page 158)
4. Remove the right side grille. (See Right Side Grille on Page 159)

Figure 345



5. Pinch off the upper and lower hoses (Item 1) [Figure 345] to prevent spilled fuel while the hoses are disconnected from the pre-filter.
6. Reposition the upper and lower hose clamps (Item 1) [Figure 345] and remove the hoses from the pre-filter.
7. Loosen the clamp (Item 2) [Figure 345].
8. Remove the pre-filter and discard.
9. Install the new pre-filter into the clamp (Item 2) [Figure 345] and tighten the clamp.
10. Install the upper and lower hoses.
11. Move the hose clamps (Item 1) [Figure 345] back into the correct position as shown.
12. Remove tools used to pinch off the upper and lower hoses.

**⚠ WARNING**

**FIRE AND EXPLOSION HAZARD**

Failure to use care around combustibles can cause serious injury or death. Always clean up spilled fuel or oil. Keep heat, flames, sparks or lighted tobacco away from fuel and oil. ◀

W-2103

- Turn the start switch to on to let the electronic fuel pump purge the air.

**⚠ WARNING**

**INJECTION HAZARD**

Pressurised diesel fuel or hydraulic fluid can penetrate skin and eyes, causing serious injury or death. Fluid leaks under pressure may not be visible. Use a piece of cardboard or wood to find leaks. **DO NOT** use your bare hand. Wear safety goggles. If fluid enters skin or eyes, get immediate medical attention from a doctor familiar with this injury. ◀

W-2072


- Turn the switch to off and check for leaks at the filter.
- Reinstall the right side grille and close the right side cover and tailgate.

**Replacing The Fuel Tank Vent Filter**

See the Service Schedule for the correct service interval. (See Service Schedule on Page 149)

- Stop the engine.
- Open the tailgate. (See Tailgate on Page 157)

**Figure 346**



P200581a


- Locate the fuel tank vent filter (Item 1) [Figure 346], which is near the fuel fill.
- Remove the fuel tank vent filter (Item 1) [Figure 346].
- Install the new fuel tank vent filter and tighten.
- Close the tailgate.

**Draining The Fuel Tank**

The following item is needed to complete this task:

- Container with a capacity of 72 L (19 US gal)
- Stop the engine.

**Figure 347**



C200605a

- Remove the plug (Item 1) [Figure 347] from the tank and drain the fuel into a container.
- Replace the plug after fuel has been removed.
- Reuse, recycle, or dispose of fuel in an environmentally safe manner.

**⚠ WARNING**

**INJECTION HAZARD**

Pressurised diesel fuel or hydraulic fluid can penetrate skin and eyes, causing serious injury or death. Fluid leaks under pressure may not be visible. Use a piece of cardboard or wood to find leaks. **DO NOT** use your bare hand. Wear safety goggles. If fluid enters skin or eyes, get immediate medical attention from a doctor familiar with this injury. ◀

W-2072


**ENGINE LUBRICATION SYSTEM**

**Checking And Adding Engine Oil**

See the Service Schedule for the correct service interval.  
(See Service Schedule on Page 149)

1. Stop the engine.
2. Open the tailgate. (See Tailgate on Page 157)

**Figure 348**



C200934a

3. Remove the dipstick (Item 1) [Figure 348].
4. Keep the oil level between the marks on the dipstick.

Use a good quality motor oil that meets the correct API Service Classification.

**Engine Oil Chart**

<b>ENGINE CRANKCASE OIL</b>	
Recommended SAE Viscosity Number	
C°	F°
-40 -34 -29 -23 -18 -12 -7 -1 +4 +10 +17 +21 +27 +32 +38 +43 +49	-40 -30 -20 -10 0 +10 +20 +30 +40 +50 +60 +70 +80 +90 +100 +110 +120
NA3237A	
Refer to the temperature range anticipated before next oil change.	
Must use API Category CK-4 or better or ACEA E9 or better.	
Do not use API category FA-4 engine oil.	
[1] SAE 10W-30	

**ENGINE CRANKCASE OIL**

[2] SAE 15W-40

[3] Bobcat Synthetic Oil (SAE 5W-40)

Bobcat engine oils are recommended for use in this machine. If Bobcat engine oil is not available, use a good quality engine oil that meets API Service Category of CK-4 or better, or ACEA E9 or better.

**⚠ IMPORTANT**

**MACHINE DAMAGE HAZARD**

Failure to follow directions may result in severe engine damage.

Use of API Service Category FA-4 engine oil is not approved and may cause irreversible damage to the engine. ◀


I-2384

**Replacing Engine Oil And Filter**

See the Service Schedule for the correct service interval.  
(See Service Schedule on Page 149)

1. Run the engine until coolant is at operating temperature.
2. If necessary, rotate the upperstructure so that the oil drain plug is between the rear tracks.
3. Stop the engine.
4. Open the tailgate. (See Tailgate on Page 157)
5. Place a container under the oil pan.

**Figure 349**




C200935a

6. Remove the drain plug (Item 1) [Figure 349] from the engine oil pan and drain the oil.
7. Recycle or dispose of used oil in an environmentally safe manner.

**⚠ WARNING****FIRE AND EXPLOSION HAZARD**

Failure to use care around combustibles can cause serious injury or death. Always clean up spilled fuel or oil. Keep heat, flames, sparks or lighted tobacco away from fuel and oil. \*

W2103

**Figure 350**

C20655a


8. Remove the oil filter (Item 1) [Figure 350] and clean the filter housing surface.
9. Put clean oil on the replacement filter gasket.  
Use a genuine Bobcat replacement filter.
10. Install the filter and hand tighten.
11. Reinstall the drain plug (Item 1) [Figure 349].
12. Remove the fill cap (Item 2) [Figure 350].
13. Put oil in the engine.  
(See Capacities Specifications on Page 238)  
Do not overfill.
14. Install the fill cap (Item 2) [Figure 350].
15. Start the engine and let it run for several minutes.
16. Stop the engine.
17. Check for leaks at the oil drain plug and the oil filter.
18. Check the oil level.
19. Add oil as needed if it is not at the top mark on the dipstick.

**ENGINE COOLING SYSTEM****Cleaning The Engine Cooling System**

Allow the cooling system and engine to cool before servicing or cleaning the cooling system.


Check the cooling system every day to prevent overheating, loss of performance, or engine damage. (See Service Schedule on Page 149)

1. Stop the engine.
2. Open the right side cover.  
(See Right Side Cover on Page 158)
3. Remove the right side grille.  
(See Right Side Grille on Page 159)

**Figure 351**

P200134a

4. Remove the knob (Item 1) [Figure 351] on the condenser (if equipped).

**Figure 352**

P200135a

5. Separate the condenser (Item 1) (if equipped) from the radiator (Item 2) [Figure 352].

Be careful not to damage fins.

- Use air pressure or water pressure to clean the condenser (Item 1) and the radiator (Item 2) [Figure 352].

Be careful not to damage fins when cleaning

- Reposition the condenser (Item 1) [Figure 352] to the radiator.
- Install and tighten the knob (Item 1) [Figure 351].

### Checking Coolant Level

Check the coolant level when the coolant is cold.

#### **⚠ WARNING**

#### **BURN HAZARD**

Failure to follow instructions can cause serious burns.

Stop the engine and allow it to cool before removing the radiator cap or adding coolant. ◀

W-2070

#### **⚠ WARNING**

#### **IMPACT AND INJECTION HAZARDS**

Flying debris or pressurised fluids can cause serious injury or death.


Wear safety glasses to prevent eye injury when any of the following conditions exist:

- When fluids are under pressure.
- Flying debris or loose material.
- Engine is running.
- Tools are being used. ◀

W-2019

- Stop the engine.
- Open the tailgate. (See Tailgate on Page 157)

Figure 353



P200136a

- Check the coolant level in the coolant recovery tank (Item 1) [Figure 353].

It should be between the MAX and MIN marks.

- Add fluid as needed. (See Capacities Specifications on Page 238)

**NOTE:** The cooling system is factory filled with propylene glycol (purple colour). Do not mix propylene glycol with ethylene glycol.

#### **⚠ IMPORTANT**

#### **MACHINE DAMAGE HAZARD**

The incorrect ratio of water to coolant will reduce cooling system efficiency and may lead to premature engine failure.

- Always use the correct ratio of water to coolant.
- Always add a premixed solution. ◀

I-2124

#### Replacing Coolant (Cab Models)

The following items are needed to complete this task:

- Container to catch the coolant
- Locking hose pinching pliers or a similar tool.

These instructions are for cab models only. For canopy models, see the canopy section.

See the Service Schedule for correct service interval. (See Service Schedule on Page 149)

- Stop the engine.
- Open the tailgate. (See Tailgate on Page 157)
- Open the right side cover. (See Right Side Cover on Page 158)
- Remove the right side panel. (See Right Side Panel on Page 158)

#### **⚠ WARNING**


#### **BURN HAZARD**

Failure to follow instructions can cause serious burns.

Stop the engine and allow it to cool before removing the radiator cap or adding coolant. ◀


W-2070

Figure 354



5. When the engine is cool, loosen and remove the radiator cap (Item 1) [Figure 354].

Figure 355




6. Locate the heater valve (Item 1) [Figure 355], which is directly in front of the battery.
- The coolant is drained at the heater valve.
7. Pinch off the coolant hose (Item 2) [Figure 355] using a locking hose pinching pliers or a similar tool.
8. Reposition the clamp (Item 3) and disconnect the hose (Item 2) from the heater valve (Item 1) [Figure 355].
9. Drain the coolant into a container.
10. Install the coolant hose (Item 2) into the heater valve (Item 1) and install the clamp (Item 3) [Figure 355].
11. Remove the tool used to pinch off the coolant hose.
12. Recycle or dispose of used coolant in an environmentally safe manner.

13. Mix new coolant in a separate container. (See Capacities Specifications on Page 238)

The correct mixture of coolant to provide a -37°C (-34°F) freeze protection is 5 L propylene glycol mixed with 4,4 L of water or 1 U.S. gal propylene glycol mixed with 3.5 qt of water.

14. Add premixed coolant (47% water and 53% propylene glycol) to the radiator (Item 1) [Figure 354] until the coolant level reaches the top of the exchanger.
15. Install the radiator cap (Item 1) [Figure 354].

Figure 356



16. Add premixed coolant (47% water and 53% propylene glycol) to the recovery tank (Item 1) [Figure 356] until it is between the MAX and MIN marks.

**⚠ IMPORTANT**

**MACHINE DAMAGE HAZARD**  
The incorrect ratio of water to coolant will reduce cooling system efficiency and may lead to premature engine failure.

- Always use the correct ratio of water to coolant.
- Always add a premixed solution. ◀

I-2124

17. Run the engine until it is at operating temperature.
18. Stop the engine.
19. Add coolant to the recovery tank as needed.
20. Reinstall the right side panel.
21. Close the right side cover.
22. Close the tailgate.

## ELECTRICAL SYSTEM

### Electrical System Description

Figure 357



P200138a

The excavator has a 12 volt, negative earth electrical system. The electrical system is protected by fuses (Item 1) [Figure 357] located under the right side cover of the excavator. The fuses will protect the electrical system when there is an electrical overload. The reason for the overload must be found and corrected before starting the engine again.

### **⚠ WARNING**

#### **CHEMICAL HAZARD**

Contact with or ingestion of battery acid can cause serious injury or death.

- Batteries contain acid that burns eyes and skin on contact. Wear safety goggles, protective clothing, and rubber gloves to keep acid off body.
- In case of acid contact, wash immediately with water. In case of eye contact, get prompt medical attention and wash eye with clean, cool water for at least 5 minutes.
- If electrolyte is ingested, drink large quantities of water or milk! DO NOT induce vomiting. Get prompt medical attention. ◀


W2085

#### **Fuse And Relay Identification**

The decal inside the fuse cover (Item 1) [Figure 357] shows the location and amp ratings of the fuses.

Remove the cover to check or replace the fuses and relays.

Figure 358




The location and sizes are shown in the table below and on the decal [Figure 358]. Always replace fuses using the same type and capacity. Relays are identified by the letter “R” in the Amp column.

REF.	ICON	DESCRIPTION	AMP
1		Wiper / Washer	10
2		Switched Power	20
3		ACD	25
4		Alt / Fuel Pump	25
5		Controller (ECU)	25
6		HVAC	40
7		Ignition	5
8		ECU Sensor	15
9		Controller	25
10		ACD	25
11		Lights	20

REF.	ICON	DESCRIPTION	AMP
12		ACC	25
E		Switched Power	R
D		HVAC	R
C		Engine ECU	R
B		Horn	R
F		Fuel Lift Pump	R
G		Lights	R
H		Glow Relay	R
J		Starter	R

**Battery Disconnect Switch**

**Figure 359**



C201619a

Turn the battery disconnect switch to the OFF position before disconnecting or connecting the battery cables.

The battery disconnect switch (Item 1) [Figure 359] (if equipped) is located on the right front of the excavator.


- Rotate the switch (Item 1) [Figure 359] counterclockwise to turn the switch to the OFF position.
- Rotate the switch (Item 1) [Figure 359] clockwise to turn to the ON position (shown here in the ON position).

**Battery Maintenance**

See the Service Schedule for the correct service interval. (See Service Schedule on Page 149)

The Bobcat brand battery supplied with your machine is sealed and does not require watering. Proper charging and storage are important to maximise the life of all batteries.

**Figure 360**



P200188

Simple steps for reliability and long battery life:

- Keep battery posts and terminals clean [Figure 360].
- Keep terminals tight.
- Remove corrosion from battery and terminals with sodium bicarbonate (baking soda) and water solution.
- Put Bobcat Battery Saver or grease on the battery terminals and cable ends to prevent corrosion.
- Operate the machine for at least 15 minutes to recover from the battery drain caused by engine start up whenever practical.
- Maintain the battery charge level. This is a key factor for long battery life.
- Charge a severely discharged battery with a battery charger instead of relying on the machine charging system. (See Battery Charging on Page 175)
- Check the battery state of charge every 30 days on machines that are not frequently used. (See Testing The Battery on Page 175)

**⚠ WARNING**

**CHEMICAL HAZARD**

Contact with or ingestion of battery acid can cause serious injury or death.

- Batteries contain acid that burns eyes and skin on contact. Wear safety goggles, protective clothing, and rubber gloves to keep acid off body.
- In case of acid contact, wash immediately with water. In case of eye contact, get prompt medical attention and wash eye with clean, cool water for at least 5 minutes.
- If electrolyte is ingested, drink large quantities of water or milk! DO NOT induce vomiting. Get prompt medical attention. ◀

W-2085

### Maintaining Battery Charge Level

All batteries will self-discharge over time. This machine has features that require battery power even when the machine is not being used. Use of a quality battery maintainer is highly recommended to ensure that your machine is ready to start when you need it and avoid costly battery replacement.

#### Battery Maintainers


Use a good quality battery maintainer to keep the battery above 12.4 volts for machines that are not frequently used. Batteries below 12.4 volts must first be charged using a battery charger. Solar maintainers should have a minimum capacity of 10 watts to be effective.

#### Battery Service During Machine Storage

- Remove the battery if storing the machine for an extended period of time.
- Fully charge the battery.
- Store the battery in a cool dry place above freezing and boost charge periodically.
- If battery removal is not desired, a good quality battery maintainer must be used to compensate for battery self-discharge and parasitic loads from machine controllers, accessories, and features such as connected machine intelligence.

#### Testing The Battery

Figure 361



The simplest and most common check to determine battery state of charge is to use a digital multimeter or voltmeter (Item 1) [Figure 361].

A battery found below 12.4 volts must be charged to 100% charge per the battery charger's recommendation. Allow at least 60 minutes after operating the machine or charging the battery to get an accurate reading.

If the reading is less than 12.4 volts after the battery has been charged for several hours, see your Bobcat dealer to have a more thorough battery test performed.

The freezing point of battery electrolyte is dependent on the battery state of charge. Keeping the battery voltage above 12.4 volts will help prevent batteries from freezing, even at extremely low temperatures.

If the battery freezes, the internal grid may be damaged and the case will be distorted or cracked. If this happens, dispose of the battery according to local regulations.

#### Battery Charging

A battery charger designed for 12 volt charging systems is recommended. Follow the battery charger manufacturer's instructions to charge the battery to 12.6 volts (100% charge). Batteries should be charged at room temperature to avoid an undercharge or overcharge condition. Never attempt to charge a frozen battery.

The following table can be used to identify the approximate amount of time required to charge a discharged battery. Allow at least 60 minutes after operating the machine or charging the battery to get an accurate reading.

Battery Voltage	State of Charge	Charger Maximum Rate		
		30 Amps	20 Amps	10 Amps
12.6 V	100%	Ready to Use		
12.4 V	75%	0.9 hr	1.3 hr	2.5 hr
12.2 V	50%	1.9 hr	2.7 hr	5.1 hr
12.0 V	25%	2.9 hr	4.3 hr	7.8 hr
11.8 V	0%	4.0 hr	5.7 hr	10.7 hr

**NOTE:** Use a good quality charger to avoid battery damage from overcharging.

### ⚠ WARNING

#### EXPLOSION HAZARD

Battery gas can explode and cause serious injury or death.

- Keep arcs, sparks, flames and lighted tobacco away from batteries. When jumping from booster battery make final connection (negative) at machine frame.
- Do not jump start or charge a frozen or damaged battery. Warm battery to 16°C (60°F) before connecting to a charger. Unplug charger before connecting or disconnecting cables to a battery. Never lean over battery while boosting, testing or charging. ◀

#### Using A Booster Battery (Jump Starting)

The following item is needed to complete this task:


- 12 volt booster battery

If it is necessary to use a booster battery to start the engine, be careful! There must be one person in the

operator's seat and one person to connect and disconnect the battery cables.

1. Be sure the key switch is OFF.
2. Open the tailgate. (See Tailgate on Page 157)

Figure 362



C200723a

3. Connect the cable to the positive (+) terminal (Item 1) [Figure 362] of the excavator starter.
4. Connect the other cable to the tailgate latch bolt (Item 2) [Figure 362].
5. Start the engine.
6. After the engine has started, remove the negative (ground) cable first (Item 2) [Figure 362].
7. Disconnect the cable from the positive terminal (Item 1) [Figure 362].

**⚠ IMPORTANT**

**MACHINE DAMAGE HAZARD**

Damage to the alternator can occur

Do not operate machine if:

- Engine is operated with battery cables disconnected.
- Battery cables are connected when using a fast charger or when welding on the machine. Remove both cables from the battery.
- Extra battery cables (booster cables) are connected wrong. ◀

I-2023

**⚠ WARNING**

**CHEMICAL HAZARD**

Contact with or ingestion of battery acid can cause serious injury or death.


- Batteries contain acid that burns eyes and skin on contact. Wear safety goggles, protective clothing, and rubber gloves to keep acid off body.
- In case of acid contact, wash immediately with water. In case of eye contact, get prompt medical attention and wash eye with clean, cool water for at least 5 minutes.
- If electrolyte is ingested, drink large quantities of water or milk! DO NOT induce vomiting. Get prompt medical attention. ◀

W-2065

**Removing And Installing The Battery**

1. Open the right side cover. (See Right Side Cover on Page 158)
2. Remove the right side panel. (See Right Side Panel on Page 158)

Figure 363



P200140a

3. Disconnect the negative (-) cable (Item 1) [Figure 363].
4. Disconnect the positive (+) cable (Item 2) [Figure 363].
5. Remove the bolts (Item 3) [Figure 363] on both sides of the battery and remove the hold-down clamp.
6. Remove the battery.
 

Always clean the terminals and the cable ends, even when installing a new battery.
7. Install the battery.
8. Install the hold-down clamp and tighten the bolts.
9. Connect the positive (+) cable (Item 2) [Figure 363].

10. Connect the negative (-) cable (Item 1) [Figure 363] last to prevent sparks.

**⚠ WARNING**

**CHEMICAL HAZARD**

Contact with or ingestion of battery acid can cause serious injury or death.

- Batteries contain acid that burns eyes and skin on contact. Wear safety goggles, protective clothing, and rubber gloves to keep acid off body.
- In case of acid contact, wash immediately with water. In case of eye contact, get prompt medical attention and wash eye with clean, cool water for at least 5 minutes.
- If electrolyte is ingested, drink large quantities of water or milk! DO NOT induce vomiting. Get prompt medical attention. ◀

W-2065


**HYDRAULIC SYSTEM**

**Checking And Adding Hydraulic Fluid**

The preferred method is to check the hydraulic fluid when it is cold. See the Service Schedule for the correct service interval. (See Service Schedule on Page 149)

1. Park the machine on a flat surface.


**Figure 364**



C200403a

2. Extend the boom, arm, and bucket. Lower the bucket to the ground and lower the blade so the machine is in the position shown [Figure 364].
3. Stop the engine.
4. Open the right side cover. (See Right Side Cover on Page 158)

**Figure 365**




P200141a

5. Check the hydraulic fluid level. It must be visible in the sight gauge (Item 1) [Figure 365].

The decal on the hydraulic tank shows the correct fill level.

- Item 1 [Figure 365] is the correct fluid level when the machine is HOT (optional).
  - Item 2 [Figure 365] is the correct fluid level when the machine is COLD (preferred).
6. Clean the surface around the fill cap and remove the cap from the tank (Item 3) [Figure 365].

Figure 366



7. Check the condition of the fill strainer screen (Item 1) [Figure 366].


**⚠ WARNING**

**FIRE AND EXPLOSION HAZARD**  
 Failure to use care around combustibles can cause serious injury or death.  
 Always clean up spilled fuel or oil. Keep heat, flames, sparks or lighted tobacco away from fuel and oil. ◀

Clean or replace as necessary.

8. Add the correct fluid to the tank until it is visible in the sight gauge [Figure 365].  
 (See Capacities Specifications on Page 238)
- Be sure the screen is installed before adding fluid.
9. Check the cap.  
 Clean or replace as necessary.
10. Install the cap.
11. Close the right side cover.

**Hydraulic Fluid Chart**



Use only recommended fluid in the hydraulic system.

**Replacing The Hydraulic Filter**


**⚠ WARNING**

**FIRE AND EXPLOSION HAZARD**  
 Failure to use care around combustibles can cause serious injury or death.  
 Always clean up spilled fuel or oil. Keep heat, flames, sparks or lighted tobacco away from fuel and oil. ◀

See the Service Schedule for the correct service interval.  
 (See Service Schedule on Page 149)

1. Stop the engine.
2. Open the tailgate. (See Tailgate on Page 157)
3. Open the right side cover.  
 (See Right Side Cover on Page 158)
4. Remove the right side panel.  
 (See Right Side Panel on Page 158)

**Figure 367**



5. Install locking hose pliers (Item 1) [Figure 367] on the hoses running to the filter housing.
6. Remove the hydraulic filter (Item 2) [Figure 367].
7. Clean the housing where the filter gasket makes contact.
8. Apply clean hydraulic fluid to the filter gasket.
9. Install the new filter.  
Use a genuine Bobcat replacement filter.  
Tighten until the gasket first makes contact plus 1/2 turn.
10. Remove locking hose pliers (Item 1) [Figure 367].
11. Install the right side panel.
12. Close the right side cover.
13. Close the tailgate.

**Replacing The Case Drain Filter**

**⚠ WARNING**

**FIRE AND EXPLOSION HAZARD**  
 Failure to use care around combustibles can cause serious injury or death.  
 Always clean up spilled fuel or oil. Keep heat, flames, sparks or lighted tobacco away from fuel and oil. ◀


See the Service Schedule for the correct service interval.  
 (See Service Schedule on Page 149)

The case drain filter is located in the right front corner of the excavator.

1. Stop the engine.
2. Open the tailgate. (See Tailgate on Page 157)

3. Open the right side cover.  
 (See Right Side Cover on Page 158)
4. Remove the right side panel.  
 (See Right Side Panel on Page 158)

**Figure 368**



5. Install locking hose pliers (Item 1) [Figure 368] on the hoses running to the filter housing.
6. Remove the case drain filter (Item 2) [Figure 368].
7. Clean the housing where the filter gasket makes contact.
8. Apply clean hydraulic fluid to the filter gasket.
9. Install the new filter.  
Use a genuine Bobcat replacement filter.  
Tighten until the gasket first makes contact plus 3/4 turn.
10. Remove locking hose pliers (Item 1) [Figure 368].
11. Install the right side panel.
12. Close the right side cover.
13. Close the tailgate.

**Replacing Hydraulic Fluid**

The following items are needed to complete this task:

- Container for the hydraulic fluid
- Hose with female quick coupler on one end

**⚠ WARNING**

**INJECTION HAZARD**

Pressurised diesel fuel or hydraulic fluid can penetrate skin and eyes, causing serious injury or death.


Fluid leaks under pressure may not be visible. Use a piece of cardboard or wood to find leaks. **DO NOT** use your bare hand. Wear safety goggles. If fluid enters skin or eyes, get immediate medical attention from a doctor familiar with this injury. ◀

W2072

See the Service Schedule for the correct service interval. (See Service Schedule on Page 149)

1. Extend the boom, arm, and bucket. Lower the bucket to the ground and lower the blade so the machine is in the position shown [Figure 364].
2. Stop the engine.
3. Open the tailgate. (See Tailgate on Page 157)
4. Open the right side cover. (See Right Side Cover on Page 158)
5. Remove the right side panel. (See Right Side Panel on Page 158)


**Figure 369**



P200583a

6. Locate the drain hose (Item 1) [Figure 369], which is clamped in place under the hydraulic filter.
7. Place a container under the hose.
8. Unscrew the plug at the end of the drain hose and drain the fluid into the container.
9. Recycle or dispose of the fluid in an environmentally safe manner.
10. Put the plug back on the end of the drain hose and install the drain hose back in the storage position.


**Figure 370**



C200664b

11. Add fluid to the hydraulic tank (Item 1) [Figure 370]. (See Capacities Specifications on Page 238)  
  
The level should be between the hot fill (Item 2) and cold fill (Item 3) marks [Figure 370].
12. Locate the male coupler (Item 4) [Figure 370] that is to the left of the hydraulic tank and remove the cap.

**Figure 371**



P141795b

13. Install a female quick coupler and hose on the male quick coupler (Item 1) [Figure 371].
14. Route the hose (Item 1) from the male quick coupler into the hydraulic tank (Item 2) [Figure 371].
15. Start the machine.
16. Remove the female quick coupler (Item 1) [Figure 371] after a steady stream of hydraulic fluid, free of any air bubbles, drains from the hose.
17. Reinstall the fill cap (Item 1) [Figure 370] on the hydraulic tank.

18. Operate the machine through the hydraulic functions.
19. Stop the engine.
20. Check the hydraulic fluid level and add as needed.
21. Install the right side panel. Close the tailgate and right side cover.

## DIESEL PARTICULATE FILTER (DPF) SYSTEM

### DPF Service Description

The engine exhaust system is equipped with a diesel particulate filter (DPF). The DPF is an emissions reduction device that removes diesel particulate matter (soot) from the exhaust gases of the diesel engine. The DPF will trap and collect the soot until it is burned off. The process of burning off the collected soot is called regeneration.


A service regeneration cycle may be required if too much soot is allowed to accumulate in the DPF. This can occur in the following situations:

- The machine is often operated for brief periods (less than 30 minutes) that do not allow sufficient time for the DPF to complete an automatic or operator activated forced regeneration cycle.
- The inhibit mode is used for an extended period of time. This will inhibit the DPF from actively regenerating and burning off the collected soot.

Ash residue will remain after the regeneration process is complete. The ash must be periodically removed from the DPF.

### DPF Service Regeneration

Figure 372



The machine will alert the operator when DPF service is required [Figure 372].

Service code “P24A3” “Very High DPF Soot Mass - Service Regen Required” will be accompanied by a severe torque reduction.

Service regeneration requires the use of specialised equipment. See your Bobcat dealer for service regeneration.

### DPF Cleaning

Contact your Bobcat dealer to arrange the cleaning of the DPF when indicated.

Service code “P242F” “High DPF Ash Content - Ash Cleaning Needed” will show in the display screen when DPF cleaning is necessary.

The DPF is a critical component of the engine exhaust system and must be properly maintained. Specialised equipment is required to clean the ash from the DPF. See your Bobcat dealer for DPF cleaning.

## TRACK TENSION

### Track Tension Description

The wear of the pins and bushings on the undercarriage vary with working conditions and different types of soil conditions. It is necessary to inspect track tension and maintain the correct tension. See the Service Schedule for the correct service interval.  
(See Service Schedule on Page 149)

### Types of Track Tensioning Systems

See one of the following sections to adjust track tension depending on the track tensioning system on your machine.


- Manual track tensioning  
(See Adjusting Track Tension Manually on Page 182)
- Auto track tensioning  
(See Adjusting Track Tension Automatically on Page 184)

### Adjusting Track Tension Manually

The following item is needed to complete this task:

- Bleed tool to decrease track tension. The bleed tool will direct the flow of grease to aid in cleanup. See your Bobcat dealer to order a bleed tool.
1. Raise one side of the machine approximately 100 mm (4 in) using the boom and arm.

**Figure 373**



P128643b

2. Raise the blade fully and install jackstands under the blade [Figure 373].

Figure 374



P91969a

3. Install jackstands under the track frame [Figure 374].
4. Raise the boom until all machine weight is on the jackstands.
5. Stop the engine.


**⚠ WARNING**

**PINCHING HAZARD**

Keep finger and hands out of pinch points when checking the track tension. ◀


W2142

Figure 375



NA15893a


Figure 376



NA15892a

6. Measure the track clearance at the middle track roller.
  - Use a bolt or dowel of the appropriate size to check the gap.
    - a. For rubber tracks, measure the gap between the contact surface of the roller and the track. The clearance (Item 1) [Figure 375] should be 30,0 – 25,0 mm (1.20 – 1.00 in).
    - b. For steel or segmented tracks, measure the gap between the external roller flange and the track grouser. The clearance (Item 1) [Figure 376] should be 108,0 – 101,6 mm (4.25 – 4.00 in).

Figure 377



P113853a


7. To **increase track tension**, add grease to the track tension fitting (Item 1) [Figure 377] until the track tension is correct.

**⚠ WARNING**

**INJECTION HAZARD**

High pressure grease can penetrate skin and eyes, causing serious injury. Do not loosen the track tension fitting more than 1 - 1/2 turns. ◀

Figure 378



8. To **decrease track tension**, install the bleed tool (Item 1) on the track tension fitting (Item 2) [Figure 378]. Turn the tool 90° counterclockwise and let the grease flow into a container. Continue to release pressure until the track tension is correct.
  - a. Dispose of the grease in an environmentally friendly manner.
9. Tighten the track tension fitting to 24 – 30 N·m (18 – 22 ft-lb) torque.
10. Repeat the procedure for the opposite side.

**Adjusting Track Tension Automatically**

In machines with auto track tensioning, the machine uses hydraulic fluid to automatically maintain track tension. Operators are not required to make adjustments to the track tensioning components for normal operation of the machine.

To tension the track automatically upon startup:

1. Start the engine.
2. Lower the left control console.
3. Wait for five seconds while the track automatically tensions.

The track tension may decrease if the machine is parked for an extended period of time without operation.

See your Bobcat dealer for service if the track tension is noticeably loose after the machine sits overnight.

**Adjusting The Hydraulic Pressure Reducing Valve**

The hydraulic pressure reducing valve is adjusted at the factory to optimize track retention while maximising track life.

You can adjust the valve to allow a lower track tension, which could be beneficial in certain conditions.


The hydraulic pressure reducing valve is located on the pilot manifold.

**⚠ IMPORTANT**

**MACHINE DAMAGE HAZARD**


Failure to follow directions may result in machine damage. Exceeding factory settings can cause damage to the travel motors. ◀

Figure 379



1. To decrease the track tension, loosen the nut shown here (Item 1) [Figure 379] on the pilot manifold and turn the hex head screw counterclockwise.

Figure 380



2. After decreasing track tension, you must relieve the pressure in the cylinder. Relieve the pressure using the hydraulic tensioner valve (Item 1) [Figure 380] on the side of the tracks.
3. Make adjustments in one full turn increments and test the track tension by operating the machine.

Continue to adjust until the desired track tension for your application is achieved.

### Returning The Hydraulic Pressure Reducing Valve To Factory Setting


See your Bobcat dealer to return the hydraulic pressure reducing valve to the factory setting. To approximate the factory setting, follow the steps below.

1. Loosen the nut (Item 1) [Figure 379], turning the hex head screw clockwise until it bottoms out.
2. Turn the hex head screw counterclockwise five full turns.
3. Tighten the nut to 4,0 – 4,7 N•m (3.0 – 3.5 ft-lb) torque.

## TRAVEL MOTOR

### Checking And Adding Travel Motor Fluid

Figure 381



1. Park the excavator on a level surface with the plugs (Items 1 and 2) [Figure 381] positioned as shown.
2. Remove the plug (Item 1) [Figure 381].  
The fluid level must be at the bottom edge of the hole.
3. If the fluid level is low, remove the top plug (Item 2) [Figure 381] and add lubricant through the hole.  
Lubricant should be API GL-4 or 5 containing extreme pressure additive (SAE 80W90).
4. Install the plugs (Items 1 and 2) [Figure 381].
5. Repeat the procedure for the opposite travel motor.

### Replacing Travel Motor Fluid

See the Service Schedule for the correct service interval. (See Service Schedule on Page 149)


## WARNING

### FIRE AND EXPLOSION HAZARD

Failure to use care around combustibles can cause serious injury or death. Always clean up spilled fuel or oil. Keep heat, flames, sparks or lighted tobacco away from fuel and oil. ◀

W-2103

Figure 382



P97148F

1. Park the excavator on a level surface with plugs (Items 1, 2, and 3) [Figure 382] positioned as shown.
2. Remove top and bottom plugs (Items 1 and 2) [Figure 382] and drain the lubricant into a container.
3. Install the bottom plug (Item 2) [Figure 382].
4. Remove the middle plug (Item 3) [Figure 382].
5. Add lubricant through the top hole (Item 1) until the lube level is at the bottom edge of the check hole (Item 3) [Figure 382]. (See Capacities Specifications on Page 238)

Lubricant should be API GL-4 or 5 containing extreme pressure additive (SAE 80W90).

6. Install the plugs (Item 1 and 3) [Figure 382].
7. Repeat the procedure for the opposite travel motor.

## BELTS

### Adjusting Alternator Belt

The alternator belt is a special maintenance-free type that is pretensioned over the pulleys. This belt eliminates the need for a tensioning device and does not require periodic adjustment. Contact your Bobcat dealer for replacement parts.

### Replacing Alternator Belt


The following item is needed to complete this task:

- Alternator belt installation tool. See your local Bobcat dealer.

If your machine is equipped with air conditioning, see your Bobcat dealer for belt replacement.

1. Stop the engine.
2. Open the tailgate. (See Tailgate on Page 157)


Figure 383



P200151a


3. Loosen the two bolts (Item 1) [Figure 383] on the fan guard and slide the fan guard off.

**Figure 384**




4. Position the lower alternator tool (Item 1) around the spacer (Item 2) [Figure 384].

**Figure 385**




5. Position the upper alternator tool (Item 1) and install the bolts and nuts on the tool (Item 2) [Figure 385].

**Figure 386**




6. Loosen the top and bottom bolts (Item 1) [Figure 386].
7. Lift up on the alternator tool (Item 2) and remove the bolt (Item 3) [Figure 386].

**Figure 387**



8. Cut the old belt (Item 1) [Figure 387] and remove the belt from the pulleys.
9. Inspect the pulleys for wear.
10. Install the new belt.

**Figure 388**



C143846d

11. Use the alternator tool (Item 1) to align the alternator to the alternator mounting bolt (Item 2) [Figure 388].
12. Tighten all three alternator mounting bolts.
13. Install the fan guard and tighten the two bolts to 10 – 12 N · m (7 – 9 ft-lb) torque.
14. Close the tailgate.

**Adjusting Air Conditioning Belt**

This machine may be equipped with air conditioning.

The air conditioning belt is a special maintenance-free type that is pretensioned over the pulleys. This belt eliminates the need for a tensioning device and does not require periodic adjustment. Contact your Bobcat dealer for replacement parts.


**Replacing Air Conditioning Belt**

See your Bobcat dealer for air conditioning belt replacement.

**QUICK COUPLER**

**Inspecting And Maintaining The Bucket Link And Coupler**

**Figure 389**




S35382a

- Inspect the bucket link (Item 1) [Figure 389] for wear or damage.
- Inspect the attachment pins (Item 2) [Figure 389] for wear or damage.

Repair or replace damaged parts.

**Figure 390**



p-72274d

- Inspect the quick coupler for wear or damage. Inspect the quick coupler pins (Item 1) and the hooks (Item 2) (on the attachment) for wear or damage [Figure 390].

Repair or replace damaged parts.

## BUCKET TEETH

### Replacing Bucket Teeth

#### **⚠ WARNING**

#### IMPACT AND INJECTION HAZARDS

Flying debris and high pressure fluids can cause serious injury eye injury.


Wear safety glasses to prevent eye injury when any of the following conditions exist:

- High pressure fluids, springs or other stored energy components.
- Flying debris or loose material.
- Engine is running.
- Tools are being used.

W-2505

1. Position the bucket so the bucket teeth are at a 30° angle up from the ground to better access the teeth.
2. Lower the boom until the bucket is fully on the ground.
3. Stop the engine and exit the excavator.
4. Inspect the pins and teeth of the bucket.
5. Remove any damaged teeth.

Figure 391



P69201d

6. Position a new tooth point on the shank and install a new retaining pin (Item 1) [Figure 391].
  - a. Install the retaining pin (Item 1) as shown, with the notch (Item 2) [Figure 391] to the front, for proper fit and tooth retention.

The correct orientation of the retaining pin is also shown on the sides of tooth points (Item 3) [Figure 391].


7. Push the retaining pin in until it is flush with the top of the point.

## CUTTING EDGE (ANGLE BLADE ONLY)

### Reversing Or Replacing The Angle Blade

The cutting edge is reversible and replaceable.


Figure 392



P92276a

1. Raise the blade fully and install jackstands (Item 1) [Figure 392] under the blade arms.


Figure 393



P72782a

2. Place a jack under the cutting edge [Figure 393].

Figure 394



P72780a

3. Remove the nuts and bolts (Item 1) [Figure 394] from the cutting edge.
4. Lower the jack and remove the cutting edge.
5. Reverse the cutting edge or replace it.
6. To install, tighten nuts to 125 N·m (90 ft-lb) torque.

**MACHINE LUBRICATION**


**Grease Fitting Locations**

Always use a good quality lithium-based multipurpose grease when lubricating the machine. Apply the lubricant until extra grease shows.

**Lubricate Every 8 – 10 Hours**

*Bucket, Arm, and Boom*

Figure 395




NA18172h

REF	DESCRIPTION	QTY
1	Bucket Pivot	3
2	Bucket Link	2
3	Bucket Cylinder Rod End	1
4	Arm	1
5	Bucket Link Pin	1
6	Bucket Cylinder Base End	1
7	Arm Pivot	1
8	Arm Cylinder Rod End	1
9	Arm Cylinder Base End	1
10	Boom Cylinder Rod End	1

Boom Base

Figure 396




NA18172i

REF	DESCRIPTION	QTY
1	Boom Swing Cylinder Rod End	1
2	Boom Cylinder Base End	1
3	Boom Pivot	1
4	Boom Swing Pivot	2

Blade Cylinder

Figure 397




NA20141a

REF	DESCRIPTION	QTY
1	Angle Blade Cylinder Rod End (Angle Blade Only)	1
2	Angle Blade Cylinder Base End (Angle Blade Only)	1
3	Angle Blade Pivot (Angle Blade Only)	1
4	Blade Cylinder Base End	1
5	Blade Pivots	2
6	Blade Cylinder Rod End	1

Lubricate Every 50 Hours

Figure 398



P01982b


REF	DESCRIPTION	QTY
1	Swing Pinion [A]	1
2	Swing Circle	1

[A] Install three to four pumps of grease then rotate the upperstructure 90°. Install three to four pumps of grease and again rotate the upperstructure 90°. Repeat this until the slew pinion has been greased at four positions.

PIVOT PINS

Pivot Pin Inspection And Maintenance

Figure 399



P200155a

The pivots and cylinders (Item 1) have a large pin held in position with a bolt (Item 2) and a nut (Item 3) [Figure 399] securing the pin.

After the nut (Item 3) and bolt (Item 2) [Figure 399] are installed and nuts are tightened together, the bolt should be free to spin.

See your Bobcat dealer for replacement parts.

## STORAGE AND RETURN TO SERVICE

### Extended Storage Procedure

Sometimes it may be necessary to store your machine for an extended period of time. Below is a list of items to perform before storage.

- Thoroughly clean the machine including the engine compartment.
- Lubricate the machine.
- Replace worn or damaged parts.
- Drive the machine onto planks in a dry protected shelter.
- Lower the boom fully with the bucket flat on the ground.
- Put grease on any exposed cylinder rods.
- Put fuel stabiliser in the fuel tank and run the engine a few minutes to circulate the stabiliser to the pump and fuel injectors.

**NOTE:** If biodiesel blend fuel has been used, perform the following:

- Drain the fuel tank, refill with 100% petroleum diesel fuel, add fuel stabiliser and run the engine for at least 30 minutes.
- Drain and flush the cooling system. Refill with premixed coolant.
- Replace all fluids and filters (engine, hydraulic).
- Replace air cleaner, heater, and air conditioning filters.
- Put all controls in NEUTRAL position.
- Remove the battery. Charge the battery. Store the battery in a cool dry location above freezing temperatures and charge it periodically during storage.
- Cover the exhaust pipe opening.
- Tag the machine to indicate that it is in storage condition.
- Clean HVAC drain valves (if equipped).

### Returning Machine To Service

Follow this list of items to return the machine to service after it has been in extended storage.


- Check the engine and hydraulic oil levels.
- Check coolant level.
- Install a fully charged battery.
- Remove grease from exposed cylinder rods.

- Check all belt tensions.
- Be sure all shields and guards are in place.
- Lubricate the machine.
- Remove cover from exhaust pipe opening.
- Start the engine and let run for a few minutes while observing the instrument panels and systems for correct operation.
- Drive machine off the planks.
- Operate machine, check for correct function.
- Stop the engine and check for leaks. Repair as needed.

**NAVIGATION (STANDARD DISPLAY)**

**Opening Navigation Bar**

**Figure 400**



1. Select the navigation handle (Item 1) [Figure 400] to open the navigation bar.
2. Select one of the following screens that appear on the navigation bar:
  1. **GAUGES** screen
  2. **CAMERA** screen  
(See Operating Rear View Camera on Page 42)
  3. **VITALS** screen  
(See Vitals (Standard Display) on Page 195)
  4. **SERVICE** screen  
(See Service (Standard Display) on Page 196)
  5. **DEPTH CHECK** screen (if equipped)  
(See Depth Check (Standard Display) on Page 112)
  6. **SETTINGS** screen  
(See Settings (Standard Display) on Page 197)

**Active Shortcuts**

**Figure 401**



The following icons can appear in the navigation handle position [Figure 401]. Selecting an icon will take you directly to the indicated screen.


ICON	DESCRIPTION	FUNCTION
	Navigation Handle	Opens and closes the navigation bar.
	Service Due	Opens <b>SERVICE</b> screen.
	Software Update	Opens <b>SOFTWARE</b> screen.
	Machine Derate	Opens <b>MACHINE PERFORMANCE</b> screen.
	Warning	Opens <b>SERVICE CODES</b> screen.

## VITALS (STANDARD DISPLAY)

## Accessing Vital Detail And Machine Performance

1. Select **[NAVIGATION HANDLE]**→ **[VITALS]**.


Figure 402



NA3752b

2. On the **VITAL DETAIL** screen [Figure 402], view a digital readout of the gauges. The screen provides real-time monitoring of:
  - Engine Speed (RPM)
  - Engine Oil Pressure
  - Engine Coolant Temperature
  - System Voltage
  - Hydraulic Fluid Pressure
  - Hydraulic Fluid Temperature
  - Fuel Usage (G/h or L/h)
3. Select **[MACHINE PERFORMANCE]** (Item 1) [Figure 402] to view any limitations or restrictions that prevent machine damage.

Figure 403



NA3702

Figure 404



NA3785

Examples of machine performance screens are shown in [Figure 403] and [Figure 404].

**SERVICE (STANDARD DISPLAY)****Recording A Service**


1. Select **[NAVIGATION HANDLE]**→ **[SERVICE]**.

**Figure 405**

2. Select **[RECORD A SERVICE]** (Item 1) [Figure 405] to record the service as completed.

**Viewing Service Codes**

1. Select the **[NAVIGATION HANDLE]**→ **[SERVICE]**.

**Figure 406**

2. Select **[VIEW SERVICE CODES]** (Item 1) [Figure 406].

**Figure 407**

Hours	Code	User
Active	R7404	Owner
Main Controller No Communication		
Active	M5332	Owner
Offset Rod Solenoid Overcurrent		
Active	M5028	Owner
Front Light Output Failure		


3. Scroll down if necessary to view service codes [Figure 407].

**SETTINGS (STANDARD DISPLAY)**

**Adjusting Display Brightness**

1. Select **[NAVIGATION HANDLE]**→ **[SETTINGS]**→ **[DISPLAY SETTINGS]**.

**Figure 408**




2. Select **[AUTO BRIGHTNESS]** (Item 1) [Figure 408] to turn it on / off. When on, the brightness will automatically adjust according to the ambient light.  
OR  
To adjust the display brightness, move the slider (Item 2) [Figure 408] to the left to dim, to the right to brighten.

**Managing Operators**


1. Select **[NAVIGATION HANDLE]**→ **[SETTINGS]**→ **[SECURITY SETTINGS]**.
2. Enter the password and select the **[ENTER]** icon.

**Figure 409**



3. Select **[MANAGE OPERATORS]** (Item 1) [Figure 409].

**Figure 410**



4. Select **[EDIT PASSWORD]** (Item 1) [Figure 410] to change a password or remove an operator.  
OR  
Select **[ADD PASSWORD]** (Item 2) [Figure 410] to enter a password for a new operator.

**Machine Lockout And Quick Start**

The owner can enable Machine Lockout:

- If Machine Lockout is on, a password must be entered before the machine can be operated.
- If Machine Lockout is off, the machine can be operated without a password.

The owner also has the option to enable Quick Start:

- If Quick Start is on, the machine can be started before the display is fully booted up.
- If Quick Start is off, the machine can't be started until the display is fully booted up.

The machine will not start if engine fuel priming or pre-heat is required. When the Wait to Start light turns off, the machine can be started. (See Quick Start Description on Page 77)

**Password Description**


**Owner Password:** Allows for full use of the machine and to set up the display security settings. There is only one owner password. The owner password must be used to change the owner or operator passwords. If this password is lost, contact your Bobcat dealer to unlock the machine.

**Operator Passwords:** Allows starting and operating of the machine. The owner password is needed to change an operator password. There can be multiple operator passwords.

**Enabling Machine Lockout And Quick Start**

1. Select **[NAVIGATION HANDLE]**→ **[SETTINGS]**→ **[SECURITY SETTINGS]**.

Figure 411



NA37476

2. Select **[MACHINE LOCKOUT]** (Item 1) [Figure 411] to turn on / off.
3. Select **[QUICK START]** (Item 2) [Figure 411] to turn on / off.

Quick Start is always enabled when the Machine Lockout is off.

### Setting The System Language

1. Select **[NAVIGATION HANDLE]**→ **[SETTINGS]**→ **[LANGUAGE SETTINGS]**.

Figure 412



NA3718


2. On the **SET LANGUAGE** screen, scroll through the languages and select the desired language.

The selected language will take effect immediately and can be different for each operator.

### Switching Between English / Metric Units

1. Select **[NAVIGATION HANDLE]**→ **[SETTINGS]**.

Figure 413



NA3878

2. Scroll down and select **[UNITS]** (Item 1) [Figure 413] to toggle between English and metric units.

### Software Version

1. Select **[NAVIGATION HANDLE]**→ **[SETTINGS]**→ **[SOFTWARE INFORMATION]**.

Figure 414



NA3751

2. Use the **SOFTWARE** screen to find your software version and check for updates.

To update the software, see your Bobcat dealer.

## GAUGES (TOUCH DISPLAY)


## Notification Drawer

Figure 415



1. Press the clock (Item 1) [Figure 415] to open the notification drawer.

Figure 416



2. Use the notification drawer to gain quick access to:
  - Auto Brightness (Item 1)
  - Job Clocks (Item 2)
  - Screen Brightness (Item 3)
  - Night Mode Adjustment (Item 4)
3. Press the up arrow (Item 5) [Figure 416] to close the drawer.

## Accessing Vital Detail And Machine Performance

Figure 417




1. Select the vitals icon (Item 1) to navigate to the **VITAL DETAIL** screen.

Figure 418




2. On the **VITAL DETAIL** screen, view a digital readout of the gauges. The screen provides real-time monitoring of:
  - Engine Speed (RPM)
  - Engine Oil Pressure
  - Engine Coolant Temperature
  - System Voltage
  - Hydraulic Fluid Pressure
  - Hydraulic Fluid Temperature
  - Fuel Usage (G/h or L/h)
3. Select [**MACHINE PERFORMANCE**] (Item 1) [Figure 418] to view any limitations or restrictions that prevent machine damage.

Figure 419



NA3786

Figure 420



NA3787

Examples of machine performance screens are shown in [Figure 419] and [Figure 420].

## CAMERA (TOUCH DISPLAY)

## Operating Rear View Camera

Figure 421



NA3384j


Figure 422



C208172a

- Select [**CAMERA**] (Item 1) [Figure 421] to access the **CAMERA** screen.  
OR  
Press the right joystick button (Item 1) [Figure 422] to toggle between the **CAMERA** screen and the current screen.

Figure 423



NA3428b

The rotating spinner icon (Item 1) [Figure 423] indicates you are viewing a live broadcast from the camera.


- Select the **[FULL SCREEN]** icon (Item 2) [Figure 423] to make the camera view full screen. Touch anywhere on the screen to go back to the view shown.
- Select the **[SETTINGS]** icon (Item 3) [Figure 423] to go to the **CAMERA SETTINGS** screen.

(See Adjusting Rear View Camera Settings on Page 201)

### Adjusting Rear View Camera Settings

Select the **[SETTINGS]** icon on the **CAMERA** screen (Item 3) [Figure 423] to go to the **CAMERA SETTINGS** screen.

Figure 424



P132994a

- Select **[BACKUP LINES]** (Item 1) [Figure 424] to turn the lines on / off.
- Use the slider (Item 2) [Figure 424] to adjust the Backup Lines in or out.
- Select **[CENTER LINE]** (Item 3) [Figure 424] to turn the centre line on / off.

### PHONE (TOUCH DISPLAY)

See your Touch Display User Guide for more information about phone settings.

## AUDIO (TOUCH DISPLAY)

See your Touch Display User Guide for more information about audio settings.

## SERVICE (TOUCH DISPLAY)

### Viewing Service Codes

The most recent service codes are stored in history and can be viewed on the display.

**Figure 425**



NA3384

1. Select **[SERVICE]** (Item 1) [Figure 425] and then navigate to **[VIEW SERVICE CODES]**.

**Figure 426**



P132935a

2. Select a code (Item 1) [Figure 426] to go to the **SERVICE CODE DETAILS** screen.

Figure 427



P132977a

3. On the **SERVICE CODE DETAIL** screen, you can select **[CALL DEALER]** (Item 1) [Figure 427] (if a phone is paired, and the dealer information is entered).

OR

Scroll down to see code history. This will show when the code was activated in the past. It will show the machine hours, date, and the operator for each time the code was activated.

See the full list of service codes at the end of this chapter. (See Diagnostic Service Codes on Page 215)

### Viewing And Adjusting Service Schedule

The Service Schedule information on the display is based off the machine's Service Schedule. The service times show when the maintenance interval for each component is due. The display will notify the operator shortly before the next service is due and continue until the service is performed.

Figure 428



NA3384i

1. Select **[SERVICE]** (Item 1) [Figure 428].


Figure 429



C132961b

2. View the hours remaining until next scheduled service is due (Item 1) [Figure 429] and any overdue service on the service screen.
3. Select **[VIEW SERVICE SCHEDULE]** (Item 2) [Figure 429].

Figure 430



NA3759b

4. On the **SERVICE SCHEDULE** screen, view the next scheduled maintenance (Item 1) [Figure 430].
5. To make the maintenance interval more frequent, select **[ADJUST]** (Item 2) [Figure 430].
  - a. Select a new service interval and select **[ACCEPT]**.

### Recording A Service


After a service has been completed, you can create a record of what was done.

Figure 431



1. Select **[SERVICE]** (Item 1) [Figure 431].

Figure 432



2. Select **[RECORD A SERVICE]** (Item 1) [Figure 432].


Figure 433



3. Select **[+ADD SERVICE ITEM]** (Item 1) [Figure 433] to add additional items that were performed.
4. Select **[ADD NOTES]** (Item 2) [Figure 433] to add notes to the record.

5. Select **[RECORD SERVICE]** (Item 3) [Figure 433] to save the service record.

Figure 434




The Service Record will now list all the items that were marked as completed [Figure 434].

**Removing Service Records**

You must be logged in as the owner to complete this task.


1. Select **[SERVICE]** → **[VIEW SERVICE RECORD]**.

Figure 435



2. Select **[EDIT]** (Item 1) [Figure 435] to remove a service record.
3. After entering the password, select the **[ENTER]** icon.

Figure 436



4. Select the **[DELETE]** icon (Item 1) [Figure 436] to remove a service record.
5. Select **[SAVE]** (Item 2) [Figure 436] to confirm.  
OR  
Select **[X]** (Item 3) [Figure 436] to cancel.

## ATTACHMENTS (TOUCH DISPLAY)

### Accessing Attachment Information

The display shows basic attachment information, including the joystick switches that are used to control the attachments. The tooltips screens give information on using the attachment.


Always read and understand your Attachment Operator & Maintenance Manual before using attachments.

Figure 437



1. Select **[ATTACHMENTS]** (Item 1) [Figure 437].

Figure 438



2. Select one of the available attachments [Figure 438].

Figure 439



The basic joystick information is shown on the tooltips screens [Figure 439].

- Select the arrows (Item 1) [Figure 439] to access additional information.
- Scroll down to find the tooltips.

## SETTINGS (TOUCH DISPLAY)

### Setting Date And Time

1. Select **[SETTINGS]** → **[DISPLAY SETTINGS]**.

Figure 440



2. Select **[SET DATE]** (Item 1) [Figure 440].
  - a. Scroll to set the day, month, and year (Item 2) [Figure 440].
  - b. Select **[ACCEPT]** (Item 3) [Figure 440] to save the change.

Figure 441




3. Select **[SET TIME]** (Item 1) [Figure 441].
  - a. Scroll to choose between a 12 hr or 24 hr clock (Item 2) [Figure 441].
  - b. Scroll to set hour, minute, and AM / PM (Item 2) [Figure 441].
  - c. Select **[ACCEPT]** (Item 3) [Figure 441] to save the change.

### Adjusting Display Brightness

1. Select **[SETTINGS]** → **[DISPLAY SETTINGS]**.

Figure 442



2. To adjust the display brightness, move the slider (Item 1) [Figure 442] to the left to dim, to the right to brighten.

OR

Select **[AUTO BRIGHTNESS]** (Item 2) [Figure 442] to turn it on / off. When on, the brightness will automatically adjust according to the ambient light.


OR

Select **[DAY]**, **[AUTO]**, or **[NIGHT]** (Item 3) [Figure 442] mode. Auto mode automatically switches between Day and Night modes.

**Releasing Hydraulic Pressure In Excavator**

The engine must have been recently started to relieve hydraulic pressure.

Figure 443



The Auxiliary Pressure Release icon (Item 1) [Figure 443] will be visible when releasing auxiliary pressure is possible.

1. Put the attachment flat on the ground.
2. Stop engine and then turn start switch to on, but do not start the engine.
3. Make sure the left console is fully lowered.

4. To release auxiliary pressure, select the Auxiliary Pressure Release icon (Item 1) [Figure 443].

OR

Select **[SETTINGS]**→ **[MACHINE SETTINGS]**→ **[AUXILIARY PRESSURE RELEASE]**.

Either will bring you to the **AUXILIARY PRESSURE RELEASE** screen.

Figure 444



5. To release auxiliary pressure, press the AUX button on the jog shuttle as shown on the screen [Figure 444].

Figure 445



The spinner (Item 1) [Figure 445] will rotate until the Auxiliary Pressure Release procedure is complete.

You will get a message on the display if the auxiliary pressure cannot be released.


Possible reasons for a failure to release auxiliary pressure include:

- Insufficient hydraulic pressure in the accumulator to activate the pressure release feature.
- Operator attempted to release the hydraulic pressure while the engine was running.

If there is not enough pressure in the accumulator to release the hydraulic pressure, start the excavator for a short period of time to recharge the accumulator. Stop the engine, and then repeat the auxiliary pressure release procedure.

Some fault codes can also prevent the auxiliary pressure release feature from functioning correctly.

Figure 446




When the process is completed, a notification (Item 1) will appear indicating that the auxiliary pressure has been released. Press [DISMISS] (Item 2) [Figure 446].

**Setting The Auxiliary Hydraulics Flow**

1. Select [SETTINGS] → [MACHINE SETTINGS] → [AUXILIARY SETTINGS].

Figure 447



The **AUXILIARY SETTINGS** screen shows six commonly used attachments (Item 1) [Figure 447].

Each attachment icon is preset with the recommended hydraulic flow.

See the table below to identify icons.

Icon	Attachment
	Auger
	Cutter / Crusher
	Breaker
	Rotating Grapple
	Brush Cutter
	Tilt Coupler

2. Choose the flow that best matches the attachment / operator requirements by selecting a pre-set hydraulic flow icon (Item 1) [Figure 447].  
OR  
Press the arrow (Item 2) [Figure 447] icon to select a custom-set hydraulic flow icon. Adjust the hydraulic flow by moving the slider (Item 3) [Figure 447] from 0% flow (off) to 100% flow in 10% increments.
3. If necessary, press [RESET] (Item 4) [Figure 447] to revert the selected flow setting back to the original factory setting.

**NOTE:** Operators can set and save their own flows for the pre-set and custom-set flows.

**NOTE:** If the auxiliary hydraulics are enabled when the engine is turned off, they will stay enabled at engine restart. If detent flow was enabled at engine off, it will be disabled at engine restart.


**Activating Auto Idle**

**Figure 448**



1. Select **[SETTINGS]**→ **[MACHINE SETTINGS]**.  
OR  
Select the **[MACHINE SETTINGS]** icon (Item 1) [Figure 448].

**Figure 449**



2. Select **[AUTO-IDLE]** (Item 1) [Figure 449] to turn it on / off.
3. Select **[AUTO-IDLE DELAY TIME]** (Item 2) [Figure 449] to set the delay time.

**Figure 450**



4. Swipe up or down (Item 1) [Figure 450] to select the auto-idle delay time to best suit the operating conditions.
5. Select **[ACCEPT]** (Item 2) [Figure 450] to set the new time delay setting.

**Password Description**


**Owner Password:** Allows for full use of the machine and to set up the display security settings. There is only one owner password. The owner password must be used to change the owner or operator passwords. If this password is lost, contact your Bobcat dealer to unlock the machine.

**Operator Passwords:** Allows starting and operating of the machine. The owner password is needed to change an operator password. There can be multiple operator passwords.

**Changing The Owner And Operator Passwords**

1. Select **[SETTINGS]**→ **[SECURITY SETTINGS]**.
2. Enter the password if prompted.

**Figure 451**



3. Select **[MANAGE OPERATORS]** (Item 1) [Figure 451].

Figure 452



P132958a

4. Select the owner or an operator [Figure 452].

Figure 453



C132959a

5. Select **[OPERATOR PASSWORD]** (Item 1) [Figure 453].
6. Enter a new password and select **[ENTER]**.

**Adding An Operator**

1. Select **[SETTINGS]** → **[SECURITY SETTINGS]** → **[MANAGE OPERATORS]**.


Figure 454



P132958b

2. Select **[+ADD AN OPERATOR]** (Item 1) [Figure 454].

Figure 455




P132959a

3. Select **[OPERATOR NAME]** and enter the new operator name.
4. Select **[OPERATOR PASSWORD]** and assign the operator password.
5. Select **[RADIO LOCKOUT]** and / or **[PHONE LOCKOUT]** if you want to prohibit the operator from using these functions.
6. Select **[DONE]**.

**Removing An Operator**

1. Select **[SETTINGS]** → **[SECURITY SETTINGS]** → **[MANAGE OPERATORS]**.

Figure 456



P132958a

2. Select an operator [Figure 456].

Figure 457



3. Scroll down and select **[DELETE OPERATOR]** (Item 1) [Figure 457].

### Machine Lockout And Quick Start

The owner can enable Machine Lockout:

- If Machine Lockout is on, a password must be entered before the machine can be operated.
- If Machine Lockout is off, the machine can be operated without a password.

The owner also has the option to enable Quick Start:

- If Quick Start is on, the machine can be started before the display is fully booted up.
- If Quick Start is off, the machine can't be started until the display is fully booted up.

The machine will not start if engine fuel priming or pre-heat is required. When the Wait to Start light turns off, the machine can be started.

(See Starting The Engine on Page 77)

### Enabling Machine Lockout and Quick Start

1. Select **[SETTINGS]**→ **[SECURITY SETTINGS]**.
2. Select **[MACHINE LOCKOUT]** (Item 1) [Figure 458] to turn on / off.

Figure 458



3. Select **[QUICK START]** (Item 2) [Figure 458] to turn on / off.

Quick Start is always enabled when Machine Lockout is off.

### Auto Lock Time At Key OFF

The Auto Lock Time is the amount of time the operator has to key ON the machine without needing to re-enter a password.

1. Select **[SETTINGS]**→ **[SECURITY SETTINGS]**.

Figure 459



2. Select **[AUTO LOCK TIME AT KEY OFF]** (Item 1) [Figure 459].

Figure 460



3. Swipe up or down to set the Auto Lock Time (Item 1) [Figure 460].
4. Select **[ACCEPT]** (Item 2) [Figure 460].

**System Sleep Time At Key OFF**

System sleep time is the length of time the display will be in sleep mode when the machine is turned off. When in sleep mode, the display can quickly boot up when the machine is turned on. When the start switch is turned on after being off for a period longer than system sleep time, it will take several seconds for the display to boot up.

The sleep time is factory set and can be changed using the owner password.

Setting the sleep time to a shorter time will conserve the battery.

1. Select **[SETTINGS]** → **[SECURITY SETTINGS]**.

Figure 461



2. Select **[SYSTEM SLEEP TIME AT KEY OFF]** (Item 1) [Figure 461].

Figure 462



3. Swipe up or down to set the sleep time (Item 1) [Figure 462].
4. Select **[ACCEPT]** (Item 2) [Figure 462].

**Enabling Password Error Lockout**

When Password Error Lockout is on, the operator will have only five attempts to enter the password before being locked out.

1. Select **[SETTINGS]** → **[SECURITY SETTINGS]**.

Figure 463



2. Select **[PASSWORD ERROR LOCKOUT]** (Item 1) [Figure 463] to turn on / off.

**Accessing Operator Statistics**

1. Select **[SETTINGS]** → **[OPERATOR STATISTICS]**.

Figure 464



- Use the **OPERATOR STATISTICS** screen [Figure 464] to view:
  - Operator Name
  - Fuel Used Per Hour (GPH or LPH)
  - Idle Hours
  - Total Fuel

**Using The Job Clock**

Figure 465



- To open the **JOB CLOCK** screen, select the clock icon (Item 1) [Figure 465] and then **[VIEW ALL]**.  
OR  
Select **[SETTINGS]** (Item 2) [Figure 465] and then **[JOB CLOCKS]**.

Figure 466



- To start an existing job clock, select **[START]** (Item 1) [Figure 466].
- Select **[STOP]** (Item 2) [Figure 466] to stop the job clock.  
OR  
Key off will also stop the job clock automatically.  
The total job hours will be displayed.
- To add a new job clock, select **[ADD JOB CLOCK]** (Item 3) [Figure 466].
  - Type in the new job clock name and select **[ENTER]**.
- To delete an existing job clock, select **[EDIT]** (Item 4) [Figure 466].
  - Select the delete icon by the job clock you want to delete.
  - Select **[SAVE]**.
- Select a job clock (Item 5) [Figure 466] to view the associated **JOB CLOCK DETAIL** screen [Figure 467].

Figure 467



The **JOB CLOCK DETAIL** [Figure 467] screen will show:

- Job Name
- Job Total Time
- Job Engine Hours
- Job Engine Idle Hours
- Total Fuel
- Fuel Used Per Hour (GPH or LPH)
- History by user

### Setting The System Language

1. Select **[SETTINGS]**→ **[LANGUAGE SETTINGS]**.

Figure 468



P132941a

2. On the **SET LANGUAGE** screen, scroll through the languages and select the desired language.

A check mark (Item 1) [Figure 468] will appear when accepted.

### Switching Between English / Metric Units

1. Select **[SETTINGS]**.

Figure 469



P132940a

2. Scroll down and select **[UNITS]** (Item 1) [Figure 469] to toggle between English and metric units.

### Dealer Information

Your dealer must have entered their contact information into the display for the following information to be available.

1. Select **[SETTINGS]**→ **[DEALER]**.

Figure 470




C132951a

2. Use the **DEALER** screen to find your dealer information. You can call your dealer if a phone is paired (Item 1) [Figure 470].

### Software Version

1. Select **[SETTINGS]**→ **[SOFTWARE]**.

Figure 471



P132952

2. Use the **SOFTWARE** screen to find your software version and check for updates.

To update the software, see your Bobcat dealer.

## DIAGNOSTIC SERVICE CODES

## Service Codes List

CODE	DESCRIPTION
H0104	Boom Angle Sensor No Communication
H0204	Arm Angle Sensor No Communication
H0304	Bucket Angle Sensor No Communication
H0405	Angle Sensor Supply Short To Battery
H0406	Angle Sensor Supply Short To Ground
H0407	Angle Sensor Supply Open Circuit
H0705	Aux 4 Base Short to Battery
H0706	Aux 4 Base Short to Ground
H0707	Aux 4 Base Open Circuit
H0732	Aux 4 Base Overcurrent
H0805	Aux 4 Rod Short to Battery
H0806	Aux 4 Rod Short to Ground
H0807	Aux 4 Rod Open Circuit
H0832	Aux 4 Rod Overcurrent
H0905	Direct To Tank Short to Battery
H0906	Direct to Tank Short to Ground
H0907	Direct to Tank Open Circuit
H0932	Direct to Tank Overcurrent
H2521	Angle Blade Control Switch Out Of Range High
H2522	Angle Blade Control Switch Out Of Range Low
H2524	Angle Blade Control Switch Out Of Neutral
H2605	Angle Blade Base Solenoid Short To Battery
H2606	Angle Blade Base Solenoid Short To Ground
H2607	Angle Blade Base Solenoid Open Circuit
H2632	Angle Blade Base Solenoid Overcurrent
H2705	Angle Blade Rod Solenoid Short To Battery
H2706	Angle Blade Rod Solenoid Short To Ground
H2707	Angle Blade Rod Solenoid Open Circuit
H2732	Angle Blade Rod Solenoid Overcurrent
H2805	Diverter Output Short To Battery
H2806	Diverter Output Short To Ground

CODE	DESCRIPTION
H2807	Diverter Output Open Circuit
H2832	Diverter Output Overcurrent
H2848	Diverter Multiple Input
H3128	Interrupted Power Failure
H3904	Left Joystick In Error
H3912	Left Joystick Thumb Switch Not In Neutral
H3913	Left Joystick Grip No Communication
H3916	Left Joystick No Communication
H3928	Left Joystick Internal Failure
H3948	Left Joystick Multiple
H4423	Secondary Not Programmed
H4497	Secondary Controller Programmed
H4621	5 Volt Sensor Supply Out Of Range High
H4622	5 Volt Sensor Supply Out Of Range Low
H4721	8 Volt Sensor Supply Out Of Range High
H4722	8 Volt Sensor Supply Out Of Range Low
H5705	Angle Blade Aux 4 Base Short to Battery
H5706	Angle Blade Aux 4 Base Short to Ground
H5707	Angle Blade Aux 4 Base Open Circuit
H5732	Angle Blade Aux 4 Base Overcurrent
H5805	Angle Blade Aux 4 Rod Short to Battery
H5806	Angle Blade Aux 4 Rod Short to Ground
H5807	Angle Blade Aux 4 Rod Open Circuit
H5832	Angle Blade Aux 4 Rod Overcurrent
H7404	Main Controller No Communication
H7604	Display No Communication
H7902	Door Unlock Error On
H7903	Door Unlock Error Off
H8002	Door Lock Error On
H8003	Door Lock Error Off
L0102	Lights Button Error On
L0202	High Flow Enable Button Error On
L0302	Auxiliary Enable Button Error On
L0402	Information Button Error On
L7404	Information Button Error On

CODE	DESCRIPTION
L7672	Information Button Error On
LOWVL-TG	Low Battery Voltage
M0116	Air Filter Not Connected
M0117	Air Filter Plugged
M0144	Air Filter Derate Level 1
M0145	Air Filter Derate Level 2
M0216	Hydraulic/hydrostatic Filter Not Connected
M0217	Hydraulic/hydrostatic Filter Plugged
M0309	System Voltage Too Low
M0310	System Voltage Too High
M0311	System Voltage Extremely High
M0314	System Voltage Extremely Low
M0322	System Voltage Out Of Range Low
M0414	Engine Oil Pressure Extremely Low
M0415	Engine Oil Pressure In Shutdown
M0610	Engine Speed Too High
M0611	Engine Speed Extremely High
M0613	Engine Speed No Signal
M0615	Engine Speed In Shutdown
M0618	Engine Speed Out Of Range
M0710	Hydraulic Oil Temp Too High
M0711	Hydraulic Oil Temp Extremely High
M0715	Hydraulic Oil Temp In Shutdown
M0721	Hydraulic Oil Temp Out Of Range High
M0722	Hydraulic Oil Temp Out Of Range Low
M0810	Engine Coolant Temp Too High
M0811	Engine Coolant Temp Extremely High
M0815	Engine Coolant Temp In Shutdown
M0821	Engine Coolant Temp Out Of Range High
M0822	Engine Coolant Temp Out Of Range Low
M0826	Engine Coolant Temp Out Of Range Low
M0909	Fuel Level Too Low
M0921	Fuel Level Out Of Range High
M0922	Fuel Level Out Of Range Low

CODE	DESCRIPTION
M1121	Console Sensor Out Of Range High
M1122	Console Sensor Out Of Range Low
M1128	Console Sensor Failure
M1305	Fuel Hold Solenoid Short To Battery
M1306	Fuel Hold Solenoid Short To Ground
M1307	Fuel Hold Solenoid Open Circuit
M1402	Fuel Pull Solenoid Error On
M1403	Fuel Pull Solenoid Error Off
M1407	Fuel Pull Solenoid Open Circuit
M1428	Fuel Pull Solenoid Failure
M1605	Hydraulic Bypass Short to Battery
M1606	Hydraulic Bypass Short to Ground
M1607	Hydraulic Bypass Open Circuit
M1632	Hydraulic Bypass Overcurrent
M1705	Hydraulic Lock Valve Short To Battery
M1706	Hydraulic Lock Valve Short To Ground
M1707	Hydraulic Lock Valve Open Circuit
M1732	Hydraulic Lock Valve Overcurrent
M1802	Power Beyond Valve Output Error On
M1803	Power Beyond Valve Output Error Off
M1902	Power Beyond Valve Relay Error On
M1903	Power Beyond Valve Relay Error Off
M2005	Two Speed Primary Solenoid Short To Battery
M2006	Two Speed Primary Solenoid Short To Ground
M2007	Two Speed Primary Solenoid Open Circuit
M2102	Glow Plug Output Error On
M2103	Glow Plug Output Error Off
M2107	Glow Plug Output Open Circuit
M2128	Glow Plug Output Failure
M2202	Starter Output Error On
M2203	Starter Output Error Off
M2207	Starter Output Open Circuit
M2228	Starter Output Failure
M2302	Starter Relay Error On

CODE	DESCRIPTION
M2303	Starter Relay Error Off
M2402	Fuel Pull Relay Error On
M2403	Fuel Pull Relay Error Off
M2521	Load Sense Sensor Out Of Range High
M2522	Load Sense Sensor Out Of Range Low
M2602	Glow Plug Relay Error On
M2603	Glow Plug Relay Error Off
M2721	Throttle Primary Sensor Out Of Range High
M2722	Throttle Primary Sensor Out Of Range Low
M2805	Diverter Output Short To Battery
M2806	Diverter Output Short To Ground
M2807	Diverter Output Open Circuit
M3128	Interrupted Power Failure
M3204	Throttle Controller No Communication To Bobcat Controller
M3223	Throttle Controller Not Calibrated
M3228	Throttle Controller Failure
M3299	Throttle Controller Calibration In Process
M3304	Deluxe Panel No Communication
M3372	Display Software Incompatible
M3373	Display Software Outdated
M3702	HYD Exchange Output Error On
M3703	HYD Exchange Output Error Off
M3904	Jog Shuttle No Communication
M4028	Wrong ECU Detected
M4109	Alternator Voltage Too Low
M4110	Alternator Voltage High
M4204	Keyless Entry No Communication
M4304	Keyless Start Panel No Communication
M4404	Secondary No Communication
M4472	Secondary Controller Software Incompatible
M4473	Secondary Controller Software Outdated
M4621	5 Volt Sensor Supply Out Of Range High
M4622	5 Volt Sensor Supply Out Of Range Low

CODE	DESCRIPTION
M4721	8 Volt Sensor Supply Out Of Range High
M4722	8 Volt Sensor Supply Out Of Range Low
M4802	Front Light Relay Error On
M4803	Front Light Relay Error Off
M5002	Front Light Output Error On
M5003	Front Light Output Error Off
M5205	Offset Base Solenoid Short To Battery
M5206	Offset Base Solenoid Short To Ground
M5207	Offset Base Solenoid Open Circuit
M5232	Offset Base Solenoid Overcurrent
M5305	Offset Rod Solenoid Error On
M5306	Offset Rod Solenoid Short To Ground
M5307	Offset Rod Solenoid Open Circuit
M5332	Offset Rod Solenoid Overcurrent
M5421	Offset Control Switch Out Of Range High
M5422	Offset Control Switch Out Of Range Low
M5424	Offset Control Switch Out Of Neutral
M5505	Auxiliary Base Solenoid Short To Battery
M5506	Auxiliary Base Solenoid Short To Ground
M5507	Auxiliary Base Solenoid Open Circuit
M5532	Auxiliary Base Solenoid Overcurrent
M5605	Auxiliary Rod Solenoid Short To Battery
M5606	Auxiliary Rod Solenoid Short To Ground
M5607	Auxiliary Rod Solenoid Open Circuit
M5632	Auxiliary Rod Solenoid Overcurrent
M5721	Auxiliary Control Switch Out Of Range High
M5722	Auxiliary Control Switch Out Of Range Low
M5724	Auxiliary Control Switch Out Of Neutral
M5810	Fuel Temperature High
M5811	Fuel Temperature Extremely High
M5815	Fuel Temperature In Shutdown
M5826	Fuel Temperature In Shutdown
M6021	Left Control Switch Out of Range High
M6022	Left Control Switch Out of Range Low

CODE	DESCRIPTION
M6024	Left Control Switch Out of Neutral
M6121	Right Control Switch Out of Range High
M6122	Right Control Switch Out of Range Low
M6124	Right Control Switch Out of Neutral
M6204	Load Moment Sensor In Error
M6221	Overload Warning Sensor Out of Range High
M6222	Overload Warning Sensor Out of Range Low
M6402	Switched Power Relay Error On
M6403	Switched Power Relay Error Off
M6505	ECU Power Short To Battery
M6506	ECU Power Short To Ground
M6507	ECU Power Open Circuit
M6604	ECU No Communication
M6702	HVAC Output Error On
M6703	HVAC Output Error Off
M6905	Dump Valve Short to Battery
M6906	Dump Valve Short to Ground
M6907	Dump Valve Open Circuit
M6932	Dump Valve Overcurrent
M7002	Switched Power Output Error On
M7003	Switched Power Output Error Off
M7007	Switched Power Output Open Circuit
M7028	Switched Power Output Failure
M7423	Main Controller Not Programmed
M7472	Main Controller Software Incompatible
M7473	Main Controller Software Outdated
M7497	Main Controller Controller Programmed
M7604	Standard Display Panel No Communication
M7748	Key Switch Multiple
M7839	Hourmeter Changed
M8004	Cooling Fan Controller No Communication
M8005	Cooling Fan Short To Battery
M8006	Cooling Fan Short To Ground

CODE	DESCRIPTION
M8021	Cooling Fan Out Of Range High
M8022	Cooling Fan Out Of Range Low
M8025	Cooling Fan Unresponsive
M8027	Cooling Fan CAN Error
M8028	Cooling Fan Failure
M8029	Cooling Fan Wiring Fault
M8030	Cooling Fan Controller Fault
M8302	Wait to Start Lamp Error On
M8303	Wait to Start Lamp Error Off
M8615	Engine Speed Derate In Shutdown
M8625	Engine Speed Derate Unresponsive
M9111	Fuel Filter Extremely Plugged
M9117	Fuel Filter Plugged
M9144	Fuel Filter Derate Level 1
M9145	Fuel Filter Derate Level 2
M9202	Fuel Lift Pump Error On
M9203	Fuel Lift Pump Error Off
M9287	Fuel Pump Failure Time Exceeded
M9309	Fuel Pressure Low
M9314	Fuel Pressure Extremely Low
M9321	Fuel Pressure Out Of Range High
M9322	Fuel Pressure Out Of Range Low
M9344	Fuel Pressure Derate Level 1
M9701	Turbo Prime Sequence Active
P0002	Fuel Rail Pressure Fault
P0003	Fuel Rail Pressure Fault
P0004	Fuel Rail Pressure Fault
P000F	Fuel Rail Pressure High - Over Relief
P0072	Engine Compartment Temperature Sensor Out of Range Low
P0073	Engine Compartment Temperature Sensor Out of Range High
P007C	Inlet Air Temperature Sensor Out of Range Low
P007D	Inlet Air Temperature Sensor Out of Range High
P0087	Fuel Rail Pressure Fault

CODE	DESCRIPTION
P009B	Common Rail Pressure Relief Valve Open Count Exceeds Limit
P009C	Common Rail Pressure Relief Valve Opened
P009D	Common Rail Pressure Relief Valve Opened
P009F	High Rail Pressure
P00AC	Intake Manifold Temperature Sensor Out of Range Low
P00AD	Intake Manifold Temperature Sensor Out of Range High
P00BC	Low Manifold Absolute Pressure (Low boost)
P00BE	Air Flow Fault (MAF / MAP agreement)
P0100	Mass Air Flow Sensor Short to Battery or Open Circuit
P0101	Mass Air Flow Sensor Electrical Fault
P0102	Mass Air Flow Sensor Out of Range Low
P0103	Mass Air Flow Sensor Out of Range High
P0107	Manifold Absolute Pressure Sensor Out of Range Low
P0108	Manifold Absolute Pressure Sensor Out of Range High
P0117	Coolant Temperature Sensor Out of Range Low
P0118	Coolant Temperature Sensor Out of Range High
P011E	Coolant Temperature Low Fault
P0121	Engine Speed Control Signal Fault
P0122	Engine Speed Control Signal Fault
P0123	Engine Speed Control Signal Fault
P0124	Engine Speed Control Signal Fault
P0182	Fuel Temperature Sensor Out of Range Low
P0183	Fuel Temperature Sensor Out of Range High
P018C	Low Fuel Filter Pressure
P018D	High Fuel Filter Pressure
P018F	Common Rail Pressure Relief Valve Open Time Exceeds Limit
P0192	Rail Pressure Sensor Out of Range Low
P0193	Rail Pressure Sensor Out of Range High

CODE	DESCRIPTION
P0196	Oil Level/Temp Sensor Fault
P01C2	Fuel Filter Pressure Sensor Out of Range Low
P01C4	Low Fuel Filter Pressure Warning
P01C5	Low Fuel Filter Pressure - Derate
P01C6	Fuel Filter Pressure Sensor Out of Range High
P0201	Injector #1 Open Circuit
P0202	Injector #2 Open Circuit
P0203	Injector #3 Open Circuit
P0204	Injector #4 Open Circuit
P0215	Engine Shutoff Request Signal Detected
P0218	CAN Communication Fault - Transmission Oil Temperature
P0219	Engine Overspeed Detected
P0221	Engine Speed Control Signal Fault
P0222	Engine Speed Control Signal Fault
P0223	Engine Speed Control Signal Fault
P0224	Engine Speed Control Signal Fault
P0252	Low Fuel Rail Pressure
P0254	Fuel Rail Pressure Control Fault
P025A	Fuel Metering Unit Open Circuit
P025B	Fuel Metering Unit Fault
P025C	Fuel Metering Unit Short to Ground
P025D	Fuel Metering Unit Short to Battery
P028A	Fan PWM Open Circuit
P028D	Fan PWM Short to Ground
P028E	Fan PWM Short to Battery
P02E0	Air Control Valve H-Bridge Drive Open Circuit
P02E2	Air Control Valve H-Bridge Drive Short to Ground
P02E3	Air Control Valve H-Bridge Drive Short to Battery
P02E4	Air Control Valve Position Fault
P02E5	Air Control Valve Position Fault
P02E7	Air Control Valve Close Position Fault
P02E8	Air Control Valve Sensor Out of Range Low

CODE	DESCRIPTION
P02E9	Air Control Valve Sensor Out of Range High
P02EA	Air Control Valve Close Position Fault
P02EB	Air Control Valve Close Position Fault
P02EE	Injector #1 Short Circuit
P02EF	Injector #2 Short Circuit
P02F0	Injector #3 Short Circuit
P02F1	Injector #4 Short Circuit
P0340	Cam Sensor Signal Fault
P0342	Cam Sensor Signal Fault
P0344	Cam Sensor Signal Fault
P0372	Crank Sensor Signal Fault
P0374	Crank Sensor Signal Fault
P0380	Glow Plug Relay Open Circuit
P0381	Glow Plug Lamp Open Circuit
P0383	Glow Plug Relay Short to Ground
P0384	Glow Plug Relay Short to Battery
P0406	EGR Position Sensor Out of Range High
P0407	EGR Position Sensor Out of Range Low
P0408	EGR Flow Rate Error
P0421	DOC Efficiency Fault (During Regen)
P042E	EGR Control Position Fault
P042F	EGR Control Position Fault
P049B	EGR Flow Rate Error
P0512	Engine Start Switch Stuck On
P0522	Engine Oil Pressure Sensor Out of Range Low
P0523	Engine Oil Pressure Sensor Out of Range High
P0527	Fan Speed Timeout Fault
P0528	Cooling Fan Overspeed
P0529	Cooling Fan Underspeed
P0544	Turbine Inlet Temperature Fault
P0545	Turbine Inlet Temperature Sensor Out of Range Low
P0546	Turbine Inlet Temperature Sensor Out of Range High

CODE	DESCRIPTION
P055B	Oil Pressure Warning Lamp Open Circuit
P055C	Oil Pressure Warning Lamp Short to Ground
P055D	Oil Pressure Warning Lamp Short to Battery
P0562	ECU Battery Voltage Extremely Low
P0563	ECU Battery Voltage Extremely High
P056D	DEF Supply Module Communication Fault
P0591	PTO Lamp Open Circuit
P0592	PTO Lamp Short to Ground
P0593	PTO Lamp Short to Battery
P05ED	DEF Heater Line Short to Battery
P060B	ECU Calculation Error
P060C	ECU Communication Fault
P0615	Starter Relay Open Circuit
P0616	Starter Relay Short to Ground
P0617	Starter Relay Short to Battery
P062D	Injector Bank Short Circuit 1
P062E	Injector Bank Short Circuit 2
P062F	ECU Data Read Fault
P0630	ECU Data Write Fault
P0641	ECU 5V Sensor Supply Voltage Out of Range High
P0642	ECU 5V Sensor Supply Voltage Out of Range Low
P0657	ECU Sensor Supply 1 Short to Ground
P0658	ECU Sensor Supply 1 Voltage Low
P0659	ECU Sensor 1 Voltage High
P0669	High ECU Temperature
P0685	ECU Main Relay Fault
P068A	ECU Main Relay Fault
P06AD	ECU Temperature Sensor Short to Ground
P06AE	ECU Temperature Sensor Short to Battery
P06F0	DEF Supply Module Fault
P06F1	DEF Supply Module Fault
P0C17	EGR Closed Position Fault
P0C18	EGR Closed Position Fault

CODE	DESCRIPTION
P0C19	EGR Closed Position Fault
P1013	Engine Speed Fault
P101A	ECU Internal Fault
P1033	High DPF Inlet Temperature
P1044	DEF Tank Temperature Sensor Error Low
P1045	DEF Tank Temperature Sensor Error High
P106C	Low DEF Quality
P106D	High DEF Quality
P1073	High Engine Compartment Temperature
P107D	High Inlet Air Temperature
P108A	DEF Supply Pump Motor Speed Fault
P108B	DEF Supply Pump Motor Speed Fault
P108C	DEF Supply Pump Motor Fault
P10AD	High Intake Manifold Temperature
P1118	High Engine Coolant Temp
P1183	High Fuel Temperature
P1227	Low DEF Tank Temperature Fault
P1230	DEF Tank Level Signal Error
P12E5	EGR Fault - Level 1 Inducement
P12E6	EGR Fault - Level 2 Inducement
P12E7	EGR Fault - Level 3 Inducement
P12E8	EGR Fault - Warning
P12E9	SCR Dosing Interrupted - Level 1 Inducement
P12EA	SCR Dosing Interrupted - Level 2 Inducement
P12EB	SCR Dosing Interrupted - Level 3 Inducement
P12EC	SCR Dosing Interrupted - Warning
P12F2	DEF Quality - Level 1 Inducement
P12F3	DEF Quality - Level 2 Inducement
P12F4	DEF Quality - Level 3 Inducement
P12F5	DEF Quality - Warning
P12F6	SCR Tampering - Level 1 Inducement
P12F7	SCR Tampering - Level 2 Inducement
P12F8	SCR Tampering - Level 3 Inducement

CODE	DESCRIPTION
P12F9	SCR Tampering - Warning
P1303	SCR Fault Repeat Offense - Level 1 Inducement
P1304	SCR Fault Repeat Offense - Level 2 Inducement
P1305	SCR Fault Repeat Offense - Level 3 Inducement
P1450	High DEF Pump Pressure
P1451	Low DEF Pump Pressure
P1452	High DEF Pump Pressure
P1453	DEF Pump Pressure Stabilization Fault
P1454	Low DPF Differential Pressure
P1457	Low DEF Pump Pressure
P1459	DEF Pressure Reduction Fault
P1460	DEF Afterrun Error
P1461	DEF Reverting Valve Pressure Fault
P1522	Low Engine Oil Pressure
P1546	High Turbine Inlet Temperature
P1562	ECU Battery Voltage Low
P1563	ECU Battery Voltage High
P1564	ECU Battery Voltage Extremely High
P1565	ECU Battery Voltage Extremely Low
P160B	ECU Internal Fault
P160C	ECU Internal Fault
P160D	ECU Internal Fault
P160E	ECU Internal Fault
P160F	ECU Memory Fault
P1610	ECU Internal Fault
P1611	ECU Internal Fault
P1612	ECU Internal Fault
P1613	ECU Internal Fault
P1614	ECU Internal Fault
P1615	ECU Internal Fault
P1616	ECU Internal Fault
P1617	ECU Internal Fault
P1618	ECU Internal Fault
P1619	ECU Internal Fault
P1657	ECU Sensor Supply 1 Voltage Fault

CODE	DESCRIPTION
P1669	ECU Sensor Supply 2 Voltage Fault
P1684	ECU Sensor Supply 3 Voltage Fault
P1893	DEF Backflow Line Pressure Fault
P1904	Glow Plug Lamp Short to Ground
P1906	DPF Regeneration Switch Inhibit Lamp Open Circuit
P1907	DPF Regeneration Switch Inhibit Lamp Short to Ground
P1908	DPF Regeneration Switch Inhibit Lamp Short to Battery
P190B	High Fuel Rail Pressure
P190C	Low Fuel Rail Pressure
P192E	Check Engine Lamp Open Circuit
P192F	Check Engine Lamp Short to Ground
P1931	Check Engine Lamp Short to Battery
P1934	Pressure Relief Valve Fault
P202D	DEF Leakage Fault
P202E	DEF Dosing Valve Error
P2032	DPF Inlet Temperature Sensor Out of Range Low
P2033	DPF Inlet Temperature Sensor Out of Range High
P2034	DPF Inlet Temperature Fault
P203A	DEF Level Sensor Open Circuit
P203F	DEF Tank Empty
P2041	DEF Level Sensor Short Circuit
P2043	DEF Temperature Sensor Open Circuit
P2046	DEF Temperature Sensor Short Circuit
P2047	DEF Dosing Valve Short to Battery
P2048	DEF Dosing Valve Short to Ground
P2049	DEF Dosing Valve Open Circuit
P204A	DEF Pressure Fault
P204C	DEF Supply Pump Pressure Sensor Out of Range Low
P204D	DEF Supply Pump Pressure Sensor Out of Range High
P2050	DEF Dosing Valve Short to Battery
P2051	DEF Dosing Valve Short to Ground

CODE	DESCRIPTION
P205E	High DEF Tank Temperature
P208A	DEF Supply Pump Motor Open Circuit
P208B	DEF Supply Pump Motor Signal Error
P208C	DEF Supply Pump Motor Short to Ground
P208D	DEF Supply Pump Motor Short to Battery
P208E	DEF Dosing Valve Blocked
P20A0	DEF Reverting Valve Open Circuit
P20A1	High DEF Reverting Valve Temperature
P20A2	DEF Reverting Valve Short to Ground
P20A3	DEF Reverting Valve Short to Battery
P20A5	DEF Reverting Valve Pressure Fault
P20AC	DEF Supply Module Heater Fault
P20AD	DEF Supply Module Heater Fault
P20B0	DEF Supply Module Temperature Fault
P20B1	DEF Tank Heater Valve Open Circuit
P20B3	DEF Tank Heater Valve Short to Ground
P20B4	DEF Tank Heating/Coolant Valve Short to Battery
P20B9	DEF Supply Module Heater Relay Open Circuit
P20BA	DEF Supply Module Heater Fault
P20BB	DEF Supply Module Heater Relay Short to Ground
P20BC	DEF Supply Module Heater Relay Short to Battery
P20BD	DEF Pressure Line Heater Relay Open Circuit
P20BE	DEF Pressure Line Heater Fault
P20BF	DEF Pressure Line Heater Relay Short to Ground
P20C0	DEF Pressure Line Heater Relay Short to Battery
P20C1	DEF Backflow Line Heater Relay Open Circuit
P20C2	DEF Backflow Line Heater Fault
P20C3	DEF Backflow Line Heater Relay Short to Ground
P20C4	DEF Backflow Line Heater Relay Short to Battery
P20C5	DEF Suction Line Heater Relay Open Circuit

CODE	DESCRIPTION
P20C6	DEF Suction Line Heater Fault
P20C7	DEF Suction Line Heater Relay Short to Ground
P20C8	DEF Suction Line Heater Relay Short to Battery
P20EE	SCR Efficiency Low
P20FF	DEF Supply Module Communication Timeout
P2135	Engine Speed Control Signal Fault
P2136	Engine Speed Control Signal Fault
P213E	ECU Internal Shutdown
P2143	EGR H-Bridge Driver Open Circuit
P2144	EGR H-Bridge Driver Short to Ground
P2145	EGR H-Bridge Driver Short to Battery
P214F	DEF Supply Module Heater Open Circuit
P215E	DEF Suction Line Heater SC/STG Fault
P215F	DEF Suction Line Heater Open Circuit
P21C2	DEF Main Heater Relay Open Circuit
P21C3	DEF Main Heater Relay Short to Ground
P21C4	DEF Main Heater Relay Short to Battery
P21C7	SCR System Main Relay Fault
P21C8	SCR System Main Relay Short to Ground
P21C9	SCR System Main Relay Short to Battery
P21DD	DEF Supply Module Heater Short to Ground
P2202	Upstream NOx Sensor Short Circuit
P2203	Upstream NOx Sensor Open Circuit
P2215	Downstream NOx Sensor Short Circuit
P2216	Downstream NOx Sensor Open Circuit
P221C	DEF Pressure Line Heater Electrical Fault
P221D	DEF Pressure Line Heater Open Circuit
P221E	DEF Backflow Line Heater Electrical Fault
P221F	DEF Backflow Line Heater Open Circuit
P2228	Atmospheric Pressure Low Fault
P2229	Atmospheric Pressure High Fault
P225D	Low Upstream NOx Concentration
P2265	Water in Fuel Detected - Derate

CODE	DESCRIPTION
P2266	Water in Fuel Sensor Out of Range Low
P2267	Water in Fuel Sensor Out of Range High
P2269	Water in Fuel Detected
P2381	Glow Plug Lamp Short to Battery
P2383	Upstream NOx Sensor Installation Fault
P2384	Downstream NOx Sensor Installation Fault
P2397	Upstream NOx Concentration Low
P2398	Downstream NOx Concentration Low
P23B2	DEF Supply Module Heater Fault
P23B3	DEF Supply Module Heater Temperature Fault
P23B4	DEF Supply Module Heater Temperature Fault
P23B5	DEF Supply Module Temperature Fault
P23B6	DEF Supply Module Temperature Fault
P242F	High DPF Ash Content - Ash Cleaning Needed
P2454	DPF Differential Pressure Sensor Out of Range Low
P2455	DPF Differential Pressure Sensor Out of Range High
P2463	High DPF Soot Mass - Regen Required
P246B	DPF Regeneration Failure
P246C	High DPF Differential Pressure - DPF Plugged
P24A3	Very High DPF Soot Mass - Service Regen Required
P2505	High ECU Temperature
P2506	ECU Software Reset
P2507	ECU Internal Fault
P2508	ECU Internal Fault
P2509	ECU Internal Fault
P250A	Oil Level/Temp Sensor Open Circuit
P250C	Oil Level/Temp Sensor Short to Ground
P250D	Oil Level/Temp Sensor Short to Battery
P250F	Check Engine Oil Level
P2511	ECU Internal Fault
P2546	Multi-Torque Switch Out of Range Low
P2547	Multi-Torque Switch Out of Range High


CODE	DESCRIPTION
P25BA	DPF Regeneration Inhibit and Enable Switch Fault
P25BB	DPF Regeneration Enable Switch Short to Battery
P25BC	DPF Regeneration Inhibit Switch Short to Battery
P260E	DPF Regeneration Enable Switch Lamp Open Circuit
P260F	DPF Regeneration Enable Switch Lamp Short to Ground
P2611	DPF Regeneration Enable Switch Lamp Short to Battery
P2632	Fuel Feed Pump Open Circuit
P2633	Fuel Feed Pump Short to Ground
P2634	Fuel Feed Pump Short to Battery
P2635	Fuel Feed Pump Fault
P263D	DEF Pressure Line Heating Fault
P2669	ECU Sensor Supply 2 Short to Ground
P2670	ECU Sensor Supply 2 Out of Range Low
P2671	ECU Sensor Supply 2 Out of Range High
P2684	ECU Sensor Supply 3 Short to Ground
P2685	ECU Sensor Supply 3 Out of Range Low
P2686	ECU Sensor 3 Out of Range High
P268C	Injector #1 IQA Code Missing
P268D	Injector #2 IQA Code Missing
P268E	Injector #3 IQA Code Missing
P268F	Injector #4 IQA Code Missing
P273F	High Transmission Oil Temperature (CAN)
P274F	High Transmission Oil Temperature (H/W Switch)
P2C11	DEF Dosing Valve Fault
P304C	Low DEF Supply Pump Pressure
P304D	High DEF Supply Pump Pressure
P3052	DPF Differential Pressure Sensor Fault
P30B1	High DEF Tank Heating/Coolant Valve Fault
P30B9	High DEF Supply Module Heater Relay Fault
P30BD	High DEF Pressure Line Heater Relay Fault

CODE	DESCRIPTION
P30C1	High DEF Backflow Line Heater Relay Fault
P30C5	High DEF Suction Line Heater Relay Fault
P31C5	High DEF Main Heater Relay Fault
P32EE	Injector #1 Short Circuit
P32EF	Injector #2 Short Circuit
P32F0	Injector #3 Short Circuit
P32F1	Injector #4 Short Circuit
P350D	Oil Level/Temp Sensor Communication Fault
P350E	Oil Level/Temp Sensor Fault
P350F	Low Engine Oil Level
P360E	DPF Regeneration Active Lamp Open Circuit
P360F	DPF Regeneration Active Lamp Short to Ground
P3611	DPF Regeneration Active Lamp Short to Battery
R3327	Display CAN Error
R3334	Display CAN Error
R3335	Display CAN Error
R3904	Jog Shuttle No Communication
R4304	Keyless Start Panel No Communication
R7404	Main Controller No Communication
R7423	Display Not Programmed
R7492	Main Controller Authentication Failed
R9604	Radio No Communication
U0028	ECU CAN Communication Fault
U0029	ECU CAN Communication Fault
U010F	ECU CAN Communication Fault
U013C	ECU CAN Communication Fault - Engine Speed
U01B7	ECU CAN Communication Fault - Regeneration Switch
U01B8	ECU CAN Communication Fault - Multiple Torque Switch
U01B9	ECU CAN Communication Fault - Engine Shut Down
U029D	ECU CAN Communication Fault - Upstream NOx Sensor

<b>CODE</b>	<b>DESCRIPTION</b>
U029E	ECU CAN Communication Fault - Downstream NOx Sensor
U02A2	ECU CAN Communication Fault - DEF Tank
U030D	Upstream NOx Sensor Heating Fault
U030E	Downstream NOx Sensor Heating Fault
U043D	ECU CAN Communication Fault - Engine Speed Control
U0606	ECU CAN Communication Fault - Engine Speed Control
U0607	ECU CAN Communication Fault
U0608	ECU CAN Communication Fault - Engine Speed Control
U0619	ECU CAN Communication Fault - DEF Sensor
U0632	ECU CAN Communication Fault - Cooling Fan Control
U1001	CAN Communication Fault - Hydraulic Oil Temperature
U1003	ECU Received Engine Shutdown Request from Machine Controller
U1028	DEF Quality Sensor Open Circuit
U1030	DEF Quality Sensor Short Circuit
U1031	ECU CAN Communication Fault
U1032	ECU CAN Communication Fault - PTO
U1033	ECU CAN Communication Fault - Starter Relay
VRLOW-VLTG	Very Low Battery Voltage

MACHINE DIMENSIONS

Figure 472




NA20143a

Where applicable, specifications conform to SAE or ISO standards and are subject to change without notice.

REF	DESCRIPTION	STANDARD ARM	LONG ARM
A	OVERALL LENGTH WITH STANDARD COUNTERWEIGHT	5543 mm (218.2 in)	5541 mm (218.1 in)
	OVERALL LENGTH WITH ADD-ON COUNTERWEIGHT	-	5612 mm (220.9 in)
B	OVERALL HEIGHT	2551 mm (100.4 in)	2551 mm (100.4 in)
C	WIDTH OF UPPERSTRUCTURE	1849 mm (72.8 in)	1849 mm (72.8 in)
E	SLEW CLEARANCE, REAR OF UPPERSTRUCTURE WITH STANDARD COUNTERWEIGHT	1265 mm (49.8 in)	1265 mm (49.8 in)
	SLEW CLEARANCE, REAR OF UPPERSTRUCTURE WITH ADD-ON COUNTERWEIGHT	-	1335 mm (52.6 in)
G	CLEARANCE, UPPERSTRUCTURE TO GROUNDLINE	637 mm (25.1 in)	627 mm (24.7 in)
J2	NOMINAL DISTANCE BETWEEN CENTERLINES OF DRIVE SPROCKETS AND IDLERS	2004 mm (78.9 in)	2004 mm (78.9 in)
J4	NOMINAL OVERALL LENGTH OF TRACK ASSEMBLY	2523 mm (99.3 in)	2523 mm (99.3 in)
K	OVERALL WIDTH OF CRAWLER	1960 mm (77.2 in)	1960 mm (77.2 in)
CA	MACHINE CENTERLINE TO WORKING EQUIPMENT CENTERLINE, NORMAL OPERATION	125 mm (4.9 in)	125 mm (4.9 in)
CB2	MACHINE CENTERLINE TO WORKING EQUIPMENT CENTERLINE, WORK WIDTH AT MAX RH ROTATION	730 mm (28.7 in)	730 mm (28.7 in)
CB4	MACHINE CENTERLINE TO WORKING EQUIPMENT CENTERLINE, WORK WIDTH AT MAX LH ROTATION	473 mm (18.6 in)	473 mm (18.6 in)
CC	BUCKET EDGE TO WORKING EQUIPMENT CENTERLINE	300 mm (11.8 in)	300 mm (11.8 in)
CD2	WORKING WIDTH MAX RH ROTATION WITH STANDARD COUNTERWEIGHT	2245 mm (88.4 in)	2245 mm (88.4 in)
	WORKING WIDTH MAX RH ROTATION WITH ADD-ON COUNTERWEIGHT	-	2315 mm (91.1 in)
CD4	WORKING WIDTH MAX LH ROTATION WITH STANDARD COUNTERWEIGHT	2227 mm (87.7 in)	2227 mm (87.7 in)
	WORKING WIDTH MAX LH ROTATION WITH ADD-ON COUNTERWEIGHT	-	2273 mm (89.5 in)
CF	MIN. RADIUS IN TRAVEL POSITION	4278 mm (168.4 in)	4276 mm (168.3 in)
CG	BLADE HEIGHT	422 mm (16.6 in)	422 mm (16.6 in)
CL	BLADE WIDTH	1959 mm (77.1 in)	1959 mm (77.1 in)

Figure 473




NA20144a

Where applicable, specifications conform to SAE or ISO standards and are subject to change without notice.

REF	DESCRIPTION	STANDARD ARM	LONG ARM
AA	MAX. RADIUS AT GROUNDLINE	5822 mm (229.2 in)	6209 mm (244.5 in)
AB	MAX. DIGGING DEPTH	3537 mm (139.3 in)	3937 mm (155.0 in)
AF	MAX. DEPTH OF VERTICAL WALL THAT CAN BE EXCAVATED.	2561 mm (100.8 in)	2942 mm (115.8 in)
AG	BUCKET FLAT ON GROUNDLINE	2215 mm (87.2 in)	2104 mm (82.8 in)
AQ	BOOM PIVOT ANGLE	126°	126°
AR	ARM PIVOT ANGLE	116°	116°
AS	BUCKET PIVOT ANGLE	186°	186°
BA	MAX. RADIUS OF WORKING EQUIPMENT	5958 mm (234.6 in)	6336 mm (249.4 in)
BB	MAX. HEIGHT OF WORKING EQUIPMENT	5630 mm (221.7 in)	5885 mm (231.7 in)
BE	MIN. CLEARANCE OF FULLY CURLED BUCKET AT MAX. BOOM HEIGHT	2156 mm (84.9 in)	1768 mm (69.6 in)
BM	MIN. CLEARANCE OF FULLY CURLED BUCKET AT MAX. ARM HEIGHT	4126 mm (162.4 in)	4381 mm (172.5 in)
CP	MAX. APPROACH ANGLE	27°	27°
CQ	MAX. BLADE HEIGHT	390 mm (15.4 in)	390 mm (15.3 in)
CR	MAX. BLADE DEPTH	547 mm (21.6 in)	547 mm (21.6 in)

Figure 474



NA15927b





Where applicable, specifications conform to SAE or ISO standards and are subject to change without notice.

REF	DESCRIPTION	WITH ANGLE BLADE
CG	BLADE HEIGHT	434 mm (17.1 in)
CH	MACHINE CENTERLINE TO BLADE	2062 mm (81.2 in)
CL	BLADE WIDTH	1976 mm (77.8 in)
CP	MAX. APPROACH ANGLE	24°
CQ	MAX. BLADE HEIGHT	467 mm (18.4 in)
CR	MAX. BLADE DEPTH	675 mm (26.6 in)
CS	MAX. BLADE ANGLE, RIGHT / LEFT	25°
CT	TRACKS TO ANGLE BLADE CUT EDGE	8 mm (0.3 in)
CU	TRACKS TO ANGLE BLADE CAST EDGE	193 mm (7.6 in)
CV	BLADE WIDTH FULLY ANGLED, RIGHT / LEFT	1790 mm (70.5 in)
CW	MACHINE CENTERLINE TO ANGLE BLADE CUT EDGE	1608 mm (63.3 in)
CX	MACHINE CENTERLINE TO ANGLE BLADE CAST EDGE	2446 mm (96.3 in)
CY	TRACK TO BLADE CLEARANCE WITH BLADE FULLY ANGLED, RIGHT / LEFT	138 mm (5.4 in)



**RATED LIFT CAPACITY – LONG ARM AND HEAVY COUNTERWEIGHT**

Where applicable, specifications conform to SAE or ISO standards and are subject to change without notice.

										
				A	B	A	B			
 1925 mm	 2900 mm					kg @ max. B				
						3000 mm	4000 mm	5000 mm	3000 mm	4000 mm
4000 mm		*1036 kg		*1198 kg @ 4580 mm		*1036 kg		*1036 kg		876 kg @ 4580 mm
3000 mm		*1121 kg		*1218 kg @ 5170 mm		*1121 kg		835 kg		729 kg @ 5170 mm
2000 mm		*1382 kg		*1269 kg @ 5480 mm		*1181 kg		848 kg		677 kg @ 5480 mm
1000 mm		*1729 kg		*1334 kg @ 5550 mm		1164 kg		846 kg		656 kg @ 5550 mm
Ground		*1964 kg		*1400 kg @ 5400 mm		1158 kg		851 kg		682 kg @ 5400 mm
-1000 mm		*2030 kg		*1482 kg @ 5020 mm		1190 kg		868 kg		751 kg @ 5020 mm



















































































































































\* 

SW 20  7415164A

7415164A

**RATED LIFT CAPACITY – STANDARD ARM AND HEAVY COUNTERWEIGHT**

Where applicable, specifications conform to SAE or ISO standards and are subject to change without notice.

																																																																																																																																																																																																																																																																																																					
--	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	---	--	--	--

## EXCAVATOR SPECIFICATIONS

Certain specification(s) are based on engineering calculations and are not actual measurements. Specification(s) are provided for comparison purposes only and are subject to change without notice. Specification(s) for your individual Bobcat equipment will vary based on normal variations in design, manufacturing, operating conditions, and other factors.

### Performance Specifications

Operating weight (for cab with heater, rubber tracks, counterweight, standard bucket, and no operator)	5610 kg (12368 lb)
If equipped with the following	Cab with HVAC, add 19 kg (42 lb) Steel Tracks, add 125 kg (276 lb) Segmented Tracks, add 243 kg (536 lb) Standard Arm, subtract 21 kg (57 lb) Add On Counterweight, add 239 (528 lb) Angle Blade, add 176 kg (387 lb)
Travel speed (Low / High)	2,9 km/h / 4,9 km/h (1.8 mph / 3.0 mph)
Digging Force (per ISO 6015) (long arm)	28405 N (6386 lbf)
Digging Force (per ISO 6015) (standard arm)	33472 N (7525 lbf)
Digging Force (per ISO 6015) (bucket)	47841 N (10755 lbf)

### Controls Specifications

Steering	Two hand levers and foot pedals
Hydraulics	Two hand-operated joysticks control boom, bucket, arm, and upperstructure slew. Thumb switch controls auxiliary hydraulics and boom swing.
Standard Blade	Hand lever
Angle Blade (if equipped)	Switch on blade lever
Two Speed	Switch on blade lever
Boom Swing	Electric switch on left joystick
Auxiliary Hydraulics	Electric switches on joysticks
Engine	Engine speed control dial with auto idle feature, key or keyless start switch.
Starting Aid	Glow Plugs activated by start switch
Travel Brakes (Service & Parking)	Hydraulic lock in motor circuit
Swing Brakes (Service)	Hydraulic lock on motor
Swing Brakes (Holding)	Spring applied - hydraulic release

### Engine Specifications

Make / Model	2.4 L Bobcat® Engine, V2, Stage 5
Fuel / Cooling	Diesel / Liquid

Horsepower:	
– Gross power (ISO 14396)	41,0 kW (55.0 hp)
– Gross power (SAE J1995)	41,2 kW (55.3 hp)
– Rated Power	41,0 kW (55.0 hp)
Torque:	
– Gross Torque (ISO 14396)	190,0 N•m (140.1 lb-ft)
– Gross Torque (SAE J1995)	191,0 N•m (140.8 lb-ft)
– Rated Torque	190,0 N•m (140.1 lb-ft)
Number Of Cylinders	4
Displacement	2,392 L (146.0 in <sup>3</sup> )
Bore / Stroke	90,0 x 94,0 mm (3.54 x 3.70 in)
Lubrication	Forced lubrication / cartridge type
Crankcase Ventilation	Closed breathing
Air Filter	Dual dry replacement paper elements
Ignition	Diesel – Compression
Low Idle Speed	1050 ± 25 rpm
High Idle Speed	2200 ± 25 rpm
Engine Coolant	Propylene Glycol / water mixture (53% PG / 47% water)

**Hydraulic System Specifications**

Pump Type	single outlet variable displacement piston pump with gear pumps
Pump Capacity	138,5 L/min (36.6 U.S. gpm)
Auxiliary Flow	85,7 L/min (22.6 U.S. gpm)
2nd Auxiliary Flow	45,4 L/min (12.0 U.S. gpm)
Control Valves	closed center individually compensated
System Relief Pressure	270 bar (3916 psi)
Slew Relief Pressure	245 bar (3553 psi)
Joystick Control Pressure	30 bar (435 psi)
Arm Port Relief, Base End And Rod End	310 bar (4496 psi)
Boom Port Relief, Base End And Rod End	310 bar (4496 psi)
Bucket Port Relief, Base End And Rod End	310 bar (4496 psi)
Blade Port Relief, Base End	280 bar (4061 psi)
Angle Blade (If Equipped) Port Relief, Base End And Rod End	290 bar (4206 psi)
Main Hydraulic Filter Bypass	3.4 bar (50 psi)

Case Drain Filter Bypass	1.7 bar (25 psi)
Auxiliary Relief	210 bar (3045 psi)
Automatic Track Tensioning System	
– Rubber Tracks	70 bar (1015 psi)
– Steel Tracks	30 bar (435 psi)

### Hydraulic Cylinders

Cylinder	Bore	Rod	Stroke
Boom (cushion up)	101,6 mm (4.00 in)	57,2 mm (2.25 in)	697,2 mm (27.45 in)
Arm (cushion retract / extend)	88,9 mm (3.50 in)	57,2 mm (2.25 in)	757,4 mm (29.82 in)
Bucket	82,6 mm (3.25 in)	50,8 mm (2.00 in)	524,0 mm (20.63 in)
Boom Swing	95,3 mm (3.75 in)	50,8 mm (2.00 in)	490,7 mm (19.32 in)
Blade	101,6 mm (4.00 in)	50,8 mm (2.00 in)	218,4 mm (8.60 in)
Angle Blade (If Equipped)	63,5 mm (2.50 in)	38,1 mm (1.50 in)	422,9 mm (16.65 in)

### Hydraulic Cycle Times

Bucket Curl	3.1 seconds
Bucket Dump	2.2 seconds
Arm Retract	3.3 seconds
Arm Extend	3.7 seconds
Boom Raise	5.3 seconds
Boom Lower	5.9 seconds
Boom Swing Left	5.2 seconds
Boom Swing Right	4.6 seconds
Blade Raise	3.3 seconds
Blade Lower	3.9 seconds
Angle Blade Left (If Equipped)	1.9 seconds
Angle Blade Right (If Equipped)	2.0 seconds

### Electrical System Specifications

Starting Aid	Glow Plugs
Alternator	12 volt, 90 amp open frame with internal regulator
Battery	12 volt negative earth, 700 CCA at -18°C (0°F), 110 min reserve capacity at 25 amp
Starter	12 volt, 2.0 kW reduction drive
LED Lights	20 watts (each)

**Drive System Specifications**

Final Drive	Each track driven by hydraulic axial piston motor
Drive Reduction	58.9:1 two-stage planetary
Gradeability	30°
Travel Brakes	Hydraulic lock on motor

**Slew System Specifications**

Slew Motor	Axial piston connected to a planetary drive
Slew Circle	Single-row shear-type ball bearings with internal gear
Slew Speed	8,9 rpm

**Undercarriage Specifications**

Crawler Track Design	Sealed track rollers with box-section track roller frame
Track Adjuster	Grease type track adjusters with shock absorbing recoil springs
Width of Crawler	1960 mm (77.2 in)

**Capacities Specifications**

Fuel Tank	72,0 L (19.0 U.S. gal)
Hydraulic Reservoir	15,1 L (4.00 U.S. gal)
Hydraulic System Capacity (Center of Sight Glass)	60,0 L (15.85 U.S. gal)
Cooling System	9,5 L (2.50 U.S. gal)
Engine Oil and Filter	9,8 L (10.35 qt)
Final Drive (each)	1,0 L (1.1 qt)
Air Conditioning Refrigerant (R-134a)	0,77 kg (1.7 lb)

**Track Specifications**

Type	Rubber	Steel	Segmented
Width	400 mm (15.7 in)	400 mm (15.7 in)	400 mm (15.7 in)
Number of Shoes	Single Assembly	39	39
Number of Track Rollers (per side)	5	5	5

**Ground Pressure Specifications**

Machine Configuration	Rubber Tracks	Steel Tracks	Segmented Tracks
Standard Arm	31,7 kPa (4.59 psi)	32,3 kPa (4.69 psi)	33,0 kPa (4.79 psi)
Long Arm	31,8 kPa (4.61 psi)	32,5 kPa (4.71 psi)	33,1 kPa (4.81 psi)
Add-On Counterweight	33,1 kPa (4.80 psi)	33,8 kPa (4.90 psi)	34,5 kPa (5.00 psi)

**Environmental Specifications****DECLARED SINGLE-NUMBER NOISE EMISSION VALUES**  
In accordance with ISO 6395

Bystander noise level per Directive 2000/14/EC – $L_{wA}$	97 dB(A)
Operator noise level per Directive 2006/42/EC – $L_{pA}$	78 dB(A)

**DECLARED VIBRATION EMISSION VALUES**  
In accordance with EN 12096

Whole-body vibration per ISO 2631-1	0,30 m/s <sup>2</sup> (0.984 ft/s <sup>2</sup> )
Hand-arm vibration per ISO 5349-1	0,46 m/s <sup>2</sup> (1.509 ft/s <sup>2</sup> )

**FLUORINATED GREENHOUSE GAS (F-GAS) VALUES**  
(for machines equipped with HVAC)

F-gas type	HFC-134a
F-gas mass	0,77 kg
CO <sub>2</sub> equivalent (t)	1,10 t
GWP	1430

**ENGINE CO<sub>2</sub> EMISSION VALUES**

CO <sub>2</sub> emission	750,6 g/kWh
--------------------------	-------------

This CO<sub>2</sub> measurement results from testing over a fixed test cycle under laboratory conditions a(n) (parent) engine representative of the engine type (engine family) and shall not imply or express any guarantee of the performance of a particular engine.

**Temperature Range**

Operation and storage	-17° – +43°C (-1.3° – +109.4°F)
-----------------------	---------------------------------

## BOBCAT® EXCAVATORS WARRANTY

Doosan Bobcat EMEA s.r.o. ("Bobcat") warrants that this Bobcat® Excavator will be free from defects in design, material or workmanship for twenty four (24) months from the retail date to the owner or 2000 hours of machine usage, whichever occurs first. During the warranty period, only official Bobcat dealers (as listed on [www.bobcat.com](http://www.bobcat.com)) are entitled to deal with warranty claims and shall repair or replace, at Bobcat's option, without charge for parts, labour or travel of technicians, any part of the Bobcat® equipment which fails because of defects in design, material or workmanship. The owner shall provide any official Bobcat dealer with prompt written notice of the defect and allow reasonable time for replacement or repair. Bobcat may, at its option, request failed parts to be returned to the factory or to any other designated location. Transportation of the Bobcat® equipment to the official Bobcat dealer for warranty work is not the responsibility of Bobcat. Service schedules must adhere to prescribed intervals and Bobcat® genuine parts/lubricants must be used. The warranty does not apply to tires, tracks or other accessories not manufactured by Bobcat. For warranty coverage on engines, consult with your official Bobcat dealer. For these non-covered items, the owner shall refer solely to the warranty, if any, of the respective manufacturers thereof, in accordance with the respective manufacturers warranty statement. Coverage for air-conditioning refill and couplers is limited as failures generally originate from factors not under Bobcat's control such as, but not limited to, prolonged storage or abuse. This limited coverage is, depending on the component, 50 to 500 hours of machine usage. The warranty does not cover: (i) Oils and lubricants, coolant fluids, filter elements, brake linings, tune-up parts, bulbs, fuses, alternator fan belts, drive belts, pins, bushings and other high-wear items. (ii) Damages resulting from abuse, misuse, accidents, alterations, use of non-genuine Bobcat parts, use of the product with any bucket or attachment not approved by Bobcat, air flow obstructions, or failure to maintain or use the Bobcat product according to the instructions applicable to it. (iii) Ground engaging parts such as bucket teeth and cutting edges. (iv) Fuel or hydraulic system cleaning, engine tune-up, brake inspection or adjustment. (v) Adjustments or slight defects which generally do not affect the stability or reliability of the machine. (vi) Damage or defect resulting from improper storage, weathering, lack of use, use and operation in a corrosive or chemical environment. (vii) Damage or defect caused by operation of the product under extreme weather or geographical conditions without the written agreement of Bobcat.

BOBCAT EXCLUDES OTHER CONDITIONS, WARRANTIES OR REPRESENTATIONS OF ALL KINDS, EXPRESSED OR IMPLIED, STATUTORY OR OTHERWISE (EXCEPT THAT OF TITLE) INCLUDING ALL IMPLIED WARRANTIES AND CONDITIONS RELATING TO MERCHANTABILITY, SATISFACTORY QUALITY AND FITNESS FOR A PARTICULAR PURPOSE. CORRECTIONS BY BOBCAT OF NON-CONFORMITIES WHETHER PATENT OR LATENT, IN THE MANNER AND FOR THE WARRANTY PERIOD PROVIDED ABOVE, SHALL CONSTITUTE FULFILLMENT OF ALL LIABILITIES OF BOBCAT FOR SUCH NON-CONFORMITIES, WHETHER BASED ON CONTRACT, WARRANTY, TORT, NEGLIGENCE, INDEMNITY, STRICT LIABILITY OR OTHERWISE WITH RESPECT TO OR ARISING OUT OF SUCH PRODUCT. THE REMEDIES OF THE END-USER/OWNER SET FORTH UNDER THE PROVISIONS OF THE WARRANTY OUTLINED ABOVE ARE EXCLUSIVE AND THE TOTAL LIABILITY OF BOBCAT INCLUDING ANY HOLDING, SUBSIDIARY, ASSOCIATED OR AFFILIATED COMPANY OR DISTRIBUTOR WITH RESPECT TO THIS SALE OR THE PRODUCT AND SERVICE FURNISHED HEREUNDER IN CONNECTION WITH THE PERFORMANCE OR BREACH THEREOF, OR FROM DELIVERY, INSTALLATION, REPAIR OR TECHNICAL DIRECTION COVERED BY OR FURNISHED UNDER THIS SALE, WHETHER BASED ON CONTRACT, WARRANTY, TORT, NEGLIGENCE, INDEMNITY, STRICT LIABILITY OR OTHERWISE SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT UPON WHICH SUCH LIABILITY IS BASED. BOBCAT INCLUDING ANY HOLDING, SUBSIDIARY, ASSOCIATED OR AFFILIATED COMPANY AND DISTRIBUTOR SHALL IN NO EVENT BE LIABLE TO THE END-USER/OWNER, ANY SUCCESSORS IN INTEREST OR ANY BENEFICIARY OR ASSIGNEE RELATING TO THIS SALE FOR ANY CONSEQUENTIAL, INCIDENTAL, INDIRECT, SPECIAL OR PUNITIVE DAMAGES ARISING OUT OF THIS SALE OR BY ANY BREACH THEREOF, OR ANY DEFECT IN, OR FAILURE OF, OR MALFUNCTION OF THE PRODUCT UNDER THIS SALE, WHETHER BASED UPON LOSS OF USE, LOST PROFITS OR REVENUE, INTEREST, LOST GOODWILL, WORK STOPPAGE, IMPAIRMENT OF OTHER GOODS, LOSS BY REASON OF SHUTDOWN OR NON-OPERATION, INCREASED EXPENSES OF OPERATION OR CLAIMS OF USER OR CUSTOMERS OF THE USER FOR SERVICE INTERRUPTION WHETHER OR NOT SUCH LOSS OR DAMAGE IS BASED ON CONTRACT, WARRANTY, TORT, NEGLIGENCE, INDEMNITY, STRICT LIABILITY OR OTHERWISE.

4700003enUS (11-20)



- A**
- accessories ..... 17
  - air conditioning belt
    - adjusting ..... 188
    - replacing ..... 188
  - air conditioning switch ..... 34
  - air filter
    - replacing inner ..... 162
    - replacing outer ..... 161
  - alternator belt
    - adjusting ..... 186
    - replacing ..... 186
  - angle blade
    - operating ..... 65
    - reversing or replacing ..... 189
  - arm load holding valve
    - location ..... 110
    - lowering with base end hose failure ..... 111
    - lowering with rod end hose failure ..... 111
  - attachment
    - accessing information ..... 205
    - depth check calibration for standard display ..... 117
    - depth check calibration for touch display ..... 131
    - releasing hydraulic pressure ..... 58
    - releasing secondary auxiliary hydraulic pressure ..... 60
  - attachment mounting system
    - weights ..... 108
  - attachments ..... 17
  - audio settings
    - radio ..... 45
  - auto idle ..... 48
    - activating ..... 48, 209
  - auto shift drive motors ..... 47
  - auxiliary hydraulics
    - selecting flow ..... 208
- B**
- backfilling ..... 32
  - battery
    - booster (jump starting) ..... 175
    - charging ..... 175
    - during machine storage ..... 175
    - installing ..... 176
    - jump starting ..... 175
    - maintainer ..... 175
    - maintaining charge level ..... 175
    - maintenance ..... 174
    - removing ..... 176
    - testing ..... 175
  - battery disconnect switch ..... 174
  - beacon switch ..... 33
  - belt
    - air conditioning ..... 188
    - alternator ..... 186
  - biodiesel blend fuel ..... 163
  - blade
    - raising and lowering ..... 65
  - blade control lever ..... 65
  - boom load holding valve
    - location ..... 108
    - loss of hydraulic pressure ..... 109
    - lowering with base end hose failure ..... 109
    - lowering with rod end hose failure ..... 109
  - boom swing
    - enabling ..... 73
  - boom swing switch ..... 33, 62
  - bucket
    - tooth ..... 189
  - bucket tooth
    - replacing ..... 189
  - buckets
    - types ..... 17
- C**
- cab
    - ROPS / TOPS / FOPS ..... 48
  - cab door
    - operating ..... 48
  - camera
    - adjusting position ..... 43
    - maintaining ..... 42
    - settings ..... 201
  - case drain filter
    - replacing ..... 179
  - clamp
    - activating ..... 104
  - clock ..... 45
  - cold temperature starting tips ..... 78
  - control console
    - lowering ..... 78
    - raising ..... 78
  - control console lockouts
    - inspecting and maintaining ..... 153
  - coolant
    - checking level ..... 170
    - replacing in cab models ..... 170
  - counter-rotation left turn ..... 54
  - counter-rotation right turn ..... 53
  - coupler
    - inspecting and maintaining ..... 188
- D**
- daily inspection ..... 74
  - date
    - setting ..... 206
  - dealer information ..... 214
  - decal
    - location ..... 23
  - decals ..... 23
  - Declaration of Conformity
    - hydrofluorocarbon ..... 13
    - machine ..... 9
    - radio ..... 11
    - touch display ..... 10
  - delivery report ..... 15
  - depth check system
    - calibrating arm for standard display ..... 115
    - calibrating arm for touch display ..... 130
    - calibrating attachment for standard display ..... 117
    - calibrating attachment for touch display ..... 131
    - calibrating boom for standard display ..... 113
    - calibrating boom for touch display ..... 127
    - checking the arm sensor ..... 141
    - checking the boom sensor ..... 141
    - checking the bucket sensor ..... 140
    - description ..... 112, 125
    - digging to the target depth for standard display ..... 121
    - digging to the target depth for touch display ..... 135
    - setting grade zone for standard display ..... 121
    - setting grade zone for touch display ..... 134
    - setting target depth for standard display ..... 119
    - setting target depth for touch display ..... 133

setting unit scale on touch display .....	127	cleaning and maintaining .....	160
setting up laser receiver for standard display .....	123	front guard kit .....	18
setting up laser receiver for touch display .....	137	maintaining .....	18
setting warning zone for standard display .....	120	fuel fill pump .....	164
setting warning zone for touch display .....	134	fuel filter	
settings screen for standard display .....	112	removing water .....	165
settings screen for touch display .....	126	replacing .....	165
troubleshooting .....	140	fuel pre-filter	
derate .....	80	replacing .....	166
diesel particulate filter (DPF)		fuel specifications .....	163
automatic regeneration operation .....	68	fuel tank	
description .....	66	draining .....	167
DPF Cleaning .....	181	filling .....	163
DPF Service Description .....	181	fuel tank vent filter	
DPF service regeneration .....	181	replacing .....	167
forced parked regeneration operation .....	70	fuses	
forced regeneration operation .....	69	identification .....	172
icons .....	68	location .....	172
inhibit mode operation .....	71		
regeneration tables .....	67	<b>G</b>	
dimensions .....	226	gauges screen .....	36, 38
display brightness		German style coupler	
adjusting .....	197, 206	installing attachments .....	92
		removing attachments .....	94
<b>E</b>		grade zone	
Eco mode .....	72	description .....	120, 134
electrical system		grinding safety .....	21
description .....	172		
emergency exit .....	51	<b>H</b>	
front window .....	51	horn .....	33
right window .....	51	HVAC	
engine		ducting .....	51
starting .....	77	HVAC filters	
stopping .....	85	cleaning .....	160
engine CO <sub>2</sub> emission values .....	239	hydraulic clamp	
engine cooling system		activating .....	104
cleaning .....	169	operation .....	104
engine oil		weights .....	108
adding .....	168	hydraulic filter	
chart .....	168	replacing .....	178
checking .....	168	hydraulic fluid	
replacing .....	168	adding .....	177
engine speed		chart .....	178
setting .....	72	checking .....	177
engine speed control dial .....	72	replacing .....	179
exhaust system safety .....	21	hydraulic pressure	
		releasing .....	58, 207
<b>F</b>		hydraulic pressure reducing valve	
Falling-Object Protective Structure .....	18	adjusting .....	184
fan motor dial .....	34	returning to factory setting .....	185
fastening		hydraulic quick coupler	
machine to trailer .....	145	installing attachments .....	99
filters		removing attachments .....	102
fuel .....	165	hydraulic quick coupler switch .....	33
fire prevention		hydraulic system	
electrical .....	20	warming .....	78
fire extinguishers .....	21		
fuelling .....	21	<b>I</b>	
hydraulic system .....	20	inspection checkbook .....	153
flammable fluids .....	20	introduction .....	14
flow rate		ISO 9001	
hydraulics .....	57	certification .....	14
fourth auxiliary hydraulics .....	62	BSI .....	14
location of lines .....	60	ISO 9001 .....	14
selecting .....	60		
fresh air filter			

- TUV ..... 14  
ISO control pattern ..... 54–55
- J**
- job clock ..... 213  
jog shuttle ..... 34, 40–41  
  operation ..... 40–41
- K**
- Klac System  
  adjusting ..... 91  
  installing attachments ..... 88  
  removing attachments ..... 90
- L**
- language  
  setting ..... 198, 214
- laser  
  using for depth check system (standard display) ..... 124  
  using for depth check system (touch display) ..... 138
- laser receiver  
  set up for standard display ..... 123  
  set up for touch display ..... 137
- left console ..... 33  
  raising and lowering ..... 46
- left joystick button ..... 33
- left turn ..... 53
- lift capacity ..... 107  
  calculating ..... 107  
  long arm and add on counterweight ..... 232  
  long arm and heavy counterweight ..... 233  
  standard arm and heavy counterweight ..... 234
- lifting device  
  operating ..... 105
- lifting objects ..... 105
- lifting the machine ..... 143
- light  
  cab interior ..... 50
- lubrication locations  
  bucket, arm, boom, and blade cylinder ..... 190  
  swing pinion and swing circle ..... 192
- M**
- machine dimensions ..... 226
- machine lockout ..... 197, 211  
  enabling ..... 197
- machine performance ..... 195, 199
- machine signs ..... 23  
  pictorial only safety signs ..... 22
- machine storage ..... 175
- maintenance  
  schedule ..... 149
- maintenance safety ..... 20
- mechanical pin grabber coupler  
  installing attachments ..... 95  
  removing attachments ..... 97
- mirrors  
  adjusting ..... 76
- N**
- navigation bar ..... 194
- navigation handle ..... 194
- noise emission values ..... 239
- notification drawer ..... 199
- O**
- oil  
  engine ..... 168
- oil filter  
  replacing ..... 168
- operating the excavator  
  in water ..... 83  
  on slopes ..... 81
- Operation & Maintenance manual  
  location ..... 75
- operator  
  adding on standard display ..... 197  
  adding on touch display ..... 210  
  removing from system ..... 210
- operator statistics ..... 212
- Operator's Handbook  
  location ..... 75
- options ..... 17
- overload warning device  
  operating ..... 64
- overload warning device switch ..... 33
- P**
- password ..... 77, 197, 209  
  changing ..... 197, 209
- password error lockout ..... 212
- pin-on attachment  
  installing attachment ..... 86  
  removing attachment ..... 87
- pivot pins  
  inspection and maintenance ..... 192
- primary auxiliary hydraulics  
  activating ..... 56
- Q**
- quick coupler  
  adjusting ..... 91
- quick couplers ..... 55  
  connecting ..... 56  
  disconnecting ..... 56
- Quick Start ..... 77, 211  
  enabling ..... 197
- R**
- radio ..... 44–45  
  timer ..... 44
- rated lift capacity ..... 105
- rear view camera  
  adjusting position ..... 43  
  cleaning ..... 42  
  maintaining ..... 42  
  operating ..... 42, 200  
  settings ..... 201
- recirculation filter  
  cleaning and maintaining ..... 159
- right console ..... 34
- right joystick ..... 34
- right joystick button ..... 34
- right joystick switch ..... 34

- right side cover  
  opening and closing ..... 158
- right side grille  
  removing and installing ..... 159
- right side panel  
  removing and installing ..... 158
- right turn ..... 53
- rpm  
  setting ..... 72
- S**
- seat belt ..... 76  
  inspecting and maintaining ..... 154
- secondary auxiliary hydraulic pressure  
  releasing ..... 60
- secondary auxiliary hydraulics  
  operating ..... 59
- serial number  
  engine ..... 15  
  location ..... 15  
  machine ..... 15
- service  
  record ..... 196  
  recording ..... 203  
  schedule ..... 149
- service codes  
  viewing ..... 196, 202
- service codes list ..... 215
- service manual ..... 22
- service records  
  removing ..... 204
- service schedule ..... 149, 203
- sleep cycle ..... 77
- sleep time ..... 212
- slopes  
  operating on ..... 81
- software version ..... 198, 214
- specifications  
  capacities ..... 238  
  controls ..... 235  
  drive system ..... 238  
  engine ..... 235  
  environmental ..... 239  
  ground pressure ..... 238  
  hydraulic system ..... 236  
  performance ..... 235  
  slew system ..... 238  
  temperature range ..... 239  
  undercarriage ..... 238
- standard control pattern ..... 54
- standard display ..... 36
- standard items ..... 17
- starting safety ..... 21
- storage  
  and return to service ..... 193  
  preparing the machine for ..... 193
- strobe switch ..... 33
- suspension seat  
  adjustment ..... 76
- T**
- tailgate  
  opening and closing ..... 157
- temperature control dial ..... 34
- third auxiliary hydraulics ..... 63
- time  
  setting ..... 206
- timer ..... 44
- Top Guard (FOPS II) kit ..... 18
- touch display ..... 38  
  audio ..... 202  
  phone ..... 201
- towing ..... 142
- track tension  
  adjusting ..... 182  
  adjusting automatically ..... 184
- track tensioning system  
  types ..... 182
- tracks  
  adjusting tension ..... 182  
  protecting from damage ..... 84
- training resources ..... 22
- transporting  
  machine ..... 144
- travel  
  forward ..... 52  
  reverse ..... 52
- travel motion alarm  
  description ..... 52, 155  
  disabling ..... 52  
  inspecting ..... 155
- travel motion alarm cancel switch ..... 34
- travel motion alarm switch  
  maintaining ..... 156
- travel motor ..... 185  
  adding fluid ..... 185  
  replacing fluid ..... 185
- travel motor fluid  
  replacing ..... 185
- two-speed travel  
  with angle blade option ..... 47  
  without angle blade option ..... 46
- U**
- ultra low sulfur fuel ..... 163
- units  
  selecting ..... 198, 214
- upperstructure  
  rotating ..... 32
- V**
- vibration emission values ..... 239
- vitals screen ..... 195, 199
- W**
- wait to start light ..... 34
- warning zone  
  description ..... 120, 134
- warranty  
  excavator ..... 240
- welding safety ..... 21
- window  
  operating ..... 50  
  operating front ..... 49
- window washer reservoir ..... 51
- wiper / washer switch ..... 33



**Reference Information**

Compact Excavator Serial Number: .....

Engine Serial Number: .....

NOTES: .....

.....

.....

.....

YOUR BOBCAT DEALER NAME:

Dealer Address:

Affix Business Card Here or enter dealer information

**Sales Contact** (Name): \_\_\_\_\_  
(Phone): \_\_\_\_\_  
(Email): \_\_\_\_\_

**Rental Contact** (Name): \_\_\_\_\_  
(Phone): \_\_\_\_\_  
(Email): \_\_\_\_\_

Affix Business Card Here or enter dealer information

**Service Contact** (Name): \_\_\_\_\_  
(Phone): \_\_\_\_\_  
(Email): \_\_\_\_\_

**Parts Contact** (Name): \_\_\_\_\_  
(Phone): \_\_\_\_\_  
(Email): \_\_\_\_\_