

# Service manual

Portable compressor

M 64

No.: 9\_5898 20 E

RAMIRENT

Manufacturer:

**KAESER KOMPRESSOREN GmbH**

96410 Coburg • PO Box 2143 • GERMANY • Tel. +49-(0)9561-6400 • Fax +49-(0)9561-640130

<http://www.kaeser.com>

RAMIRENT

Original instructions  
/KKW/M64 2.00 en SBA-MOBILAIR

20110722 104727

<b>1</b>	<b>Regarding this document</b>	
1.1	Using this document .....	1
1.2	Further Documents .....	1
1.3	Copyright .....	1
1.4	Symbols and labels .....	1
1.4.1	Warnings .....	1
1.4.2	Potential damage warnings .....	2
1.4.3	Other alerts and their symbols .....	2
<b>2</b>	<b>Technical Specifications</b>	
2.1	Nameplate .....	4
2.2	Options summary .....	4
2.2.1	Compressed air treatment devices .....	5
2.2.2	Tool lubricator .....	5
2.2.3	Compressed air distributor .....	5
2.2.4	Low temperature equipment .....	6
2.2.5	Diesel particulate filter .....	6
2.2.6	Equipment for fire hazard areas .....	6
2.2.7	Generator .....	6
2.2.8	Battery isolating switch .....	6
2.2.9	Chassis .....	7
2.2.10	Lighting .....	7
2.2.11	Hose reels .....	7
2.2.12	Anti-theft device .....	7
2.2.13	Pedestrian protection .....	7
2.2.14	Instrument panel cover .....	8
2.3	Machine (without options) .....	8
2.3.1	Sound emission .....	8
2.3.2	Torques .....	8
2.3.3	Ambient conditions .....	8
2.3.4	Additional specifications according to the machine's operating licence .....	9
2.4	Chassis .....	9
2.4.1	Mass .....	9
2.4.2	Tyres .....	9
2.4.3	Wheel nut/bolt tightening torque .....	10
2.4.4	Towbar tightening torque .....	10
2.5	Compressor .....	10
2.5.1	Working pressure and FAD .....	10
2.5.2	Compressed air outlet .....	10
2.5.3	Pressure relief valves .....	11
2.5.4	Select Temperature .....	11
2.5.5	Cooling oil recommendation .....	11
2.5.6	Cooling oil charge .....	12
2.6	Engine .....	12
2.6.1	Engine data .....	12
2.6.2	Oil recommendation .....	13
2.6.3	Recommended Cooling Fluid .....	13
2.6.4	Fluid volumes .....	13
2.6.5	Batteries .....	14
2.7	Options .....	14
2.7.1	Tool lubricator .....	14
2.7.2	Fresh air filter .....	14
2.7.3	Low temperature equipment .....	14
2.7.4	Diesel particulate filter .....	15
2.7.5	Generator (50 Hz version) .....	16

2.7.6 Generator (60 Hz version) .....	18
<b>3 Safety and Responsibility</b>	
3.1 Basic instructions .....	21
3.2 Specified use .....	21
3.3 Incorrect Use .....	21
3.4 User's Responsibilities .....	21
3.4.1 Observe statutory and universally accepted regulations .....	21
3.4.2 Determining personnel .....	22
3.4.3 Adherence to inspection schedules and accident prevention regulations .....	22
3.4.4 Complying with inspection intervals for diesel particulate filters .....	23
3.5 Dangers .....	23
3.5.1 Safely dealing with sources of danger .....	23
3.5.2 Safe machine operation .....	26
3.5.3 Organisational Measures .....	29
3.5.4 Danger areas .....	29
3.6 Safety devices .....	29
3.7 Safety signs .....	30
3.8 Generator operation .....	32
3.8.1 Comply with the protective measures against dangerous electric current .....	32
3.8.2 Safe generator operation .....	32
3.8.3 Connecting extension cables .....	33
3.8.4 Do not exceed the maximum supply system load .....	33
3.8.5 Perform regular generator inspections .....	33
3.9 Emergencies .....	34
3.9.1 Correct fire fighting .....	34
3.9.2 Injury from handling operating fluids/materials .....	34
3.10 Warranty .....	35
3.11 Identifying the effects of improper modifications .....	35
3.12 Environment protection .....	36
<b>4 Design and Function</b>	
4.1 Bodywork .....	37
4.2 Machine installation .....	38
4.3 Machine function .....	39
4.4 Operating modes and control modes .....	40
4.4.1 Operating modes .....	40
4.4.2 PART LOAD control .....	40
4.5 Safety devices .....	41
4.5.1 Monitoring functions with shutdown .....	41
4.5.2 Further safety devices .....	42
4.6 Options .....	42
4.6.1 Compressed air treatment options .....	42
4.6.2 Low temperature equipment options .....	44
4.6.3 Optional battery isolating switch .....	46
4.6.4 Options for operating in fire hazard areas .....	47
4.6.5 Generator option .....	47
4.6.6 Diesel particulate filter option .....	51
4.6.7 Transport options .....	52
4.6.8 Hose reel option .....	52
4.6.9 Optional anti-theft device .....	53
4.6.10 Pedestrian protection option .....	53
4.6.11 Instrument panel cover option .....	53
<b>5 Installation and Operating Conditions</b>	
5.1 Ensuring safety .....	54

5.2	Installation conditions .....	54
<b>6</b>	<b>Installation</b>	
6.1	Ensuring safety .....	56
6.2	Reporting Transport Damage .....	56
6.3	Fitting the towbar .....	56
6.3.1	Fitting the height adjustable towbar .....	56
6.4	Adjusting the chassis .....	57
6.4.1	Adjusting the towbar height .....	58
6.4.2	Adjusting the coupling height .....	58
6.4.3	Changing the towing eye .....	59
<b>7</b>	<b>Initial Start-up</b>	
7.1	Ensuring safety .....	62
7.2	Before Initial Start-up (or Recommissioning) .....	62
7.2.1	Note when commissioning .....	62
7.2.2	Special measures for re-commissioning after storage .....	63
7.3	Checking installation and operating conditions .....	63
7.4	Low-temperature operation (winter) .....	64
7.4.1	Starting assistance .....	64
7.4.2	Starting up low-temperature equipment .....	66
7.5	Activating the generator .....	67
<b>8</b>	<b>Operation</b>	
8.1	Ensuring safety .....	70
8.2	Starting and stopping .....	70
8.2.1	Running the machine .....	71
8.2.2	Engine pre-heating .....	71
8.2.3	Starting the machine .....	72
8.2.4	Allow the machine to run up to operating temperature .....	72
8.2.5	Switching to LOAD .....	73
8.2.6	Regulating the shut-off valve .....	73
8.2.7	Shutting down the machine .....	74
8.3	Using the hose reel .....	74
8.3.1	Using the hose reel (EC version) .....	74
8.3.2	Using the hose reel (USA version) .....	76
8.4	Operating the tool lubricator .....	77
8.5	Using the low-temperature equipment .....	78
8.5.1	Using with the frost protector switched on .....	78
8.5.2	Coolant pre-heating .....	79
8.6	Operating the battery isolating switch .....	79
8.7	Generator operation .....	79
8.7.1	Switching in the generator .....	80
8.7.2	Switching off the generator .....	80
<b>9</b>	<b>Fault Recognition and Rectification</b>	
9.1	Basic instructions .....	81
9.2	Evaluate engine faults and alarms .....	81
9.2.1	Engine refuses to start or does not turn over .....	81
9.2.2	Engine does not reach full speed .....	82
9.2.3	Indicator lamp remains on .....	82
9.3	Evaluate compressor faults and alarms .....	83
9.3.1	Working pressure too high .....	83
9.3.2	Working pressure too low. ....	83
9.3.3	Pressure relief valve blowing off .....	84
9.3.4	Machine overheating .....	84

9.3.5	Too much oil residue in the compressed air .....	85
9.3.6	Oil flows from the compressor air filter after shutdown .....	85
9.3.7	High moisture content in the compressed air .....	86
9.4	Evaluate faults in the diesel particulate filter .....	86
9.5	Evaluate generator faults and alarms .....	87
9.5.1	There is no voltage or too low a voltage from the generator .....	87
9.5.2	Generator voltage too high .....	87
<b>10</b>	<b>Maintenance</b>	
10.1	Ensuring safety .....	89
10.2	Following the maintenance plans .....	90
10.2.1	Logging maintenance work .....	90
10.2.2	Maintenance tasks after commissioning .....	90
10.2.3	Regular Maintenance Work .....	91
10.3	Engine maintenance .....	95
10.3.1	Water cooler maintenance .....	96
10.3.2	Engine air filter maintenance .....	100
10.3.3	Fuel system maintenance .....	102
10.3.4	Checking the engine oil level .....	106
10.3.5	Engine oil filling and topping up .....	107
10.3.6	Changing the engine oil .....	108
10.3.7	Replace the engine oil filter .....	111
10.3.8	Drive Belt Maintenance .....	112
10.3.9	Battery maintenance .....	115
10.4	Compressor Maintenance .....	118
10.4.1	Checking cooling oil level .....	118
10.4.2	Cooling oil filling and topping up .....	119
10.4.3	Changing the cooling oil .....	120
10.4.4	Replace the compressor oil filter .....	122
10.4.5	Oil separator tank dirt trap maintenance .....	124
10.4.6	Changing the Oil Separator Cartridge .....	125
10.4.7	Compressor air filter maintenance .....	129
10.4.8	Checking pressure relief valves .....	132
10.5	Clean cooler/radiator .....	132
10.5.1	Cleaning the cooler/ radiator .....	132
10.5.2	Cleaning the compressed air aftercooler .....	133
10.6	Maintenance of rubber sealing strips .....	134
10.7	Chassis maintenance .....	135
10.7.1	Wheel checks .....	135
10.7.2	Towbar maintenance .....	135
10.7.3	Brake system maintenance .....	138
10.8	Maintenance of Optional Items .....	141
10.8.1	Tool lubricator maintenance .....	142
10.8.2	Cyclone separator maintenance .....	143
10.8.3	Combination filter maintenance .....	145
10.8.4	Fresh air filter maintenance .....	148
10.8.5	Frost protector maintenance .....	151
10.8.6	Generator drive belt maintenance .....	152
10.8.7	Spark arrestor cleaning .....	158
10.8.8	Engine air intake shut-off valve maintenance .....	160
10.9	Documenting maintenance and service work .....	162
<b>11</b>	<b>Spares, Operating Materials, Service</b>	
11.1	Note the Nameplate .....	163
11.2	Ordering consumable parts and operating fluids/materials .....	163

11.3	KAESER AIR SERVICE .....	164
11.4	Service Addresses .....	164
11.5	Spares for service and repair .....	164
<b>12</b>	<b>Decommissioning, Storage and Transport</b>	
12.1	De-commissioning .....	238
12.1.1	Temporary de-commissioning .....	238
12.1.2	Long-term de-commissioning and storage .....	239
12.2	Transport .....	240
12.2.1	Safety .....	240
12.2.2	Towing the compressor on the road .....	240
12.2.3	Parking the compressor .....	247
12.2.4	Transport with a crane .....	248
12.2.5	Transporting with a forklift truck .....	249
12.2.6	Transporting as a load .....	249
12.3	Storage .....	251
12.4	Disposal .....	251
<b>13</b>	<b>Annex</b>	
13.1	Identification .....	252
13.2	Pipeline and instrument flow diagram (P+I diagram) .....	252
13.3	Dimensional drawings .....	257
13.3.1	Dimensional drawing - chassis with height-adjustable tow bar .....	257
13.3.2	Dimensional drawing, chassis with fixed height tow bar .....	259
13.3.3	Dimensional drawing, chassis without parking brake .....	261
13.3.4	Dimensional drawings of stationary machine (skids) .....	263
13.3.5	Dimensional drawings of stationary machine (base frame) .....	265
13.4	Wiring diagrams .....	267
13.4.1	Electrical Diagram .....	267
13.4.2	Connection adapter for the diesel particulate filter .....	280
13.4.3	Lighting and signalling system connection .....	285
13.4.4	Lighting and signalling system connection .....	293
13.4.5	Generator electrical diagram, 400 V, 3-ph .....	298
13.4.6	Generator electrical diagram, 230 V, 3-ph .....	307
13.4.7	Generator electrical diagram, 115 V, 2-ph .....	316
13.4.8	Generator electrical diagram, 230 V, 2-ph .....	325
13.5	Fuel circulation diagram .....	334
13.6	Operating instructions for compressed air filter (combination filter) .....	337
13.7	Operating instructions for compressed air filter (fresh air filter) .....	358
13.8	Service tasks on the diesel particulate filter .....	372
13.9	Service tasks - Generator .....	372

RAMIRENT

Fig. 1	Location of safety signs .....	30
Fig. 2	Bodywork .....	37
Fig. 3	Right-hand door opened .....	38
Fig. 4	Left-hand door opened .....	38
Fig. 5	Machine layout .....	39
Fig. 6	Stepless regulation of FAD (standstill) .....	41
Fig. 7	Compressed air options .....	42
Fig. 8	Tool lubricator .....	44
Fig. 9	Frost protector .....	45
Fig. 10	Coolant pre-heating .....	46
Fig. 11	Battery isolating switch .....	46
Fig. 12	Instrument panel – generator control box, 400 V AC .....	48
Fig. 13	Instrument panel – generator control box, 230 V AC .....	49
Fig. 14	Generator instrument panel - control box, 115 V, single-phase (50 Hz) .....	49
Fig. 15	Generator instrument panel - control box, 230 V, single-phase (60 Hz) .....	50
Fig. 16	General design of the diesel particulate filter system .....	51
Fig. 17	Minimum distance from excavations/slopes and walls .....	54
Fig. 18	Fitting the height adjustable towbar .....	57
Fig. 19	Towbar height adjustment .....	58
Fig. 20	Adjusting the coupling height .....	59
Fig. 21	Changing the ball hitch/towing eye (European chassis) .....	60
Fig. 22	Replacing the ball coupling/eye (US chassis) .....	61
Fig. 23	Jumper cable connection diagram .....	65
Fig. 24	Coolant pre-heating .....	67
Fig. 25	Insulation monitoring - 400 V AC, 3-phase generator .....	68
Fig. 26	Insulation monitoring - 230 V AC, 3-phase generator .....	68
Fig. 27	insulation monitoring - 115 V, single-phase generator .....	68
Fig. 28	insulation monitoring - 230 V, single-phase generator .....	69
Fig. 29	Starting instruments .....	71
Fig. 30	Label referring to the warm-up period when ambient temperatures are below -10 °C .....	73
Fig. 31	Control line shut-off valve .....	73
Fig. 32	Hose reel (EC design) .....	75
Fig. 33	Hose reel (EC design) .....	76
Fig. 34	Setting the tool lubricator .....	77
Fig. 35	Frost protector on and off .....	78
Fig. 36	Battery isolating switch .....	79
Fig. 37	Checking coolant level .....	97
Fig. 38	Draining the coolant from the radiator .....	99
Fig. 39	Engine air filter maintenance .....	101
Fig. 40	Cleaning the filter element .....	101
Fig. 41	Fuel system maintenance .....	103
Fig. 42	Bleeding the fuel system .....	103
Fig. 43	Fuel filter with water trap maintenance .....	104
Fig. 44	Changing the fuel pre-filter .....	105
Fig. 45	Fuel micro-filter maintenance .....	105
Fig. 46	Checking the engine oil level .....	107
Fig. 47	Draining the engine oil .....	109
Fig. 48	Changing the engine oil .....	110
Fig. 49	Changing the oil filter .....	111
Fig. 50	Belt guard attachment .....	112
Fig. 51	Kontrollere at drivremmen sitter som den skal .....	113
Fig. 52	Belt tension checking by hand .....	113
Fig. 53	Changing/tensioning the drive belt .....	114
Fig. 54	Safety signs - warning stickers on the battery .....	115

Fig. 55	Checking cooling oil level .....	118
Fig. 56	Draining the compressor cooling oil .....	121
Fig. 57	Draining the oil from the heat exchanger .....	122
Fig. 58	Changing the oil filter .....	123
Fig. 59	Oil separator tank dirt trap maintenance .....	124
Fig. 60	Changing the Oil Separator Cartridge .....	126
Fig. 61	Changing the oil separator cartridge (Option ba) .....	128
Fig. 62	Compressor air filter maintenance .....	130
Fig. 63	Cleaning the filter element .....	131
Fig. 64	Cleaning the cooler/ radiator .....	133
Fig. 65	Cleaning the compressed air aftercooler .....	134
Fig. 66	Maintaining the height-adjustable towbar .....	136
Fig. 67	Maintaining the fixed-height towbar .....	136
Fig. 68	Ball coupling (EC version) .....	137
Fig. 69	Ball coupling (USA version) .....	138
Fig. 70	Checking the brake lining thickness .....	139
Fig. 71	Adjusting the wheel brake .....	140
Fig. 72	Brake rod adjustment .....	140
Fig. 73	Tool lubricator maintenance .....	142
Fig. 74	Cleaning the dirt trap .....	144
Fig. 75	Combination filter maintenance .....	145
Fig. 76	Fresh air filter maintenance .....	148
Fig. 77	Filling the frost protector .....	151
Fig. 78	Securing the belt guard at the generator .....	153
Fig. 79	Belt tension checking by hand .....	154
Fig. 80	Generator belt tensioning .....	155
Fig. 81	Generator belt tensioner .....	155
Fig. 82	Checking the pulley alignment .....	157
Fig. 83	Aligning the generator .....	158
Fig. 84	Spark arrestor cleaning .....	159
Fig. 85	Engine air intake shut-off valve maintenance .....	160
Fig. 86	Towing alignment .....	242
Fig. 87	Ball coupling (KNOTT-EU) .....	242
Fig. 88	Safety control display ball hitch KNOTT-EU .....	243
Fig. 89	Ball coupling (USA version): .....	244
Fig. 90	Safety sign - secure the chocks .....	246
Fig. 91	Breakaway cable attachment .....	246
Fig. 92	Injury can occur if the towbar is unsupported and allowed to fall. ....	247
Fig. 93	Safety sign - secure the chocks .....	248
Fig. 94	Transport using a forklift truck .....	249
Fig. 95	Load secured by strapping .....	250
Fig. 96	Identification .....	252

Tab. 1	Danger levels and their definitions (personal injury) .....	1
Tab. 2	Danger levels and their definition (damage to property) .....	2
Tab. 3	Nameplate .....	4
Tab. 4	Combined label for coupling load and options fitted. ....	5
Tab. 5	Compressed air treatment options .....	5
Tab. 6	Tool lubricator option .....	5
Tab. 7	Compressed air distributor option .....	5
Tab. 8	Low temperature equipment options .....	6
Tab. 9	Diesel particulate filter option .....	6
Tab. 10	Optional equipment for fire hazard areas .....	6
Tab. 11	Generator option .....	6
Tab. 12	Optional battery isolating switch .....	6
Tab. 13	Chassis options .....	7
Tab. 14	Lighting options .....	7
Tab. 15	Hose reel option .....	7
Tab. 16	Optional anti-theft device .....	7
Tab. 17	Pedestrian protection option .....	7
Tab. 18	Instrument panel cover options .....	8
Tab. 19	Guaranteed sound power level .....	8
Tab. 20	Emission sound pressure level .....	8
Tab. 21	Torques for hex-head screws .....	8
Tab. 22	Ambient conditions .....	8
Tab. 23	Mass of the machine .....	9
Tab. 24	Tyres .....	9
Tab. 25	Wheel nut/bolt tightening torque .....	10
Tab. 26	Towbar tightening torque .....	10
Tab. 27	Working pressure and FAD .....	10
Tab. 28	Compressed air distributor .....	10
Tab. 29	Pressure relief valve opening pressure .....	11
Tab. 30	Machine temperatures .....	11
Tab. 31	Compressor block discharge temperature .....	11
Tab. 32	Cooling oil recommendation .....	11
Tab. 33	Cooling oil charge .....	12
Tab. 34	Engine data .....	12
Tab. 35	Engine oil recommendation .....	13
Tab. 36	Recommended oil for engines with diesel particulate filters .....	13
Tab. 37	Fluid volumes .....	13
Tab. 38	Batteries .....	14
Tab. 39	Road breaker lubricant recommendation .....	14
Tab. 40	Fresh air filter conditions .....	14
Tab. 41	Environmental conditions, low temperature equipment .....	14
Tab. 42	Recommended antifreeze .....	15
Tab. 43	Batteries, low-temperature equipment .....	15
Tab. 44	Coolant pre-heater .....	15
Tab. 45	Diesel particulate filter data .....	15
Tab. 46	Generator data .....	16
Tab. 47	Delivery in generator mode .....	16
Tab. 48	Connection sockets .....	17
Tab. 49	Circuit breaker .....	17
Tab. 50	Generator operating limits .....	17
Tab. 51	Maximum three-phase mains loading .....	18
Tab. 52	Maximum single-phase mains loading .....	18
Tab. 53	Power reduction at elevated ambient temperatures .....	18
Tab. 54	Generator data .....	18

Tab. 55	Delivery in generator mode .....	19
Tab. 56	Connection sockets .....	19
Tab. 57	Circuit breaker .....	20
Tab. 58	Generator operating limits .....	20
Tab. 59	Maximum power supply load .....	20
Tab. 60	Power reduction at elevated ambient temperatures .....	20
Tab. 61	Inspection intervals according to regulations .....	23
Tab. 62	Danger areas .....	29
Tab. 63	Safety signs .....	30
Tab. 64	Generator/compressor operation .....	47
Tab. 65	Generator operating modes .....	47
Tab. 66	Measures for re-commissioning the compressor after a long period of storage .....	63
Tab. 67	Positioning and operating conditions checklist .....	63
Tab. 68	Low-temperature equipment checklist .....	67
Tab. 69	Test instructions for a generator with an earth leak detection device .....	69
Tab. 70	Fault: engine refuses to start or comes to a stop .....	81
Tab. 71	Fault: engine does not reach full speed .....	82
Tab. 72	Indicator lamp remains on .....	82
Tab. 73	Fault: working pressure too high .....	83
Tab. 74	Fault: working pressure too low .....	83
Tab. 75	Fault: pressure relief valve blowing off .....	84
Tab. 76	Fault: machine overheating .....	84
Tab. 77	Fault: too much oil residue in the compressed air .....	85
Tab. 78	Fault: oil flows from the compressor air filter after shutdown .....	85
Tab. 79	Fault: high moisture content in the compressed air .....	86
Tab. 80	Faults in the diesel particulate filter .....	86
Tab. 81	Fault 'blue engine exhaust' .....	86
Tab. 82	Grey or brownish exhaust gas .....	87
Tab. 83	There is no voltage or too low a voltage from the generator .....	87
Tab. 84	Generator voltage too high .....	87
Tab. 85	Maintenance tasks after commissioning .....	90
Tab. 86	Maintenance intervals and regular maintenance tasks .....	91
Tab. 87	Regular machine maintenance tasks .....	91
Tab. 88	Regular maintenance task options .....	94
Tab. 89	KAESER coolant mixture table .....	98
Tab. 90	Belt tension values .....	154
Tab. 91	Maintenance log .....	162
Tab. 92	Compressor consumables .....	163
Tab. 93	Consumable engine parts .....	163
Tab. 94	"Temporarily decommissioned" information notice .....	238
Tab. 95	"Long-term decommissioning and storage" checklist .....	239
Tab. 96	Text for the "long-term decommissioned and storage" information notice .....	240
Tab. 97	Safety control display ball hitch .....	244

# 1 Regarding this document

## 1.1 Using this document

The operating manual is a component of the product. It describes the machine as it was at the time of first delivery after manufacture.

- Keep the operating manual in a safe place throughout the life of the machine.
- Supply any successive owner or user with this operating manual.
- Please insert any amendment or revision of the operating manual sent to you.
- Enter details from the machine nameplate and individual items of equipment in the table in chapter 2.

## 1.2 Further Documents

Further documents included with this operating manual are:

- Certificate of acceptance / operating instructions for the pressure vessel
- Declaration of Conformity in accordance with the applicable directive
- Engine documentation (not electric-motor-driven machines)

Missing documents can be requested from KAESER.

- Make sure all documents are complete and observe the instructions contained in them.
- Make sure you provide the data from the nameplate when ordering documents.

## 1.3 Copyright

This service manual is copyright protected. Queries regarding use or duplication of the documentation should be referred to KAESER. Correct use of information will be fully supported.

## 1.4 Symbols and labels

- Please note the symbols and labels used in this document.

### 1.4.1 Warnings

Warning notices indicate dangers that may result in injury when disregarded.

Warning notices indicate three levels of danger identified by the corresponding signal word:

Signal term	Meaning	Consequences of ignoring the warning
DANGER	Warns of an imminent danger	Will result in death or severe injury
WARNING	Warns of a potentially imminent danger	May result in death or severe injury
CAUTION	Warns of a potentially dangerous situation	May result in a moderate physical injury

Tab. 1 Danger levels and their definitions (personal injury)

Warning notices preceding a chapter apply to the entire chapter, including all sub-sections.

For example,

## 1 Regarding this document

### 1.4 Symbols and labels



#### DANGER

These show the kind of danger and its source.

The possible consequences of ignoring a warning are shown here.

If you ignore the warning notice, the "DANGER" signal word indicates a lethal or severe injury will occur.

- The measures required to protect yourself from danger are shown here.

Warning notes referring to a sub-section or the subsequent action are integrated into the procedure and numbered as an action.

For example,



#### 1. WARNING!

These show the kind of danger and its source.

The possible consequences of ignoring a warning are shown here.

If you ignore the warning notice, the "WARNING" signal word indicates that a lethal or severe injury may occur.

- The measures required to protect yourself from danger are shown here.

2. Always read and comply with warning instructions.

### 1.4.2 Potential damage warnings

Contrary to the warnings shown above, damage warnings do not indicate a potential personal injury.

Warning notices for damages are identified by their signal term.

Signal term	Meaning	Consequences of ignoring the warning
NOTE	Warns of a potentially dangerous situation	Damage to property is possible

Tab. 2 Danger levels and their definition (damage to property)

For example,



#### NOTICE

These show the kind of danger and its source.

Potential effects when ignoring the warning are indicated here.

- The protective measures against the damages are shown here.
- Carefully read and fully comply with warnings against damages.

### 1.4.3 Other alerts and their symbols



This symbol indicates particular important information.

Material Here you will find details on special tools, operating materials or spare parts.

Precondition Here you will find conditional requirements necessary to carry out the task.  
The conditions relevant to safety shown here will help you to avoid dangerous situations.

- This symbol is placed by lists of actions comprising one stage of a task.

1. In process instructions with several steps ...
2. ... the sequence of action steps is numbered.

Result	Shows the expected conclusion of the previous action.
Option da	► Information relating to one option only are marked with an option code (e.g., "option da" means that this section is only valid for machines with the air treatment components "aftercooler and cyclone separator"). Option codes used in this service manual are explained in chapter 2.2.
	Information referring to potential problems are identified by a question mark. The cause is named in the help text ... ► ... as is a solution.
	This symbol refers to important information or measures concerning environmental protection.
Further information	Further subjects are introduced here.

## 2 Technical Specifications

### 2.1 Nameplate

The machine's nameplate provides the model designation and important technical information.

The nameplate is located on the outside of the machine (see illustration in chapter 13.1)

► Enter here the nameplate data as a reference:

Feature	Value
Vehicle identity no.	
Permissible total weight	
Permissible coupling load	
Permissible axle load	
Portable compressor	
Material number	
Serial number:	
Year of manufacture	
Total weight	
Lifting point load capacity	
Rated motor power	
Engine speed	
Maximum working pressure	

Tab. 3 Nameplate

### 2.2 Options summary

A list of the options fitted to your machine helps to relate the information in this service manual.

A list of options fitted is given as code letters on the right side of the coupling load / options label.

The label is to be found

- on the outside of the machine
- on the front (see chapter 13.1)

 The following table lists all possible options.

Only the codes for those options fitted appear on the label.

M 64	part number	Serial number: Options fitted																																																																						
Here is given the specified coupling load.																																																																								
<table border="1"> <tr><td>da</td><td>db</td><td>dc</td><td>dd</td><td>_</td></tr> <tr><td>-</td><td>-</td><td>ec</td><td>-</td><td>-</td></tr> <tr><td>fa</td><td>-</td><td>fc</td><td>-</td><td>-</td></tr> <tr><td>-</td><td>-</td><td>-</td><td>-</td><td>-</td></tr> <tr><td>-</td><td>-</td><td>-</td><td>-</td><td>-</td></tr> <tr><td>ba</td><td>bb</td><td>-</td><td>-</td><td>-</td></tr> <tr><td>la</td><td>lb</td><td>lc</td><td>-</td><td>-</td></tr> <tr><td>ga</td><td>-</td><td>-</td><td>-</td><td>-</td></tr> <tr><td>oa</td><td>-</td><td>-</td><td>-</td><td>-</td></tr> <tr><td>-</td><td>-</td><td>-</td><td>-</td><td>-</td></tr> <tr><td>-</td><td>-</td><td>si</td><td>sh</td><td>-</td></tr> <tr><td>sa</td><td>-</td><td>sc</td><td>sd</td><td>-</td></tr> <tr><td>ta</td><td>tb</td><td>tc</td><td>-</td><td>te</td></tr> <tr><td>sf</td><td>sg</td><td>ua</td><td>pa</td><td>pb</td></tr> </table>			da	db	dc	dd	_	-	-	ec	-	-	fa	-	fc	-	-	-	-	-	-	-	-	-	-	-	-	ba	bb	-	-	-	la	lb	lc	-	-	ga	-	-	-	-	oa	-	-	-	-	-	-	-	-	-	-	-	si	sh	-	sa	-	sc	sd	-	ta	tb	tc	-	te	sf	sg	ua	pa	pb
da	db	dc	dd	_																																																																				
-	-	ec	-	-																																																																				
fa	-	fc	-	-																																																																				
-	-	-	-	-																																																																				
-	-	-	-	-																																																																				
ba	bb	-	-	-																																																																				
la	lb	lc	-	-																																																																				
ga	-	-	-	-																																																																				
oa	-	-	-	-																																																																				
-	-	-	-	-																																																																				
-	-	si	sh	-																																																																				
sa	-	sc	sd	-																																																																				
ta	tb	tc	-	te																																																																				
sf	sg	ua	pa	pb																																																																				

02-M0277

Tab. 4 Combined label for coupling load and options fitted.

- Take a list of fitted options from the combined coupling load / options label and enter the fitted options as reference.

### 2.2.1 Option da, db, dc, dd

**Compressed air treatment devices**

Option	Option code	Available?
Aftercooler and cyclone separator	da	
Heat exchanger	db	
Fresh air filter	dc	
Filter combination	dd	

Tab. 5 Compressed air treatment options

### 2.2.2 Option ec

**Tool lubricator**

Option	Option code	Available?
Tool lubricator	ec	

Tab. 6 Tool lubricator option

### 2.2.3 Option fa, fc

**Compressed air distributor**

Option	Option code	Available?
Non-separated compressed air distribution line	fa	
Separated compressed air lines downstream of the option	fc	

Tab. 7 Compressed air distributor option

**2.2.4 Option ba, bb****Low temperature equipment**

Option	Option code	Available?
Low temperature equipment	ba	
Low temperature equipment + engine coolant pre-heating	bb	

Tab. 8 Low temperature equipment options

**2.2.5 Option lc****Diesel particulate filter**

Option	Option code	Available?
Diesel particulate filter	lc	

Tab. 9 Diesel particulate filter option

**2.2.6 Option la, lb****Equipment for fire hazard areas**

Option	Option code	Available?
Spark arrestor	la	
Spark arrestor and engine air intake shut-off valve (automatic)	lb	

Tab. 10 Optional equipment for fire hazard areas

**2.2.7 Option ga****Generator**

Option	Option code	Available?
Generator	ga	

Tab. 11 Generator option

**2.2.8 Option oa****Battery isolating switch**

Option	Option code	Available?
Battery isolating switch	oa	

Tab. 12 Optional battery isolating switch

**2.2.9 Option sa, sc, sd, sh, si**  
**Chassis**

Option	Permissible axle load [kg]	Option code	Available?
Height adjustable towbar	1350	sa	
Fixed height towbar	1350	sd	
Fixed height towbar without parking brake	1350	sh	
Stationary, on skids	-	sc	
Stationary, on a base frame	-	si	

Tab. 13 Chassis options

**2.2.10 Option ta, tb, tc, te**  
**Lighting**

Option	Option code	Available?
None (stationary)	ta	
Reflective warning triangle	tb	
EG - 12 V	tc	
USA - 12 V (DOT conformity)	te	

Tab. 14 Lighting options

**2.2.11 Option ua**  
**Hose reels**

Option	Option code	Available?
Hose reels	ua	

Tab. 15 Hose reel option

**2.2.12 Option sf**  
**Anti-theft device**

Option	Option code	Available?
Anti-theft device	sf	

Tab. 16 Optional anti-theft device

**2.2.13 Option sg**  
**Pedestrian protection**

Option	Option code	Available?
Pedestrian protection	sg	

Tab. 17 Pedestrian protection option

**2.2.14 Option pa, pb  
Instrument panel cover**

Option	Option code	Available?
Instrument panel cover	pa	
Generator control box cover	pb	

Tab. 18 Instrument panel cover options

**2.3 Machine (without options)**
**2.3.1 Sound emission**

Guaranteed sound power level:

Type	M 64
Guaranteed sound power level* [dB(A)]	98
* To Directive 2000/14/EC	

Tab. 19 Guaranteed sound power level

Emission sound pressure level:

Type	M 64
Emission sound pressure level** [dB(A)] (according to EN ISO 11203: 1995 number 6.2.3.d)	80.5
Measurement distance: d = 1 m	

Logarithmic surface ratio: Q2 = 17.3 dB(A)

\*\* Calculated from the guaranteed sound power level (2000/14/EC Directive, Sound Emission Standard ISO 3744)

Tab. 20 Emission sound pressure level

**2.3.2 Torques**

Recommended values for hexagonal bolts of strength category 8.8

Hex-head screws							
Thread	M6	M8	M10	M12	M14	M16	M18
Torque [Nm]	9,5	23	46	80	127	195	280

Tab. 21 Torques for hex-head screws

**2.3.3 Ambient conditions**

Positioning	Limit value
Maximum altitude amsl* [m]	1000
* Higher altitudes are permissible only after consultation with the manufacturer.	

Positioning	Limit value
Minimum ambient temperature [°C]	-10
Maximum ambient temperature [°C]	+50

\* Higher altitudes are permissible only after consultation with the manufacturer.

Tab. 22 Ambient conditions

### 2.3.4 Additional specifications according to the machine's operating licence

For specifications according to the machine's operating licence, such as:

- dimensions,
- track width,
- footprint,

are to be found in the dimensioned drawing in chapter 13.3.



The dimensional drawings also show the position of the following inlets and outlets:

- Cooling air inlet
- Cooling air outlet
- Compressed air outlet
- Exhaust

## 2.4 Chassis

### 2.4.1 Mass



The values given are the maximum in each case. Actual mass of individual machines are dependent on equipment fitted (see machine nameplate).

Feature	Chassis			Stationary
Overrun brake	with	with	without	-
Height adjustment	with	without	with	-
Actual total weight [kg]*				
Permissible axle load [kg]	1350	1350	1350	-

\* Enter here for reference, the actual total weight taken from the nameplate.

Tab. 23 Mass of the machine

### 2.4.2 Tyres

Characteristic/marking	Value	
Market	Europe	USA
Dekkdimensjon	185 R 14C	205/75D14
Maximum and recommended tyre pressure [bar]	4.5	3.5

Characteristic/marking	Value	
Market	Europe	USA
Wheel bolts	M 12 x 1.5	½" x 2" (fine)

Tab. 24 Tyres

### 2.4.3 Wheel nut/bolt tightening torque

Market	Wheel bolt thread	Wrench size	Torque [Nm]
Europe	M 12 x 1.5	SW 17	90
USA	½" x 2" (fine)	13/16"	100

Tab. 25 Wheel nut/bolt tightening torque

### 2.4.4 Towbar tightening torque

Components	Thread	Strength category	Torque [Nm]
Ball coupling	M12	8.8	77
	M12	10.9	115
	M14	10.9	125
Towing eye	M12	10.9	115
	M14	10.9	180
Locking lever	M20	–	250
	M28	–	400
	M36	–	650

Tab. 26 Towbar tightening torque

## 2.5 Compressor

### 2.5.1 Working pressure and FAD

Maximum working pressure [bar]	7	10
SIGMA airend	270	260
Free air delivery [m <sup>3</sup> /min]	6.4	5.0

Tab. 27 Working pressure and FAD

### 2.5.2 Compressed air outlet

Outlet valve ["]	Number
G 3/4	2
G 1	1

Tab. 28 Compressed air distributor

### 2.5.3 Pressure relief valves

Maximum working pressure: see machine nameplate

Maximum working pressure [bar]	Relief valve activating pressure [bar]
7	10
10	13

Tab. 29 Pressure relief valve opening pressure

### 2.5.4 Select Temperature

Machine temperatures	Values
Recommended airend discharge temperature for switching to load [°C]	30
Typical compressor block discharge temperature during operation [°C]	75 – 100
Maximum compressor block discharge temperature (automatic safety shut-down) [°C]	115

Tab. 30 Machine temperatures

Temperature at the compressor block discharge port		
Ambient temperature [°C]	Combination valve (thermostatic valve)	
	with ambient temperature acquisition [°C]	without ambient temperature acquisition [°C] (Option db)
10	90	–
20	–	90
25	60	–

Tab. 31 Compressor block discharge temperature

### 2.5.5 Cooling oil recommendation

A sticker showing the type of oil used is located near the oil separator tank filler.  
Information on ordering cooling oil is found in chapter 11.

Characteristic	SIGMA FLUID	
Oil grade	S-460	MOL
Classification	Silicone-free, synthetic oil	Mineral oil
Application	Standard oil for all applications except in connection with foodstuffs.  Particularly suitable for machines with a high duty cycle.	Standard oil for all applications except in connection with foodstuffs.  Particularly suitable for machines with a low duty cycle.

Characteristic	SIGMA FLUID	
Oil grade	S-460	MOL
Approval	—	—
Viscosity at 40 °C	45 mm <sup>2</sup> /s (D 445; ASTM test)	44 mm <sup>2</sup> /s (DIN 51562-1)
Viscosity at 100 °C	7.2 mm <sup>2</sup> /s (D 445; ASTM test)	6.8 mm <sup>2</sup> /s (DIN 51562-1)
Flash point	238 °C (D 92; ASTM test)	220 °C (ISO 2592)
Density at 15 °C	864 kg/m <sup>3</sup> (ISO 12185)	—
Pour point	-46 °C (D 97; ASTM test)	-33 °C (ISO 3016)
Demulsibility at 54 °C	40/40/0/10 min (D 1401; ASTM test)	—

Tab. 32 Cooling oil recommendation

### 2.5.6 Cooling oil charge

Cooling oil	Fluid volume [l]
Machine	15.0
Compressor unit + heat exchanger (option db)	17.0

Tab. 33 Cooling oil charge

## 2.6 Engine

### 2.6.1 Engine data

Feature	Specification
Make/Model	Kubota V 2403-T
Engine control	Mechanical
Fuel injection	Mechanical
Rated engine power [kW]	43.3
Speed at LOAD mode [min <sup>-1</sup> ]	2700
speed at IDLE mode [min <sup>-1</sup> ]	2000
Type of fuel	Diesel *
Fuel consumption under LOAD mode [l/h]	11.7
Oil consumption related to fuel consumption [%]	approx. 0.2

\* Use only diesel fuel to EN 590 or ASTM D975. Consult the engine manufacturer on the use of other fuels if necessary.

Tab. 34 Engine data

### 2.6.2 Oil recommendation

The engine oil must meet the following classification:

- ACEA, class E4, E7
- API, class CF, CI-4



The engine is filled initially with engine oil of viscosity class SAE 10W–40.

Ambient temperature [°C]	Viscosity class
20 ..... 50	SAE 40
0 ..... 20	SAE 20W
-15 ..... 0	SAE 10W
-10 ..... 40	SAE 15W-40
-30 ..... 30	SAE 5W-30
-20 ..... 40	SAE 10W-40

Tab. 35 Engine oil recommendation

#### Option Ic Recommended oil for engines with diesel particulate filters

The engine oil must meet the following classification:

- ACEA, class E6
- API, class CJ-4

Ambient temperature [°C]	Viscosity class	Approved by the manufacturer.
-20 ..... 40	SAE 10W-40	Shell Rimula Signia 10W-40 *

\* Use only engine with low white ash build up.

Tab. 36 Recommended oil for engines with diesel particulate filters

### 2.6.3 Recommended Cooling Fluid

The engine coolant must meet the requirements of specification ASTM D4985.



Do not use a standard coolant / antifreeze that only meets the requirements of ASTM D3306. Such coolants are intended only for light use in vehicles and could shorten the useful life of the engine.

The engine service manual gives further information on coolant application.

### 2.6.4 Fluid volumes

Description	Fluid volume [litre]
Engine oil	9.0
Fuel	105.0

Description	Fluid volume [litre]
Coolant	9.5

Tab. 37 Fluid volumes

### 2.6.5 Batteries

Feature	Value
Voltage [V]	12
Capacity [Ah]	80
PTC testing current [A] (according to EN 50342)	640

Tab. 38 Batteries

Further information Depending on machine equipment, a higher capacity battery may be required. See chapter 2.7.3.

## 2.7 Options

### 2.7.1 Option ec

#### Tool lubricator

Description	Temperature range [°C]	Fluid volume [litre]
Special road breaker lubricant	-25 ..... 50	2.5

Tab. 39 Road breaker lubricant recommendation

### 2.7.2 Option dc

#### Fresh air filter

Feature	Value
Maximum working pressure [bar]	16
Minimum ambient temperature [°C]	1.5
Maximum ambient temperature [°C]	30

Tab. 40 Fresh air filter conditions

### 2.7.3 Option ba

#### Low temperature equipment

##### 2.7.3.1 Ambient conditions

Positioning	Limit value
Maximum altitude amsl* [m]	1000
Minimum ambient temperature [°C]	-25

\* Higher altitudes are permissible only after consultation with the manufacturer.

Positioning	Limit value
Maximum ambient temperature [°C]	+50
* Higher altitudes are permissible only after consultation with the manufacturer.	

Tab. 41 Environmental conditions, low temperature equipment

#### 2.7.3.2 Compressed air line frost protection

Antifreeze	Fluid volume [litre]
Wabcothyl	0.3

Tab. 42 Recommended antifreeze

#### 2.7.3.3 Batteries

Feature	Value
Voltage [V]	12
Capacity [Ah]	100
PTC testing current [A] (according to EN 50342)	850

Tab. 43 Batteries, low-temperature equipment

#### 2.7.3.4 Option bb Coolant pre-heating

Coolant pre-heater	Value
Voltage [V]	230
Power [W]	550

Tab. 44 Coolant pre-heater

#### 2.7.4 Option lc Diesel particulate filter

Feature	Data
Fuel	Diesel *
Operating voltage [V]	12
Filter element	SiC monolith
Degree of particle separation [%] (by mass)	≥99 (elementary carbon)
Ambient temperature [°C]	-20 ..... 50
Protection rating	IP 65

\* Use only diesel fuel to EN 590 or ASTM D975. Consult the engine manufacturer on the use of additives.

Tab. 45 Diesel particulate filter data

**2.7.5 Option ga  
Generator (50 Hz version)**
**Generator specification:**

Features	Generator 400V, 3-ph		Generator 230V, 3-ph		Generator 115V, 2- phase
Rated power [kVA] 3-phase/2-phase	13.0	8.5	13.0	8.5	7.0
Rated power [kVA] single-phase	7.0	5.0	7.5	5.0	5.0
Voltage constant [%] balanced load			±5		
Voltage constant [%] single-phase, unbalanced load			+6/-10		
Rated power [kVA] 3-phase/2-phase	18.8	12.3	32.6	21.0	31.0
Rated current [A] 1-phase	30.0	21.7	32.6	21.0	45.0
Rated current [A] short circuit (0.3 s/170 V)	300.0	260.0	330.0	330.0	420.0
Power factor ( $\cos \phi$ )			0.8 – 1		
Frequency [Hz]			50		
Speed [ $\text{min}^{-1}$ ]			3000		
Distortion factor [%]			<5		
Type	Synchronous internal pole (electronically controlled)				
Protection rating	IP 54				

**Tab. 46 Generator data**
**Reduced FAD:**

Features	Generator 13.0 [kVA]	Generator 8.5 [kVA]		Generator 7.0 [kVA]
Maximum working pres- sure [bar]	7	7	10	7
SIGMA airend	260	260	270	260
Free air delivery [ $\text{m}^3/\text{min}$ ]	5.0	5.0	6.4	5.0
FAD with simultaneous generator operation [ $\text{m}^3/\text{min}$ ]	1.7	3.9	3.0	1.7

**Tab. 47 Delivery in generator mode**

**Connections:**

Type	Generator 400V, 3-ph	Generator 230V, 3-ph	Generator 115V, 2-phase
Power sockets	Quantity:		
16 A; 230 V/1~/N/PE	3	–	–
16 A; 400 V/3~/N/PE	1	–	–
16 A; 230 V/2~/PE	–	2	–
32 A; 230 V/3~/PE	–	1	–
16 A; 230 V/3~/PE	–	1	–
32 A; 115 V/2~/PE	–	–	1
16 A; 115 V/2~/PE	–	–	2

Tab. 48 Connection sockets

**Overload protection switch**

Type	Generator 400V, 3-ph	Generator 230V, 3-ph	Generator 115V, 2-phase
Miniature circuit breaker [A]	Quantity:		
16	1	1	2
32	–	1	1

Tab. 49 Circuit breaker

**Operating limits:**

(to EN 60034-22, page 10, table)

Features	Value
Design category	G3
Voltage adjustment range [%]	±5
Static voltage deviation [%]	1
Maximum dynamic voltage drop [%]	-15
Maximum dynamic voltage rise [%]	20
Maximum voltage settling time [ms]	1500
Maximum voltage asymmetry [%]	1

Tab. 50 Generator operating limits

**Maximum power loading by consumers**

Resistive consumers include lamps and heaters, for example.

Electric motors and transformers are inductive consumers.

Nominal rating conditions:

- Ambient temperature: 25 °C
- Max. height above sea level at the place of use: 1000 m

#### Three-phase power supply

Generator		400V, 3-ph		230V, 3-ph	
Rated power [kVA]		13.0	8.5	13.0	8.5
Resistive consumers [kVA]	-	13.0	8.5	12.7	8.5
Inductive consumers [kW]	Rated power	7.5	5.0	12.7	8.5

Tab. 51 Maximum three-phase mains loading

#### AC power:

Generator		400V, 3-ph		230V, 3-ph		115V, 2-ph
Rated power [kVA]		13.0	8.5	13.0	8.5	7.0
Resistive consumers [kVA]	per phase	3.5	-	3.5	-	-
	total	10.5	5.0	10.5	5.0	5.0
Inductive consumers [kW]	Rated power per phase	3.5	-	3.5	-	-
	Rated power total	10.5	5.0	10.5	5.0	5.0

Tab. 52 Maximum single-phase mains loading

#### Power reduction at elevated ambient temperatures:

Ambient temperature [°C]	Generator power
≤30	Full power available
>30	Reduction of 10% for each temperature rise of 10°C.

Tab. 53 Power reduction at elevated ambient temperatures

#### 2.7.6 Option ga Generator (60 Hz version)

##### Generator specification:

Features	Generator 250V, 2-phase	
Rated power [kVA] 2-phase	13.0	8.0

Features	Generator 250V, 2-phase	
Rated power [kVA] single-phase	7.0	5.0
Voltage [V]	250/125	
Voltage constant [%] balanced load		±5
Voltage constant [%] single-phase, unbalanced load		+6/-10
Rated current [A] 2-phase (230 V)	56.0	35.0
Rated current [A] 2-phase (115 V)	56.0	44.0
Rated current [A] short circuit (0.3 s/170 V)	360.0	360.0
Power factor ( $\cos \phi$ )		0.8 – 1
Frequency [Hz]		60
Speed [ $\text{min}^{-1}$ ]		3600
Distortion factor [%]		<5
Type	Synchronous internal pole (electronically controlled)	
Protection rating	IP 54	

Tab. 54 Generator data

**Reduced FAD:**

Features	Generator 13.0 [kVA]	Generator 8.0 [kVA]	
Maximum working pres- sure [bar]	7	7	10
Free air delivery [ $\text{m}^3/\text{min}$ ]	5.4	7.0	5.4
FAD with simultaneous generator operation [ $\text{m}^3/\text{min}$ ]	1.8	3.2	1.8

Tab. 55 Delivery in generator mode

**Connections:**

Power sockets	Quantity:
30 A; 250 V/2~/PE	2
20 A; 125 V/2~/PE	2

Tab. 56 Connection sockets

**Overload protection switch**

Type	Generator 250V, 2-phase	Generator 125V, 1-phase
Miniature circuit breaker [A]		Quantity:
20	1	1

**Tab. 57 Circuit breaker**
**Operating limits:**

(to EN 60034-22, page 10, table)

Features	Value
Design category	G3
Voltage adjustment range [%]	±5
Static voltage deviation [%]	1
Maximum dynamic voltage drop [%]	-15
Maximum dynamic voltage rise [%]	20
Maximum voltage settling time [ms]	1500
Maximum voltage asymmetry [%]	1

**Tab. 58 Generator operating limits**
**Maximum power loading by consumers**

Resistive consumers include lamps and heaters, for example.

Electric motors and transformers are inductive consumers.

**Nominal rating conditions:**

- Ambient temperature: 25 °C
- Max. height above MSL of the place of installation: 1,000 m

Generator [kVA]		13.0	8.0
Resistive consumers [kVA]	per phase	6.5	4.0
	total	13.0	8.0
Inductive consumers [kW]	Rated power	5.0	5.0

**Tab. 59 Maximum power supply load**
**Power reduction at elevated ambient temperatures:**

Ambient temperature [°C]	Generator power
≤30	Full power available
>30	Reduction of 10% for each temperature rise of 10°C.

**Tab. 60 Power reduction at elevated ambient temperatures**

## 3 Safety and Responsibility

### 3.1 Basic instructions

The machine is manufactured to the latest engineering standards and acknowledged safety regulations. Nevertheless, dangers can arise through its operation:

- danger to life and limb of the operator or third parties,
- Impairments to the machine and other material assets.



Disregard of warning or safety instructions can cause serious injuries!

- Use this machine only if it is in a technically perfect condition and only for the purpose for which it is intended; observe all safety measures and the instructions in the service manual!
- Immediately rectify (have rectified) any faults that could be detrimental to safety!

### 3.2 Specified use

The machine is intended solely for generating compressed air for industrial use. Any other use is considered incorrect. The manufacturer is not liable for any damages that may result from incorrect use. The user alone is liable for any risks incurred.

- Keep to the specifications listed in this service manual.
- Operate the machine only within its performance limits and under the permitted ambient conditions.
- Do not use compressed air for breathing purposes unless it is specifically treated.

### 3.3 Incorrect Use

Improper usage can cause damage to property and/or (severe) injuries.

- Only use the machine as intended.
- Never direct compressed air at persons or animals.
- Do not use untreated compressed air for breathing purposes.
- Do not allow the machine to take in toxic, acidic, flammable or explosive gases or vapours.
- Do not operate the machine in areas in which specific requirements with regard to explosion protection are in force.

### 3.4 User's Responsibilities

#### 3.4.1 Observe statutory and universally accepted regulations

These are, for example, nationally applied European directives and/or valid national laws and safety and accident prevention regulations.

- Observe relevant statutory and accepted regulations during operation, transporting and maintenance of the machine.

### **3.4.2 Determining personnel**

Suitable personnel are experts who, by virtue of their training, knowledge and experience as well as their knowledge of relevant regulations can assess the work to be done and recognize the possible dangers involved.

Authorised operators possess the following qualifications:

- are of legal age,
- are conversant with and adhere to the safety instructions and sections of the service manual relevant to operation,
- have received adequate training and authorization to operate vehicles and electrical and compressed air devices.

Authorised maintenance personnel possess the following qualifications:

- are of legal age,
- have read, are conversant with and adhere to the safety instructions and sections of the service manual applicable to maintenance,
- are fully conversant with the safety concepts and regulations of motor vehicle, electrical and compressed air engineering,
- are able to recognize the possible dangers of motor vehicle, electrical and compressed air devices and take appropriate measures to safeguard persons and property,
- have received adequate training in and authorization for the safe installation and maintenance of this machine.

Authorised transport personnel possess the following qualifications:

- are of legal age,
  - are conversant with and adhere to the safety instructions and sections of the service manual relevant to transporting,
  - are trained and authorised in safe vehicle transporting,
  - are conversant with the safety regulations relating to handling motor vehicles and transport goods,
  - are able to recognise the possible dangers of motor vehicles and take appropriate measures to safeguard persons and property.
- Ensure that personnel entrusted with operation, maintenance and transporting are qualified and authorized to carry out their tasks.

### **3.4.3 Adherence to inspection schedules and accident prevention regulations**

The machine is subject to local inspection schedules.

#### **Examples of German operation**

- Have the pre-commissioning inspection carried out according to the Ordnance on Safety and Health, paragraph 14.
- Recurring inspections according to BGR 500, chapter 2.11:  
The user must ensure that the machine's safety devices are checked for function as required or at least annually.

### 3 Safety and Responsibility

#### 3.5 Dangers

- Carry out oil changes to BGR 500, chapter 2.11.  
The user must ensure that the cooling oil is changed as required or at least annually and the oil change must be documented. Intervals may be varied if an analysis proves that the oil is still usable.
- Keep to inspection intervals in accordance with the Ordinance on Industrial Safety and Health with maximum intervals as laid down in §15.

Inspection	Inspection interval	Inspecting authority
Equipment inspection	Before commissioning	Approved supervisory body
Internal inspection	Every 5 years after commissioning or the last inspection	Competent person (e. g. KAESER Service Technician)
Strength test	Every 10 years after commissioning or the last inspection	Competent person (e. g. KAESER Service Technician)

Tab. 61 Inspection intervals according to regulations

#### Checking the lifting point

The user is responsible for ensuring that the machine's lifting point and fixings are inspected according to national regulations for wear and damage.

- Have the lifting point checked.  
If the lifting point and fixings are not fully in order the machine may not be lifted in this way.  
Have the machine repaired immediately.

#### 3.4.4 Option Ic

#### Complying with inspection intervals for diesel particulate filters

The machine is subject to local inspection schedules. Inspecting authority: e.g. KAESER Service.

- Have the TRGS 554 inspection carried out annually and the TÜV (or local equivalent) every two years.

### 3.5 Dangers

#### Basic instructions

The following describes the various forms of danger that can occur during machine operation.

Basic safety instructions are found in this service manual at the beginning of each chapter in the section entitled 'Safety'.

Warning instructions are found before a potentially dangerous task.

#### 3.5.1 Safely dealing with sources of danger

The following describes the various forms of danger that can occur during machine operation.

#### Exhaust fumes

Exhaust gases from combustion engines contain carbon monoxide, a colour- and odour-less but highly toxic gas. The inhalation of minute quantities can be lethal.

Furthermore, diesel exhaust contains soot particles, some of which are noxious.

### 3 Safety and Responsibility

#### 3.5 Dangers

- Do not inhale exhaust fumes.
- Never use the machine in enclosed spaces, only in the open.
- Direct the exhaust fumes to the open air with a pipe of at least 100 mm diameter.

#### Fire and explosion

Spontaneous ignition and combustion of fuel can result in serious injury or death.

- Do not allow open flames or sparks at the place of use.
- Do not smoke while re-fueling.
- Never refuel the machine when it is running.
- Do not allow fuel to overflow.
- Wipe up spilled fuel immediately.
- Provide a fire extinguisher in the immediate vicinity.
- For the operation in combustible environment, fit the machine with an exhaust silencer (Option Ia).

#### Hot coolant

The cooling system of a liquid-cooled engine at running temperature is under high pressure. Coolant can spray out when the filler cap is opened causing severe burns.

- Let the machine cool down before opening the cooling system.
- Unscrew the filler cap carefully by a quarter to half a turn at first. Remove the filler cap only when pressure has escaped completely.

#### Electricity

Touching voltage carrying components can result in electric shocks, burns or death.

- Allow only qualified and authorised electricians or trained personnel under the supervision of a qualified and authorised electrician to carry out work on electrical equipment according to electrical engineering regulations.
- Check regularly that all electrical connections are tight and in order.
- Switch off any external power sources.  
For example, the connections to the electrical engine cooling water pre-heater.

#### Forces of compression

Compressed air is a contained force. Uncontrolled release of this force can cause serious injury or death. The following information concerns work on components that could be under pressure.

- Wait until the compressor has automatically vented (check: the pressure gauge must read 0 bar!)
- Then open an outlet valve carefully to ensure that the line between the minimum pressure / check valve and the compressed air outlet is vented.
- Do not carry out welding, heat treatment or mechanical modifications to pressurized components (e.g. pipes and vessels) as this influences the component's resistance to pressure.  
The safety of the machine is then no longer ensured.

#### Compressed air quality

The composition of the compressed air must be suitable for the actual application in order to preclude health and life-threatening dangers.

### 3 Safety and Responsibility

#### 3.5 Dangers

- Use appropriate systems for air treatment before using the compressed air from this machine as breathing air (fresh air reinforcement) and/or for the processing of foodstuffs.
- Use foodstuff-compatible cooling oil whenever compressed air is to come into contact with foodstuffs.

#### Spring force

Springs under tension or compression store energy. Uncontrolled release of this force can cause serious injury or death.

Minimum pressure / check valves, pressure relief valves and inlet valves are powerfully spring-loaded.

- Do not open or dismantle any valves.

#### Rotating components

Touching the fan wheel, the coupling or the belt drive while the machine is switched on can result in serious injury.

- Do not open the access doors and cover panels while the machine is running.
- Switch off and lock out the machine and check that no voltage is present before opening the access doors or canopy.
- Wear close-fitting clothes and a hair net if necessary.
- Make sure all covers and safety guards are in place and secured before starting.

#### Temperature

The operation of the combustion engine and the compression generate high temperatures. Touching hot components may cause injuries.

- Avoid contact with hot components.  
These include, for example, engine, compressor airend, oil and compressed air lines, coolers and oil separator tank. Any objects in or near the flow of exhaust gas or discharged cooling air will become very hot.
- Wear protective clothing.
- Wear protective gloves when connecting or disconnecting compressed air hoses.
- Allow the machine to cool down before commencing any maintenance work.
- When welding is taking place on or near the machine take adequate measures to ensure that no parts of the machine or any oil vapours can ignite because of sparks or heat.

#### Noise

The enclosure absorbs the machine noise to a tolerable level. This function will be effective only if the bodywork is closed.

- Operate the machine only with closed bodywork and intact sound insulation.
- Wear hearing protection if necessary.  
The pressure relief valve blowing off can be particularly loud.

#### Operating fluids/materials

The used operating fluids and materials can cause adverse health effects. Suitable safety measures must be taken in order to prevent injuries.

- Strictly forbid fire, open flame and smoking.

- Follow safety regulations when dealing with fuel, lubricants, antifreeze and chemical substances.
- Avoid contact with skin and eyes.
- Do not inhale fumes or vapours from fuel or oil.
- Do not eat or drink while handling fuel, cooling and lubricating fluids or antifreeze.
- Suitable fire extinguishing material must be to hand.
- Use only KAESER approved operating materials.

**Unsuitable spare parts**

Unsuitable spare parts compromise the safety of the machine.

- Use only spare parts approved by the manufacturer for use in this machine.
- Use only genuine KAESER replacement parts on pressure bearing parts.

**Conversion or modification of the machine**

Modifications, additions to and conversions of the machine can result in unpredictable dangers.

- Do not convert or modify the machine!
- Do not fit any non-approved additional components.
- Do not make any changes to the machine that will increase its weight beyond the permissible limit and/or endanger its safe use or transportation.
- Obtain written approval by the manufacturer prior to any technical modification or expansion of the machine.

**3.5.2 Safe machine operation**

Information on conduct that will help in handling the machine safely is given here.

**Personal protective equipment**

When working on the machine you may be exposed to dangers that can result in accidents with severe adverse health effects.

- Wear protective clothing as necessary.

Suitable protective clothing (examples):

- Safety workwear
- Protective gloves
- Safety boots
- Eye protection
- Ear protection

**3.5.2.1 Transporting**

The weight and size of the machine require safety measures during its transport to prevent accidents.

- Allow transportation only by personnel trained in safely dealing with motor vehicles and the transporting of goods.
- Ensure that no persons are on the machine when transporting.

**Transport as trailer**

Non-compliance with the basic rules for a safe trailer operation may cause severe accidents during machine transport.

- The maximum permissible load for the towing vehicle coupling and the maximum coupling load given for the machine must not be exceeded.
- Avoid causing a shift in the centre of gravity by an excessive or incorrectly distributed load.
- Do not tow in a manner that will impose excessive stress on the machine or chassis.
- Adjust towing speed to accommodate ground conditions. This applies particularly to unpaved roads and when taking curves.
- The towbar must be parallel with the ground otherwise towing instability can develop, resulting in damage to the machine and/or towing vehicle.
- Before moving the machine, make sure any security devices (e.g. anti-theft chain) are released.

**Transport as trailer on public roads**

- Do not tow machines without illumination and signaling equipment on public roads.
- Ensure all running gear, including chassis, wheels, brakes, signalling and lighting, is in safe condition.
- The local laws and regulations regarding the use of public roads must be observed.

**Transporting with a crane**

Non-compliance with the safety regulations for load suspension and hoisting equipment may cause severe accidents during lifting and moving the machine with cranes.

- Do not enter the danger zone while the machine is being lifted.
- Never lift the machine over people or occupied buildings.
- Avoid extreme weight shifting caused by additional loads or additions (tilting).
- Do not exceed the lifting capacity on the machine's lifting point (lifting eye).
- Only the designated lifting point should be used to attach lifting gear and under no circumstances are handles, towbar or other components to be used.
- Use only hooks and shackles that comply with local safety regulations
- Do not attach cables, chains or ropes directly to the machine's lifting eye.
- Do not manipulate the crane suspension system, in particular the holding points of the crane lifting eye.
- Avoid jerking when lifting, as this may damage components.
- Loads must be slowly lifted and carefully set down.
- Never allow the load to hang from the crane longer than necessary.



The following are forbidden:

- Air transport of the machine by slinging beneath a helicopter.
- dropping by parachute.

**3.5.2.2 Positioning**

A suitable installation location for the machine prevents accidents and faults.

- Do not position the machine directly against a wall. A build up of heat from the exhaust can damage the machine.

### 3 Safety and Responsibility

#### 3.5 Dangers

- Ensure accessibility so that all work on the machine can be carried out without danger or hindrance.
- Do not operate in areas in which specific requirements with regard to explosion protection are applied.  
For instance, the requirements of ATEX directive 94/9/EC "Equipment and Protective Systems intended for use in Potentially Explosive Atmospheres".
- Ensure adequate ventilation.
- Place the machine in such a manner that the working conditions in its environment are not impaired.
- Comply with limit values for ambient temperature and humidity.
- The intake air must not contain any damaging contaminants,

Damaging contaminants are for instance:

- Exhaust gasses from internal combustion engines,
  - flammable, explosive or chemically instable gases and vapours,
  - Acid or base forming substances such as ammonia, chlorine or hydrogen sulfide.
- Do not position the machine in warm cooling outlet air from other machines.
  - Keep suitable fire extinguishing agents ready for use.
  - Chock the wheels to prevent unwanted movement.
  - Do not place additional loads on the machine (e.g. excavator bucket as anti-theft measure).

##### 3.5.2.3 Commissioning, operation and maintenance

During commissioning, operation and maintenance you may be exposed to dangers resulting from, e.g., electricity, pressure and temperature. Careless actions can cause accidents with severe adverse effects for your health.

- Allow maintenance work to be carried out only by authorised personnel.
- Wear close-fitting, flame-resistant clothing. Wear protective clothing as necessary.
- Switch off the machine and lock out the supply disconnecting device.
- Wait until the compressor has automatically vented (check: The pressure gauge must read 0 bar!).
- Then open the outlet valve carefully to ensure that the line between the minimum pressure / check valve and the compressed air outlet is vented.
- Allow the machine to cool down.
- Do not open the bodywork while the machine is switched on.
- Do not open or dismantle any valves.
- Use only spare parts approved by KAESER for use in this machine.
- Carry out regular inspections:
  - for visible damage and leakage,
  - of safety devices,
  - of the EMERGENCY STOP device,
  - of parts needing monitoring.
- Pay particular attention to cleanliness during all maintenance and repair work. Cover components and openings with clean cloths, paper or tape to keep them clean.
- Do not leave any loose components, tools or cleaning rags on or in the machine.

### 3 Safety and Responsibility

#### 3.6 Safety devices

- Components removed from the machine can still be dangerous:  
Do not attempt to open or destroy any components taken from the machine.
- Use only suitable compressed air hoses.

Compressed air hoses must meet the following requirements:

- that are of the right type and size for the highest permissible machine working pressure,
  - that are not damaged, worn or of reduced quality,
  - that have hose couplings and connections of the right type and size.
- 
- Make sure compressed air hoses are de-pressurised before disconnecting from the machine.
  - Secure the open end of an air hose before applying air pressure. An unsecured hose may whip and cause injury.
  - At working pressures >7 bar, compressed air hoses should be secured by a cable to their respective outlet valves.

#### 3.5.2.4 De-commissioning, storage and disposal

Improper handling of old operating fluids and components represent a danger for the environment.

- Drain out fluids and dispose of according to environmental regulations.  
These include, for example, fuel, engine oil and compressor cooling oil and engine coolant.
- Dispose of the machine in accordance with local environmental regulations.

#### 3.5.3 Organisational Measures

- Designate personnel and their responsibilities.
- Give clear instructions on reporting faults and damage to the machine.
- Give instructions on fire reporting and fire-fighting measures.

#### 3.5.4 Danger areas

The table gives information on areas dangerous to personnel.

Only authorized personnel may enter these areas.

Task	Danger area	Authorized personnel
Transport	Within a 3 m radius of the machine.	Operating personnel to prepare for transport. No personnel during transport.
	Beneath the lifted machine.	No personnel!
Commissioning	Within the machine.	Maintenance personnel
	Within a 1 m radius of the machine.	
Operation	Within a 1 m radius of the machine.	Operating personnel
Maintenance	Within the machine.	Maintenance personnel
	Within a 1 m radius of the machine.	

Tab. 62 Danger areas

#### 3.6 Safety devices

Various safety devices ensure safe working with the machine.

- Do not change, bypass or disable safety devices.
- Regularly check safety devices for their correct function.
- Do not remove or obliterate labels and notices.
- Ensure that labels and notices are clearly legible.

Further information More information on safety devices is contained in chapter 4.5.

### 3.7 Safety signs

The diagram shows the positions of safety signs on the machine. The table lists the various safety signs used and their meanings.




Fig. 1 Location of safety signs

Item	Sign	Meaning
160*		Incorrect oil levels can cause damage to the machine or excessive oil content in the compressed air! ➤ Check the oil level regularly and correct as necessary.
310 311		It is forbidden to run the machine with open access doors or panels. Personal injury or machine damage can result from an open machine enclosure. ➤ Operate only with the enclosure fully closed. ➤ Transport only with the enclosure fully closed.

\* Location within the machine

\*\* Portable machines only

\*\*\* only machines with option dc

\*\*\*\* only machines with option ga

### 3 Safety and Responsibility

#### 3.7 Safety signs

Item	Sign	Meaning
320*		Loud noise and oil mist! Hearing damage and burns from relief valve blow off. ➤ Wear hearing protectors and protective clothing. ➤ Close the canopy or doors. ➤ Work with caution.
330 331		Hot surface! Risk of burns caused by contact with hot components! ➤ Do not touch the surface. ➤ Wear long-sleeved garments (not synthetics such as polyester) and protective gloves.
332		Hot surfaces and dangerous gasses! Burns from contact with hot components or gasses. ➤ Do not touch the surface. ➤ Wear long-sleeved garments (not synthetics such as polyester) and protective gloves. ➤ Do not inhale dangerous gases.
450		Loud noise and compressed air blast! Damage to hearing and injury if ball valve is opened without a compressed air hose being connected. ➤ Connect a compressed air hose. ➤ Open the ball valve.
500**		Risk of accident from unstable towing! Injury and machine damage possible. ➤ The compressor towbar must be parallel with the ground when coupled to the towing vehicle. ➤ Note instructions in the service manual regarding transporting.
510**		Malfunction due to insufficient maintenance. Injury and machine damage possible. ➤ Regularly maintain the chassis. ➤ Note the instructions in the operating manual regarding the chassis.
600*		Risk of fatal injury caused by dismantling valves (spring-loaded or under pressure)! ➤ Do not open or dismantle valves. ➤ Call an authorised Service Technician in the event of a fault.
620 621		Risk of serious lacerations or even severing of extremities (fingers) from rotating components! ➤ Operate the machine only with closed safety guards, access doors and panels. ➤ Shut down the machine before opening a door or canopy.

\* Location within the machine

\*\* Portable machines only

\*\*\* only machines with option dc

\*\*\*\* only machines with option ga

### 3 Safety and Responsibility

#### 3.8 Generator operation

Item	Sign	Meaning
850***		Risk of fatal injury caused by contact with live components! ➤ Take protective measures.
1222***		Danger! Mortal danger from CO, CO <sub>2</sub> or toxic gas. ➤ Draw in only surrounding air of breathing quality.
		Danger! Danger to health from discharge of oily compressed air. ➤ Maintain surrounding air temperature between +1.5 °C and 30 °C. ➤ Check the oil indicator at least once a day.

\* Location within the machine

\*\* Portable machines only

\*\*\* only machines with option dc

\*\*\*\* only machines with option ga

Tab. 63 Safety signs

### 3.8 Option ga Generator operation

#### 3.8.1 Comply with the protective measures against dangerous electric current

Protection against dangerous electric current is regulated by the "Low-voltage current generating installations" directive IEC 60364–5–551 (DIN VDE 0100–551).

The protective measure concerning "isolation, insulation monitoring and shut-down" is applied. The generator is equipped with an automatic mains cut-out with overcurrent release and insulation monitoring in accordance with this protective measure.

- Observe and follow the regulations concerning protection against dangerous electric current when using the generator.

#### 3.8.2 Safe generator operation

Take note of the following to ensure the safe operation of the machine with a generator:

- Check correct function of the insulation monitoring device daily.
- Do not earth the neutral line (N) or connect it to the common protective earth/equipotential bonding (PE).
- Make sure the equipotential bonding to earth is properly carried through (mains and machine through cable to consumer).
- If the generator feeds a network (TN network), let the network's protective measures remain effective or create another protective measure that is effective.
- Adjust the protective measures accordingly if the generator feeds a different network.
- Only a qualified electrician is allowed to carry out work on the generator or generator control box. The electrician is responsible for the effectiveness of the protective measures provided.
- Do not use the generator for feeding the construction current distribution.
- A generator with insulation monitoring must not be connected to another insulation monitoring device as these monitoring devices can then have counter effects.

- Ground fault current (F1) protection switches do not function in unearthing networks (IT network such as provided by the generator). The isolation provided by the generator, however, makes a further ground fault current protection switch unnecessary.
- Follow the regulations of the local electricity supply utility and obtain any necessary permits.
- When cleaning the inside of the machine, do not direct water or steam jets directly at the generator or terminal box.
- Check regularly that all electrical connections are tight and in proper condition.

### **3.8.3 Connecting extension cables**

- When operating the generator, observe the regulations regarding the connection of extension cables.

Bear in mind:

- In IT networks, the total length of power cables may not exceed 250 m ((DIN VDE 0100, Part 728 / IEC 60364-5-551)).
- Use at least H07RN-F cables to DIN VDE 0282 Part 4 (IEC 60245-4 / HD 22.4) as non-fixed extension cables.

### **3.8.4 Do not exceed the maximum supply system load**

- When operating the generator, do not exceed the maximum supply system load due to connected consumers.

Bear in mind:

- The power consumption values of simultaneous consumers are added.
- The maximum continuous power loading on the generator by the connected consumers is limited by the safety cut-out.

### **3.8.5 Perform regular generator inspections**

To ensure a safe operation, the machine must be subjected to regular inspections.

Daily inspection prior to activating the device by authorised operating personnel:

- Insulation monitor function check.

Annual inspection by trained and authorised electrician:

- Inspect the generator and generator control cubicle for mechanical damages.
- Inspect the protective conductor.
- Measure the dielectric resistance.
- Measure the substitute leakage current.
- Test the generator functionality.
- Test the proper functioning of the generator fan and clean, if required.
- Clean the cooling air openings.
- Check and tighten the screw connections at the generator and the generator control cubicle.
- Check covers and power socket caps for damage and good sealing.
- Check the completeness of labeling and warning labels.

## 3.9 Emergencies

### 3.9.1 Correct fire fighting

#### Suitable measures

Calm and prudent action can save lives in the event of a fire.

- Keep calm.
- Give the alarm.
- Shut down the machine from the instrument panel if possible.
- Warn and move endangered personnel to safety.
- Help incapacitated persons.
- Close the doors.
- When trained accordingly: Attempt to extinguish the fire.

#### Extinguishing substances

- Suitable extinguishing media:  
Foam  
Carbon dioxide  
Sand or soil
- Unsuitable extinguishing media:  
Strong jet of water

### 3.9.2 Injury from handling operating fluids/materials

The following operating fluids/materials are in the machine:

- fuel
- Lubricating oil
- Compressor cooling oil
- Engine coolant
- Battery electrolyte
- Tool lubricant (option e)
- Antifreeze (option ba)

#### Eye contact

Fuel, oil and other fluids/materials can cause irritation.

- Rinse open eyes thoroughly for a few minutes.
- Seek medical advice for persistent irritation.

#### Skin contact

Fuel, oil and other fluids/materials may irritate after prolonged contact.

- Wash thoroughly with skin cleaner, then with soap and water.
- Contaminated clothing should be intensively cleaned before reuse.

**Inhalation**

Fuel and oil vapours impair breathing.

- Clear the respirator tract from fuel or oil vapour.
- Seek medical help if difficulty with respiration continues.

**Ingestion**

- Wash out the mouth immediately.
- Do not induce vomiting.
- Seek medical aid.

**3.10 Warranty**

This service manual contains no independent warranty commitment. Our general terms and conditions apply with regard to warranty.

A condition of our warranty is that the machine is used solely for the purpose for which it is intended and under the conditions specified.

Due to the multitude applications for which the machine is suitable the obligation lies with the user to determine its suitability for his specific application.

Furthermore, we accept no warranty obligation for:

- the use of unsuitable parts or operating materials,
- un-authorised modifications,
- incorrect maintenance,
- incorrect repair.

Correct maintenance and repair includes the use of genuine KAESER spare parts and operating materials.

- Obtain confirmation from KAESER that your specific operating conditions are suitable.

**3.11 Identifying the effects of improper modifications**

The machine and various modules are designed according to applicable regulations and are submitted for approval procedures by the relevant authorities (where applicable).

Concerned modules include:

- Compressor drive motor
- Fuel supply
- Exhaust system
- Chassis (if available)
- Compressor unit
- Pressure-bearing components (e.g., valves, vessels, pipelines)

Remodeling or modifications can have the result that the interaction of the individual modules according to regulations is no longer ensured. Thus, the prerequisites required for approval by the authorities may no longer be given.

The concerned directives and regulations can be:

- Machinery directive
- Pressure vessel directive
- EMC directive
- Directive on environmental noise

In machines requiring a national road traffic permit, remodeling or modifications may adversely affect their approval for road traffic.

- Exhaust emission limits may not be met.
- The prerequisites for approval are no longer given.

Remodeling or modifications restrict the service work that can be performed for you (examples):

- Warranty (if directly and originally affected by the remodeling or modification)
- Reduced replacement part supply (scope, delivery times)

## **3.12 Environment protection**

The operation of this machine may cause dangers for the environment.

- Do not allow operating materials to escape to the environment or into the sewage system.
- Store and dispose of operating materials and replaced parts in accordance with local environment protection regulations.
- Observe national regulations.  
This applies particularly to parts contaminated with fuel, oil, coolants and acids.

## 4 Design and Function

### 4.1 Bodywork

Bodywork is understood to be the exterior of the machine mounted on the chassis.




Fig. 2 Bodywork

- |     |                      |     |                                 |
|-----|----------------------|-----|---------------------------------|
| [1] | Right-hand wing door | [5] | Sound damping louvre for cooler |
| [2] | Handle               | [6] | Left-hand wing door             |
| [3] | Snap fastener        | [7] | Cover for lifting eye           |
| [4] | Lower body           |     |                                 |

The bodywork has several functions when it is closed:

- Weather protection
- Sound insulation
- Guarding against touching
- Cooling air flow


The bodywork is not suitable for the following uses:

- Persons walking, standing or sitting on the machine.
- Use as resting place or storage of any kind of load.


Safe and reliable operation is only ensured when the bodywork is closed.

The wing doors are provided with handles for opening. Release the doors by the snap fasteners.

The doors are held open by gas springs.

**4.2 Machine installation**

**Fig. 3 Right-hand door opened**

- |   |                                 |   |  |
|---|---------------------------------|---|--|
| ① | Operating panel                 | ⑦ | Fuel micro-filter                          |
| ② | Oil separator tank              | ⑧ | Oil cooler                                 |
| ③ | Oil filler port with plug       | ⑨ | Coolant expansion tank                     |
| ④ | Combination valve               | ⑩ | Engine air filter                          |
| ⑤ | Fuel tank                       | ⑪ | Control valve with proportional controller |
| ⑥ | Fuel pre-filter with water trap |   |  |


**Fig. 4 Left-hand door opened**

- |   |                              |   |                       |
|---|------------------------------|---|-----------------------|
| ⑫ | Water cooler                 | ⑯ | Airend                |
| ⑬ | Fan                          | ⑰ | Battery               |
| ⑭ | Lifting eye                  | ⑱ | Inlet valve           |
| ⑮ | Drive motor                  | ㉑ | Pressure relief valve |
| ⑯ | tool box provides sufficient | ㉒ | Lifting eye cover     |
| ⑰ | Compressor air filter        |   |                       |

## 4.3 Machine function

### Machine function (without options)

Item numbers correspond to the pipe and instrument flow diagram (P&ID) in chapter 13.2.




Fig. 5 Machine layout

- |    |                            |    |  |
|----|----------------------------|----|--|
| 1  | Compressor air filter      | 16 | Oil return line                        |
| 3  | Inlet valve                | 19 | Combination valve (thermostatic valve) |
| 4  | Airend                     | 20 | Oil cooler                             |
| 5  | Oil separator tank         | 21 | Oil filter                             |
| 7  | Oil separator cartridge    | 23 | Proportional controller                |
| 10 | Compressed air distributor | 24 | Engine air filter                      |
| 12 | Temperature gauge switch   | 27 | Venting valve                          |
| 13 | Pressure relief valve      | 28 | Fan                                    |
| 14 | Pressure gauge             | 37 | Minimum pressure/check valve           |
| 15 | Drive motor                | 52 | Control valve                          |

Ambient air is cleaned as it is drawn in through the filter ①.

The air is then compressed in the airend ④.

The airend is driven by an internal combustion engine [15].

Cooling oil is injected into the airend. It lubricates moving parts and forms a seal between the rotors themselves and between them and the airend casing. This direct cooling in the compression chamber ensures a very low airend discharge temperature.

Cooling oil recovered from the compressed air in the oil separator tank [5] gives up its heat in the oil cooler [20]. The oil then flows through the oil filter [21] and back to the point of injection. Pressure within the machine keeps the oil circulating. A separate pump is not necessary. A thermostatic valve [19] automatically maintains optimum cooling oil temperature.

Compressed air, freed of cooling oil in the oil separator tank [5], flows through the minimum pressure / check valve [37] into the air distributor [10]. The minimum pressure / check valve ensures that there is always a minimum internal pressure sufficient to maintain cooling oil circulation in the machine.

The cooling fan [28] ensures optimum cooling of all components within the enclosure.

## **4.4 Operating modes and control modes**

### **4.4.1 Operating modes**

The machine operates in the following modes:

- **LOAD**
  - The inlet valve is open.
  - The engine runs at maximum speed.
  - The compressor block delivers compressed air.
- **MODULATING**
  - With the help of a control valve (the proportional controller) the degree of opening of the inlet valve is steplessly varied in response to the air demand.
  - The load and fuel consumption of the engine rises and falls with the air demand.
  - The compressor block delivers compressed air.
- **IDLE**
  - The inlet valve is closed.
  - The control valve opens, allowing pressure in the oil separator tank to be applied to the inlet valve.
  - Compressed air then flows in a closed circuit through the compressor block, the oil separator tank and the control valve.
  - The pressure in the oil separator tank remains constant.
  - The engine runs at minimum speed.
- **STANDSTILL (shut down)**
  - The inlet valve closes.
  - The venting valve opens to de-pressurise the machine.
  - The engine stops.

### **4.4.2 PART LOAD control**

The control system regulates the volume of air generated to match the actual demand. The machine keeps the working pressure constant by varying the volume of compressed air delivered, thereby matching the air demand.

With the help of a mechanical control valve (the proportional controller), the opening and closing of the inlet valve is continuously varied in relation to the actual air demand. The compressor block provides compressed air for connected consumers.

This stepless delivery regulation minimises fuel consumption of the engine. The load and fuel consumption of the engine rises and falls with the air demand.




Fig. 6 Stepless regulation of FAD (standstill)

- [3] Inlet valve
- [4] Airend
- [5] Oil separator tank
- [26] Engine speed control cylinder
- [46] Nozzle

- [63] Directional valve (proportional valve)
- [52] Control valve comprising the following components:
  - [23] Proportional controller
  - [27] Venting valve
- [62] Combined auxiliary valve (directional control valve)

## 4.5 Safety devices

### 4.5.1 Monitoring functions with shutdown

The following functions are monitored automatically.

- Engine oil pressure
- Coolant temperature
- Airend discharge temperature
- Engine alternator



The fuel stop device is activated when an alarm occurs. The engine comes to a stop and the venting valve releases pressure from the machine.

### 4.5.2 Further safety devices

The following safety devices are provided and may not be modified in any way.


- Pressure relief valves:  
Pressure relief valves protect the system against unacceptable pressure rise. They are factory set.
- Enclosures and guards for moving parts and electrical connections  
Protect against accidental contact.

## 4.6 Options

The options available for your machine are described below.

### 4.6.1 Option da, db, dc, dd, ec Compressed air treatment options

For some applications, the compressed air generated by this machine must be treated before use. The following describes the possible air treatment options that may be fitted to the machine.



04-M0010

Fig. 7 Compressed air options

- |   |                                |   |  |
|---|--------------------------------|---|--|
| ① | Tool lubricator (option ec)    | ④ | Cyclone separator (Option da)          |
| ② | Filter combination (Option dd) | ⑤ | Compressed air aftercooler (Option da) |
| ③ | Heat exchanger (Option db)     | ⑥ | Fresh air filter (Option dc)           |

#### 4.6.1.1 Option da Compressed air aftercooler

The aftercooler lowers the compressed air temperature to only 5 K to 10 K above ambient. Most of the moisture carried in the air is removed in the aftercooler.

**4.6.1.2 Option da**  
**Cyclone separator**

Condensate accumulating during the air cooling process is separated, fed to the exhaust gas silencer and evaporated there.

**4.6.1.3 Option db**  
**Heat exchanger**

The oil/air heat exchanger is fed with hot compressor cooling oil that warms the outgoing moisture-reduced compressed air.

This warm, dry compressed air is ideal for sand blasting, for example.

**4.6.1.4 Option dd**  
**Filter combination**

The dried compressed air passes through a pre-filter and micro-filter combination and emerges oil-free.

**4.6.1.5 Option dc**  
**Fresh air filter**

Compressed air from oil-injected compressors may not be used directly as breathing air.

The concentration of contaminants will increase during the compression of the intake ambient air and cooling oil and abraded particles can enter the compressed air. This requires a subsequent treatment of the pre-filtered compressed air.

Air must be filtered to remove all contaminants, such as fine dust and oil as well as odours, before it can be used for breathing purposes.

For this purpose, part of the compressed air output from the compressor is passed through a micro-filter and activated carbon filter combination.

The connection to air treated in this way is specially marked. It is designed as a quick-release coupling next to the outlet valves on the compressed air distributor.

**DANGER**

Danger from toxic air!

Danger of respiratory arrest because the filter does not remove CO/CO<sub>2</sub>, methane or other toxic gasses or vapours.

- Never use the machine in enclosed spaces, only in the open.
- Clean inlet air without hazardous contaminants. Engine exhaust must not be drawn into the compressor.



The treated air does not meet the local standards for 'Compressed air for breathing apparatus'. Therefore, it must not be used as pure breathing air but may be used to reinforce the flow of fresh air when working in dusty or dirty conditions such as sand blasting.

Further information See chapter 2.7.2 for ambient conditions under which the fresh air filter can be used.

**4.6.1.6 Option ec**  
**Tool lubricator**

Compressed air containing lubricating oil is needed for the lubrication of certain air tools. The tool lubricator introduces a fine oil mist into the compressed air for this purpose.

A metering valve on the lubricator regulates the amount of oil in the compressed air:

- minimum oil to lubricate the tools and prevent corrosion,
- more oil for cleaning and to prevent wear in the tools.

The oil flow can be stopped by a shut-off valve.

The oil flow adjusts automatically to changes in air demand (one or more tools/consumers on line).




Fig. 8 Tool lubricator

- |   |                                   |   |               |
|---|-----------------------------------|---|---------------|
| ① | Tool lubricator                   | ④ | Oil tank      |
| ② | Compressed air outlet distributor | ⑤ | Metering knob |
| ③ | Shut-off ball valve               |   |               |

**Option fc Points to be observed with separate compressed air lines:**



**NOTICE**

Lubrication with tool oil.

Air tools that must not be lubricated can be damaged.

- Blow any residual oil out of the line before connecting such an air tool.

#### 4.6.2 Option ba, bb

##### Low temperature equipment options

Special equipment is provided for operation in extremely low temperatures.

This equipment guarantees machine operation at temperatures from -25 °C..... +50 °C .

The electrical system enables trouble-free engine starting at ambient temperatures down to -20 °C.

###### 4.6.2.1 Option ba

###### Frost protection

Control air is mixed with an alcohol-based antifreeze to prevent control and regulating devices freezing. This considerably lowers the freezing point of any moisture in the air.




Fig. 9 Frost protector

- |                             |                              |
|-----------------------------|------------------------------|
| ① Control line (defrosting) | ③ Shut-off ball valve        |
| ② Frost protector           | ④ Control line (bypass line) |

#### Operating the machine in cold temperatures:

The frost protector is activated when the machine is started or stopped in ambient temperatures below freezing. Due to the anti-freeze in the air flow, valves and control lines in the interior are moistened preventing a freezing of the control and regulating system.

During machine operation, the generated innate heat counteracts a potential freezing of individual components.

#### Machine operation in Summer:

Anti-freeze is not required for the regulating air at ambient temperatures of more than 0 °C.

##### 4.6.2.2 Option bb Coolant pre-heating

The engine coolant can be pre-heated to improve cold-starting.

The power supply to the coolant preheater takes place via a separate network connector. A flexible power cable (supplied) connects the machine's power plug to the user's power socket. The coolant pre-heater works according to the principle of self-circulation.




Fig. 10 Coolant pre-heating

- |  |   |
|--|---|
| <span style="border: 1px solid black; padding: 2px;">1</span> Operating panel<br><span style="border: 1px solid black; padding: 2px;">2</span> Connection for the coolant pre-heater | <span style="border: 1px solid black; padding: 2px;">3</span> Engine block<br><span style="border: 1px solid black; padding: 2px;">4</span> Coolant pre-heating |
|--|---|

The ideal coolant pre-heating period is 2-3 hours before the machine is started. A pre-heating period of more than 3 hours is not necessary, as the maximum effect has already been achieved within this period (thermal balance).

Continuous operation of maximum 6 hours must be followed by a rest of approximately 3 hours.

#### 4.6.3 Option oa Optional battery isolating switch

The «battery isolating switch» disconnects the battery completely from the machine's electrical system (fire protection, battery discharge protection).



**NOTICE**

Danger of short circuit!

Damage to the machine electrics is possible.

- Use the «battery isolating switch» only when the machine is shut down.
- Do not use the «battery isolating switch» as a main or emergency switch.




Fig. 11 Battery isolating switch

- 1 «Battery isolating switch»

**4.6.4 Option Ia, Ib****Options for operating in fire hazard areas****4.6.4.1 Option Ia****Spark arrestor**

A spark arrestor on the exhaust silencer is required when operating a diesel engine in a fire hazard area and in forestry and agricultural applications. In such applications, a spark may ignite flammable materials.

The spark arrestor prevents the exhaust silencer emitting any glowing fuel residue.

**4.6.4.2 Option Ib****Engine air intake shut-off valve**

Any flammable gas drawn into the diesel engine's air intake alters and enriches the controlled fuel/air mixture fed to the engine. This causes a sudden and uncontrolled increase in engine speed that can lead to serious mechanical damage. Without appropriate preventive measures, the engine and compressor can be destroyed. Explosion or fire are also possible.

When flammable gas is drawn into the engine, shutting off the fuel supply will not stop the engine right away. Only by shutting off the air intake can the engine be brought to an immediate stop.

The self-closing valve shuts off the engine air intake as soon as flammable gas is drawn in. This brings the engine to an immediate stop.

**4.6.5 Option ga****Generator option**

A generator is installed to provide a power supply to electrical consumers. The generator is driven from the engine by a drive belt. A tensioning device automatically ensures optimum belt tension.

**4.6.5.1 Operating modes**

The compressor works with the normal air delivery regulation and generates electrical power at the same time.

The generator can work in two modes. These are selected by the mode switch:

- Automatic cut-in
- Continuous load

Generator main switch	Mode selector switch	What is provided?
OFF	-	Compressed air
ON	Position 1 (automatic start mode)	Compressed air and electrical power
	Position 2 (continuous load)	Electrical power and compressed air

Tab. 64 Generator/compressor operation

Operating mode	Automatic cut-in	Continuous load
Switch position	Position 1	Position 2

Operating mode	Automatic cut-in	Continuous load
Engine speed	Electrical power input > 100 VA: automatic maximum speed	Permanent maximum speed (engine under full load)
	Power consumption below minimum value: Engine run-on time of approximately 2 minutes at maximum speed	
Advantages:	Fuel saving Constant oscillation between maximum and minimum speed avoided	Continuous generator power available without delay

Tab. 65 Generator operating modes

#### 4.6.5.2 Operating controls

The switches, fuses and outlet sockets for electrical consumers are located on the generator control box. Individual consumers are connected only by these outlet sockets.





Fig. 12 Instrument panel – generator control box, 400 V AC


- |   |                           |   |                                       |
|---|---------------------------|---|---------------------------------------|
| ① | «Mode selector switch»    | ④ | Generator control box                 |
| ② | Three-phase power sockets | ⑤ | «Generator main switch»               |
| ③ | AC power sockets          | ⑥ | «Safety cut-out »(with shunt release) |



04-M0006

Fig. 13 Instrument panel – generator control box, 230 V AC

- |   |                               |   |                                       |
|---|-------------------------------|---|---------------------------------------|
| ① | «Mode selector switch»        | ⑤ | Generator control box                 |
| ② | 32 A three-phase power socket | ⑥ | «Generator main switch»               |
| ③ | AC power sockets              | ⑦ | «Safety cut-out»                      |
| ④ | 16 A three-phase power socket | ⑧ | «Safety cut-out »(with shunt release) |



04-M0281

Fig. 14 Generator instrument panel - control box, 115 V, single-phase (50 Hz)

- |   |                                     |   |                                       |
|---|-------------------------------------|---|---------------------------------------|
| ① | Generator control box               | ⑤ | «Generator main switch»               |
| ② | Single phase power socket, 32 A     | ⑥ | «Safety cut-out»                      |
| ③ | Single phase AC power sockets, 16 A | ⑦ | «Safety cut-out»                      |
| ④ | «Mode selector switch»              | ⑧ | «Safety cut-out »(with shunt release) |




Fig. 15 Generator instrument panel - control box, 230 V, single-phase (60 Hz)

- |  |   |
|--|---|
| <span style="border: 1px solid black; padding: 2px;">①</span> «Mode selector switch»<br><span style="border: 1px solid black; padding: 2px;">②</span> Single phase AC power sockets, 250 V<br><span style="border: 1px solid black; padding: 2px;">③</span> Single phase AC power sockets, 125 V | <span style="border: 1px solid black; padding: 2px;">④</span> Generator control box<br><span style="border: 1px solid black; padding: 2px;">⑤</span> «Generator main switch»<br><span style="border: 1px solid black; padding: 2px;">⑥</span> «Safety cut-out »(with shunt release) |
|--|---|

#### 4.6.5.3 Note when operating the generator

##### Do not exceed the maximum supply system load

- When operating the generator, do not exceed the maximum supply system load due to connected consumers.

Bear in mind:

- The power consumption values of simultaneous consumers are added.
- The maximum continuous power loading on the generator by the connected consumers is limited by the safety cut-out.

##### Connect electrical consumers



##### DANGER

Devices start automatically without warning.  
Serious injury and damage to property is possible.

- Make sure that electric consumers are switched off.

Before connecting electrical consumers, carry out the following:

- Read the technical specification for the generator before connecting voltage-sensitive equipment.
- Check that electrical consumers and their connecting cables are in perfect condition.
- Plug in and switch on consumers one-by-one.
- Consumers with unfavourable on/off characteristics (e.g. high starting current) should be started first.

Do not exceed the rated current for each outlet socket to avoid overloading the generator.

##### Switching off the generator

Before deactivating the generator, carry out the following:

- Switch off electrical consumers and unplug them one-by-one.

- Switch off consumers drawing the highest current last.
- Check that the protective covers on the power sockets are correctly closed.
- Run the engine for a further 2 minutes after switching off the generator to allow the generator to cool down.

#### 4.6.6 Option Ic Diesel particulate filter option

The exhaust from a diesel engine contains invisible particles that are dangerous to health. The diesel particulate filter reduces the amount of particles (mostly soot), protecting human health and the environment.

The diesel particulate filter is integrated in the engine's exhaust system. The engine exhaust flows through the filter module and nearly all the damaging particles are trapped. A control unit monitors the function of the diesel particulate filter system.

When the filter medium has trapped a specific amount of soot, it is regenerated while the machine is under LOAD. The control unit initiates and monitors the regeneration process. Diesel fuel is injected into the exhaust stream. This causes a special catalyst to heat the exhaust gas to over 550 °C and the soot is burnt off the filter medium in CO<sub>2</sub>.

The machine is shut down if the back pressure in the exhaust exceeds a specific value.

##### General design




Fig. 16 General design of the diesel particulate filter system

①	Fuel tank	⑦	Silencer module
②	Diesel engine	⑧	Outlet of cleaned exhaust gas
③	Exhaust pipe with contaminated gases.	⑨	Electronic control unit
④	Diesel injection	a	Fuel line
⑤	Oxidizing catalytic converter	b	Exhaust back pressure monitor
⑥	Filter module	c	Exhaust gas temperature monitor



The diesel particulate filter system meets the requirements of TRGS 554, TA and VERT (Switzerland).

**4.6.7 Option sa, sc, sd, sh, si  
Transport options****4.6.7.1 Option sa  
Chassis**

The chassis has the following features:

- Single-axle
- Rubber-spring axle
- Height-adjustable towbar

**4.6.7.2 Option sd  
Chassis**

The chassis has the following features:

- Single-axle
- Rubber-spring axle
- Fixed height towbar

**4.6.7.3 Option sh  
Chassis**

The chassis has the following features:

- Single-axle
- Rubber-spring axle
- Fixed height towbar
- Without parking brake

**4.6.7.4 Option sc  
Stationary frame**

The frame has the following features:

- Skids
- Use as stationary machine
- Mounted on truck/trailer platform

**4.6.7.5 Option si  
Stationary frame**

The frame has the following features:

- Frame
- Use as stationary machine
- Mounted on truck/trailer platform

**4.6.8 Option ua  
Hose reel option**

The machine is provided with an extension hose to allow connection and operation of remote air tools. A hose reel is provided for safe storage of this hose.

**4.6.9 Option sf  
Optional anti-theft device**

The machine is fitted with a security chain as theft protection.

**4.6.10 Option sg  
Pedestrian protection option**

The machine is provided with pedestrian protection that functions both as a deflector and against pedestrians being run-over.

**4.6.11 Option pa, pb  
Instrument panel cover option**

To prevent unauthorised use and as protection during transport the machine is fitted with instrument panel cover(s).

- Instrument panel cover (option pa)
- Generator control box cover (option ga)

## 5 Installation and Operating Conditions

### 5.1 Ensuring safety

The conditions in which the machine is installed and operated have a decisive effect on safety. Warning instructions are located before a potentially dangerous task.



Disregard of warning instructions can cause serious injuries!

#### Complying with safety notes

Disregard of safety notes can cause unforeseeable dangers!

- Strictly forbid fire, open flame and smoking.
- If welding is carried out on or near the machine, take adequate measures to prevent sparks or heat from igniting fuel or oil vapours or parts of the machine.
- Do not store inflammable material in the vicinity of the machine.
- The machine is not explosion-proof!  
Do not operate in areas in which specific requirements with regard to explosion protection are applied.  
For instance, the requirements of ATEX directive 94/9/EC "Equipment and Protective Systems intended for use in Potentially Explosive Atmospheres".
- Suitable fire extinguishing material must be to hand.
- Ensure that required ambient conditions are maintained.

Required ambient conditions may be:

- Ambient temperature
- Air composition at the installation site:
  - clean with no damaging contaminants (e.g., dust, fibres, fine sand)
  - free of explosive or chemically unstable gases or vapours
  - free of acid/alkaline forming substances, particularly ammonia, chlorine or hydrogen sulfide.

### 5.2 Installation conditions

#### Precondition

The floor must be level, firm and capable of bearing the weight of the machine.




Fig. 17 Minimum distance from excavations/slopes and walls

1. Keep sufficient distance (at least 1.5 m) from the edges of excavations and slopes.

2. Ensure that the machine is as level as possible.



The machine can be temporarily operated on a slope of not more than 15°.

3. Ensure accessibility so that all work on the machine can be carried out without danger or hindrance.



4. **NOTICE!**

Fire hazard from build-up of heat and hot exhaust system!

Insufficient distance from a wall may well cause heat build-up that could damage the machine.

➢ Do not position the machine directly against a wall.

➢ Ensure always sufficient ventilation space around the machine.

5. Position the machine as far as possible from any wall.

6. Ensure there is enough free space all round and above the machine.

7. Keep air inlet and outlet openings free of obstructions so that the cooling air can flow freely through the machine.

8. Place the machine in such a manner that

■ wind does not blow into the cooling air outlet.

■ exhaust gases and heated cooling air can not be drawn into the compressor.

9. **NOTICE!**

Ambient temperature too low!

Frozen condensate and highly viscous engine or compressor cooling oil can cause damage when starting the machine.

➢ Use winter grade engine oil.

➢ Use low viscosity compressor cooling oil.

➢ Allow the machine to warm up in IDLE (low speed), see chapter 8.2.4.

10. At ambient temperatures below 0 °C, follow instructions in chapter 7.4.

# 6 Installation

## 6.1 Ensuring safety

Follow the instructions below for safe installation.

Warning instructions are located before a potentially dangerous task.



Disregard of warning instructions can cause serious injuries!

### Complying with safety notes

Disregard of safety notes can cause unforeseeable dangers!

- Follow the instructions in chapter 3 'Safety and Responsibility'.
- Installation work may only be carried out by authorised personnel.

Further information Details of authorised personnel are found in chapter 3.4.2.

Details of dangers and their avoidance are found in chapter 3.5.

## 6.2 Reporting Transport Damage

1. Check the machine for visible and hidden transport damage.
2. Inform the carrier and the manufacturer in writing of any damage found.

## 6.3 Fitting the towbar

Material Protective gloves  
Wrench  
Hard rubber hammer  
Appropriate tube as lever for the locking lever

Precondition The machine is standing firm and level.  
The machine is switched off.



### CAUTION

Danger of pinching!

Severe pinching injury to fingers is possible.

- Always wear protective gloves.
- Work with caution.


### 6.3.1 Option sa

#### Fitting the height adjustable towbar

If the machine is shipped on a transport frame, it is necessary to dismantle the towbar to save space. The overrun braking mechanism with centre piece is secured to the wooden frame next to the towbar. The locking lever is packed in the machine.

The towbar must be re-assembled before removing the transport frame.

Option sa



06-M0782

**Fig. 18 Fitting the height adjustable towbar**

- |                               |                   |
|-------------------------------|-------------------|
| [1] Overrun braking mechanism | [4] Split pin     |
| [2] Securing bolts            | [5] Locking lever |
| [3] Towbar centre-piece       | [6] Towbar        |

1. Remove all transport securing items from the towbar components.
2. Take the locking lever out of the machine, remove the packing and unscrew the securing bolt.
3. Locate the teeth of the centre piece in those of the towbar and insert the securing bolt from the back. If necessary use light hammer blows to help the process.
4. Make sure the teeth engage and screw on the locking lever.
5. Tighten the locking lever. Make sure the teeth in the adjustment joint mesh together. (See chapter 2.4.4 for tightening torque).
6. Fully tighten the lever with a few hammer blows and insert the split pin.
7. Pull up the parking brake (pull the hand brake lever up).

## 6.4 Adjusting the chassis

Material	Pliers Hard rubber hammer Appropriate tube as lever for the locking lever
Precondition	The machine is shut down. The machine is disconnected from the towing vehicle and safely parked.


**CAUTION**


Danger of pinching!

Severe injury to fingers is possible if they become trapped in the adjusting mechanism.

- Always wear protective gloves.
- Work with caution.

#### 6.4.1 Option sa Adjusting the towbar height

Option sa



06-M0016

Fig. 19 Towbar height adjustment

- |     |                           |     |                             |
|-----|---------------------------|-----|-----------------------------|
| [1] | Overrun braking mechanism | [4] | Locking lever               |
| [2] | Towbar centre-piece       | [5] | Split pin                   |
| [3] | Towbar                    | [6] | Split pin properly inserted |

1. Pull out the cotter pins at both joint components and loosen the locking lever until the teeth in the height adjustment joints are no longer engaged.
2. The fixed part of the towbar must be parallel to the ground when the compressor is coupled to the towing vehicle, see illustration 19.  
The centre-piece can be moved up to 49° upwards and 10° downwards for height adjustment.
3. Tighten the locking lever again and secure by striking with a hard rubber hammer.
4. Insert the cotter pin.
5. Check if:
  - the teeth in the tow bar height adjusting joints are fully engaged,
  - the locking levers are tightened,
  - the cotter pin is correctly inserted to secure the locking lever (see Pos. 6 in Fig. 19).
6. Tighten the locking lever again after 50 km.




- The serrations joint will not disengage. The serrations are corroded together.  
➤ Free the teeth by jerking the towbar horizontally and vertically.

#### 6.4.2 Option sh Adjusting the coupling height

The height of the towbar can be adjusted, to a degree, to suit the towing vehicle coupling height. There are three height levels.

Option sh


**Fig. 20** Adjusting the coupling height

- |  |  |
|--|--|
| <span style="border: 1px solid black; padding: 2px;">1</span> Towbar<br><span style="border: 1px solid black; padding: 2px;">2</span> Prop stand<br><span style="border: 1px solid black; padding: 2px;">3</span> Fixing holes | <span style="border: 1px solid black; padding: 2px;">4</span> Ball coupling<br><span style="border: 1px solid black; padding: 2px;">5</span> Hex-head screw<br><span style="border: 1px solid black; padding: 2px;">6</span> Hexagonal nut |
|--|--|

1. Position the compressor near the towing vehicle hitch and secure with chocks under the wheels.
2. Adjust the prop to bring the towbar horizontal.
3. Unscrew the nuts and withdraw the fixing bolts.
4. Adjust the vertical position of the towing coupling/eye to match the height of the towing vehicle coupling. Line up the fixing holes in the coupling/eye with those in the towbar.
5. **WARNING!**



Risk of accident due to separation of the machine from the towing vehicle!  
 Improper fastening of the ball coupling or hitch to the tow-bar can cause a separation of the trailer from the towing vehicle and thus an accident.

- Check that the ball coupling or hitch are properly attached to the tow-bar with both cotter pins.
- 6. Insert the fixing bolts and tighten the nuts.
- 7. Tighten the nuts.

#### 6.4.3 Changing the towing eye

The towbar can be fitted with various towing eyes or couplings.

Material Protective gloves


Wrench

Hammer

Precondition The machine is shut down.

The machine is disconnected from the towing vehicle and safely parked.

- Ascertain which towbar is fitted to the machine.

**6.4.3.1 Option sa, sd**
**Changing the towing eye (European chassis)**

**Fig. 21** Changing the ball hitch/towing eye (European chassis)

- |                  |                     |
|------------------|---------------------|
| ① Protective cap | ⑤ Towbar tube       |
| ② Hexagonal nut  | ⑥ Protective sleeve |
| ③ Washer         | ⑦ Ball coupling     |
| ④ Hex-head screw | ⑧ Towing eye        |

1. Push back the protective sleeve ⑥.
2. Remove the protective caps ① of both screw connections.
3. Remove the nuts ②, remove the washers ③ and withdraw the screws ④.
4. Remove the ball coupling ⑦ or eye ⑧ from the towbar tube ⑤.
5. Push the new ball coupling or towing eye in/in the towbar tube.
6. Adjust the position of the components till the holes in the coupling/eye line up with those in the towbar tube.
7. Insert the securing bolts ④, fit the washers ③ and nuts and tighten. Tread nuts ② on both screws and tighten with torque wrench (see chapter 2.4.4).
8. Replace the protective caps ① and slide the protective sleeve ⑥ forward.

## 6.4.3.2 Option sh

Changing the towing eye (USA chassis version)

Option sh




Fig. 22 Replacing the ball coupling/eye (US chassis)

- [1] Towbar
- [2] Ball coupling
- [3] Towing eye

- [4] Hex-head screw
- [5] Hexagonal nut

1. Unscrew the nuts [5] and withdraw the fixing bolts [4].
2. Remove the coupling or eye from the towbar.
3. Place the new ball coupling or towing eye on/in the towbar and line up the fixing holes on towing eye/coupling and towbar.
4. **WARNING!**  
Risk of accident due to separation of the machine from the towing vehicle!  
Improper fastening of the ball coupling or hitch to the tow-bar can cause a separation of the trailer from the towing vehicle and thus an accident.
  - Check that the ball coupling or hitch are properly attached to the tow-bar with both cotter pins.
5. Insert the fixing bolts and tighten the nuts.
6. Tighten the nuts.



## 7 Initial Start-up

### 7.1 Ensuring safety

Here you will find instructions for a safe commissioning of the machine.  
Warning instructions are located before a potentially dangerous task.



Disregard of warning instructions can cause serious injuries!

#### Complying with safety notes

Disregard of safety notes can cause unforeseeable dangers!

- Follow the instructions in chapter 3 'Safety and Responsibility'.
- Commissioning tasks may only be carried out by authorised personnel!
- Make sure that no one is working on the machine.
- Ensure that all service doors and panels are locked.

Further information	Details of authorised personnel are found in chapter 3.4.2. Details of dangers and their avoidance are found in chapter 3.5.
---------------------	---

### 7.2 Before Initial Start-up (or Recommissioning)

Incorrect or improper commissioning can cause injury to persons and damage to the machine.

#### 7.2.1 Note when commissioning



The initial start-up of every machine takes place at the factory. Every machine is also given a trial run and passes a careful check.

- Commissioning may only be carried out by authorised installation and service personnel who have been trained on this machine.
- Remove all packing materials on and in the machine.
- Observe the machine during the first few hours of operation to ensure that it is operating correctly.

### 7.2.2 Special measures for re-commissioning after storage

- Carry out the following before every start-up after long period of storage:

Storage period longer than:	Remedy
5 months	<ul style="list-style-type: none"> <li>➤ Remove the desiccant from the openings in the air intake filters of the engine and compressor.</li> <li>➤ Check the air and oil filters.</li> <li>➤ Drain the preserving oil from the separator tank.</li> <li>➤ Fill with cooling oil.</li> <li>➤ Drain the preserving oil from the engine.</li> <li>➤ Fill with engine oil.</li> <li>➤ Check the engine coolant</li> <li>➤ Check the battery charge state.</li> <li>➤ Reconnect the battery.</li> <li>➤ Check all fuel lines, engine oil lines and compressor cooling oil lines for leaks, loose connections, wear and damage.</li> <li>➤ Clean the bodywork with a grease and dirt dissolving agent.</li> <li>➤ Check the tyre pressures.</li> </ul>
36 months	<ul style="list-style-type: none"> <li>➤ Have the overall technical condition checked by an authorised KAESER Service Technician.</li> </ul>

Tab. 66 Measures for re-commissioning the compressor after a long period of storage

### 7.3 Checking installation and operating conditions

- Check and confirm all the items in the checklist before starting the machine.

Check	See chapter	Confirmed?
➤ Are the operators fully conversant with safety regulations?	–	
➤ Have all the positioning conditions been fulfilled?	5	
➤ Is there sufficient cooling oil in the separator tank?	10.4.1	
➤ Is there sufficient oil in the engine?	10.3.4	
➤ Is the maintenance indicator on the air intake filters (engine and compressor) OK?	10.3.2, 10.4.7	
➤ Is there sufficient coolant in the coolant expansion tank?	10.3.1	
➤ Is there sufficient fuel in the fuel tank?	–	
➤ Is there sufficient tool oil in the tool lubricator? (Option ec)	10.8.1	
➤ Is there enough antifreeze in the frost protector? (Option ba)	10.8.5	
➤ Are the access doors closed and all body panels in place?	–	
➤ Are the tyre pressures OK?	–	

Tab. 67 Positioning and operating conditions checklist

## 7.4 Low-temperature operation (winter)

The machine's electrical equipment is designed for starting at ambient temperatures as low as  $-10^{\circ}\text{C}$ .

- In temperatures below  $0^{\circ}\text{C}$ , use the following operating materials/components:
  - Winter-grade engine oil,
  - low viscosity cooling oil for the compressor,
  - Winter-grade diesel fuel
  - stronger battery



Use air hoses that are as short as possible under extremely cold conditions.

**Allow the engine to warm up:**



### 1. **NOTICE!**

Problems with pneumatic control at low temperatures.

Damage to the machine may be caused by ice particles in the pneumatic control and feedback systems.

- Let the machine warm up in IDLE to ensure trouble-free regulation.

2. Allow the machine to warm up in idle with open air outlet valves until an airend discharge temperature of  $+30^{\circ}\text{C}$  is reached. The airend discharge temperature is shown at the temperature gauge switch on the instrument panel.

### 7.4.1 Starting assistance

If the machine's starter battery is discharged, it can be started with the battery of another vehicle or engine-driven machine.

Material Jumper cables

Precondition The machine is disconnected from the towing vehicle and safely parked.



### **WARNING**

Fire and explosion hazard.

High currents can flow if the battery is short-circuited. A damaged battery can catch fire or explode.

Battery casing may crack and allow acidic fluid to spray out.

- Observe the instructions provided with the jumper cables.
- Do not connect the battery jumper cables to the negative pole of the discharged battery or to the bodywork of the machine.
- Work with caution.




Fig. 23 Jumper cable connection diagram

- |     |  |     |  |
|-----|--|-----|--|
| [A] | Engine battery (receiving battery)                               | [3] | Positive pole clamp (red) on engine battery        |
| [B] | Assisting vehicle battery (external donor battery)               | [4] | Negative pole clamp (black/blue) on engine battery |
| [1] | Negative pole clamp (black/blue) on battery of assisting vehicle | [5] | Bare metal point on the engine block (earth)       |
| [2] | Positive pole clamp (red) on battery of assisting vehicle        |     |  |

#### Observing the safety instructions:



1. **WARNING!**  
Fault in starting aid process!
  - Connect only batteries of the same voltage.
  - Ensure that machine and assisting vehicle do not touch.
  - Switch off all consumers prior to connecting and disconnecting the batteries.
  - Only use standard jumper cables of sufficient diameter and with insulated terminal clamps.
  - Observe the instructions provided with the jumper cables.
  - Keep jumper cables away from rotating parts.
  - Avoid short-circuits due to incorrect poling and/or bridging with tools.
  - Do not bend over the batteries when attaching jumper cables.
  - Do not attempt to start the machine if its batteries are frozen. Allow the battery to thaw first.
  - Do not try to start the machine with a boost charger.
2. Comply with the safety instruction shown when using starting aids and starter batteries.

#### Preparations:

1. Park the assisting vehicle in close distance to the engine, without their bodywork touching each other.
2. Stop the engine of the assisting vehicle.
3. Open the accesses to the batteries (remove maintenance panels/bonnet and pole caps).
4. Switch off all power consumers.

**Connecting the battery jumper cables**

1. Clamp the first terminal clamp ③ of the red jumper cable to the positive pole of the engine's battery.
2. Clamp the second terminal clamp ② of the red jumper cable to the positive pole of the assisting vehicle's battery.
3. **DANGER!**  
Explosion hazard!  
A spark may ignite an explosive gas mixture.
  - Do not, under any circumstances, connect the negative pole of the assisting machine to the negative pole of the battery in the machine to be started.  
This can cause sparks when connecting and disconnecting the pole clamps of the jumper cable.
  - Work with caution.
4. Connect the first pole clamp ④ of the black jumper cable to the engine block or a connected, solid and unpainted metal component of the engine ⑤ (as distant as possible to the batteries).
5. Clamp the second terminal clamp ① of the black jumper cable to the negative pole of the assisting vehicle's battery.

**Starting the engine**

1. Start the engine of the assisting vehicle and run at high speed.
2. Start the compressor engine.

 Upon a successful start, run both engines for approximately 10 – 15 minutes. This is important, in particular for a fully discharged battery. The battery will pick up only little current in the beginning and has a high internal resistance. Any voltage peaks occurring in the engine generator in this state can be attenuated only by the battery of the assisting vehicle. The engine electronics in particular, of the machine is sensitive to overvoltages and could be damaged easily.

**Disconnecting the battery jumper cables**

1. Stop the engine of the assisting vehicle.
2. Disconnect the jumper cables in the reverse order, first negative (-) then positive (+).
3. Place the pole caps.
4. Close the maintenance panels and/or bonnet.

 A stop of the compressor engine as soon as the cables are disconnected could indicate major damage to the alternator or battery to be repaired by a specialised workshop.

**7.4.2 Option ba, bb****Starting up low-temperature equipment**

- Ascertain which low temperature equipment is fitted to the machine.

**Option ba Operating the frost protector**

- Use the checklist when initially starting the frost protector.

To be checked	See chapter	Confirmed?
Check the level of antifreeze in the frost protector.	10.8.5	
Close the tap on the frost protector.	8.5	

Tab. 68 Low-temperature equipment checklist

**Option bb Operating the coolant pre-heater:**

The engine coolant can be pre-heated to improve cold-starting.

The connection for the mains supply is located on the machine's instrument panel.


**Option bb**

Fig. 24 Coolant pre-heating

- ①** Operating panel  
**②** Connection for the coolant pre-heater  
**③** Power cable

- ④** Coolant pre-heating  
**⑤** Engine block

**1. DANGER!**

Danger of fatal injury from electric shock!

Serious injury or death can result from a short-circuit in the electric coolant pre-heater.


- The power cable for the coolant pre-heater may only be plugged into an electrical socket fitted with a protective earth.
- Have the coolant pre-heating and associated wiring checked according to the maintenance schedule.

2. Connect the coolant pre-heater to the user's power socket with the power cable supplied.

## 7.5 Option ga Activating the generator


The generator can be operated without earthing.

Test the insulation monitoring daily with the engine running before activating the generator.



07-M0003


Fig. 25 Insulation monitoring - 400 V AC, 3-phase generator



07-M0004


Fig. 26 Insulation monitoring - 230 V AC, 3-phase generator

- |  |  |
|--|--|
| ① «Main switch»  | ④ «Mains circuit breaker»<br>«Circuit breaker» designed as automatic circuit-breaker with shunt trip |
| ② «Mode selection switch»  | ⑤ AC power sockets   |
| ③ Test button «Insulation monitoring» with indicator light for <i>earth leak</i> | ⑥ AC power sockets   |



07-M0288

Fig. 27 insulation monitoring - 115 V, single-phase generator



07-M0326

Fig. 28 insulation monitoring - 230 V, single-phase generator

- |   |  |     |  |
|---|--|-----|--|
| ① | «Main switch»  | ④   | «Mains circuit breaker»<br>(``Circuit breaker'' designed as automatic circuit-breaker with shunt trip) |
| ② | «Mode selection switch»  | ⑤/⑥ | AC power sockets   |
| ③ | Test button «Insulation monitoring» with indicator light for <i>earth leak</i> |     |  |

1. Activate the machine.
2. **DANGER!**  
Risk of fatal injury caused by contact with live components!
  - The generator may only be used if the «circuit breaker» («mains circuit breaker») has tripped during the test!
3. Check the insulation monitor according to instructions:



Test instructions are provided on the label attached to the generator control box.

**DANGER!**

**Electrical power.**

Risk of fatal injury caused by contact with live components!

- Test the «main circuit breaker» each day while the machine is running.
  - The generator may only be operated if the mains circuit breaker is functioning correctly.
- Checking the «safety cut-out»:

- Turn on «mains circuit breaker» ④ for the generator.
- Press and hold the «test button» ③ for 3 seconds.

The «mains circuit breaker » ④ trips.

Problem: The «mains circuit breaker» does not trip out?

- Shut down the generator and call your authorised KAESER Service.

Tab. 69 Test instructions for a generator with an earth leak detection device.

## 8 Operation

### 8.1 Ensuring safety

Here you will find instructions for a safe commissioning of the machine.

Warning instructions are located before a potentially dangerous task.



Disregard of warning instructions can cause serious injuries!

#### Complying with safety notes

Disregard of safety notes can cause unforeseeable dangers!

- Follow the instructions in chapter 3 'Safety and Responsibility'.
- Make sure that no one is working on the machine.



#### WARNING

Danger of injury from hot, rotating and electrically live components!  
Serious injury can be caused by touching such components.

- Ensure that all doors/canopy and panels are locked.
- Shut down the machine before opening any doors/canopy.
- Do not carry out any checks or settings while the machine is running.

Further information	Details of authorised personnel are found in chapter 3.4.2. Details of dangers and their avoidance are found in chapter 3.5.
---------------------	---

### 8.2 Starting and stopping

Precondition	No personnel are working on the machine. All doors and siding panels are closed.
--------------	---



#### NOTICE

Serious damage to engine from cold starting sprays.  
Cold-start assists, such as ether or other sprays, can cause severe engine damage.

- Do not use cold start sprays.




Fig. 29 Starting instruments

- |     |   |     |  |
|-----|---|-----|--|
| [1] | «Controller On» switch  | [5] | Compressed air outlet pressure gauge                                 |
| [2] | «Starter switch »   | [6] | Temperature gauge switch   |
| [3] | ○ – STOP/Off  | [7] | Operating hours counter  |
|     | – On  | [8] | Indicator fault on the diesel particulate filter<br>(Option Ic only) |
|     | — Preheat   |     |  |
|     | — START   |     |  |
| [4] | — «Load On» key with integrated <i>LOAD mode</i> indicating light |     |  |
|     |   |     |  |
| [3] | — «Load On» key with integrated <i>LOAD mode</i> indicating light |     |  |
| [4] | Charging indicator lamp, group alarm lamp                         |     |  |

#### Notes concerning snow and ice

Considerable snow or ice may build up on the machine under low temperature conditions.

- Remove any snow and ice from the machine before operating.

#### 8.2.1 Running the machine

1. Open the right-hand access door.
2. Turn the «Controller On» switch.
3. Close the door.
4. Turn the «starter switch» to "ON".  
The *charging indicating light* must light.

#### 8.2.2 Engine pre-heating

The pre-heating period should be between 5 and a maximum of 10 seconds depending on ambient temperature. Low ambient temperatures require a longer pre-heating period.



- The electric fuel pump starts automatically during pre-heating. This vents the fuel line before each start.



#### 1. **NOTICE!**

Destruction of the glow plug!

Excessive pre-heating can cause severe damage to the glow plug.

► Never allow the glow plugs to operate for longer than 10 seconds.

#### 2. Turn the «starter switch» to the "Pre-heat" position and hold for 8 to 10 seconds.

The engine's glow plugs are energised and the engine pre-heated.

### 8.2.3 Starting the machine



#### 1. **NOTICE!**

Destruction of the starter!

Improper operation could destroy the starter.

► As long as the engine is running, do not actuate the starter switch.

► Do not turn and hold the starter switch for longer than 30 seconds.

► Wait for a few minutes after each attempt to start the engine.

► The starter switch must be returned to the neutral position before each start attempt (re-start protection).

#### 2. Turn the «starter switch »to "START" and release it as soon as the engine starts.

The *charging indicator lamp* extinguishes as soon as the engine is running.

#### 8.2.3.1 Option Ic

##### Note the indicator for the diesel particulate filter

Upon activating the «starter switch», the indicator light *Alarm, diesel particle filter* will light up briefly and goes out if there is no fault. The machine can be operated normally. The diesel particulate filter traps any soot emitted from the engine. When the filter module has reached capacity, the control unit switches automatically to regeneration.

► Note the indication *alarm, diesel particle filter*.

Indicating lamp dark: diesel particulate filter works normal.

Indicating lamp flashes or is lit: take measures as described in chapter 9.4 "Faults in the diesel particulate filter".




The control unit records the alarm message so it can be proven if the machine continues to be operated with an illuminated alarm indication. The manufacturer accepts no liability from consequential damage.

### 8.2.4 Allow the machine to run up to operating temperature

To avoid unnecessary wear, the engine should be run in IDLE until the airend discharge temperature reaches +30 °C. The airend discharge temperature is shown at the temperature gauge switch on the instrument panel.

Option ba



08-M0008

Fig. 30 Label referring to the warm-up period when ambient temperatures are below -10 °C

- Allow the machine to warm up in IDLE (low speed).

### 8.2.5 Switching to LOAD

Precondition The airend discharge temperature must be at least +30 °C




1. **WARNING!**  
Compressed air can cause serious injuries.
  - Never direct compressed air at persons or animals.
  - Make sure that no one is working on the machine.
  - Ensure that all panels are in place.
  - Ensure that all machine doors are closed.
2. Press the «Load On» button.

Result The integrated *LOAD* indicator lights and the engine accelerates to maximum speed.

### 8.2.6 Regulating the shut-off valve

To prevent users' devices from venting when the compressor shuts down and automatically vents, a shut-off valve is installed in the control air line between oil separator tank and air distributor.



08-M0289

Fig. 31 Control line shut-off valve

- ① Compressed air outlet distributor
- ② Shut-off ball valve
  - I – open
  - 0 – closed

1. Open the right-hand access door.

2. Check that the shut-off valve in the control air line is open. If not, open it.  
The machine is ready for operation.
3. Close the door.

### **8.2.7 Shutting down the machine**

**NOTICE**

Thermal overload of the turbocharger!

Abrupt stopping of the engine under load can cause a fault or damage to the turbocharger.

- Run the engine a few minutes in idle before shutting down to allow the turbocharger to cool.

**Operating the machine in the cool-down phase**

1. Close all «compressed air outlet valves» on the air distributor.  
The engine runs in IDLE and the turbocharger can cool down.
2. After approx. 2 to 3 minutes, switch the «starter switch» to the "STOP/Off" position.  
The engine turns off.

**Make sure equipment is protected from venting**

Compressed air lines to consumers should not vent when the compressor shuts down.

A typical example would be a user's auxiliary air receiver.



The shut-off valve must remain open for any other applications!

1. Open the right-hand access door.
2. Close the shut-off valve.

Further information Close the shut-off valve in the control line (see Fig. 31).

**Shutting down the machine:**

1. Switch off the «Controller On» switch.
  2. Close the door.
- Secure both doors with locks as necessary.

### **8.3 Option ua** **Using the hose reel**

The machine is fitted with an compressed air extension hose.

A hose reel is provided for safe storage of this hose.

- Check which hose reel is fitted to your machine.

#### **8.3.1 Using the hose reel (EC version)**

The hose reel is on the front of the machine.




Fig. 32 Hose reel (EC design)

- |                             |                           |
|-----------------------------|---------------------------|
| ① Winding handle (fold out) | ⑤ Securing holes          |
| ② Hose reel                 | ⑥ Hose reel side plate    |
| ③ Hose                      | ⑦ Clamping screw          |
| ④ Hose coupling             | ⑧ Transport securing bolt |

#### 8.3.1.1 Operating the machine with an extension air hose.

1. Loosen the transport securing pin ⑧ and the clamping screw ⑦.
2. Fold out the crank handle ① and reel out the required length of hose ③.
3. Tighten the clamping knob.  
The reel is locked against unwanted reeling in or out.
4. Fold in the handle.
5. Connect the air tool.
6. Activate the machine.
7. Open the compressed air shut-off valve.

#### 8.3.1.2 Operating the machine without an extension air hose.

1. Close the compressed air shut-off valve.
2. Disconnect the air consumer.
3. Fold out the winding handle ① and reel in the hose ③ firmly and evenly.
4. Tighten the clamping screw ⑦.  
The reel is locked against unwanted reeling in or out.
5. Fold in the handle.

#### 8.3.1.3 Securing the hose reel for transport

1. Check that the hose is firmly and evenly reeled in. Reel again, if necessary.
2. Locate the securing hole ⑧ in the reel's side plate ⑤ until it is aligned with the securing screw ②.
3. Screw in the securing bolt fully.
4. Tighten the clamping screw ⑦.

### 8.3.2 Using the hose reel (USA version)

The hose reel is mounted on the towbar.




Fig. 33 Hose reel (EC design)

- |   |                |   |                |
|---|----------------|---|----------------|
| ① | Winding handle | ③ | Hose           |
| ② | Hose reel      | ④ | Clamping screw |

#### 8.3.2.1 Operating the machine with an extension air hose.

1. Loosen the clamping screw ④.
2. Reel out the required length of hose ③.
3. Tighten the clamping knob.  
The reel is locked against unwanted reeling in or out.
4. Connect the air tool.
5. Activate the machine.
6. Open the compressed air shut-off valve.

#### 8.3.2.2 Operating the machine without an extension air hose.

1. Close the compressed air shut-off valve.
2. Disconnect the air consumer.
3. Loosen the clamping screw ④.
4. Use the winding handle ③ to reel in the hose ① firmly and evenly.
5. Tighten the clamping knob.  
The reel is locked against unwanted reeling in or out.

#### 8.3.2.3 Securing the hose reel for transport

1. Check that the hose is firmly and evenly reeled in. Reel again, if necessary.
2. Tighten the clamping screw ④.  
The reel is locked against unwanted reeling in or out.

## 8.4 Option ec Operating the tool lubricator

Precondition The machine is shut down.  
Tool lubricator filled with oil




Fig. 34 Setting the tool lubricator

- ① Shut-off valve  
I – open  
0 – closed  
② Metering knob

- Open the right-hand access door.

### Adding lubricating oil

1. Open the shut-off valve.
2. Close the door.

### Setting the oil flow

The amount of oil the compressed air should contain depends on the application and must be determined by the user. It depends on the nature of the air consumers and the supply hoses.

The metering valve controls the flow of oil into the air.

- Turning clockwise: reduces the oil flow.
- Turning counter-clockwise: increases the oil flow.

1. Set the required oil flow.
2. Close the door.

Further information Fill the tool lubricator with suitable oil (see chapter 10.8.1)

### Shutting off lubricating oil

1. Close the shut-off valve.
2. Close the door.

## 8.5 Option ba, bb Using the low-temperature equipment

- Ascertain which low temperature equipment is fitted to the machine.

### 8.5.1 Option ba Using with the frost protector switched on




Fig. 35 Frost protector on and off

- ① Shut-off valve
  - I – open
  - 0 – closed
- ② Frost protector tank

Precondition The machine is switched off.

- Open the right-hand access door.

#### Machine operation with activated frost protector:

Operation at temperatures below 0 °C (winter operation).

Precondition Frost protector filled with antifreeze

1. Keep the frost protector shut-off valve permanently closed (position 0).
2. Close the access door.

Result The machine is ready for winter operation.

Further information See chapter 10.8.5 for filling the frost protector with antifreeze.

#### Machine operation without activated frost protector:

Operation at temperatures above 0 °C (summer operation).

1. Leave the frost protector shut-off valve open permanently (position I).
2. Close the access door.



### 8.5.2 Option bb

#### Coolant pre-heating

- Start the coolant pre-heating as described in chapter 7.4.2.

### 8.6 Option oa

#### Operating the battery isolating switch



08-M0046

Fig. 36 Battery isolating switch

① «Battery isolating switch»

I – on

0 – off

- Open the left-hand door.

#### Start the machine

1. Switch the «battery isolating switch» on.

The battery is now connected to the machine's electrical system. The machine can now be started.

2. Close the access door.

#### Shutting down the machine:

1. Switch the «battery isolating switch» to the 'off' position

The battery is disconnected from the machine's electrical system.

2. Close the access door.

### 8.7 Option ga

#### Generator operation



#### DANGER

Risk of fatal injury caused by contact with live components!

- Check correct function of the insulation monitoring device daily (see chapter 7.5).
- Have the generator and control box checked annually by a qualified electrician (see chapter 13.9).

#### 8.7.1 Switching in the generator

Precondition LOAD mode

Read and follow the instructions on generator operation in chapter 4.6.5.3.

1. Turn the «generator main switch »to the "I" position.
2. Set the «automatic circuit-breaker(s)» to the "I" position.
3. Turn the mode selector switch to the required mode of operation

Further information See chapter 4.6.5.2 for generator controls.

See chapter 4.6.5.1 for generator operating modes.

#### 8.7.2 Switching off the generator

Precondition Read and follow the instructions on switching off the generator in chapter 4.6.5.3.



##### 1. **NOTICE!**

Thermal overload of the turbo generator!

Stopping the machine abruptly after the generator has been in operation for some time can cause heat damage to the generator.

- Allow the engine to run for about 2 minutes in idle before shutting down to allow the generator to cool down.

2. Set the «automatic circuit breaker(s)» to the "0" position.

3. Turn the «generator main switch» to the "0" position.

4. Close all «compressed air outlet valves» on the air distributor.

The engine runs in IDLE and the generator can cool down.

After running about 2 minutes in IDLE, the generator has cooled down enough so that the engine can be stopped.

## 9 Fault Recognition and Rectification

### 9.1 Basic instructions

The following tables are intended to assist in fault finding and rectification.

1. Do not attempt fault rectification measures other than those given in this manual!
2. In all other cases:  
Have the fault rectified by an authorized KAESER service representative.

Further information Observe the instructions in chapter 3 "Safety and Responsibility" and prevailing local safety regulations when rectifying faults and malfunctions.  
Comply also with local applicable safety provisions!

### 9.2 Evaluate engine faults and alarms

Further information The engine service manual gives further information.

#### 9.2.1 Engine refuses to start or does not turn over

Possible cause	Remedy	Where can I get help?		
		Specialised workshop	KAESER-service	Engine service manual
Defective starter.	Have replaced.	X	-	-
The fuel cut-off device has not opened.	Check the coil and electrics and have changed if necessary.	X	-	-
Fuel tank empty.	Fill up the fuel tank	-	-	-
Airlock in the fuel line between fuel tank and injector pump.	Bleed the fuel line (see chapter 10.3.3).	-	-	X
Fuel filter clogged.	Clean or replace, see chapter 10.3.3.	-	-	X
Fuel line broken.	Have replaced.	X	X	-
Defective control fuse or relay.	Have repaired or replaced if necessary.	X	X	-
Airend discharge temperature too high.	Have adjusted.	-	X	-
Defective temperature gauge switch giving no enable signal.	Have repaired or replaced if necessary.	-	X	-
Starter switch defective.	Have repaired or replaced if necessary.	-	X	-
Electrical connections and/or cables loose or broken.	Tighten the connection or have the cable replaced.	X	X	-
Defective battery or low charge.	Maintain battery, see chapter 10.3.9.	-	-	-

Possible cause	Remedy	Where can I get help?		
		Specialised workshop	KAESER -service	Engine service manual
Defective alternator.	Have repaired or replaced if necessary.	X	X	-
Defective alternator regulator.	Have repaired or replaced if necessary.	X	X	-
Oil pressure switch indicating insufficient oil pressure.	Check engine oil level, see chapter 10.3.4.	-	-	X
	Have the engine repaired or exchanged.	X	X	-

Tab. 70 Fault: engine refuses to start or comes to a stop.

### 9.2.2 Engine does not reach full speed

Possible cause	Remedy	Where can I get help?		
		Specialised workshop	KAESER -service	Engine service manual
Airlock in the fuel line between fuel tank and injector pump.	Bleed the fuel line (see chapter 10.3.3).	-	-	X
Fuel filter clogged.	Clean or replace, see chapter 10.3.3.	-	-	X
Fuel line broken.	Have replaced.	X	X	-
Speed adjustment cylinder mal-adjusted or defective.	Repair or have replaced if necessary.	X	X	-

Tab. 71 Fault: engine does not reach full speed.

### 9.2.3 Indicator lamp remains on

Possible cause	Remedy	Where can I get help?		
		Specialised workshop	KAESER -service	Engine service manual
Electrical connections and/or cables loose or broken.	Tighten the connection or have the cable replaced.	X	X	-
Defective alternator.	Have repaired or replaced if necessary.	X	X	-
Defective alternator regulator.	Have repaired or replaced if necessary.	X	X	-

Possible cause	Remedy	Where can I get help?		
		Specialised workshop	KAESER-service	Engine service manual
Engine oil pressure too low.	Check engine oil level, see chapter 10.3.4.	–	–	X
	Check the engine and have repaired if necessary.	X	X	–

Tab. 72 Indicator lamp remains on

### 9.3 Evaluate compressor faults and alarms

#### 9.3.1 Working pressure too high

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER-service
Proportional controller maladjusted or defective.	Have repaired or replaced if necessary.	–	X
Inlet valve does not close.	Check the controller, the control air line and the inlet valve and replace if necessary.	–	X
Pressure gauge indicating false pressure.	Have repaired or replaced if necessary.	–	X
Venting valve does not blow off.	Check the connections and function and have repaired or replaced as necessary.	–	X

Tab. 73 Fault: working pressure too high

#### 9.3.2 Working pressure too low

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER-service
Proportional controller maladjusted or defective.	Have repaired or replaced if necessary.	–	X
Inlet valve not opening or only opening partially.	Repair or have replaced if necessary.	–	X
Pressure gauge indicating false pressure.	Have repaired or replaced if necessary.	–	X
Pressure relief valve maladjusted and/or leaking.	Have repaired or replaced if necessary.	–	X
Venting valve does not close.	Check the connections and function and have repaired or replaced as necessary.	–	X

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER-service
The engine runs at maximum speed (LOAD).	See chapter 9.2.	X	X
Engine air filter and/or compressor air filter clogged.	Clean or change, see chapters 10.3.2 and 10.4.7.	-	-
Oil separator cartridge heavily clogged.	Change, see chapter 10.4.6.	-	-

Tab. 74 Fault: working pressure too low

### 9.3.3 Pressure relief valve blowing off

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER-service
Oil separator cartridge heavily clogged.	Change, see chapter 10.4.6.	-	-
Inlet valve does not close.	Check the controller, the control air line and the inlet valve and replace if necessary.	-	X
Pressure relief valve maladjusted and/or leaking.	Adjust or have replaced if necessary.	-	X

Tab. 75 Fault: pressure relief valve blowing off

### 9.3.4 Machine overheating

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER-service
Defective cooling fan.	Have the blades or the complete fan wheel replaced.	-	X
Oil cooler clogged.	Clean surface, see chapter 10.5.	-	-
Defective working element in the combination valve.	Have repaired or replaced if necessary.	-	X
Gauge working pressure too high (proportional controller maladjusted).	Reset to the permissible value or have replaced.	-	X
Oil separator cartridge heavily clogged.	Measure the pressure differential and change the cartridge if greater than 1 bar. See chapter 10.4.6 for changing.	-	X
Compressor oil filter clogged.	Change, see chapter 10.4.4.	-	-
Compressor cooling oil level too low.	Topping up, see chapter 10.4.2.	-	-

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER-service
Oil pipes leaking.	Seal leaks or have pipes changed.	X	X
Engine cooling system or cooling fan defective.	Have repaired.	X	X
Ambient temperature too high.	See installation conditions in chapter 5.2.	-	-

Tab. 76 Fault: machine overheating

### 9.3.5 Too much oil residue in the compressed air

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER-service
Oil separator cartridge scavenge line clogged.	Clean the oil separator cartridge dirt trap or replace the strainer and nozzle if necessary. See chapter 10.4.5.	-	X
Fractured oil separator cartridge.	See chapter 10.4.6 for changing.	-	-
Oil level in the oil separator tank too high.	Reduce to maximum level, see chapters 10.4.1 and 10.4.3.	-	-

Tab. 77 Fault: too much oil residue in the compressed air

### 9.3.6 Oil flows from the compressor air filter after shutdown

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER-service
Defective non-return function of the inlet valve.	Repair or have replaced if necessary.	-	X

Tab. 78 Fault: oil flows from the compressor air filter after shutdown

**9.3.7 Option da, db, dc, dd**
**High moisture content in the compressed air**

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER-service
Blocked condensate drain on the cyclone separator.	Clean the cyclone separator dirt trap or replace the strainer and nozzle if necessary. See chapter 10.8.2.	–	X

Tab. 79 Fault: high moisture content in the compressed air

**9.4 Option Ic**
**Evaluate faults in the diesel particulate filter**

A fault in the diesel particulate filter will trigger the indication *fault, diesel particulate filter*.

Indication	Meaning	Remedy
Flashes	The exhaust temperature is too low for regenerating the filter module. Regeneration of the filter module interrupted by shutting down the machine or IDLE running.	Run the machine in LOAD mode for some time.
Illuminates for about 10 seconds every minute.	Maintenance due on the diesel particulate filter.	Contact KAESER Service.
Remains illuminated	Fault in the diesel particulate filter system	Disabling the machine Contact KAESER Service.

Tab. 80 Faults in the diesel particulate filter

**Blue engine exhaust**

There is unburnt lubricating oil in the engine exhaust which is partially deposited in the filter module of the diesel particulate filter and the rest escapes as blue smoke.

Meaning	Remedy	Where can I get help?		
		Specialised workshop	KAESER-service	Engine service manual
A diesel particulate filter overburdened with oil and regenerated at too high temperature can result in damage to the ceramic filter module.	Carry out engine maintenance to avoid damage to the filter module.	X	X	X

Tab. 81 Fault 'blue engine exhaust'

**Grey or brownish exhaust gas**

Meaning	Remedy	Where can I get help?		
		Specialised workshop	KAESER-service	Engine service manual
The exhaust contains residues of hydrocarbons or sulphate.	Have the fuel injection system checked. Use an engine oil that produces low white ash.	X	X	X

Tab. 82 Grey or brownish exhaust gas

**9.5 Option ga**  
**Evaluate generator faults and alarms**
**9.5.1 There is no voltage or too low a voltage from the generator**

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER-service
Defective drive belt.	have replaced.	X	X
Generator / regulator defective	Have repaired.	X	X
Overload protection switch triggered because of overload or defect.	Check the power requirement of the connected consumers and reduce if necessary; check the consumers for short circuits.	X	-
	Check the overload protection switch and have changed if necessary.	X	X
Engine speed too low.	Have reset to rated speed.	X	X
Generator not switched in.	Switch in the generator.	-	-
The compressor's working pressure is set too high, engine overloaded, speed drops off	Have the working pressure adjusted.	X	X
The engine power is reduced because of climatic conditions or other effects.	Keep the generator and compressor load below the rated power	-	-

Tab. 83 There is no voltage or too low a voltage from the generator

**9.5.2 Generator voltage too high**

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER-service
Generator / regulator defective	Have repaired.	X	X

Possible cause	Remedy	Where can I get help?	
		Specialised workshop	KAESER-service
Engine speed too high.	Have reset to rated speed.	X	X

Tab. 84 Generator voltage too high

RAMIRENT

# 10 Maintenance

## 10.1 Ensuring safety

Follow the instructions below for safe installation.

Warning instructions are located before a potentially dangerous task.



Disregard of warning instructions can cause serious injuries!

### Complying with safety notes

Disregard of safety notes can cause unforeseeable dangers!

- Follow the instructions in chapter 3 'Safety and Responsibility'.
- Allow maintenance work to be performed by authorised personnel only.
- Make sure that no one is working on the machine.
- Ensure that all protective devices and cover panels are in place and secured.
- Ensure that all tools have been removed from the machine.
- Do not carry out any checks or maintenance while the machine is running.



The access doors are held up by gas struts.

- Check that the doors remain open.

Change any gas strut that is not able to hold the door open.

### When working on the compressed air system

Compressed air is a contained force. Uncontrolled release of this force can cause serious injury or death. The following safety concerns relate to any work on components that could be under pressure.

- Disconnect the air consumers.
- Wait until the machine is automatically vented (check that the pressure gauge indicates 0 bar).
- Open outlet valves carefully to ensure that the line between the minimum pressure/check valve and the compressed air outlet is vented.
- Do not open or dismantle any valves.

### When working on the drive system

Touching rotating, very hot or electrically live components can result in serious injury.

- Shut down the machine before opening any doors/canopy.
- Disconnect the negative terminals on the batteries.
- Ensure that the machine is cooled down.

Further information Details of authorised personnel are found in chapter 3.4.2.

Details of dangers and their avoidance are found in chapter 3.5.

**Option Ic Work on the diesel particulate filter****NOTICE**

Damage of the diesel particulate filter!

- The machine must be shut down immediately if any damage or functional defect in the diesel particulate filter is noticed.
- Only authorised specialists, such as KAESER Service Technicians may carry out maintenance work on the diesel particulate filter.

## 10.2 Following the maintenance plans

### 10.2.1 Logging maintenance work



The maintenance intervals given are those recommended for KAESER original components with average operating conditions.

- In adverse conditions, perform maintenance work at shorter intervals.  
  
Adverse conditions are, e.g.:
  - high temperatures
  - much dust
  - frequent use
- Adjust the maintenance intervals with regard to local installation and operating conditions.
- Logging all maintenance work.  
This enables the frequency of individual maintenance tasks and deviations from our recommendations to be determined.

Further information A list is given in chapter 10.9.

### 10.2.2 Maintenance tasks after commissioning

The table below lists maintenance tasks required after commissioning (initial start-up).

- Carry out maintenance tasks according to the following schedule.

Component: Task	After the first 10 h	After the first 50 h	See chapter	Note
<b>Engine</b>				
Change oil.		X	10.3.6	Engine SM
Change the oil filter.		X	10.3.7	Engine SM
Check the fuel lines and clamps.		X		Engine SM
<b>Wheels/chassis:</b>				

h = operating hours; Engine-SM = manufacturer's engine service manual

Component: Task	After the first 10 h	After the first 50 h	See chapter	Note
Re-tighten the wheel nuts/bolts.		X		
<b>Option ga, gb – generator:</b>				
Check the generator-drive belt tension and re-tension if necessary.	X		10.8.6	

**h = operating hours; Engine-SM = manufacturer's engine service manual**

Tab. 85 Maintenance tasks after commissioning

### 10.2.3 Regular Maintenance Work

The following table lists the various maintenance intervals.

Maintenance interval	Short description
Daily	–
Every 250 h, at least annually.	A250
Every 500 h, at least annually.	A500
Every 1000 h, at least annually.	A1000
Every 1500 h, at least annually.	A1500
Every 2000 h, at least every 2 years.	A2000
Every 3000 operating hours	A3000
Every 20000 operating hours	A20000
Every 36000 h, at least every 6 years.	A36000

Tab. 86 Maintenance intervals and regular maintenance tasks

The table below lists regular maintenance tasks.

- Carry out maintenance tasks punctually taking ambient and operating conditions into consideration.

#### 10.2.3.1 Machine maintenance schedule

- Carry out maintenance tasks according to the following schedule.

Component: Function	Daily	A250	A500	A1000	A1500	A2000	A3000	A36000	See chapter	Note
<b>Engine</b>									10.3.2	

Check inlet air filter maintenance indicator. X

Engine SM = engine manufacturer's service manual; SW = specialised workshop.

Component: Function	Daily	A250	A500	A1000	A1500	A2000	A3000	A36000	See chapter	Note
Check engine oil level.	X								10.3.4	Engine SM
Clean the engine air filter		X							10.3.2	Engine SM
Change the engine oil		X							10.3.6	
Replace the engine oil filter.		X							10.3.7	Engine SM
Check/adjust the drive belt tension.		X							10.3.8	Engine SM
Replace the drive belt.			X						10.3.8	Engine SM
Change engine air filter.			X						10.3.2	
Have the valve clearance adjusted.			X							SW Engine SM
Have the turbocharger checked.							X			SW
Check the engine coolant level.	X								10.3.1	Engine SM
Clean the radiator.		X							10.5	
Check antifreeze concentration.		X							10.3.1	Engine SM
Check radiator hose and hose clips, have replaced if necessary.		X								SW Engine SM
Replace the coolant.				X					10.3.1	Engine SM
Fill up the fuel tank	X									
Check/empty the water trap.	X								10.3.3	
Check fuel lines and hose clamping bands, have replaced if necessary.		X								SW
Replace fuel lines and clamps.				X						SW
Clean the fuel micro-filter.		X							10.3.3	Engine SM
Change the fuel pre-filter.			X						10.3.3	
Replace the fuel micro-filter.			X						10.3.3	Engine SM
Clean the fuel tank.			X							
Clean the tank fuel strainer.			X							

Engine SM = engine manufacturer's service manual; SW = specialised workshop.

Component: Function	Daily	A250	A500	A1000	A1500	A2000	A3000	A36000	See chapter	Note
Have the fuel injectors checked.				X						SW
Have the fuel injector pump checked.						X				SW
Check the battery electrolyte level and connections.			X						10.3.9	
<b>Compressor:</b>										
Check inlet air filter maintenance indicator.	X								10.4.7	
Check cooling oil level.	X								10.4.1	
Clean the compressor air filter.		X							10.4.7	
Clean the oil cooler.	X								10.5	
Have the pressure relief valve(s) checked.		X							10.4.8	
Check/clean the oil separator tank dirt trap.		X							10.4.5	
Change compressor air filter.			X						10.4.7	
Change the cooling oil.			X						10.4.3	
Change the compressor oil filter.				X					10.4.4	
Change the separator cartridge in the oil separator tank.						X			10.4.6	
<b>Wheels/chassis/bodywork:</b>										
Check the tyre pressures.		X								
Check wheel bolts and nut for tightness.		X								
Carry out chassis maintenance.			X						10.7	
Grease the ball coupling, joints and towbar.			X						10.7.2	
Brake maintenance			X						10.7.3	
Check wear on the brake linings.			X						10.7.3.1	
Have the wheel brakes adjusted.			X							SW
Check all screw connections, hinges, locks, handles and snap fasteners of the doors for wear and secure fixing.	X									
Grease the door hinges.			X							

Engine SM = engine manufacturer's service manual; SW = specialised workshop.

Component: Function	Daily	A250	A500	A1000	A1500	A2000	A3000	A36000	See chapter	Note
Carry out rubber sealing strip maintenance.		X							10.6	
Have the lifting point checked.		X								SW
<b>Other maintenance tasks</b>										
Check all accessible screw fittings, pipes and clamps for wear and tightness.			X							
Check hoses for proper seating, leaks and wear.			X							
Have hose lines replaced.								X		SW
Check that all electrical connections are tight.		X								
Engine SM = engine manufacturer's service manual; SW = specialised workshop.										

**Tab. 87 Regular machine maintenance tasks**
**10.2.3.2 Maintenance schedule for options**

- Carry out maintenance tasks according to the following schedule.

Option: Function	Daily	A250	A500	A1000	A2000	A20000	See chapter	Note
<b>Option ec - tool lubricator</b>								
Check the oil level in the tool lubricator.	X						10.8.1	
<b>Options da, db, dc, dd – cyclone separator:</b>								
Clean and check the dirt trap.			X				10.8.2	
<b>Options da, db, dc, dd – compressed air aftercooler:</b>								
Clean the radiator.		X					10.5.2	
<b>Option dd – filter combination:</b>								
Drain condensate.	X						10.8.3	
Change the filter elements			X				10.8.3	
<b>Option dc – fresh air filter:</b>								
Drain condensate.	X						10.8.4	
Check the oil indicator.	X						10.8.4	
Change the filter elements			X				10.8.4	
<b>Option ba – frost protector:</b>								
SW = refer to a specialised workshop; KS = call KAESER Service								

Option: Function	Daily	A250	A500	A1000	A2000	A20000	See chapter	Note
Winter operation: Check the level of antifreeze in the frost protector.	X						10.8.5	
<b>Engine coolant pre-heater (Option bb)</b>			X					SW
Have the coolant pre-heating and associated wiring checked.				X				
<b>Option la – spark arrestor:</b>			X				10.8.7	
Clean the spark arrestor.			X					
Blow out the spark arrestor with compressed air.			X					
<b>Option lb - engine air intake shut-off valve</b>								
Clean and check the engine air intake shut-off valve		X					10.8.8	
<b>Option ga, gb – generator:</b>								
Check/adjust belt tension.	X						10.8.6	
Visually inspect the drive belt.	X						10.8.6	
Have the generator and control box checked.			X				13.9	EL
Replace the drive belt.					X		10.8.6	
Have the generator bearings checked.					X			SW
Have the generator bearings changed.						X		SW
<b>Option lc – diesel particulate filter</b>								
Have the whole diesel particu- late filter system serviced.			X				3.4.4	SW KS
Have the diesel engine emission checked according to TRGS 554.					X		3.4.4	SW KS
SW = refer to a specialised workshop; KS = call KAESER Service								

Tab. 88 Regular maintenance task options

### 10.3 Engine maintenance

- Perform maintenance tasks according to the schedule in chapter 10.2.3.1.

### 10.3.1 Water cooler maintenance

Material	Coolant Coolant tester Receptacle Wrench Funnel Cleaning cloth
Precondition	The machine is shut down. The machine is standing level. The machine is fully vented, the pressure gauge reads 0 bar. Machine is cooled down. All compressed air consumers are disconnected and the air outlet valves are open.

**WARNING**

Danger of scalding by hot coolant!

Serious injuries can be caused by hot coolant.

- Let the machine cool down before opening the cooling system.

**CAUTION**

There is danger of injury from coolant containing antifreeze!

- Avoid eye and skin contact with coolant. If the eyes are affected, rinse immediately with running water.
- Wear protective glasses and gloves.

**NOTICE**

Insufficient coolant can damage the engine.

Insufficient coolant will cause the engine to overheat. Overheating can cause serious damage to the engine.

- Check the coolant level daily.
- Top up the coolant as necessary.
- Open the left-hand door.

#### 10.3.1.1 Checking coolant level

Check the coolant level of the engine daily before starting.

The level is checked on the coolant expansion tank:

- The tank is semi-transparent so the coolant level can be seen from outside.
- The level should be between the *minimum and maximum markings* with the engine cooled down.




Fig. 37 Checking coolant level

- |   |                        |   |                         |
|---|------------------------|---|-------------------------|
| 1 | Filler port with cap   | 5 | Coolant level           |
| 2 | Water cooler           | A | maximum markings (FULL) |
| 3 | Overflow               | B | minimum-markings (LOW)  |
| 4 | Coolant expansion tank |   |                         |

1. Check the level of coolant in the expansion tank.  
Top up when the coolant level falls below the *minimum marking* (B).
2. Close the door.



Determine and rectify the cause of coolant loss.

#### 10.3.1.2 Checking the coolant

The coolant should be checked according to the maintenance schedule to ensure quality and operational life.

Coolant quality can be determined by the following parameters:

- Visual check
- Antifreeze concentration measurement
- Unscrew and remove the expansion tank filler cap (1).

##### Visual check

The coolant should be checked for its colour and any particles or sediments floating in it.

- Take a coolant sample and analyse.

The coolant should be changed if it is discoloured or has floating particles.

##### Antifreeze concentration measurement

An instrument (e.g. refractometer) is used to check antifreeze concentration.

Maximum frost protection is ensured with an antifreeze concentration of 55% by volume, as frost protection and heat transfer properties deteriorate beyond this point. Higher concentration also leads to higher operating temperature.

1. **NOTICE!**

The engine can be damaged if the antifreeze concentration is insufficient.

Corrosion

Damage to the cooling system.

Engine casing fracture

➤ Check coolant.

➤ Protect the coolant against frost.

➤ Top up as necessary.

## 2. Use the coolant tester as instructed by the manufacturer to test the coolant.

Change the coolant when the concentration of antifreeze is too low.

**Finish off the work steps:**

1. Screw on the filler cap.

2. Close the door.

#### 10.3.1.3 Mixing coolant

Do not use water without coolant additive. Water alone is corrosive at engine operating temperature. Water alone does not offer sufficient protection from boiling or freezing.

The coolant is a mixture of clean, fresh water and antifreeze with corrosion inhibitor.

For reasons of corrosion protection and the need to raise the boiling point, the coolant must remain in the cooling system throughout the year.

The maximum permissible coolant life is 2 years.

➤ Follow coolant recommendations in chapter 2.6.3.

#### Preparing coolant

Precondition Coolant must meet the specification of ASTM D4985.

➤ The coolant should be mixed in the proportions given by the manufacturer.

#### KAESER coolant mixture table

Antifreeze	Water	Frost protection to [°C]
1 part	2 parts	-18
1 part	1.5 parts	-25
1 part	1 part	-37

Tab. 89 KAESER coolant mixture table



The concentration of antifreeze should not be less than 33% for ensured corrosion protection.

#### 10.3.1.4 Filling and topping up the coolant

The proportion of antifreeze in the coolant should not fall below 33% to ensure frost and corrosion protection and prevent the build up of deposits in the cooling circuit. Topping up with water alone dilutes the antifreeze concentration and is forbidden.



Make sure that there is sufficient room for hot coolant to expand without overflowing.

Precondition The negative cable to the battery is disconnected.

1. Twist and remove the expansion tank filler cap.
2. Mix a quantity of coolant according to the table and top up to the mark.  
Top up until the coolant level is just below the *maximum mark* [A].
3. Screw on the filler cap.
4. Reconnect the negative battery terminal.
5. Close the door.
6. Start the engine and allow to IDLE for about 1 minute.
7. Stop the engine.
8. Open the left-hand door.
9. Check the coolant level.  
Top up if the coolant level in the expansion tank has fallen.
10. Visually inspect for leaks.
11. Close the door.



If the coolant has been changed, check the level of the new coolant frequently at first as it can decrease due to the escape of air locks in the cooling circuit.

#### 10.3.1.5 Draining the coolant

The complete volume of coolant contained in the circuit can be drained from the radiator. The water cooler is drained by a separate drain plug (accessible from underneath through the access hole in the floor pan).

Precondition Machine is cooled down.

The negative cable to the battery is disconnected.




Fig. 38 Draining the coolant from the radiator

- |                            |                            |
|----------------------------|----------------------------|
| [1] Filler cap             | [4] Oil cooler             |
| [2] Coolant expansion tank | [5] Radiator drain plug    |
| [3] Water cooler           | [6] Coolant expansion tank |

1. Unscrew and remove the expansion tank filler cap [1].
2. Position a receptacle beneath the water cooler drain point (accessible through a hole in the floor panel).

3. Unscrew the drain plug **5** and allow the coolant to drain into the receptacle.
4. Fit a new gasket on the drain plug and screw it back in again.
5. Screw on the filler cap.
6. Close the door.



➤ Dispose of used coolant in accordance with environmental protection regulations.

Further information The operating manual supplied by the engine manufacturer provides further information on coolant change and cleaning the cooling system.

#### 10.3.2 Engine air filter maintenance

Clean the filter according to the maintenance schedule or if the maintenance indicator shows this to be necessary.

Renew the air filter element after 2 years at the latest or after it has been cleaned 5 times.



- Using the engine without an air filter element is not permitted!
- Do not use an air filter element with damaged folds or gasket.
- The use of an unsuitable air filter can permit dirt to ingress the engine and cause premature wear and damage.

Material Compressed air for blowing out  
Spare parts (as required)  
Cleaning cloth

Precondition The machine is shut down.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Machine is cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.



##### **NOTICE**

Damaged air filter element.  
Wear in the engine from intake of contaminated air.

- Do not try to clean the filter element by striking or knocking it.
- Do not wash the filter element.




Fig. 39 Engine air filter maintenance

- |   |  |   |                |
|---|--|---|----------------|
| 1 | Maintenance indicator                          | 5 | Filter element |
| 2 | Red zone indicator scale                       | 6 | Retaining clip |
| 3 | Indicating piston of the maintenance indicator | 7 | Filter cap     |
| 4 | Reset knob for the maintenance indicator       |   |                |




Fig. 40 Cleaning the filter element

- |   |   |
|---|---|
| 1 | Compressed air gun with blast pipe bent to 90° at the end |
| 2 | Filter element  |

#### Checking contamination of the air filter:

Air filter maintenance is necessary when the yellow piston inside the maintenance indicator reaches the red zone.

1. Open the left-hand door.
2. Check the air filter maintenance indicator.  
If the yellow piston reaches the red zone, clean or renew the filter element.
3. Close the door.

#### Cleaning the air filter:

1. Open both doors.
2. Release the retaining clamps, lift off the cap and extract the air filter.
3. Carefully clean the inside of the housing, the cover and sealing faces with a damp cloth.

4. Cleaning the filter element:
  - Use dry compressed air ( $\leq 5$  bar!) at an angle to blow dust from the element from inside to outside until no further dust develops.
  - The blast pipe must be long enough to reach the bottom of the element.
  - The tip of the blast pipe must not touch the element.
  - Cleaning sealing faces.
5. Inspect the element carefully for any damage.  
Replace any damaged filter element.
6. Insert the cleaned or new filter element into the filter housing. Make sure it is properly in place and sealed by its gaskets.
7. Replace the cap and secure with the clip.

**Resetting the maintenance indicator:**

- Repeatedly press the reset knob on the maintenance indicator.  
The yellow piston within the indicator is reset and the maintenance indicator is ready for use again.
- Close the doors.



Dispose of old parts and contaminated materials according to environmental regulations.

### 10.3.3 Fuel system maintenance

Make sure no dirt enters the fuel system during maintenance. Clean components and their surroundings before dismounting.


Material	Spare parts Receptacle Cleaning cloth
Precondition	The machine is shut down. The machine is standing level. The machine is fully vented, the pressure gauge reads 0 bar. Machine is cooled down. All compressed air consumers are disconnected and the air outlet valves are open. The negative cable to the battery is disconnected.

**DANGER**

Danger of fire from spontaneous ignition of fuel!

Serious injury or death could result from the ignition and combustion of fuel.

- Allow no open flames or sparks at the place of use.
- Ensure that the maximum ambient temperature is not exceeded at the place of use.
- Stop the engine.
- Wipe up escaped fuel.
- Keep fuel away from hot machine parts.


**Fig. 41 Fuel system maintenance**

- |  |  |
|--|--|
| <b>①</b> Fuel pump<br><b>②</b> Fuel pre-filter<br><b>③</b> Fuel filter with water trap | <b>④</b> Fuel strainer<br><b>⑤</b> Fuel tank<br><b>⑥</b> Fuel micro-filter |
|--|--|


► Open the right-hand access door.

#### 10.3.3.1 Bleeding the fuel system

Air can enter the fuel system if the fuel tank is empty after a fuel filter change or when carrying out work on the fuel lines.

If the engine refuses to start despite a full tank, bleed the fuel system.

Precondition Battery connected.


**Fig. 42 Bleeding the fuel system**

- |  |
|--|
| <b>①</b> Bleed screw<br><b>②</b> Fuel micro-filter |
|--|

1. Place a receptacle beneath the fuel fine filter housing.
2. Loosen the micro-filter bleed screw.
3. Close the door.
4. Turn the «starter switch» (operator panel) to the "On" position.  
The fuel pump runs and air is bled out of the fuel system.
5. After approx. 10 to 15 minutes, switch the «starter switch» to the "STOP/Off" position.

6. Open the right-hand access door.
7. Tighten the bleed screw again.
8. Remove the receptacle.
9. Close the door.




Start the engine as soon as the fuel system has been bled and allow to run for at least 5 minutes in IDLE.

10. Open the right-hand access door.
11. Visually check the fuel system for leaks. If required, re-tighten all fittings.
12. Close the door.

#### 10.3.3.2 Fuel filter with water trap maintenance

A water trap is installed between the tank and the fuel pump. The water trap is semi-transparent so the fuel level can be seen from outside.



10-M0414

Fig. 43 Fuel filter with water trap maintenance

- ① Bleeding screw
- ② Water trap
- ③ Drain plug

#### Checking the fuel water trap

Water, being denser than diesel fuel, sinks to the bottom of the water trap. The presence of water can be verified by it having a different colour than the fuel. Check daily whether water has collected in the water trap or any dirt has accumulated.

- Check the fuel in the transparent water trap.  
Fuel contaminated. Immediately empty the fuel water trap.

#### Emptying the fuel water trap

Precondition Water and/or contamination are visible in the water trap.


1. Place a receptacle beneath the fuel micro-filter housing.
2. Loosen the bleed screw ① in the filter head.
3. Loose the drain screw ③ and allow water and dirt to drain out into the receptacle.
4. Remove the receptacle.
5. Reconnect the battery.
6. Close the door.



The mixture of fuel and water and any materials contaminated with fuel must be disposed of in accordance with environment protection regulations.

#### 10.3.3.3 Fuel filter maintenance

##### Changing the fuel pre-filter:




10-M0855

Fig. 44 Changing the fuel pre-filter

- ① Fuel hose
- ② Hose clamp
- ③ Fuel pre-filter

1. Place a receptacle beneath the fuel pre-filter housing.
2. Loosen the hose clamps, carefully pull the fuel hoses from the connection at the fuel pre-filter. Capture and wipe off any escaping fuel.
3. Install a new fuel pre-filter between the plastic hoses and secure using hose clamps, taking care the flow is in the right direction.
4. Remove the receptacle.

##### Replacing the fuel micro-filter:



10-M0164

Fig. 45 Fuel micro-filter maintenance

- ① Filter holder
- ② Filter cartridge
- ③ Turn in this direction to unscrew the filter cartridge.

1. Place a receptacle beneath the fuel fine filter housing.
2. Use a filter wrench to loosen then unscrew the filter cartridge. Catch fuel in the receptacle.
3. Clean the sealing faces of the micro-filter cartridges and the opposite site of the filter mount with lint-free cloth.

4. Mount the micro-filter cartridges on the filter mount:
  - Moisten the rubber seals of the filter mount and the sealing faces of the new filter cartridge with some fuel.
  - Manually screw the filter cartridge to the filter head (clockwise), until seal is tight.
5. Reconnect the battery.
6. Close the door.



The fuel system must be bled after the filter cartridges have been changed.



Dispose of fuel and any materials and components contaminated with it in accordance with environmental protection regulations.

#### Starting the machine and performing a test run:


1. Switch the machine on and run it in IDLE mode for approx. 1 minute.
2. Shut down the machine.
3. Open the right-hand access door.
4. Visually check the fuel system for leaks.
5. Tighten all fittings.
6. Close the door.

Further information The engine service manual provides further information on fuel system maintenance.

#### 10.3.4 Checking the engine oil level

The engine oil is indicated by a dipstick in the oil sump. The oil level should ideally be between the two marks on the dipstick. The oil level should not be allowed to fall below the *minimum level*.

Material	Cleaning cloth
Precondition	The machine is shut down. The machine is standing level. The machine is fully vented, the pressure gauge reads 0 bar. Engine cooled down. All compressed air consumers are disconnected and the air outlet valves are open.



10-M0854

Fig. 46 Checking the engine oil level

- |   |  |
|---|--|
| <span style="border: 1px solid black; padding: 2px;">1</span> Oil filler neck cover, engine oil<br><span style="border: 1px solid black; padding: 2px;">2</span> Dipstick | <span style="border: 1px solid black; padding: 2px;">A</span> Mark for <i>maximum oil level</i><br><span style="border: 1px solid black; padding: 2px;">B</span> Mark for <i>minimum oil level</i> |
|---|--|

1. Open the right-hand access door.
2. Withdraw the dipstick, wipe with a lint-free cloth and replace fully.
3. Withdraw the dipstick once more and read off the oil level.  
The level should be between the maximum and minimum markings.  
Top up if the level has reached or fallen below the *minimum level* mark.
4. Close the access door.



The marked *maximum oil level* should not be exceeded in order for the level of oil in the crankcase not to reach the crankshaft. If this were to occur, it could create oil bubbles that would reduce the oil's lubricating capability and impair engine performance.

### 10.3.5 Engine oil filling and topping up

Material      Engine oil

Cleaning cloth

Funnel

Precondition      The machine is shut down.  
The machine is standing level.  
The machine is fully vented, the pressure gauge reads 0 bar.  
All compressed air consumers are disconnected and the air outlet valves are open.  
The negative cable to the battery is disconnected.

#### Filling with engine oil



See chapter 2.6.4 for engine oil filling volume.  
The oil dipstick is marked with the «maximum oil level».

1. Open the right-hand access door.
2. Remove the filler cap and fill with fresh oil.

3. Wait 5 minutes then check the oil level.



It takes a few minutes for oil to reach the sump.

- Top up if the level is too low.
4. Replace the plug in the filler port.
  5. Reconnect the negative battery terminal.
  6. Close the door.

#### Starting the machine and performing a test run:

1. Switch the machine on and run it in IDLE mode for approx. 5 minutes.
2. Shut down the machine.
3. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
4. Open the right-hand access door.
5. Check the oil level after about 5 minutes.  
Top up if the level is too low.
6. Visually inspect for leaks.
7. Close the door.

#### 10.3.6 Changing the engine oil

The engine oil should be changed:

- according to the maintenance schedule,
- according to the degree of contamination of the intake air,
- at least once a year.

Material	Engine oil Receptacle Wrench Cleaning cloth
Precondition	The machine is shut down. The machine is standing level. The machine is fully vented, the pressure gauge reads 0 bar. Engine at operating temperature. All compressed air consumers are disconnected and the air outlet valves are open. The negative cable to the battery is disconnected.



#### CAUTION

Danger of burns from hot components and escaping engine oil!

- Wear long-sleeved clothing and gloves.

#### Draining the engine oil:

The engine oil is drained directly at the machine's oil pan. For this purpose, a drainage outlet is provided in the floor pan.




Fig. 47 Draining the engine oil

- |   |                       |   |                             |
|---|-----------------------|---|-----------------------------|
| 1 | Engine block          | 4 | Floor pan                   |
| 2 | Engine oil sump       | 5 | Underside of floor pan      |
| 3 | Engine oil drain plug | 6 | Drain hole in the floor pan |

1. Open the left-hand door.
2. Remove the oil oil filler cover.
3. Place the oil receptacle below the drain hole in the floor pan.
4. Unscrew the drain plug and allow the engine oil to drain into the receptacle.
5. Clean the drain plug and screw in with a new gasket.
6. Replace the plug in the filler port.
7. Close the door.



Dispose of old oil and oil-soaked working materials according to environmental protection regulations.

Further information See chapter 10.3.5 for oil filling.  
The engine service manual gives instructions on oil changing.

#### 10.3.6.1 Option ga Changing the engine oil

This is done from a oil drain valve with the aid of a separate drain hose.




Fig. 48 Changing the engine oil

- |                         |  |
|-------------------------|--|
| ① Generator             | ⑤ Drain hose with rapid action hose coupling |
| ② Engine oil sump       | ⑥ Underside of floor pan                     |
| ③ Engine oil drain line | ⑦ Drain hole in the floor pan                |
| ④ Oil drain valve       |  |

#### Draining the engine oil:

1. Open the left-hand door.
2. Remove the oil oil filler cover.
3. Place the oil receptacle below the drain hole in the floor pan.
4. Lay the free end of the drain hose ⑤ in the receptacle.
5. Remove the protective cap from the oil drain valve ④.
6. Screw the drain hose with rapid action hose coupling onto the oil drain valve.  
The valve opens and oil drains through the hose.
7. When all the oil has drained out, uncouple and remove the drain hose.
8. Replace the protective cap on the oil drain valve.
9. Replace the plug in the filler port.
10. Close the door.



Dispose of old oil and oil-soaked working materials according to environmental protection regulations.

Further information

See chapter 10.3.5 for oil filling.

The engine service manual gives instructions on oil changing.

### 10.3.7 Replace the engine oil filter


Material	Spares Filter wrench Cleaning cloth Receptacle
Precondition	The machine is shut down. The machine is fully vented, the pressure gauge reads 0 bar. Engine cooled down. All compressed air consumers are disconnected and the air outlet valves are open. The negative cable to the battery is disconnected.



#### CAUTION

Danger of burns from hot components and escaping engine oil!

- Wear long-sleeved clothing and gloves.



10-M0166

Fig. 49 Changing the oil filter

- ① Engine block
- ② Oil filter
- ③ Direction of rotation to unscrew the filter

1. Open the left-hand door.
2. Prepare a receptacle.
3. Use a filter wrench to loosen and unscrew the filter. Catch any escaping oil.
4. Carefully clean sealing surfaces using lint-free cloth.
5. Lightly oil the new filter's gasket.
6. Turn the oil filter clockwise by hand to tighten.
7. Check the engine oil level.  
Top up if the level is too low.
8. Reconnect the negative battery terminal.
9. Close the door.

Further information The engine service manual gives further information on oil filter changing.



Dispose of old oil filters, old oil and materials contaminated with oil according to environmental protection regulations.

### 10.3.8 Drive Belt Maintenance

The lifespan of the drive belts is affected by belt tension.

- Slack belts can slip and become damaged.
- Over-tight belts stretch and fatigue quicker. Over-tight belts also place unnecessary stress on bearings and shorten their life.

Material      Wrench  
                  suitable clamping lever (short, thin rod)  
                  Spares

Precondition    The machine is shut down.  
                  The machine is fully vented, the pressure gauge reads 0 bar.  
                  Machine is cooled down.  
                  All compressed air consumers are disconnected and the air outlet valves are open.  
                  The negative cable to the battery is disconnected.



#### WARNING

Beware of rotating pulleys and moving belts.  
There is danger of serious injury from pinching.

- Never check the drive belts unless the engine is at standstill.
- Never run the machine without a belt guard.

- Open both doors.

#### Removing the belt guard:




Fig. 50 Belt guard attachment

- ① Engine block
- ② Hex-head screw
- ③ Belt guard

1. Unscrew the securing screws of the belt guard and remove the belt guard.

## 10.3.8.1 Visual check

Carry out a visual check for damage:

- Check the belts thoroughly for cracks, fraying or stretching.  
Replace the belt immediately if any damage or wear is found.

Check the belt seating:




Fig. 51 Kontrollere at drivremmen sitter som den skal

- ① Belt pulley
- ② Drive belt
- ③ Pulley guidance groove

- Check the drive belt seating.  
If the belt sits too deep in the guidance groove: immediately change the drive belt.
- 1. Replace the belt guard.
- 2. Reconnect the negative battery terminal.
- 3. Close the doors.

## 10.3.8.2 Checking belt tension

Check belt tension when they are warm, not hot, to avoid length variations through temperature.

The belt tension can be checked by hand: To check the tension, press the belt inwards with the thumb at the mid-point between pulleys.




Fig. 52 Belt tension checking by hand

- [A] Permissible deflection of the belt
- [\*] Approximate pressure exerted: 10 kg  
Permissible movement: 7–9 mm

1. Check belt tension by hand (see Fig. 52).
2. Increase the tension on a loose belt.
3. Replace the belt guard.
4. Reconnect the negative battery terminal.
5. Close the doors.

#### 10.3.8.3 Changing/tensioning the drive belt

The drive belt is tensioned via the screw fastening of the alternator.




Fig. 53 Changing/tensioning the drive belt

- |                                    |                           |
|------------------------------------|---------------------------|
| [1] Engine block                   | [4] Alternator            |
| [2] Drive belt                     | [5] Hexagon nut (locknut) |
| [3] Hexagon screw (securing screw) | [6] Lever                 |

#### Tensioning the drive belt:

1. Loosen the alternator securing screw and clamping nut.
2. Place a suitable lever between the alternator and engine block.
3. Gently push the alternator in the direction of the arrow (outwards) using the lever until the drive belt is tensioned.
4. Re-tighten the securing screw and clamping screw.
5. Remove the lever.
6. Check the belt tension (see Fig. 52).

Belt tension too low: Push the AC generator further in the direction of the arrow.

Belt tension too high: Slightly push the AC generator opposite the arrow direction.

#### Changing the belts

1. Loosen the alternator securing screw and clamping nut until the drive belt can be taken off the pulleys.
2. Take off the belt.
3. Check the pulleys for dirt and wear.  
Clean the pulleys.  
Worn pulley: Have the pulley replaced.

4. Manually route the new drive belt over the pulleys without using force.
5. Tension the drive belt. Ensure that the drive belt is correctly positioned in its guide.



A belt that has been replaced may not be used again.

After running for two to three hours, check the belt tension again.



Old belts should be disposed of in accordance with the latest environmental regulations.

#### Making operational:

1. Replace the belt guard.
2. Reconnect the negative battery terminal.
3. Close the doors.

Further information The operating manual of the engine manufacturer provides further information on removing, changing and tensioning drive belts.

### 10.3.9 Battery maintenance

- Check the charging system if the battery discharges without reason.

#### 10.3.9.1 Safety



##### WARNING

Danger of acid burns from escaping electrolyte!

- Wear appropriate protective clothing including acid-proof rubber gloves.
- Always wear eye and face protection.
- Do not tip the battery. Electrolyte may run out of the vent holes.
- Work with caution.

#### When working on the battery comply with the following safety signs:

A warning label with safety signs is attached to the battery.



10-M0167

Fig. 54 Safety signs - warning stickers on the battery.

- Take heed of any safety signs on the battery warning labels.

The individual safety signs have the following meaning:

- ① – Fire, sparks, open flame and smoking are forbidden!
- ② – Eye and face protection must be worn because of the danger of acid burns.
- ③ – Keep children well away from batteries and electrolyte.
- ④ – Wear protective gloves, batteries are filled with caustic electrolyte!
- ⑤ – Observe the battery manufacturer's instructions!
- ⑥ – Follow the safety rules, explosion hazard!

#### Further instructions on working with batteries:

- Do not remove battery terminal covers unnecessarily.
- Do not place tools on the battery. This can lead to short-circuiting, overheating and bursting of the battery!
- Take particular care when the battery has been in service for a long time or has just been charged as highly explosive gas is emitted!  
Ensure adequate ventilation!

##### 10.3.9.2 Battery checking and care

Even so-called 'maintenance-free' batteries need a degree of care to obtain their maximum operational life.



The outside of the battery and the terminals should be cleaned regularly with a soft cloth.  
This avoids current leaks and minimises the discharge rate.

Material Terminal grease

Distilled water

Cleaning cloth

Protective gloves

Eye protection

Precondition The machine is shut down.

The machine is standing level.

The machine is fully vented, the pressure gauge reads 0 bar.

Machine is cooled down.

- Open the left-hand door.

1. Clean the casing and terminals. Do not use a wire brush!

2. Lightly grease the terminals to prevent corrosion.

3. Check that the batteries and cable connections are properly seated and tighten if necessary.

#### Check the battery electrolyte level

The acid quantity is generally sufficient for the life of the battery. Nevertheless, the fluid level should be checked annually. The level should be up to the mark, 1 cm above the plates.



Replace the battery immediately if the casing leaks.

1. **NOTICE!**

Battery destruction!

Topping up with pure acid will increase the electrolyte concentration and can destroy the battery.

- Top up only with distilled water.

## 2. Check the electrolyte level.



If the level does not reach the mark:

- top up with distilled water.

- Close the door.

**Winter operation:**

The battery is especially stressed during the winter. Only a fraction of the normal starting energy is available at low temperatures.

1. **NOTICE!**

Danger of batteries freezing!

A discharged battery is endangered by freezing temperatures and could freeze at a temperature of -10 °C.

- Check battery charge with a acid density tester.
- Recharge the battery.
- Clean the cable connections and apply terminal grease.

## 2. Check the battery charge weekly.

Recharge as necessary.

## 3. If the machine is to be unused for a number of weeks, remove the battery and store in a frost-proof room.



In extreme cases, the use of a heavy-duty cold-start battery and/or an additional booster battery is recommended.

**10.3.9.3 Battery removal and installation**

Precondition	<p>The machine is shut down. The machine is standing level. The machine is fully vented, the pressure gauge reads 0 bar. Machine is cooled down.</p>
--------------	--

1. **WARNING!**

There is danger of batteries bursting!

A short circuited batty heats up quickly and can burst.

- Never short-circuit a battery (e.g. with a hand tool).
- Wear gloves and eye protection.

2. **NOTICE!**

Excessive voltage produced by the alternator.

Voltage peaks can destroy the alternator regulator and diodes.

- The battery serves as a buffer and must not be disconnected while the engine is running.
- Carry out work on batteries only with the machine shut down.

## 3. Open the left-hand door.

4. Disconnect the negative cable first, then the positive cable.
5. Unscrew the battery fixing clamp.
6. Replace in the reverse order.
7. Make sure the battery is properly secured.
8. Close the door.

**Battery replacement:**

If the battery is to be replaced, the new battery should have the same capacity, current rating and shape as the original battery.

- Always replace a battery with one of the same type.



The old battery is hazardous waste and must be disposed of in accordance with local environment protection regulations.

## 10.4 Compressor Maintenance


- Perform maintenance tasks according to the schedule in chapter 10.2.3.1.

### 10.4.1 Checking cooling oil level

The oil level is checked at the oil separator tank filling port. Oil must be visible in the port when the filler plug is removed.

Material      Wrench  
                  Cleaning cloth

Precondition    The machine is shut down.  
                  The machine is standing level.  
                  The machine is fully vented, the pressure gauge reads 0 bar.  
                  All compressed air consumers are disconnected and the air outlet valves are open.



10-M0152

Fig. 55 Checking cooling oil level

- |   |                    |
|---|--------------------|
| ① | Oil separator tank |
| ② | Oil filler port    |
| ③ | Filler plug        |

- |     |               |
|-----|---------------|
| (A) | Minimum level |
| (B) | Maximum level |

1. Open the right-hand access door.
2. Slowly unscrew and withdraw the plug from the oil filler port.
3. Check the cooling oil level.  
Top up if no oil is visible.
4. Replace the plug in the filler port.
5. Close the access door.

#### 10.4.2 Cooling oil filling and topping up

Material	Cooling oil Funnel Cleaning cloth Wrench
Precondition	The machine is shut down. The machine is standing level. The machine is fully vented, the pressure gauge reads 0 bar. Machine is cooled down. All compressed air consumers are disconnected and the air outlet valves are open. The negative cable to the battery is disconnected.

##### Filling with cooling oil

A sticker on the oil separator tank specifies the type of oil used.



1. **NOTICE!**  
The machine could be damaged by unsuitable oil.
  - Never mix different types of oil.
  - Never top up with a different type of oil than that already used in the machine.
2. Open the right-hand access door.
3. Slowly unscrew and withdraw the plug from the oil filler port.
4. Top up the cooling oil to the maximum level **B** with the help of a funnel.
5. Check the oil level.
6. Check the filler plug gasket for damage.  
Change a damaged gasket.
7. Replace the plug in the filler port.
8. Reconnect the negative battery terminal.
9. Close the door.

##### Starting the machine and performing a test run:

1. Start the machine and run in IDLE until the operating temperature is reached.
2. Close the outlet valves.
3. Shut down the machine.
4. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
5. Open the outlet valves.

6. Open the right-hand access door.
7. Check the oil level after about 5 minutes.  
Top up if necessary.
8. Visually inspect for leaks.
9. Close the door.

#### 10.4.3 Changing the cooling oil



Drain the oil completely from the following components:

- Oil separator tank
- Oil cooler
- Oil pipes
- Heat exchanger (Option db)

➤ Always change the oil filter when changing the oil.

Material Cooling oil

Receptacle

New gasket for the drain plug

Funnel

Cleaning cloth

Precondition The machine is shut down.

The machine is standing level.

The machine is fully vented, the pressure gauge reads 0 bar.

The machine is at operating temperature.

All compressed air consumers are disconnected and the air outlet valves are open.

Negative cable to the batteries disconnected.



##### CAUTION

There is risk of burns from hot components and escaping oil.

➤ Wear long-sleeved clothing and gloves.

➤ Open the right-hand access door.

##### 10.4.3.1 Draining the cooling oil

The cooling oil is drained directly at the oil separator tank and the oil cooler.




Fig. 56 Draining the compressor cooling oil

- |     |                               |     |                       |
|-----|-------------------------------|-----|-----------------------|
| [1] | Oil separator tank            | [4] | Oil cooler            |
| [2] | Oil separator tank drain plug | [5] | Oil cooler drain plug |
| [3] | Oil filler plug               |     |                       |

- Remove the plug [3] from the oil separator tank filling port.

#### Draining the cooling oil from the separator tank:

The oil separator tank can be drained by a separate oil drain plug located on the underside of the tank (accessible from underneath through the access hole in the floor pan).

1. Place the oil receptacle below the corresponding drain hole in the floor pan.
2. Unscrew the drain plug [2] and allow the cooling oil to drain into the receptacle.
3. Fit a new gasket on the drain plug and screw it back in again.

#### Draining the oil from the oil cooler:


The oil cooler can be drained by a separate oil drain plug located on the underside of the oil collection box (accessible from underneath through the access hole in the floor pan).

1. Place the oil receptacle below the corresponding drain hole in the floor pan.
2. Unscrew the drain plug [5] and allow the cooling oil to drain into the receptacle.
3. Fit a new gasket on the drain plug and screw it back in again.

#### Option db Draining the oil from the heat exchanger:

The heat exchanger can be drained by a separate oil drain plug located on the underside of the heat exchanger (accessible from underneath through the access hole in the floor pan).

Option db



10-M0338

**Fig. 57 Draining the oil from the heat exchanger**

- |   |   |
|---|---|
| ① Oil separator tank<br>⑦ Heat exchanger<br>⑧ Floor pan | ⑨ Heat exchanger drain plug<br>⑩ Underside of floor pan |
|---|---|

1. Place the oil receptacle below the corresponding drain hole in the floor pan.
2. Unscrew the drain plug ⑨ at the heat exchanger and allow the cooling oil to drain into the receptacle.
3. Fit a new gasket on the drain plug and screw it back in again.

**Finish off the work steps:**

1. Replace the plug in the oil separator tank filling port.
2. Close the door.



Dispose of used oil and oil-contaminated working materials according to environmental protection regulations.

Further information See chapter 10.4.2 for oil filling.

**10.4.4 Replace the compressor oil filter**

Material  
 Spares  
 Receptacle  
 Cleaning cloth

Precondition  
 The machine is shut down.  
 The machine is fully vented, the pressure gauge reads 0 bar.  
 Machine is cooled down.  
 All compressed air consumers are disconnected and the air outlet valves are open.  
 The negative cable to the battery is disconnected.


**CAUTION**

There is risk of burns from hot components and escaping oil.

- Wear long-sleeved clothing and gloves.




Fig. 58 Changing the oil filter

- |     |  |     |   |
|-----|--|-----|---|
| [1] | Oil filter                                       | [3] | Combination valve                               |
| [2] | Direction of rotation to unscrew the oil filter. | [4] | Ambient temperature sensor (not with Option db) |

**Changing the oil filter:**

1. Open the right-hand access door.
2. Prepare a receptacle.
3. Loosen the filter by turning counter-clockwise and catch any escaping oil.
4. Carefully clean sealing surfaces using lint-free cloth.
5. Lightly oil the new filter's gasket.
6. Turn the oil filter clockwise by hand to tighten.
7. Check the oil level in the oil separator tank.  
Top up if necessary.
8. Reconnect the negative battery terminal.
9. Close the door.

 Dispose of old cooling oil and any materials or parts contaminated with oil according to environment protection regulations.

**Starting the machine and performing a test run:**

1. Start the machine and run in IDLE until the operating temperature is reached.
2. Close the outlet valves.
3. Shut down the machine.
4. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
5. Open the outlet valves.
6. Open the right-hand access door.
7. Check the oil level after about 5 minutes.  
Oil level too low: top up if necessary.
8. Visually inspect for leaks.
9. Close the door.

### 10.4.5 Oil separator tank dirt trap maintenance

Material

- Cleaning cloth
- Wrench
- Small screwdriver
- Maintenance kit, control valve
- Petroleum ether or spirit

Precondition

- The machine is shut down.
- The machine is fully vented, the pressure gauge reads 0 bar.
- Machine is cooled down.
- All compressed air consumers are disconnected and the air outlet valves are open.
- The negative cable to the battery is disconnected.




Fig. 59 Oil separator tank dirt trap maintenance

- |   |                          |   |                    |
|---|--------------------------|---|--------------------|
| ① | Oil separator tank cover | ⑤ | Nozzle             |
| ② | Control valve            | ⑥ | Screw-in connector |
| ③ | Union nut                | ⑦ | Gasket             |
| ④ | Oil return line          | ⑧ | Strainer           |

► Open the right-hand access door.

#### Dirt trap maintenance:

1. Undo the union nut and bend the oil return line to one side.
2. Unscrew the screw-in connector.
3. Unscrew the strainer from the screw-in connector.
4. Use a screwdriver to unscrew the nozzle from the screw-in connector.
5. Clean the housing, strainer and sealing ring with cleaning solvent or spirit.
6. Check the nozzle, strainer and sealing ring for wear.  
Replace components if they are heavily worn.
7. Fit the nozzle and strainer to the screw-in connector.
8. Screw in the connector making sure the sealing ring seats properly.
9. Refit the oil scavenge line.

#### Making operational:

1. Reconnect the negative battery terminal.
2. Close the door.



Dispose of old parts and contaminated materials according to environmental regulations.

**Starting the machine and performing a test run:**

1. Switch the machine on and run it in IDLE mode for approx. 5 minutes.
2. Shut down the machine.
3. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
4. Open the outlet valves.
5. Open the right-hand access door.
6. Visually inspect for leaks.
7. Shut down the machine.
8. Close the door.

#### 10.4.6 Changing the Oil Separator Cartridge



The oil separator element cannot be cleaned.

The life of the oil separator cartridge is influenced by:

- contamination in the air drawn into the compressor,
- and adherence to the changing intervals for:
  - Cooling oil
  - Oil filter
  - Air filters

Material Spares

Cleaning cloth

Wrench

Precondition The machine is shut down.


The machine is fully vented, the pressure gauge reads 0 bar.

Machine is cooled down.

All compressed air consumers are disconnected and the air outlet valves are open.

The negative cable to the battery is disconnected.

- Open the right-hand access door.

**10.4.6.1 Changing the Oil Separator Cartridge**

**Fig. 60** Changing the Oil Separator Cartridge

- |  |                              |
|--|------------------------------|
| [1] Control air line union nut                             | [8] Fixing screw             |
| [2] Oil scavenge pipe (screwed to the cover)               | [9] Control valve            |
| [3] Oil scavenge pipe union nut (screwed to the dirt trap) | [10] Solenoid valve plug     |
| [5] Air pipe   | [11] seal                    |
| [6] Pipe fitting   | [12] Metal clip              |
| [7] Cover  | [13] Oil separator cartridge |

**Changing the oil separator cartridge**

1. Unscrew the union nuts [1] and [3] and place the components with connections carefully to one side.
2. Pull out the plug to the solenoid valve [10] and withdraw the cable.
3. Unscrew the fitting [6] and turn the air pipe [5] to one side.
4. Remove the screws [8] securing the cover [7] to the tank.
5. Carefully lift the cover and put to one side.



Take care that the oil scavenge pipe [2] screwed to the underside of the cover is not bent in the process.

6. Take out the old cartridge [13] and gaskets [11].
7. Clean all sealing surfaces, taking care that no foreign bodies (dirt particles) fall into the oil separator tank.



Do not remove the metal clips!

The metal parts of the oil separator cartridge are electrically interconnected. The gaskets [11] are fitted with metal clips [12] that fulfil this requirement and provide an electrical path to the oil separator tank and to the frame of the machine.

8. Insert the new oil separator cartridge with gaskets and screw down the cover.
9. Re-position the air pipe [5].
10. Replace and tighten all loosened fittings.

11. Reconnect cables.
12. Check the oil level in the oil separator tank.

Top up if necessary.



Maintenance of the control valve dirt trap must be carried out whenever the oil separator cartridge is changed.

Further information

Information on control valve dirt trap maintenance is given in chapter 10.4.5.

**Making operational:**


1. Reconnect the negative battery terminal.
2. Close the door.



Dispose of old parts and contaminated materials according to environmental regulations.

**Starting the machine and performing a test run:**

1. Start the machine and run in IDLE until the operating temperature is reached.
2. Close the outlet valves.
3. Shut down the machine.
4. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
5. Open the outlet valves.
6. Open the right-hand access door.
7. Check the oil level after about 5 minutes.  
Top up if necessary.
8. Visually inspect for leaks.
9. Close the door.

**10.4.6.2 Option ba**
**Changing the oil separator (machine with low-temperature equipment)**
**Option ba**

**Fig. 61** Changing the oil separator cartridge (Option ba)

- |   |  |
|---|--|
| ① Control air line union nut<br>② Oil scavenge pipe (screwed to the cover)<br>③ Oil scavenge pipe union nut (screwed to the dirt trap)<br>⑤ Air pipe<br>⑥ Pipe fitting<br>⑦ Cover<br>⑧ Fixing screw | ⑨ Control valve<br>⑩ Solenoid valve plug<br>⑪ Seal<br>⑫ Metal clip<br>⑬ Oil separator cartridge<br>⑭ Frost protector |
|---|--|

1. Unscrew the union nuts ① and ③ and place the components with connections carefully to one side.
2. Pull out the plug to the solenoid valve ⑩ and withdraw the cable.
3. Unscrew the fitting ⑥ and turn the air pipe ⑤ to one side.
4. Loosen the frost protector clamp ring ⑭ and empty the bowl. See chapter 10.8.5 on frost protector maintenance.
5. Remove the screws ⑧ securing the cover ⑦ to the tank.
6. Carefully lift the cover and put to one side.



Take particular care with the following components:

- The frost protector ⑭ connected to the control line,
- The oil scavenge line ② screwed to the underside of the cover.

7. Take out the old cartridge ⑬ and gaskets ⑪.

8. Clean all sealing surfaces, taking care that no foreign bodies (dirt particles) fall into the oil separator tank.



Do not remove the metal clips!

The metal parts of the oil separator cartridge are electrically interconnected. The gaskets (11) are fitted with metal clips (12) that fulfil this requirement and provide an electrical path to the oil separator tank and to the frame of the machine.

9. Insert the new cartridge and gaskets.
10. Carefully replace the cover on the tank and the frost protector with holder on the cover.
11. Screw down the cover.
12. Re-position the air pipe (5).
13. Replace and tighten all loosened fittings.
14. Check the oil level in the oil separator tank.  
Top up if necessary.



Maintenance of the control valve dirt trap must be carried out whenever the oil separator cartridge is changed.

Further information

Information on control valve dirt trap maintenance is given in chapter 10.4.5.

#### Making operational:

1. Reconnect the negative battery terminal.
2. Close the door.



Dispose of old parts and contaminated materials according to environmental regulations.

#### Starting the machine and performing a test run:

1. Start the machine and run in IDLE until the operating temperature is reached.
2. Close the outlet valves.
3. Shut down the machine.
4. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
5. Open the outlet valves.
6. Open the right-hand access door.
7. Check the oil level after about 5 minutes.  
Top up if necessary.
8. Visually inspect for leaks.
9. Close the door.

#### 10.4.7 Compressor air filter maintenance

Clean the filter according to the maintenance schedule or if the maintenance indicator shows this to be necessary.

Renew the air filter element after 2 years at the latest or after it has been cleaned 5 times.



- Using the machine without an air filter element is not permitted!
- Do not use an air filter element with damaged folds or gasket.
- The use of an unsuitable air filter can permit dirt to ingress the pressure system and cause premature wear and damage to the machine.


Material      Compressed air for blowing out  
Spare parts (as required)  
Wrench  
Cleaning cloth

Precondition      The machine is shut down.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Machine is cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.

**NOTICE**

Damaged air filter element.  
Machine damage due to contaminated intake air.


- Do not try to clean the filter element by striking or knocking it.
- Do not wash the filter element.



10-M0156

Fig. 62 Compressor air filter maintenance

- |                            |  |
|----------------------------|--|
| ① Filter cap               | ⑤ Indicating piston of the maintenance indicator |
| ② Air filters              | ⑥ Reset knob for the maintenance indicator       |
| ③ Maintenance indicator    | ⑦ Loosen the screws                              |
| ④ Red zone indicator scale |  |



10-M1013

Fig. 63 Cleaning the filter element

- ① Compressed air gun with blast pipe bent to 90° at the end
- ② Filter element

➤ Open the left-hand door.

#### Checking contamination of the air filter:

Air filter maintenance is necessary when the yellow piston inside the maintenance indicator reaches the red zone.

- Check the air filter maintenance indicator.  
If the yellow piston reaches the red zone, clean or renew the filter element.

#### Cleaning the air filter:

1. Unscrew the hex-head screw in the filter cap.
2. Lift up the cap and remove the air filter element with a slight twisting action.
3. Clean the inside of the cap, the element holder and the sealing surfaces with a damp cloth.
4. Cleaning the filter element:
  - Use dry compressed air ( $\leq 5$  bar!) at an angle to blow dust from the element from inside to outside until no further dust develops.
  - The blast pipe must be long enough to reach the bottom of the element.
  - The tip of the blast pipe must not touch the element.
  - Cleaning sealing faces.
5. Inspect the element carefully for any damage.  
Replace any damaged filter element.
6. Insert the new or cleaned air filter element in the holder. Make sure it is properly in place and sealed by its gaskets.
7. Replace the cap and secure with the hex-head screw.

#### Resetting the maintenance indicator:

- Repeatedly press the reset knob on the maintenance indicator.  
The yellow piston within the indicator is reset and the maintenance indicator is ready for use again.
- Close the door.

 Dispose of old parts and contaminated materials according to environmental regulations.

#### 10.4.8 Checking pressure relief valves

- Have pressure relief valves checked by KAESER Service in accordance with the maintenance schedule.

### 10.5 Clean cooler/radiator

The frequency of cleaning is mainly dependent on local operating conditions.

Heavy clogging of the cooler/radiator can cause oil overheating and overheating of the engine.

Check the cooler/radiator regularly for clogging.

Avoid creating dust eddies. Wear breathing protection if necessary.

Do not clean the cooler/radiator with a sharp instrument, otherwise it could be damaged.

A severely contaminated cooler/radiator should be cleaned by KAESER Service.

Material	Compressed air Face mask (as required) Water or steam jet blaster
Precondition	Machine is placed over a washing station equipped with an oil separator. The machine is shut down. Machine is cooled down. The machine is fully vented, the pressure gauge reads 0 bar. All compressed air consumers are disconnected and the air outlet valves are open. The negative cable to the battery is disconnected.



#### NOTICE

Damage to the machine can be caused by water or steam jets.

Direct water or steam jets can damage or destroy electrical components and indicating instruments.

- Cover up electrical components such as the control cabinet, alternator, starter and instruments.
- Do **not** direct water or steam jets at sensitive components such as alternator, starter or indicating instruments.
- Deploy the extension pole of the pressure washer at a distance of at least 50 cm and approximately 90° angle to the cooler/radiator surface.
- Open both doors.

#### 10.5.1 Cleaning the cooler/ radiator

The compressor oil cooler and engine coolant radiator are combined in a single cooler block.




Fig. 64 Cleaning the cooler/ radiator

- |   |  |   |                       |
|---|--|---|-----------------------|
| ① | Front end of machine, sound insulation (radiator grill) removed    | ③ | Radiator (engine)     |
| ② | Direction of impacting water or steam jet (from outside to inside) | ④ | Compressor oil cooler |

#### Cooler cleaning

1. Seal off the air intakes of the engine and compressor air filters before starting cleaning.
2. Remove the sound damping louver in front of the cooler/radiator.
3. Clean the cooling fins with compressed air, water or steam jet in the opposite direction to the cooling air flow (from inside to outside).
4. Replace the sound damping louvre.
5. Remove the protective coverings from the air filters.
6. Reconnect the battery.
7. Close the doors.
8. Start the machine and run up to operating temperature so that excess water is evaporated.

#### Check the cooler for leaks


1. Open both doors.
2. Visually inspect for leaks. Does oil/cooling water flow out?
  - Is a cooler leaking?
    - Have the defective cooler repaired immediately by KAESER Service.
    - Close the doors.
  - Clean the cooler/radiator only in a washing area equipped with an oil separator.

#### 10.5.2 Option da, db, dc, dd

#### Cleaning the compressed air aftercooler

The compressed air aftercooler is located near the air treatment devices.

Option da, db, dc, dd



10-M0779

Fig. 65 Cleaning the compressed air aftercooler

- ① Compressed air aftercooler
- ② Direction of impacting water or steam jet (from inside to outside).

1. Seal off the air intakes of the engine and compressor air filters before starting cleaning.
2. Clean the aftercooler with compressed air, water or steam jet in the opposite direction to the cooling air flow (from inside to outside).
3. Remove the protective coverings from the air filters.
4. Reconnect the battery.
5. Close the doors.
6. Start the machine and run up to operating temperature so that excess water is evaporated.



Clean the cooler/radiator only in a washing area equipped with an oil separator.

## 10.6 Maintenance of rubber sealing strips

The rubber sealing strips between the body panels and the access doors serve both as a sound-proofing measure and to prevent ingress of rain water.

Care of the rubber sealing strips is especially necessary in winter to prevent the strips from sticking and tearing when the access panels are opened.

Material Cleaning cloth

Silicone or Vaseline

Precondition The machine is shut down.

The machine is fully vented, the pressure gauge reads 0 bar.

Machine is cooled down.

All compressed air consumers are disconnected and the air outlet valves are open.

1. Open all the doors.
2. Clean the rubber sealing strips with a lint-free cloth and check for cracks, holes and other damage.  
Have any damaged gasket replaced.
3. Properly grease the rubber strips.
4. Close the doors.

## 10.7 Chassis maintenance

- Perform maintenance tasks according to the schedule in chapter 10.2.3.1.

### 10.7.1 Wheel checks

Check the wheels for tightness, visible damage and tyre pressures:

- after the first 50 km
- after every wheel change
- at least every six months

Material Torque wrench

Tyre pressure gauge

Precondition Machine shut down and secured against restarting.

1. Check/adjust for wheel fixing torques.
2. Check the tyres and wheels for any defect.  
Replace any damaged or worn tyres.
3. Check the tyre treads for sufficient depth.



According to local roadworthy regulations, at least 1.6 mm in most countries.

- Profile depth too low: change tyres.
4. Check the tyre pressures.

Result Tyre pressure too low: pump tyres.

Further information See chapter 2.4.3 for wheel fixing torques.

See chapter 2.4.2 for tyre pressures.

A sticker is found on each wheel arch giving the recommended tyre pressure.

### 10.7.2 Towbar maintenance

Clean and lubricate all sliding and rotating bearings as necessary but at least every 6 months.


Material Lithium-enriched multi-purpose grease

Acid-free oil

Cleaning cloth

Precondition The machine is shut down.


The machine is disconnected from the towing vehicle and safely parked.

**Option sa**


10-M0159

**Fig. 66** Maintaining the height-adjustable towbar

- ① Overrun brake mechanism lubricating point
- ② Lubricating points toothed coupling

**Option sd**


10-M1021

**Fig. 67** Maintaining the fixed-height towbar

- ① Overrun brake mechanism lubricating point

#### 10.7.2.1 Check the towbar

1. Check the towbar for correct function and movement.
2. Clean and oil all sliding and rotating bearings.

**Option sa Check the height setting of the towbar**

- Check the towbar height adjustment function.



The locking teeth on the towbar height adjustment joint are corroded and jammed and the towbar height cannot be adjusted.

- If necessary, free the teeth by jerking the towbar horizontally and vertically.
- Clean the toothed coupling and smear with water-repellent grease.

Further information See chapter 6.4.1 for towbar height adjustment.

**Option sa, sd Maintaining the parking brake**

- Lightly lubricate the pins and adjustment joints.

## 10.7.2.2 Option sa, sd

## Overrun braking mechanism maintenance

## Overrun braking mechanism greasing

- Pump fresh grease into the nipple until old grease is squeezed out.

Further information Lubricating points of the height-adjustable tow mechanism (Option sa) see illustration 66.  
Lubricating points of a tow mechanism non-adjustable in height (Option sd) see illustration 67.

## Checking the shock absorber

- Strongly press in the towbar against its damping force.



The towbar must return automatically when pressure is released.

Have the shock absorber replaced by a specialist workshop if:

- Return of the tow bar takes more than 30 seconds
- There is little resistance to pushing in,
- Air has entered the device,
- There is little resistance to pulling out the shock absorber.

## 10.7.2.3 Ball coupling maintenance

Option sa, sd




10-M0551

Fig. 68 Ball coupling (EC version)

- ① Lubricating points
- ② Lubricating points

Option sh



10-M0558

Fig. 69 Ball coupling (USA version)

- ① Lubricating points
- ② Lubricating points

1. Check the ball coupling for correct function and movement.
2. Clean the ball coupling. Grease or oil the ball cup, joints and bearings.

### 10.7.3 Brake system maintenance

The brake adjusting procedure ensures even wear on the brake linings by adjusting the brake shoes.

The following points must be observed:

- Carry out the adjustment procedure on all wheel brakes, one after the other.
- During adjustment, turn the wheel in the 'forward' direction only.

Material	Screwdriver Wrench Torch Lithium-enriched multi-purpose grease
----------	---

Precondition The machine is switched off.

1. Jack up the machine and lower it onto supports.
2. Release the parking brake and completely pull out the overrun braking mechanism.  
The brake cables are not tensioned.

## 10.7.3.1 Checking wheel brake lining wear




Fig. 70 Checking the brake lining thickness

- ① Inspection hole
- ② Brake linings

1. Remove the plug from the inspection hole.
2. With the aid of a torch, check the brake lining thickness.  
Brake linings of less than 2 mm thickness should be replaced by a specialist workshop.
3. Replace the plug in the inspection hole.

## 10.7.3.2 Checking the brake system settings

1. Check the free running of the wheels with released brake.  
Adjust the brake if the wheels do not turn freely.
2. Slightly tighten the parking brake.
3. Turn the wheels in the forward direction.
4. Check that there is the same braking resistance on both wheels.  
Adjust the braking system if the resistance is not the same.
5. Release the parking brake.


## 10.7.3.3 Brake system adjustment

Carry out the adjustment procedure on all wheel brakes, one after the other.




Never adjust the brakes at the brake rods!

Precondition Wheel and brake drum taken down


**Fig. 71** Adjusting the wheel brake

- |  |  |
|--|--|
| <span style="border: 1px solid black; padding: 2px;">1</span> Adjusting screw<br><span style="border: 1px solid black; padding: 2px;">2</span> Cable entry<br><span style="border: 1px solid black; padding: 2px;">3</span> Brake shoe | <span style="border: 1px solid black; padding: 2px;">4</span> Expander lock<br><span style="border: 1px solid black; padding: 2px;">5</span> Brake shoe, complete (brake shoe holder with brake pad) |
|--|--|


**Fig. 72** Brake rod adjustment

- |  |  |
|--|--|
| <b>A</b><br><span style="border: 1px solid black; padding: 2px;">7</span> Ball coupling<br><span style="border: 1px solid black; padding: 2px;">8</span> Brake cable<br><span style="border: 1px solid black; padding: 2px;">9</span> Towbar tube with expansion bellows<br><span style="border: 1px solid black; padding: 2px;">10</span> Relay lever<br><span style="border: 1px solid black; padding: 2px;">11</span> Hand brake lever, parking brake | <b>B</b><br><span style="border: 1px solid black; padding: 2px;">12</span> Transmission mechanism/brake equalisation:<br><span style="border: 1px solid black; padding: 2px;">13</span> Brake rod<br><span style="border: 1px solid black; padding: 2px;">14</span> Equaliser<br><span style="border: 1px solid black; padding: 2px;">15</span> Pull wire<br><span style="border: 1px solid black; padding: 2px;">16</span> Axle |
|--|--|

1. Check the smooth running of the expander lock 4 and actuating cable 14. When stiff, loosen brake rods 12 at the equaliser 13 (brake equalisation).
2. Turn the adjusting screw outside on 1 the brake anchor plate clockwise, until the wheel can be turned only with difficulty or not at all.
3. Loosen the adjustment screw counterclockwise (approximately 1/2 turn) until the wheel is running freely.



A light rubbing sound when the wheels turn is permissible if it does not affect free turning.  
When the brake is adjusted accurately, the pedal travel is 4 - 6 mm approximately.

**Controlling the brake equalisation:**

1. Preset the brake rod 12 in its length (some play at the relay lever 10 permitted).
2. Apply the parking brake 11 a number of times to centralize the brake linings.

3. Check the position of the equaliser **[13]** on the brake rod **[12]**.

The equaliser is in perpendicular position to the brake rods: identical play of the wheel brakes.

If the equaliser is oblique to the brake rods, correct the position of the equaliser.

#### Checking the parking brake:

- Pull parking brake lever strongly upwards and beyond the noticeable "dead point zone".  
The brake is adjusted correctly, if resistance is felt approximately 10 - 15 mm beyond the "dead point".



Adjust the brake if major deviations are noticed.

#### Brake rod adjustment:

1. To loosen the braking rod **[12]** undo the nut on the equaliser **[13]**.
2. Grease the brake rod threads.
3. Adjust the rod so there is no play or tension.  
Equaliser is perpendicular to the brake rods.
4. Tighten the nut.
5. Tighten all counter nuts.

#### Performing a test drive:

1. Reinstall brake drums and wheels.
2. Remove the jacks from the machine and couple it with the towing vehicle.
3. Test by applying the brake a number of times.  
If necessary, readjust brakes.

##### 10.7.3.4 Greasing the brake rods

Grease the brake rods when necessary (stiff movement) but at least annually.

Precondition The machine is shut down.

The machine is disconnected from the towing vehicle and safely parked.

- Clean and grease the brake rods sliding and adjustment joints.

## 10.8 Maintenance of Optional Items

- Perform maintenance tasks according to the schedule in chapter 10.2.3.2.

### 10.8.1 Option ec

#### Tool lubricator maintenance

Material      Tool oil (special lubricant for road breakers),  
                  Funnel  
                  Cleaning cloth

Precondition    The machine is shut down.  
                  The machine is standing level.  
                  The machine is fully vented, the pressure gauge reads 0 bar.  
                  Machine is cooled down.  
                  All compressed air consumers are disconnected and the air outlet valves are open.




Fig. 73 Tool lubricator maintenance

- ① Compressed air inlet
- ② Oil tank
- ③ Oil volume
- ④ Oil surface
- ⑤ Tool oil outlet

- ⑥ Tool lubricator upper part with oil filling port
- ⑦ Filler plug with dipstick and integrated riser tube
- ⑧ Metering knob
- ⑨ O-ring

► Open the right-hand access door.

#### Checking the tool lubricator oil level

Check the oil level daily.

A dip stick is attached to the underside of the oil filler plug with which to measure the oil level.

The oil level should be in the upper third of the dipstick.

1. Slowly unscrew and withdraw the oil filler plug.
2. Wipe off the dipstick with a lint-free cloth or rag and screw the plug fully in again.

3. Unscrew and withdraw the plug once more and read off the oil level on the dipstick.  
Oil level at the upper third of the dip stick: OK.  
Top up if the oil does not reach this level.
4. Close the door.

**Filling and topping up with tool lubricator oil**


1. Slowly unscrew and withdraw the oil filler plug.
2. Use a funnel to pour in the oil to the maximum level (10 – 15 mm below the top of the tank).
3. Check the oil level.
4. Check the filler plug O-ring for external damage.  
Change a damaged O-ring.
5. Insert the plug in the filler port.
6. Close the door.

Further information See chapter 2.7.1 for suitable oil grade and volume.

**10.8.2 Option da, db, dc, dd  
Cyclone separator maintenance**

Clean the cyclone separator dirt trap if the moisture content in the compressed air is too high.

Material	Cleaning cloth Wrench Small screwdriver Dirt trap maintenance kit Petroleum ether or spirit
Precondition	The machine is shut down. Machine is cooled down. The machine is fully vented, the pressure gauge reads 0 bar. All compressed air consumers are disconnected and the air outlet valves are open. The negative cable to the battery is disconnected.



10-M0391

**Fig. 74 Cleaning the dirt trap**

- |   |                       |   |                                 |
|---|-----------------------|---|---------------------------------|
| ① | Cyclone separator     | ⑥ | Strainer                        |
| ② | Dirt trap             | ⑦ | Condensate drain hose union nut |
| ③ | Condensate drain hose | ⑧ | Nozzle                          |
| ④ | Screw plug            | ⑨ | Dirt trap housing               |
| ⑤ | O-ring                |   |                                 |

- Open the left-hand door.

**Cleaning the dirt trap:**

1. Unscrew the plug ④ and remove the strainer.
2. Loosen the union nut ⑦ and detach the condensate drain hose ③ from the dirt trap.
3. Use the small screwdriver to unscrew the nozzle ⑧ from the dirt trap housing.
4. Clean the nozzle, strainer, screw plug, O-ring ⑤ and dirt trap housing ⑨ with cleaning solvent or spirit.
5. Check the nozzle, strainer and O-ring for wear.  
Replace components if they are heavily worn.
6. Place the strainer on the screw plug.
7. Screw in the plug making sure the O-ring seats properly.
8. Screw in the nozzle and re-attach the condensate drain hose.

**Making operational:**

1. Reconnect the negative battery terminal.
2. Close the door.

**Starting the machine and performing a test run:**

1. Switch the machine on and run it in IDLE mode for approx. 5 minutes.
2. Shut down the machine.
3. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
4. Open the outlet valves.
5. Open the left-hand door.

6. Check the cyclone separator housing and hose line for leaks.
7. Close the door.

### 10.8.3 Option dd Combination filter maintenance

**Precondition**

- The machine is shut down.
- The machine is standing level.
- The machine is fully vented, the pressure gauge reads 0 bar.
- All compressed air consumers are disconnected and the air outlet valves are open.


**WARNING**

Danger of injury from compressed air!

The combination filter is under pressure when operating; serious injury can result from loosening or opening components under pressure.

- Wait until the machine is completely vented (check that the pressure gauge indicates 0 bar).
- De-pressurise the combination filter.

Option dd




Fig. 75 Combination filter maintenance

- |   |  |
|---|--|
| [1] Filter combination                          | [5] Pressure differential gauge (check fittings for Service personnel) |
| [a] Pre-filter                                  | [6] Filter head  |
| [b] Micro-filter                                | [7] Casing gasket  |
| [2] Cyclone separator                           | [8] Filter element   |
| [3] Condensate drain hose fittings              | [9] Filter housing   |
| [4] Shut-off ball valve for condensate drainage |  |

- Open the left-hand door.

**10.8.3.1 Draining condensate**

Material      Receptacle  
                  Cleaning cloth

1. Place the receptacle under the combination filter hose lines.
2. Open the pre-filter and micro-filter condensate drain shut off valves.
3. Close the door.
4. Start up the machine and run in IDLE.  
The condensate collecting in the filter housings is blown out.
5. Stop the compressor as soon as air escapes.
6. Open the left-hand door.
7. Close the shut-off valve.
8. Close the door.



Condensate must be stored in suitable containers and disposed of in accordance with local environmental regulations.

**10.8.3.2 Changing the filter elements**

The pre-filter and microfilter contain different elements and these must be changed as a pair. Note location!



- Using the combination filter without an element installed is not permitted.  
Handle new filter elements only with clean fabric gloves. Do not touch the new filter elements with bare fingers – Contamination risk!

Material      Spare parts  
                  Filter wrench  
                  Wrench  
                  Cleaning cloth  
                  Clean fabric gloves

Precondition    Machine is cooled down.  
The negative cable to the battery is disconnected.

**Ensure that the combination filter is not under pressure.**

- Slowly open the pre-filter and micro-filter condensate drain shut off valves.  
Remaining pressure escapes.

**Changing the pre-filter element:**

1. Unscrew and remove the drain hose from the filter housing.
2. Unscrew the filter housing counter-clockwise.
3. Draw the filter element down and out.
4. Clean the filter head, housing and sealing surface with a lint-free cloth.
5. Check the housing gasket.  
When damaged, replace the housing gasket.

6. Insert the new filter element.



Wear gloves!

7. Screw on the filter housing clockwise.
8. Screw on the condensate drain hose.

**Changing the micro-filter element:**

1. Unscrew and remove the drain hose from the filter housing.
2. Unscrew the filter housing counter-clockwise.
3. Draw the filter element down and out.
4. Clean the filter head, housing and sealing surface with a lint-free cloth.
5. Check the housing gasket.  
When damaged, replace the housing gasket.
6. Insert the new filter element.



Wear gloves!

7. Screw on the filter housing clockwise.
8. Screw on the condensate drain hose.

**Making operational:**

1. Close the condensate drain shut-off valves.
2. Tighten the filter combination fittings.
3. Reconnect the negative battery terminal.
4. Close the door.



Dispose of old parts and contaminated materials according to environmental regulations.

Further information

Further information on changing elements can be found in the filter instructions in chapter 13.6.

**Starting the machine and performing a test run:**

1. Switch the machine on and run it in IDLE mode for approx. 5 minutes.
2. Shut down the machine.
3. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
4. Open the outlet valves.
5. Open the left-hand door.
6. Check the combination filter housing and hose lines for leaks.
7. Close the door.

### 10.8.4 Option dc

#### Fresh air filter maintenance

Before commencing work on the fresh air filter, read and understand the operating instructions given in chapter 13.7.

- Precondition
- The machine is shut down.
  - The machine is standing level.
  - The machine is fully vented, the pressure gauge reads 0 bar.
  - All compressed air consumers are disconnected and the air outlet valves are open.

Option dc




Fig. 76 Fresh air filter maintenance

- |   |                                    |   |  |
|---|------------------------------------|---|--|
| ① | Fresh air filter                   | ⑤ | Lower filter element (high capacity element) |
| ② | Upper housing                      | ⑥ | Lower housing                                |
| ③ | Upper element (adsorption element) | ⑦ | Condensate drain (tap for manual draining)   |
| ④ | Body                               | 0 | 0 - closed                                   |
|   |                                    | 1 | 1 - open                                     |
|   |                                    | ⑧ | Oil indicator                                |

► Open both doors.

##### 10.8.4.1 Draining condensate

- Material
- Receptacle
  - Cleaning cloth

1. Place the receptacle below the fresh air filter condensate drain point.
2. Open the condensate drain valve.
3. Close the doors.
4. Switch the machine on and run it in IDLE mode for approx. 2 minutes.  
The condensate collecting in the filter housings is blown out.

5. Shut down the machine.
6. Open both doors.
7. Close the drain valve.
8. Carefully remove the receptacle.
9. Close the doors.



Condensate must be stored in suitable containers and disposed of in accordance with local environmental regulations.

#### 10.8.4.2 Check the oil indicator

The fresh air filter is fitted with an oil indicator. When the indicator is blue, the filtration function can no longer be ensured and the filter must not be used. Both filter elements and the oil indicator must be changed (regardless of the maintenance schedule).

The oil indicator must be checked at least once daily.



The oil indicator does not give information on the filter element changing interval.

- Check the oil indicator.

Indicator blue - change both filter elements and the indicator.

#### 10.8.4.3 Changing consumable parts

The fresh air filter contains two different elements which must be changed as a pair. Note location!



Using the fresh air filter without an element installed is not permitted.

Handle new filter elements only with clean fabric gloves. Do not touch the new filter elements with bare fingers – Contamination risk!

Material	Spare parts Filter wrench Wrench Cleaning cloth Clean fabric gloves
----------	---

Precondition	Machine is cooled down. The negative cable to the battery is disconnected.
--------------	---

##### Ensuring the fresh air filter is depressurized:

- Open the fresh air filter drain tap to release any remaining pressure.

##### Change the lower filter element (high performance element)

1. Unscrew the lower housing counter-clockwise.
2. Draw the filter element down and out.
3. Clean the lower housing and sealing surface with a lint-free cloth.
4. Check the housing gasket.

When damaged, replace the housing gasket.

5. Insert a new lower filter element.



Wear gloves!

6. Screw on the lower housing clockwise.

**Changing the upper filter element (adsorption insert):**

1. Unscrew the upper housing counter-clockwise.
2. Draw the filter element up and out.
3. Clean the lower housing and sealing surface with a lint-free cloth.
4. Check the housing gasket.  
When damaged, replace the housing gasket.
5. Insert a new filter element.



Wear gloves!

6. Screw on the upper housing clockwise.

**Change the oil indicator:**

1. Unscrew the oil indicator.
2. Clean the housing and sealing surface with a lint-free cloth.
3. Screw in the new oil indicator.

**Making operational:**

1. Close the drain valve.
2. Reconnect the negative battery terminal.
3. Close the doors.



Dispose of old parts and contaminated materials according to environmental regulations.

**Further information**

Further information on changing elements can be found in the operating instructions for pressurised air filters (fresh air filters) in chapter 13.7.

**Starting the machine and performing a test run:**

1. Switch the machine on and run it in IDLE mode for approx. 5 minutes.
2. Shut down the machine.
3. Wait until the machine has automatically vented.  
Pressure gauge reads 0 bar.
4. Open the outlet valves.
5. Open both doors.
6. Check the fresh air filter housing and hose line for leaks.
7. Close the doors.

### 10.8.5 Option ba

#### Frost protector maintenance

At temperatures below 5°C, the level of antifreeze in the protector must be checked daily before starting the compressor.

Material    Antifreeze (Wabcothyl)  
              Cleaning cloth

Precondition    The machine is shut down.  
                  The machine is fully vented, the pressure gauge reads 0 bar.  
                  Machine is cooled down.  
                  All compressed air consumers are disconnected and the air outlet valves are open.



#### DANGER

Spontaneous ignition of antifreeze!

Danger of fire or explosion caused by the spontaneous ignition can result in serious injury.

- Never top up antifreeze unless the machine is stopped and cooled down.



#### WARNING

Compressed air!

The frost protector is under pressure when operating; serious injury can result from loosening or opening components under pressure.

- De-pressurise the frost protector

Option ba




Fig. 77 Filling the frost protector

- ① Defroster fitting
- ② Defroster lower part

1. Open the right-hand access door.
2. Unscrew the clamp ring and remove the bowl.
3. Fill the bowl ¾ full with antifreeze.
4. Carefully screw the bowl back into place.
5. Close the access door.

### 10.8.6 Option ga Generator drive belt maintenance

Correct belt tension is extremely important for the function of the generator and the operational life of the belts themselves. The lifespan of the drive belts is affected by belt tension.

- Slack V-belts can cause belt slip and damage to the belts.
- Over-tight belts stretch and fatigue quicker. Over-tight belts also place unnecessary stress on bearings and shorten their life.

Material Spare parts (if required)  
Wrench  
V-belt tension measuring device  
Liquid thread lock

Precondition The machine is shut down.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Machine is cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.  
The negative cable to the battery is disconnected.




#### WARNING

Beware of rotating pulleys and moving belts.

Touching the moving drive belt may result in severe bruising or even loss of limb or extremities.

- Check the belt only when the compressor is shut down.
- Never run the machine without a belt guard.
- Open the left-hand door.

**Remove the safety screen and the belt guard:**



10-M1078

Fig. 78 Securing the belt guard at the generator

- |     |                |     |                            |
|-----|----------------|-----|----------------------------|
| [1] | Hex-head screw | [5] | Belt guard                 |
| [2] | Washer         | [6] | Square nut                 |
| [3] | Safety screen  | [7] | Support for belt tensioner |
| [4] | Generator belt | [8] | Hexagonal nut              |

► Loosen the bolts on safety screen and belt guard and remove both protective devices.

#### 10.8.6.1 Visual check for belt damage

1. Turn the pulley by hand and inspect the full length of the belt for splits, frays or any sign of stretching.  
Change the belt immediately if any damage or wear is found.
2. Re-attach the safety screen and the belt guard.
3. Reconnect the negative battery terminal.
4. Close the door.

#### 10.8.6.2 Checking belt tension



Check belts when it is warm, not hot, to avoid length variations through temperature.

##### Checking belt tension on the drive belt:

A belt tension measuring device may be used to verify the belt tension. See the manufacturer's instructions for operation.

The belt tension may also be checked manually if no tension measuring device is available.

Generator	Checking with an instrument	Checking by hand	
Rated power [kVA]	Permissible belt tension [N]	Compressive force [N]	Permissible intrusion depth A [mm]
7.0 – 8.5	420 – 520	80	8
13.0	580 – 680	100	8.5

Tab. 90 Belt tension values




Fig. 79 Belt tension checking by hand

- A Permissible deflection of the belt
- \* Force approximately 8 – 10 kg

➤ Checking belt tension with a measuring device or by hand according to the following instructions:

Checking belt tension with tension measuring device	Belt tension checking by hand
Use a measuring device to check belt tension. 1. Check belt tension with the tension measuring device. 2. Increase the tension on a loose belt.	Press the belts in with the thumb at the midpoint between the pulleys. 1. Check belt tension by hand (see Fig. 79). 2. Increase the tension on a loose belt.

#### Checking belt tension on the tensioner:

Belt tension can be also checked using the belt tensioner, in alternative to the check directly at the drive belt.

See chapter 10.8.6.3; Figure 81.

To determine if the belt needs tensioning, the tensioner ⑥ should be loosened from the tensioning frame ④.

1. Loosen the locking nuts ②4 and ⑧.
2. Check if there is a gap between the sleeve ⑪ and the two adjacent washers and whether the spherical seat washer ⑩ and /or washer ⑯ are present.  
Tension the belts if a gap can be seen.
3. Tighten the nut ⑧ against the tensioning frame ④ and lock with the locknut ②4.

#### Making operational:

1. Re-attach the safety screen and the belt guard.
2. Reconnect the negative battery terminal.
3. Close the door.

**10.8.6.3 Belt tensioning**

(see figure 81 for location).




Fig. 80 Generator belt tensioning

- |              |                                    |
|--------------|------------------------------------|
| ① Generator  | ④ Tensioning frame                 |
| ② Belt guard | ⑤ Tensioning spindle fixed bracket |
| ③ Drive belt | ⑥ Tensioning spindle               |




Fig. 81 Generator belt tensioner

- |                              |                         |
|------------------------------|-------------------------|
| ⑦ Threaded rod               | ⑯ Conical seat washer   |
| ⑧ Hexagonal nut              | ⑰ Conical seat washer   |
| ⑨ Conical seat washer        | ⑱ Hexagonal nut         |
| ⑩ Spherical seat washer      | ⑲ Locknut (low)         |
| ⑪ Sleeve                     | ⑳ Washer                |
| ⑫ Hexagonal nut              | ㉑ Compression spring    |
| ⑬ Spherical seat washer      | ㉒ Conical seat washer   |
| ⑭ Spherical seat washer      | ㉓ Spherical seat washer |
| ⑮ Hexagon nut (self-locking) | ㉔ Locknut               |

**Tensioning the drive belt:**

1. Loosen the locknut ㉔ and nuts ⑧, ⑯ and ⑫.

2. Turn the nut **[12]** by hand until there is no gap between the sleeve **[11]** and spherical seat washer **[10]** and/or washer **[20]**.
3. Lock the nut **[19]** with the nut **[12]**.
4. Tighten the nut **[8]** against the side of the tensioning frame **[4]**. The conical seat washer **[9]** and the spherical seat washer **[23]** must lay in the tensioning frame.
5. Lock the nut **[24]** with the nut **[8]**.

**Making operational:**

1. Re-attach the safety screen and the belt guard.
2. Reconnect the negative battery terminal.
3. Close the door.

**10.8.6.4 Changing the belt**

1. Remove the tensioning device (see Fig. 81).
  - Loosen nuts **[24]** and **[8]** and lock together at the end of the threaded rod **[7]**.
  - Loosen nuts **[19]** and **[12]** on the tensioning frame **[4]** until the belt is completely slack.
  - Loosen the locking nut **[18]**.
  - With the help of the nut **[6]**, unscrew the tensioning device **[8]** from the locknut **[15]**.
  - Remove the tensioning device **[6]** from the tensioning frame **[4]** and belt tensioner holder **[5]**.
2. Changing the belts
  - Remove the belts from the pulleys.
  - Check the pulleys for dirt and wear.
    - Clean the pulleys.
    - Slitt remskive: Skift ut remskiven.
  - Check that the pulleys are lined up.
    - If the pulleys are not lined up, adjust the position of the generator until they are.
  - Without using force, place the new belt over the engine and generator pulleys.
3. Mount the tensioning device (see Fig. 81).
  - Mount the tension device **[6]** in in the tensioner holder **[5]** and tensioning frame **[4]** as illustrated.
  - Lock the nut **[8]** to the nut **[24]**.
  - Tighten the tensioning device **[6]** to the side of the motor with the nut **[15]**. For this, the tensioning device must be screwed into the locknut **[15]**.
  - Use a wrench to fixate the nut **[18]**. Use another wrench to turn nut **[8]** counter-clockwise. Secure the nut **[18]** with a drop of liquid thread lock to prevent a potential loosening due to vibration stresses.
  - Tension the belt as described in chapter 10.8.6.3.



A belt that has been replaced may not be used again.



Old belts should be disposed of in accordance with the latest environmental regulations.

**Making operational:**

1. Re-attach the safety screen and the belt guard.

2. Reconnect the negative battery terminal.
3. Close the door.

**Performing a test run:**

1. Run the compressor under LOAD operation for 15–20 minutes.
2. Open the left-hand door.
3. Remove the belt guard.
4. Check the belts again and re-tension if necessary.
5. Close the door.



Check the belt again after a further 2 operating hours.

#### 10.8.6.5 Aligning the generator

The engine and generator pulleys must be in line.

Misaligned pulleys cause:

- a belt that does not run true and may jump off the pulleys,
- high wear on one side of the belt,
- excessive noise.

Material Alignment ruler

Wrench

Liquid thread lock

1. Open the left-hand door.
2. Remove the safety screen and the belt guard.

**Checking the alignment:**




Fig. 82 Checking the pulley alignment

- [1] Generator drive pulley  
[2] Generator  
[3] Engine

- [4] Drive belt  
[5] Engine pulley  
[6] Alignment ruler

1. Lay the alignment ruler against the engine and generator pulleys.  
If the pulleys are offset, adjust the position of the generator.
2. Re-attach the safety screen and the belt guard.
3. Reconnect the negative battery terminal.
4. Close the door.

**Aligning the generator:**

The generator is aligned by turning the tensioning nut on the swing frame pivot axis. This moves the generator around its axis.




Fig. 83 Aligning the generator

[25]	Engine	[28]	Hexagonal nut
[26]	Generator	[29]	Tensioning nut (hexagon, self-locking)
[27]	Tensioning frame pivot axle head with flats for a wrench		

1. Remove the tensioning device (see chapter 10.8.6.4).
2. Using a suitable wrench, steady hold the tensioning frame axle head [27].
3. Loosen the hexagon nut [28].
4. Align the generator pulley with the engine pulley by turning the tensioning nut [29].
5. Check the pulley alignment with the alignment ruler.
6. Tighten the nut [28] using non-permanent liquid thread lock to prevent a potential loosening due to vibration stresses.
7. Replace the tensioning device (see chapter 10.8.6.4).
8. Tension the belt as described in chapter 10.8.6.3.
9. Re-attach the safety screen and the belt guard.
10. Reconnect the negative battery terminal.
11. Close the door.

**10.8.7 Option Ia**  
**Spark arrestor cleaning**

The spark arrestor must be cleaned of any soot residue every two months to prevent the emission of glowing particles from the exhaust silencer.

Material	Suitable rubber hose Soot receptacle Cleaning cloth Protective gloves Eye protection
Precondition	The machine is shut down. The machine is standing level. The machine is fully vented, the pressure gauge reads 0 bar. Machine is cooled down. All compressed air consumers are disconnected and the air outlet valves are open.


**DANGER**

Danger of suffocation from toxic exhaust fumes.


Exhaust fumes from internal combustion engines contain carbon monoxide, which is odourless and deadly.

- Use the machine only outdoors!
- Do not inhale exhaust fumes.


**CAUTION**

Danger of burns from hot components and sparks.

- Wear long-sleeved clothing and gloves.
- Wear eye protection.



10-M0385

**Fig. 84** Spark arrestor cleaning

- |     |   |     |   |
|-----|---|-----|---|
| [1] | Exhaust silencer end pipe                   | [3] | Soot drain port with plug                       |
| [2] | Opening in floor panel to access drain port | [4] | Exhaust silencer with integrated spark arrester |

1. Unscrew the soot drain plug.
2. Push one end of the hose over the drain port and place the other end in the receptacle.
3. Start the compressor engine.
4. In order to increase the pressure in the exhaust system, partially cover the exhaust discharge pipe with a fire-proof object.  
Soot will drain through the hose into the receptacle.
5. Shut down the engine.
6. Remove the hose and replace the plug.



It is recommended to blow out the spark arrestor with compressed air once a year.



Dispose of soot according to environment protection regulations.

### 10.8.8 Option Ib

#### Engine air intake shut-off valve maintenance

Material Compressed air for blowing out  
Petroleum ether or spirit  
Cleaning cloth

Precondition The machine is shut down.  
The machine is fully vented, the pressure gauge reads 0 bar.  
Machine is cooled down.  
All compressed air consumers are disconnected and the air outlet valves are open.



##### NOTICE

Engine air intake shut-off valve

The engine air intake shut-off valve does not close when flammable gas is drawn into the engine:

The machine does not shut down? Destruction of the engine and explosion and/or fire are possible!

- Do not move the valve adjusting screw.
- Have the valve set by a specialist workshop or KAESER Service.




Fig. 85 Engine air intake shut-off valve maintenance

- |   |                               |   |                                  |
|---|-------------------------------|---|----------------------------------|
| ① | Engine air intake             | ④ | Air intake hose (filter side)    |
| ② | Engine air filter             | ⑤ | Engine air intake shut-off valve |
| ③ | Air intake hose (engine side) | ⑥ | Hose clamp                       |

- Open both doors.

**Cleaning the engine air intake shut-off valve:**1. ***NOTICE!***

The engine air intake shut-off valve does not close fully.

The machine does not shut down? Destruction of the engine and explosion and/or fire are possible!

► Do not grease the valve, as this may cause a build up of dust and valve sticking.

## 2. Loosen the hose clamp on the filter side of the valve and turn the air intake hose to one side.

## 3. Check if the interior of the shut-off valve is clean.

Blow out any dirt with compressed air.



If necessary, clean the valve with petroleum ether or spirit and allow to dry.

Refer to a specialised workshop or KAESER Service if dirt cannot be removed.

**Checking the engine air intake shut-off valve for correct function and movement:**

## 1. Check the valve for signs of excessive wear.

## 2. Check that the valve plate closes fully and easily.

Result Have the valve changed if it is heavily worn or malfunctions in any way.

## 1. Reposition the air intake hose and tighten the clamp.

## 2. Close the doors.

## 3. Start the machine and switch to LOAD.

If the engine stops on switching to LOAD, have the valve adjusted by a specialist workshop or KAESER Service.

## 10.9 Documenting maintenance and service work

Machine number:

- Enter maintenance and service work carried out in the list.

Tab. 91 Maintenance log

# 11 Spares, Operating Materials, Service

## 11.1 Note the Nameplate

The nameplate contains all information to identify your machine. This information is essential to us in order to provide you with optimal service.

- Please give the information from the nameplate with every enquiry and order for spares.

## 11.2 Ordering consumable parts and operating fluids/materials

KAESER consumable parts and operating materials are original KAESER products. They are matched to application in our machines and ensure trouble-free operation.

Unsuitable or poor quality maintenance parts and operating materials may damage the machine or impair its proper function.

Damage to the machine can also result in personal injury.



### WARNING

There is risk of personal injury or damage to the machine resulting from the use of unsuitable spare parts or operating materials.

- Use only original KAESER parts and operating fluids/materials.
- Do not use alternative consumable parts and operating fluids and materials.

### Compressor unit

Name	Quantity	Number
Air filter element	1	1260
Oil filter	1	1210
Oil separator cartridge set	1	1450
Cooling oil	1	1600

Tab. 92 Compressor consumables

### Kubota engine parts

Name	Quantity	Number
Air filter element	1	1280
Fuel prefilter	1	1910
Fuel filter cartridge	1	1920
Fuel filter with water trap	1	1980
Oil filter cartridge	1	1905
Oil drain plug sealing ring	1	4496
Injector	1	4475
Injector nozzle gasket	1	4476
V-belts	1	4470
Glow plug	1	4466

Name	Quantity	Number
Engine oil	1	1925

Tab. 93 Consumable engine parts

### 11.3 KAESER AIR SERVICE

KAESER AIR SERVICE offers:

- Authorized service technicians with KAESER factory training.
  - Increased operational reliability ensured by preventive maintenance.
  - Energy savings achieved by avoidance of pressure losses.
  - The security of genuine KAESER spare parts.
  - Increased legal certainty as all regulations are kept to.
- Why not sign a KAESER AIR SERVICE maintenance agreement.

The advantages:

Lower costs and higher compressed air availability.

### 11.4 Service Addresses










Addresses of KAESER agents are given at the end of this manual.


### 11.5 Spares for service and repair

With the help of this parts list you can plan your material requirement according to operating conditions and order the spare parts you need.

- ➤ Make sure that any service or repair tasks not described in this manual are carried out by an authorised KAESER Service Technician.

(Option)

 <p>6001</p>	 <p>8900</p>	 <p>( 9400 )</p>
 <p>5001</p>	 <p>8800</p>	 <p>( 9300 )</p>
 <p>2001</p>	 <p>4001</p>	 <p>8000</p>
<p>1001</p>	 <p>3001</p>	<p>( 9200 )</p>




SEG-1656\_01

		<b>Legend</b>	<b>KAESER</b>
		Inlet air/Cooling air/Exhaust	SEL-1579_01E

<b>Item</b>	<b>Name</b>	<b>Option</b>
1255	Compressor air filter housing	
1260	Compressor air filter element	
1280	Engine air filter element	
1290	Engine air filter, complete	
1310	Compressor air filter holder	
1320	Engine air filter holder	
1360	Engine air intake hose	
1370	Connection-Kit chalwyn-valve	X
1385	Engine stop valve	X
1395	Hose clamp	
1396	Hose clamp	
3050	Air filter maint. indicator	
3051	Maintenance indicator fpr engine air filter	
4600	Engine fan	
4610	Fan coupling	
4660	Fan cover	
9800	Exhaust silencer	
9810	Engine exhaust pipe	
9840	Exhaust pipe clamp	
9845	guarding against touching	

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.



SEG-3329\_01


		<b>Legend</b>	<b>KAESER</b>
		<b>Oil circuit/Comprsd.air outlet</b>	<b>SEL-2506_01E</b>
<b>Item</b>	<b>Description</b>	<b>Option</b>	

0321	Oil/air gasket set		
1210	Compressor oil filter element		
2020	Minimum pressure/check valve		
2022	Maintenance kit, MP/CV		
2024	Overhaul kit, MP/CV		
2060	Combination valve		
2062	Maintenance kit, combi. valve		
2064	Overhaul kit, combination valve		
5050	Radiator		
5162	Compressor oil cooler drain		
6610	Oil scavenge line		
9416	Dirt trap maintenance kit		
7561	Hose line		
9250	Pipe clamp element		
9251	Pipe connection seal		
9252	Pipe adapter		
9855	Venting valve		
9860	Compressed air distributor		
9870	Outlet valve		
9872	Claw coupling		X
9880	Large outlet valve		
9885	Hose reel		X
9886	Consumer feed lines		X
9887	Hose reel ball valve		X
9889	Spare part hose line		X

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

Service-Kit



SEG-1687\_01


	<b>Legend</b>	<b>KAESER</b>
	Instrument panel	SEL-1627_01E

<b>Item</b>	<b>Description</b>	<b>Option</b>
3170	Starting relay	
3180	Shutdown relay	
3190	Power relay socket	
3610	Control fuse set	
3615	Fuse socket (set)	
3620	Control relay	
3621	Glow plug relay	
3625	Control relay socket	
3626	Socket for glow plug relay	
3940	Charging/fault indicator lamp	
3941	Back-pressure indicator	
3950	Main switch	
3955	Starter switch	
3960	Changeover switch full load mode	
3965	Temperature gauge	
3980	Pressure gauge, instrument panel	
3985	Operating hours counter	
3996	Instrument lamp set	

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

Service-Kit  
(Option)




SEG-2494\_01

		<b>Legend</b>	<b>KAESER</b>
		Electrics/Instruments	SEL-1975_01D
<b>Item</b>	<b>Description</b>		
3220	Battery		
3225	Battery cable		
3230	Battery bracket		
3240	Battery isolating switch		X
3250	Mains supply cable set		
3910	Instrument panel		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

Service-Kit  
(Option)



SEG-1659\_01


		<b>Legend</b>	<b>KAESER</b>
		Airrend/engine	SEL-1585_01E

<b>Item</b>	<b>Description</b>	<b>Option</b>
1600	Sigma Fluid *)	
1925	Engine oil *)	
2040	Inlet valve	
2042	Maintenance kit, inlet valve	
2044	Overhaul kit, inlet valve	
4050	SIGMA exchange airend	
4400	Drive coupling	
4420	Belt guard	
4430	Mounting bracket for airend base	
4450	Drive motor	
4760	Engine preheater	X
4950	Speed adjusting cylinder	
4951	Swivel joint	
4990	Compressor mountings	
4991	Engine mountings	

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

\*) see cooling oil/engine oil recommendations




		<b>Legend</b>	<b>KAESER</b>
		Drive motor	SEL-1629_01E

<b>Item</b>	<b>Description</b>	<b>Option</b>
1905	Engine oil filter element	
4460	Alternator	
4461	Alternator regulator	
4465	Starter	
4466	Glow plug	
4470	Engine V-belt	
4475	Injector nozzle	
4476	Injector nozzle seal	
4481	Oil pressure switch	
4482	Coolant thermostat	
4483	Temperature switch	
4486	Fuel cut-off	
4488	Engine oil cooler	
4495	Engine oil drain	
4496	Oil drain seal	

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.




		Legend	KAESER
		Engine cooling	SEL-2507_01E
Item	Description	Option	
5172	Engine radiator cap		
5190	Expansion tank		
5193	Expansion tank pipes		
5195	Engine antifreeze *)		
5620	Coolant hose		
5621	Coolant hose		
5630	Hose clamp		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

\*) see antifreeze recommendations

**Service-Kit**  
(Option)




SEG-1662\_01

	<b>Legend</b>	<b>KAESER</b>
	Oil separation/control air	SEL-1589_01E

<b>Item</b>	<b>Description</b>	<b>Option</b>
1450	Oil separator cartridge	
2140	Control valve	
2142	Maintenance kit, control valve	
2144	Overhaul kit, control valve	
2290	Directional control valve	
2292	Directional valve maint. kit	
6050	Oil separator tank	
6150	Pressure relief valve for oil separator tank	
7350	Control line kit	

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.


Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.



		<b>Legend</b>	<b>KAESER</b>
		Fuel supply	SEL-1591_01E
<b>Item</b>	<b>Name</b>	<b>Option</b>	
1910	Fuel prefilter		
1920	Fuel fine filter element		
1980	Fuel de-watering filter		
4485	Fuel pump		
7900	Fuel tank		
7915	Fuel tank cap		
7920	Fuel strainer		
7925	Tank support		
7930	Tank fixing		
7950	Fuel suction pipe		
7951	Connection gasket		
7960	Fuel lines		
7970	Fuel hose connection		
7975	Fuel return line		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.




	<b>Legend</b>	<b>KAESER</b>
	Bodywork	SEL-1593_01E

Item	Description	Option
8400	Lower bodywork	
8425	Canopy front	
8430	Canopy rear	
8440	Canopy, upper-centre	
8450	Left-hand wing door	
8460	Right-hand wing door	
8465	Door handle	
8470	Exhaust air grill	
8505	Hinge/closure set	
8555	Sound damping louver kit	
8600	Sealing profile	
8610	Edge protecting strip	
8620	Gas strut	
8630	Cover for lifting eye	

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.


Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.



		Legend	KAESER
		Lighting set	SEL-1605_01E
Item	Name	Option	
8861	Left rear light		
8862	Right rear light		
8863	Left light lens		
8864	Right light lense		
8865	Left side light		
8866	Right side light		
8867	Lighting bulb set		
8885	Lighting connecting socket		
8888	Connector cable		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.




	<b>Legend</b>	<b>KAESER</b>
	Lighting set USA	SEL-1959_01E

Item	Description	Option
8861	Left rear light	
8862	Right rear light	
8867	Lighting bulb set	
8888	Connector cable	
8890	Connector cable, vehicle	
8892	Connecting cable left ( blue)	
8893	Connecting cable right (red)	

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

Service-Kit




	<b>Legend</b>	<b>KAESER</b>
	Lighting set	SEL-2032_01E

Item	Description	Option
8861	Left rear light	
8862	Right rear light	
8867	Lighting bulb set	
8882	Number plate lamp	
8883	Side marker lamp yellow	
8884	Side marker lamp red	
8888	Connector cable	
8890	Vehicle connector cable	
8892	Left connecting cable (blue)	
8893	Right connecting cable (red)	

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.




SEG-1666\_01

		<b>Legend</b>	<b>KAESER</b>
		Chassis	SEL-1595_01E
<b>Item</b>	<b>Description</b>	<b>Option</b>	
8815	Lifting eye		
8820	Wheel		
8821	Chock		
8830	Left mudguard		
8831	Right mudguard		
8841	Collision guard, front-left		
8842	Collision guard, front-right		
8843	Pedestrian protection, left		X
8844	Pedestrian protection, right		X
8845	Collision guard, rear		
8851	Left light cluster holder		
8852	Right light cluster holder		
8860	Lighting set		
8881	Reflectors (set)		
8890	Connector cable		
8891	Bracket for 12V male pin socket		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.



SEG-1667\_01


	<b>Legend</b>	<b>KAESER</b>
	Chassis	SEL-1597_01E

<b>Item</b>	<b>Description</b>	<b>Option</b>
8815	Lifting eye	
8820	Wheel	
8821	Chock	
8830	Left mudguard	
8831	Right mudguard	
8841	Collision guard, front-left	
8842	Collision guard, front-right	
8843	Pedestrian protection, left	X
8844	Pedestrian protection, right	X
8845	Collision guard, rear	
8851	Left light cluster holder	
8852	Right light cluster holder	
8860	Lighting set	
8881	Reflectors (set)	

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

Service-Kit  
(Option)



SEG-1668\_01


	<b>Legend</b>	<b>KAESER</b>
	Chassis	SEL-1599_01E

<b>Item</b>	<b>Description</b>	<b>Option</b>
8815	Lifting eye	
8820	Wheel	
8821	Chock	
8830	Left mudguard	
8831	Right mudguard	
8841	Collision guard, front-left	
8842	Collision guard, front-right	
8843	Pedestrian protection, left	X
8844	Pedestrian protection, right	X
8845	Collision guard, rear	
8851	Left light cluster holder	
8852	Right light cluster holder	
8880	Reflector	

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

Service-Kit




SEG-1669\_01

		<b>Legend</b>	<b>KAESER</b>
		Chassis (stationary skid versions)	SEL-1601_01E
<b>Item</b>	<b>Description</b>	<b>Option</b>	
8810	Skids		
8811	Machine mounts for the skid		
8815	Lifting eye		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

**RAMIREZ**




		<b>Legend</b>	<b>KAESER</b>
Chassis (stationary base-frame versions)			SEL-1603_01E
Item	Description		
8805	Chassis strut		
8811	Machine mounts for the skid		
8815	Lifting eye		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.



Service-Kit





SEG-1678\_01

		<b>Legend</b>	<b>KAESER</b>
		Chassis, cpl. EU	SEL-1617_01E
<b>Item</b>	<b>Description</b>	<b>Option</b>	
8910	Chassis, complete		
8920	Drawbar, complete		
8960	Complete axle		
8988	Jockey wheel, complete		
8990	Jockey wheel		
8992	Ball coupling for car, ø 50 (DIN)		
8994	Towing eye for HGV, ø 40 (DIN)		
8995	Towing eye for HGV, ø 45		
8996	Towing eye for HGV, ø 68 x 25		
8997	Towing eye for HGV, ø 76		
8998	Towing eye for HGV, ø 68 x 42		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.




<b>Legend</b>		<b>KAESER</b>
Towbar, cpl. EU		SEL-1625_01E

<b>Item</b>	<b>Description</b>	<b>Option</b>
8921	Towbar	
8922	Chassis mounting block	
8923	Height-adjustment bar	
8930	Overrun braking mechanism	
8939	Brake transmission lever	
8940	Parking brake lever	
8941	Parking brake gas spring	
8942	Securing pin	
8943	Parking brake cable	
8947	Locking toggle, upper	
8949	Locking toggle, lower	
8950	Brake transfer cable	
8952	Securing pin	
8955	Brake rod	
8957	Breakaway cable	

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.




		Legend	KAESER
		Axle, complete, braked	SEL-1615_01E
Item	Description	Option	
8963	Wheel hub		
8965	Brake shoe set		
8966	Brake shoe spring set		
8967	Wheel brake cable		
8968	Brake cable hook-in pin		
8971	Brake adjusting set		
8972	Sealing cap for the brake backplate		
8973	Grease cap for the brake drum		
8974	Flanged locknut for the axle bearing		
8975	Brake actuating kit		
8976	Protective shell for brake cable		
8980	Wheel bolt		
8982	Wheel bearing set		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

Service-Kit


SFG-1677\_01



		Legend	KAESER
		GB chassis	SEL-1611_01E
Item	Description	Option	
8910	Chassis, complete		
8920	Drawbar, complete		
8960	Complete axle		
8988	Jockey wheel, complete		
8990	Jockey wheel		
8992	Ball coupling for car, ø 50 (DIN)		
8994	Towing eye for HGV, ø 40 (DIN)		
8995	Towing eye for HGV, ø 45		
8996	Towing eye for HGV, ø 68 x 25		
8997	Towing eye for HGV, ø 76		
8998	Towing eye for HGV, ø 68 x 42		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.




		<b>Legend</b>	<b>KAESER</b>
		Drawbar cpl. GB	SEL-1623_01E
<b>Item</b>	<b>Description</b>	<b>Option</b>	
8921	Towbar		
8922	Chassis mounting block		
8931	Grease nipple for overrun head		
8935	Towbar		
8936	Towbar guide bush		
8937	Towbar shock absorber		
8938	Towbar protective sleeve		
8939	Brake transmission lever		
8940	Parking brake lever		
8941	Parking brake gas spring		
8943	Parking brake cable		
8955	Brake actuating rod		
8957	Breakaway cable		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.




		<b>Legend</b>	<b>KAESER</b>
		Axle, complete, braked	SEL-1615_01E
<b>Item</b>	<b>Description</b>	<b>Option</b>	
8963	Wheel hub		
8965	Brake shoe set		
8966	Brake shoe spring set		
8967	Wheel brake cable		
8968	Brake cable hook-in pin		
8971	Brake adjusting set		
8972	Sealing cap for the brake backplate		
8973	Grease cap for the brake drum		
8974	Flanged locknut for the axle bearing		
8975	Brake actuating kit		
8976	Protective shell for brake cable		
8980	Wheel bolt		
8982	Wheel bearing set		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.


Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.



		<b>Legend</b>	<b>KAESER</b>
		Chassis	SEL-1607_01E
<b>Item</b>	<b>Description</b>	<b>Option</b>	
8910	Chassis, complete		
8920	Drawbar, complete		
8960	Complete axle		
8989	Prop		
8993	Ball coupling for car, ø 2"		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.


Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.







		<b>Legend</b>	<b>KAESER</b>
		Drawbar cpl. US	SEL-1619_01E
<b>Item</b>	<b>Description</b>	<b>Option</b>	
8921	Towbar		
8922	Chassis mounting block		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.



Service-Kit



SEG-1682\_01  
8981  
8979  
8963


		<b>Legend</b>	<b>KAESER</b>
		Axle, complete, non-braked	SEL-1609_01E
<b>Item</b>	<b>Description</b>	<b>Option</b>	
8963	Wheel hub		
8973	Grease cap for the brake drum		
8974	Flanged locknut for the axle bearing		
8979	Wheelbolts		
8981	Wheel nut		
8982	Wheel bearing set		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

RAMIREZ

Service-Kit




SEG-1670\_01

		Legend	KAESER
		Power generation	SEL-1637_01E
Item	Name	Option	
9110	Generator		
9115	Generator cabinet		
9120	Generator panel		
9125	Generator drive belt		
9126	Generator regulator		
9130	Generator drive pulley		
9135	Engine drive pulley		
9145	Belt adjustment		
9150	Socket joint		
9160	Control valve for generator		
9170	Control line kit for generator		
9180	Generator cable set		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.




		<b>Legend</b>	<b>KAESER</b>
		Generator panel, 400V	SEL-1563_01E
Item	Description	<b>Option</b>	
9121	Single phase power socket, 16A		
9122	16A three-phase power socket		
9127	Generator main switch		
9128	Mode selector switch		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

**RAMIREZ**




		<b>Legend</b>	<b>KAESER</b>
		Generator panel, 230V	SEL-1561_01E
Item	Description	<b>Option</b>	
9121	Single phase power socket, 16A		
9122	DC power socket, 16A		
9124	DC power socket, 32A		
9127	Generator main switch		
9128	Mode selector switch		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

**RAMIREZ**




		<b>Legend</b>	<b>KAESER</b>
		Generator panel, 115V	SEL-1665_01E
Item	Description	<b>Option</b>	
9121	Single phase power socket, 16A		
9123	Single phase power socket, 32A		
9127	Generator main switch		
9128	Mode selector switch		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

**RAMIREZ**




		<b>Legend</b>	<b>KAESER</b>
		Tool lubrication	SEL-1639_01E
<b>Item</b>	<b>Description</b>	<b>Option</b>	
9210	Tool lubricator		
9212	Tool lubricator shut-off valve		
9220	Tool oil *)		
9240	Control line kit for tool lubricator		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

\*) see lubricating recommendations for road breakers

Service-Kit



SEG-1768\_01


		<b>Legend</b>	<b>KAESER</b>
		Frost protection device	SEL-1667_01E
<b>Item</b>	<b>Description</b>	<b>Option</b>	
9310	Antifreeze injector		
9312	Shut-off valve		
9320	Antifreeze for the frost protection device*)		
9330	Antifreeze injector check valve		
2412	Check valve overhaul kit		
9340	Antifreeze inj. control lines		
9350	Antifreeze drainage kit		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

\*) see antifreeze recommendations

Service-Kit  
( Option )




SEG-1673\_02

		<b>Legend</b>	<b>KAESER</b>
		Compressed air treatment	SEL-1621_02E
<b>Item</b>	<b>Description</b>	<b>Option</b>	
1510	Fresh air filter		X
1515	Pre-filter for compressed air		X
1516	Fine filter for compressed air		X
6450	Condensate separator		
7580	Hose line		X
7590	Hose line		X
9262	Pipe clamp element		X
9263	Pipe connection seal		X
9265	Pipe clamp element		X
9266	Pipe connection seal		X
9256	Pipe clamp element		
9257	Pipe connection seal		
9258	Pipe adapter		
9410	Compressed air after-cooler		
9415	Separator dirt trap		
9416	Dirt trap maintenance kit		
9425	Compressed air re-heater		X
9429	Outlet coupling for breathing air		X
9430	Air regulator for breathing air		X
9440	Outlet pipe kit for breathing air		X
9441	Condensate drain line		
9450	Condensate drain hose		X
9460	Compr.air filter shut-off vlv.		X

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.




		Legend	KAESER
		Compressed air filter comb.	SEL-1641_01E
Item	Description	Option	
1548	Body gasket		
1550	Filter element for prefilter		
1551	Filter element for microfilter		
3770	Pressure differential indicator		
6452	Separator upper part		
6454	Separator lower part		

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

RAMIREZ

Service-Kit



SEG-2482\_02

	<b>Legend</b>	<b>KAESER</b>
	Fresh air filter	SEL-2292_01E

<b>Item</b>	<b>Description</b>	<b>Option</b>
1549	Fresh air filter element	
3930	Indicator insert	
6458	Shut-off valve	

Please quote the part number and serial number of the machine together with the item number and the description of the part when ordering.

Before and during all work, be sure to read and follow the safety and service instructions in the machine's service manual.

## 12 Decommissioning, Storage and Transport

### 12.1 De-commissioning

De-commissioning is necessary, for example, under the following circumstances:

- The machine is temporarily not needed
- The machine will not be needed for a considerable time.
- The machine is to be scrapped.

Precondition The machine is shut down.

Machine dry and cool.

1. Carry out the following de-commissioning procedures.
2. Place a notice on the instrument panel describing the de-commissioning procedures carried out.

#### 12.1.1 Temporary de-commissioning

Decommissioning for about 4 months.

Material Plastic sheeting

Moisture-resistant adhesive tape

1. Disconnect the battery (the minus terminal first and then the plus terminal).
2. Close off the following openings with plastic foil and moisture-resistant adhesive tape.
  - Engine air inlet
  - Compressor air inlet
  - Exhaust silencer
3. Attach the following notice on the instrument panel showing the decommissioning measures taken.

##### Attention!

1. The machine is temporarily decommissioned.
2. The following machine openings have been covered:
  - Engine air inlet
  - Compressor air inlet
  - Exhaust silencer
3. Recommission according to service manual.

Date / signature

Tab. 94 "Temporarily decommissioned" information notice

## 12.1 De-commissioning

**Decommissioning of the compressor for several weeks during severe frost****1. NOTICE!**

Danger of batteries freezing!  
Discharged batteries are subject to frost damage and can freeze at -10 °C.

- Store batteries in a frost-free place.
- Store batteries preferably fully charged.

2. Remove the battery (batteries) and store in a frost-free room.
3. Make sure batteries are fully charged.

**12.1.2 Long-term de-commissioning and storage**

De-commissioning the machine for 5 months or longer.

Material	Receptacle Preserving oil Preservative Desiccant Plastic sheeting Moisture-resistant adhesive tape
----------	---

- The following measures must be taken for long-term decommissioning and storage:

Long-term decommissioning and storage tasks	See chapter	Confirmed?
➢ Check engine coolant.	10.3.1	
➢ Drain the engine oil.	10.3.6	
➢ Drain the oil from the oil separator tank and the oil cooler.	10.4.3	
➢ Drain oil from the heat exchanger (Option db).	10.4.3	
➢ Fill the separator tank and engine with preserving oil.	10.4.2	
	10.3.5	
➢ Run the machine for about 10 minutes to coat all parts with a protective oil film.	-	
➢ Disconnect the battery, the minus terminal first and then the plus terminal, and store in a frost-free room.	-	
➢ Check the battery fluid level.	10.6	
➢ Check the battery charge monthly and recharge if necessary to prevent the battery fluid freezing.	-	
➢ Clean the battery terminals and coat with acid-resistant grease.	-	
➢ Close the compressed air outlet valves.	-	
➢ Use plastic sheeting and moisture-resistant adhesive tape to seal off the following openings: <ul style="list-style-type: none"><li>■ Engine air inlet</li><li>■ Compressor air inlet</li><li>■ Exhaust silencer</li></ul>	-	
➢ Clean the bodywork and treat with preservative.	-	

Long-term decommissioning and storage tasks	See chapter	Confirmed?
► Feste et skilt på betjeningspanelet med angivelse av utførte tiltak fordi maskinen satt ut av drift.	–	

Tab. 95 "Long-term decommissioning and storage" checklist

- Attach the following notice on the instrument panel showing the decommissioning measures taken.

**Attention!**

1. The machine is decommissioned.
2. It is filled with preserving oil.
3. For re-commissioning:
  - Measures for re-commissioning the compressor after a long period of storage.
  - Recommission according to service manual.

Date / signature

Tab. 96 Text for the "long-term decommissioned and storage" information notice

- Store in a dry place with even temperature.

## 12.2 Transport

- Precondition**
- Machine switched off and locked off.
  - The machine is fully vented, the pressure gauge reads 0 bar.
  - Machine is cooled down.
  - All compressed air consumers are disconnected.
  - All connecting lines and hoses disconnected and removed.
  - Any loose or movable parts that may fall when transporting are removed or secured.

### 12.2.1 Safety



Allow transportation only by personnel trained in safely dealing with motor vehicles and the transporting of goods.

**1. WARNING!**

There is danger of being run over or crushed by an overturning vehicle.  
Death or serious injury can result from being crushed or run-over by a machine under tow.  
► Riding on the machine while it is under tow is strictly forbidden.

**2. Make sure the danger area is clear of personnel.**

### 12.2.2 Towing the compressor on the road

Machines with appropriate chassis versions and running gear are approved for towing on public roads. The machine is designed for a maximum towing speed of 100 km/h. National and local regulations must be observed when towing the machine on public highways.

1. **WARNING!**

Risk of accident when towing the unilluminated machine on public roads.

Death or severe injury possible due to accidents with unilluminated trailer.

➤ Do not tow machines without illumination on public roads.

## 2. Observe the safety instructions in chapter 3.5.2 "Safe machine operation".

**12.2.1 Preparing for transport****Stowing payload:**

Do not exceed the permissible loading (overall weight, coupling load, axle load).

Observe national traffic laws. If additional loading is not permitted, the additional load must be stowed in the towing vehicle.

1. Check that loading the machine with tools or accessories during transport is permissible.
2. Place additional loads only in the spaces provided (if available) and secure carefully.

**Additional precautions for a very dirty machine:**

The machine can become very dirty after prolonged use on a construction site. A machine in such condition is not suitable for towing on public roads.

1. Clean the machine, particularly the chassis, running gear, the lights and direction indicators.
2. Check the function of wheels, brakes, lights and signalling equipment.  
Functional defects must be repaired prior to transport.

**Additional precautions for conditions of snow and ice:**

Considerable snow or ice may build up on the machine under low temperature conditions.

1. **CAUTION!**

Risk of accidents caused by snow and/or ice falling off the machine!

Snow or ice falling from the towed machine can endanger following vehicles.

Problems with driving dynamics and damage to the machine could occur.

The maximum permissible axle load could be exceeded.

➤ Do not tow the machine if it is coated in snow or ice.

## 2. Remove any snow or ice before towing.

**Perform the following tasks prior to transporting the machine:**

1. Make sure the towing hitch is compatible with the ball or eye coupling on the towed machine.
2. Check that the machine is shut down and secured against accidental restarting.
3. Detach all connecting lines and hoses.
4. Make sure there are no unsecured tools lying on or in the machine.
5. Close and lock the access doors.

**Option sa Adjust the tow bar to suit the height of the towing vehicle hitch:**

When the machine is coupled up, the tow bar must be parallel with the ground.




Fig. 86 Towing alignment

1. **WARNING!**

Danger from problematic driving dynamics!

The permissible loading range may be exceeded or undercut.

Personal injury may result from towing.

Damage to the machine and/or towing vehicle is possible.

► Do not couple up the machine at an angle to the towing vehicle.

► Ensure that the towbar is horizontal when coupled to the towing vehicle.

## 2. Adjust the drawbar height to suit the height of the hitch on the towing vehicle.

Further information See chapter 6.4.1 for tow bar height adjustment.

**12.2.2.2 Coupling-up****Option sa, sd Coupling machine with ball coupling (EC version):**

To hitch up the machine, lower the open coupling onto the ball of the towing vehicle so that it clicks into place. The indicator of the safety control display will jump to the green zone of the marking identified with a "+", if the ball hitch has engaged correctly.




Fig. 87 Ball coupling (KNOTT-EU)

- ① Coupling handle  
② Ball coupling

- ③ Towing vehicle ball hitch  
④ Safety indicator

1. **NOTICE!**

There is considerable danger of injury caused by trapped fingers.

They can be trapped in the spring-loaded closing mechanism.

► Never place your fingers inside an open ball coupling.

► Always wear protective gloves.

## 12.2 Transport

2. Pull the handle of the ball coupling upwards and turn forwards.

The ball coupling is opened and will remain in the opened position and the indicator of the safety control display is in the red "X" area.

 3. **WARNING!**

Risk of accident due to unhitching of the ball coupling during transport!

If the coupling is not fully closed the compressor can become uncoupled from the towing vehicle and cause an accident.

- Check correct coupling.

4. Place the open coupling over the towing vehicle ball hitch.

The weight on the coupling will cause it to audibly latch. The coupling locks automatically.

5. Push the handle down to be certain of locking.

The coupling is fully locked when the handle is fully down and can be pushed no further.

6. Check correct coupling.

- Check that the coupling handle cannot be pushed further down.
- Check whether the indicator of the safety control display is in the green "+" zone.



The indicator of the safety control display is in the red zone ("X" or "-" position).

The coupling is open or not fully closed.

- Lift the handle and uncouple.

- Place the coupling back onto the vehicle ball hitch of the towed vehicle and forcibly push down at the coupling handle until it audibly latches.

**Option sa, sd Checking the ball coupling wear indicator (EU version):**

The ball hitch is equipped with a safety control display.

The safety control display indicates:

- Wear on the ball hitch.
- Wear on the coupling.
- Open ball hitch.

**Option sa, sd**




Fig. 88 Safety control display ball hitch KNOTT-EU

- |   |                  |
|---|------------------|
| 1 | Ball coupling    |
| 2 | Pointer          |
| 3 | Safety indicator |

- |   |                                    |
|---|------------------------------------|
| + | Green zone (OK)                    |
| - | Red zone (wear tolerance exceeded) |
| X | red zone (ball hitch open)         |


**1. WARNING!**

Danger of accident from worn coupling!

The machine may detach from the towing vehicle.

- Do not tow the machine.
- Have the ball coupling and ball hitch checked.
- Worn parts must be replaced.

**2. Hitch the machine to the towing vehicle.**
**3. Read and interpret the safety control display as follows:**

Safety indicator	Meaning
Green zone showing (+)	<ul style="list-style-type: none"> <li>■ Coupling in new condition.</li> <li>■ Towing vehicle ball hitch wear within acceptable limits.</li> <li>➢ No action necessary.</li> </ul>
Red zone (-) showing	<ul style="list-style-type: none"> <li>■ Ball hitch wear at acceptable limit, ball coupling unworn.</li> <li>■ Ball hitch in new condition; ball coupling showing increased wear.</li> <li>■ Both ball and coupling showing increased wear.</li> <li>■ Ball coupling damaged.</li> <li>➢ Have the ball coupling and ball hitch checked by a specialist workshop.</li> <li>➢ Worn parts must be replaced.</li> <li>■ Ball hitch not properly latched on coupling ball.</li> <li>➢ Reposition ball hitch on coupling ball until it audibly latches.</li> </ul>
Red zone showing (X)	<ul style="list-style-type: none"> <li>■ Ball hitch not closed, coupling rests only loosely on the coupling ball.</li> <li>➢ Reposition ball hitch on coupling ball until it audibly latches.</li> </ul>

Tab. 97 Safety control display ball hitch

**Option sh Coupling machine with ball coupling (US version):**

To couple up the compressor, lower the open coupling onto the ball hitch of the towing vehicle so that it clicks into place.




Fig. 89 Ball coupling (USA version):

- |   |                 |   |                                  |
|---|-----------------|---|----------------------------------|
| ① | Spreader sleeve | ④ | Fixing hole for the security pin |
| ② | Safety pin      | ⑤ | Coupling head                    |
| ③ | Clip            | ⑥ | Ball coupling properly secured   |

1. **NOTICE!**

There is considerable danger of injury caused by trapped fingers.  
They can be trapped in the spring-loaded closing mechanism.

- Never place your fingers inside an open ball coupling.
- Always wear protective gloves.



## 2. Release the clip ③, swivel to one side and pull out the safety pin ②.

3. **WARNING!**

Risk of accident due to unhitching of the ball coupling during transport!  
If the coupling is not fully closed the compressor can become uncoupled from the towing vehicle and cause an accident.

- Check correct coupling.
- Check correct location of the security pin.

## 4. Lower the ball coupling onto the ball hitch of the towing vehicle and pull back the spreader sleeve ① to its end stop.

The ball coupling opens and the coupling head ⑤ encloses the ball hitch of the towed vehicle.

## 5. Lift the ball coupling off the ball hitch and carefully allow the spreader sleeve ① to snap back to its initial position.

## 6. Replace the safety pin ② in the fixing holes in the ball coupling and secure with the clip ③.

**12.2.2.3 Ensure transport readiness of the coupled machine.****Option sa Prepare the machine with adjustable chassis for transport:**1. Check that the tow bar is adjusted to the correct height. (see also chapter 6.4.1)  
Check if:

- The teeth in the tow bar height adjusting joints are fully engaged.
- The locking levers are tightened
- the safety pins are properly inserted

## 2. Wind the jockey wheel to its uppermost position.

## 3. Check that the wheels are securely fitted and the tyres are in good condition.

## 4. Check the tyre pressures.

## 5. Connect the cable for the lighting and indicator systems and carry out a function check.

## 6. Release the parking brake and remove the chocks from under the wheels.

**Option sd Prepare the machine with fixed chassis with parking brake) for transport:**

## 1. Wind the jockey wheel to its uppermost position.

## 2. Check that the wheels are securely fitted and the tyres are in good condition.

## 3. Check the tyre pressures.


## 4. Connect the cable for the lighting and indicator systems and carry out a function check.

## 5. Release the parking brake and remove the chocks from under the wheels.

## 12.2 Transport

Option sh Prepare the machine with fixed chassis (without parking brake) for transport:

Option sh



12-M0393

Fig. 90 Safety sign - secure the chocks



1. **WARNING!**

Missing chocks

Serious injury or death can result from an unsecured machine rolling away.

- Secure the chocks in the transport securing device before transporting the machine.
- Replace missing chocks immediately.

2. Pull up the prop and secure in the upper position.

3. Attach the safety chain to the towing vehicle.

4. Check that the wheels are securely fitted and the tyres are in good condition.

5. Check the tyre pressures.

6. Attach the lighting and indicator systems and carry out a function check.


7. Remove the chocks and secure them in the transport securing device.



Replacement chocks can be purchased from KAESER representatives. A list is given at the end of this manual. The part number of the chock is 5.1325.0.

**Ensure emergency braking in the case of breakaway from the towing vehicle:**

If the compressor breaks away from the towing vehicle, the cable tightens and pulls on the emergency brake (parking brake).



12-M0149

Fig. 91 Breakaway cable attachment

① Breakaway cable

② Connection (spring clip)



1. **NOTICE!**

Unintentional brake application.

If the breakaway cable is too short it can apply the brakes when rounding a curve. This imposes high wear on the braking system.

- Make sure the breakaway cable is long enough.

2. Loop the end of the cable round the towing vehicle hitch and secure with the spring clip.

### 12.2.3 Parking the compressor

The parking brake is not a running brake and is used only to lock the wheels when the machine is positioned.

The machine is generally only moved by being coupled to a towing vehicle.




#### CAUTION

Injury can occur if the towbar is unsupported and allowed to fall.

A falling towbar can cause injury, especially by crushing the feet.

If the jockey wheel is raised completely, the spindle can disengage and allow the towbar to fall to the ground.

- Do not wind the jockey wheel completely out when the machine is uncoupled from the towing vehicle.



12-M0265

Fig. 92 Injury can occur if the towbar is unsupported and allowed to fall.

#### Option sa, sd Parking the machine (EC version with parking brake):

When parking on a slope, securely chock the machine before uncoupling.


1. Disconnect the lighting and signalling cable.
2. Pull on the parking brake.
3. Detach the breakaway cable.
4. Wind down the jockey wheel.
5. Place chocks under the wheels.
6. Pull up the parking brake to the stop.  
The gas spring holds the brake under tension.
7. Uncouple the compressor from the towing vehicle:
  - Pull the handle of the ball coupling upwards and turn forwards.  
The ball coupling will remain in the opened position and the indicator if the safety control display is in the red "X" area.
  - Lift the coupling off the towing hitch ball.



The gas spring automatically increases parking brake force if the machine rolls backwards or when parked on a slope.

#### Option sh Parking the machine (USA version, without parking brake):

When parking on a slope, securely chock the machine before uncoupling.



12-M0392

Fig. 93 Safety sign - secure the chocks

1. **WARNING!**

Machine without parking brake.

Serious injury or death can result from an unsecured machine rolling away.

- Securely chock the machine before uncoupling.
  - As a general rule, the machine should always be blocked with chocks when it is not being moved.
  - The machine should not be manoeuvred by hand.
2. Lower and lock the prop stand.
  3. Place chocks under the wheels.
  4. Remove the safety chain from the towing vehicle.
  5. Dismantle the lighting and signaling system.
  6. Uncouple the compressor from the towing vehicle (see Fig 89).
    - Release the clip ③, swivel to one side and pull out the safety pin ②.
    - Pull back the spreader sleeve ①.
    - Lift the ball coupling off the towing vehicle ball hitch and carefully allow the spreader sleeve to snap back to its original position.
    - Replace the safety pin ④ in the fixing holes in the ball coupling and secure with the clip.

#### 12.2.4 Transport with a crane

##### Additional precautions for conditions of snow and ice:

Considerable snow or ice may build up on the machine under low temperature conditions. This may adversely effect the machine's centre of gravity.

It is possible that the permissible loading on the crane or lifting eye is exceeded.

- Perform the following tasks in snow and ice conditions:
  - Remove any snow and ice from the machine before lifting by a crane.
  - Make sure the lifting eye cover plate is freely accessible and can be opened.

##### Perform the following tasks prior to moving the machine by crane:

A lifting eye is provided for transporting with a crane. The lifting eye is located beneath a lift-up cover in the centre of the canopy.

1. Unlock the cover from inside and lift up.
2. Position the crane hook vertically over the lifting eye.
3. Engage the hook in the eye.
4. Close and lock the access doors.
5. Lift the machine carefully.

**Take care when setting down the machine**1. **NOTICE!**

Incorrect setting down can damage the machine.

Machine components, particularly the chassis, can be damaged by incorrectly setting down.

- Set the machine down carefully.
- Do not set down unevenly.

## 2. Set the machine down slowly and carefully.

**12.2.5 Option sc****Transporting with a forklift truck**

Precondition The machine is shut down.

All connecting lines and hoses disconnected and removed.

**CAUTION**

Damage to the machine by incorrect lifting with a fork truck.

The machine may fall or be damaged by the forks.

- Do not use a fork truck to lift towable machines.
- Only stationary machines with skids may be transported with a fork truck.
- Pick up the machine only from the side with the forks through the lifting lugs.

Option sc




Fig. 94 Transport using a forklift truck

- ① Skids
- ② Lifting lugs

1. Close and lock the access doors or canopy.
2. Position the fork truck to the side of the machine with the forks lined up with the lifting lugs.
3. Drive the forks fully through the lifting lugs as far as possible.  
The forks are fully under the machine.
4. Lift the machine carefully.

**12.2.6 Transporting as a load**

The medium of transport determines the type of packing and securing.

Packing and securing methods must be such that, assuming proper handling, the goods arrive in perfect condition at the destination.

Other measures must be taken for the transport of machines by sea or air. Please contact KAESER Service for more information.

## 12.2 Transport

Material	Chocks
	Restraints or timber balks
	Straps

**Carry out a freight securing:**

- National directives and regulations for securing loads should be followed.
- Load securing is taken to mean that by full braking or sudden turning the load will not slide, fall, roll or cause unnecessary noise. Accepted technical regulations should be observed (e.g. VDI directive 2700 ff in Germany).
- Responsibility for properly secured loads falls on the driver, the vehicle keeper and the carrier.

Use chocks, restrainers or timber balks for securing the load.  
If necessary, use straps across the chassis and the tow bar.




Fig. 95 Load secured by strapping

**1. NOTICE!**

Vehicle body damage due to guys!

Movement during transportation can damage the bodywork.

- Do not use straps over the bodywork.
- Use straps only over the chassis.

2. Always observe valid accident and safety regulations when transporting.
3. The loads must be secured against rolling, tipping, slipping and falling.



Contact KAESER Service with any questions regarding transporting or load securing.

KAESER accepts no liability and provides no guarantee for damage arising from incorrect transport or insufficient or incorrect load securing provisions.

For hire, rental and trade fair plant, any transport safety devices used for the delivery must also be used for the return transport.

**Before shipment as air freight**

The machine is designated as dangerous goods for air freight purposes; any disregard can result in a heavy fine.

1. **WARNING!**

Fire and explosion risk arising from operating supplies!

The machine incorporates an internal combustion engine.

- Any dangerous fluids/materials contained within the machine must be removed before transport.

## 2. All hazardous materials must be removed.

These include:

- Residues of fuel or fuel vapours
- Lubricating and cooling oils in the engine and compressor unit
- Electrolyte charges in rechargeable batteries.
- Residual quantities of tool oil in the lubricator (Option ec).
- Residual quantities of antifreeze in the frost protector (Option ba)

## 12.3 Storage

Moisture can lead to corrosion, particularly in the engine, airend and oil separator tank.

Frozen moisture can damage components, valve diaphragms and gaskets.

The following measures also apply to machines not yet commissioned.



Please consult with KAESER if you have questions to the appropriate storage and commissioning.

**NOTICE**

Moisture and frost can damage the machine!

- Prevent ingress of moisture and formation of condensation.
- Maintain a storage temperature of >0 °C.
- Store the machine in a dry place, free from frost if possible.

## 12.4 Disposal

When disposing of a machine, drain out all liquids and remove old filters.

Precondition

The machine is decommissioned.

1. Completely drain the fuel from the machine.
2. Completely drain the cooling oil and engine oil from the machine.
3. Remove used filters and the oil separator cartridge.
4. Drain the coolant from water-cooled engines and systems.
5. The battery has been removed.
6. Hand the machine over to an authorised disposal expert.



- Operating materials and components contaminated with fuel, cooling oil or engine oil must be disposed of in accordance with local environment protection regulations.
- Old batteries are hazardous waste and must be disposed of correctly in accordance with local environment protection regulations

## 13 Annex

### 13.1 Identification





Fig. 96 Identification


- |          |   |          |   |
|----------|---|----------|---|
| <b>①</b> | VIN *) (stamped in the bodywork)<br>* Vehicle identity number | <b>④</b> | Engine nameplate with serial number   |
| <b>②</b> | Machine nameplate with serial number                          | <b>⑤</b> | Option Ic only:<br>Inspection label for the diesel particle filter<br>(on fan casing) |
| <b>③</b> | Combined label for coupling loading and<br>built-in options   |          |   |

### 13.2 Pipeline and instrument flow diagram (P+I diagram)



1	Compressor - Air filter	30	Coupling
2	Filter maintenance indicator, Compressor -Air filter	37	Minimum pressure / check valve (without air treatment)
3	Inlet valve	39	Check valve
4	Airend	41.1	Solenoid valve - Full load control
5	Oil separator tank	41.2	Solenoid valve - Inlet control
5.2	Screw plug	43	V-belt
6	Oil reserve	44	Defroster
7	Oil separator cartridge	44.1	Shut-off valve
11	Oil filler with screw plug	44.2	Solenoid valve
12	Temperature gauge switch + Indication	46	Nozzle (Secondary end Proportional controller)
13	Pressure relief valve	52	Control valve
14	Pressure gauge - Control panel	56	Water cooler
15	Diesel engine	56.1	Cooling water expansion tank
15.2	Hose coupling - Oil drain	56.7	Screw plug - Water drain
16	Oil return line	56.10	Water filling port with plug and pressure relief valve
17	Dirt trap	62	Combined control valve
17.1	Nozzle	63	Control valve (Air circulation valve)
18	Strainer	64	Generator
19	Combination valve - Oil temperature controller	72	Fail-safe heat exchanger
20	Oil cooler	73	Exhaust silencer with particulate filter
20.5	Screw plug - Oil drain	83.1	Engine air intake shut-off valve (automatic shutoff)
21	Oil filter	84	Spark arrestor
23	Proportional controller	Option	
24	Motor - Air filter	ba	Low temperature equipment
25	Filter maintenance indicator, Motor - Air filter	bb	Cooling water pre-heating
26	Engine speed adjusting piston	ga	Generator
27	Venting valve	la	Spark arrestor
28	Fan	lb	Engine air intake shut-off valve (automatic shutoff)
29	Exhaust silencer	lc	Diesel particulate filter

P&I Diagram legend		KAESER	
Mobilair		KOMPRESSOREN	
a Änderung	Datum	Ersatz durch:	Ursprung: FFMM5270-01005.02
b	Name	Gef.: Norm	M 52 / M 64 / M 70
c	Berib.	Datum	FFMM5270-01005.03
d	Piau	Grinn	Blatt 2
e			E




1	2	3	4	5	6	7	8
9	Tool lubricator						Option
9.1	Shut-off valve						
10	Compressed air distributor						da Aftercooler + Centrifugal separator
10.7	Hose line						db Heat exchanger
32	Air cooler						dc Breathing air filter
33	Centrifugal separator						dd Filter combination
33.1	Dir† trap						ec tool lubricator, with option fc
33.2	Nozzle						fa Direct air flow
34	Heat exchanger						fc Air flow split downstream of options
34.3	Shut-off valve - Oil drain						ua Hose reel
35	Breathing air filter						
35.1	Hose coupling						
35.2	Nozzle						
36	Filter combination						
36.1	Shut-off valve for condensate drain						
37	Minimum pressure / check valve (with air treatment)						
39	Check valve						
39.1	Shut-off valve						

c		Datum	11.07.2006	P&I Diagram legend	<b>KAESER</b>		
b		Berch.	Plau	Mobilair M 52/M 64/M 70	KOMPRESSOREN		
a	Änderung	Datum	Name	Ersatz durch:	Ersatz für:	Ursprung:	
						FFMM120DIAO-01001.01	FFMM270DIAO-01006.00
							Blatt 2 E

**13.3 Dimensional drawings****13.3.1 Option sa****Dimensional drawing - chassis with height-adjustable tow bar**


RAMIRENT



## 13.3.2 Option sd

Dimensional drawing, chassis with fixed height tow bar


RAMIRENT



## 13.3.3 Option sh

Dimensional drawing, chassis without parking brake


RAMIRENT



## 13.3.4 Option sc

Dimensional drawings of stationary machine (skids)


RAMIRENT



## 13.3.5 Option si

Dimensional drawings of stationary machine (base frame)

RAMIRENT



## 13.4 Wiring diagrams

### 13.4.1 Electrical Diagram

RAMIRENT

Electrical diagrams

MOBILAIR

M57, M52/M64/M70

KUBOTA-Motor

Manufacturer: Kaeser Kompressoren GmbH  
Postfach 2143  
96410 Coburg

The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.

Lfd. Nr. No.	Benennung Name	Zeichnungssummer (Kunde) Drawing No. (customer)	Zeichnungssummer (Hersteller) Drawing No. (manufacturer)	Blatt Page	Anlagenkennzeichen Unit designation
1	Cover page		DFA5764-01071.00	1	
2	List of contents		ZFA5764-01071.00	1	
3	Block diagram		UFA5764-01071.00	1	
4	Block diagram	Cross-reference	UFA5764-01071.00	2	
5	Circuit diagram	Cable set Battery	SFA5764_BK-01071.00	1	=BK
6	Circuit diagram	Compressor - unit	SFA5764_IKM-01071.00	1	=IKM
7	Circuit diagram	Control	SFA5764_BT-01071.00	1	=BT
8	Circuit diagram	Control	SFA5764_BT-01071.00	2	=BT
9	Circuit diagram	Cable set Control	SFA5764_IK1-01071.00	1	=IK1
10	Electrical equipment identification	Cable set generator	SFA5764_IK2-01071.00	1	=IK2
11	Circuit diagram	low temperature equipment	SFA5764_IK3-01071.00	1	=IK3
12	Equipment parts list		GFA5764-01071.00	1	

c		Datum 13.02.2009			=
b		Bearb. Weid			+
a		Gepr. Weid			
b	Änderung	Datum Name Norm	Ersatz durch:	Ersatz für:	
					ZFA5764-01071.00 Blatt 1 Bl.


<b>general instructions</b>																																		
Control voltage 12VDC All non-designated conductors H07V-K 1,5mm <sup>2</sup> black																																		
1	2	3	4	5	6	7	8																											
<b>components unit</b>																																		
<p>-G1 Battery</p> <p>-M1 Starter-Motor</p> <p>-B0 Oil pressure switch Motor</p> <p>-B7 Cooling water-Thermostat</p> <p>-G2 Alternator</p> <p>-M2 fuel pump</p> <p>-R10 heating flange</p> <p>-Y1 Fuel shut-off valve</p> <p>-Y3 Valve Full load operation, Venting</p>																																		
<b>components Control panel</b>																																		
<p>potentials:</p> <p>15 switched plus + (unit ON)</p> <p>19 Preheat with glowplug</p> <p>30 + terminal (Battery)</p> <p>31 - terminal (Battery), earth</p> <p>50 Starter-Control</p>																																		
<p>-B6 Distance temperature gauge Compressor airend</p> <p>-F1 Control fuse</p> <p>-F3 Fuse Glowplug</p> <p>-F4 Fuse Starter</p> <p>-H0 Charging control lamp</p> <p>-H8 Indicator light Back pressure</p> <p>-K3 Starter - Relay</p> <p>-K4 Relay Safety chain</p> <p>-K9 Relay Full load operation</p> <p>-K26 glow relay</p> <p>-K29 Relay fuel pump</p> <p>-P8 Hour meter</p> <p>-S01 switch "Control ON"</p> <p>-S1 Ignition switch</p>																																		
<p>0 = STOP</p> <p>1 = ON</p> <p>2 = Preheat with glowplug</p> <p>3 = START</p>																																		
<b>model-dependent components</b>																																		
<p>-S0 Battery isolating switch (option oa)</p> <p>-Y5 option generator: Valve FAD limitation</p> <p>-Y6 option generator:</p> <p>Valve for the motor speed</p> <p>full load control</p> <p>option: Valve defroster</p> <p>Plug connection, Generator control box</p>																																		
<p>-S7/-H7 Illuminated pushbutton</p> <p>-X21,-X24, Preselection Full load operation</p> <p>-X25,-X27 Plug connection, Control panel</p> <p>-X42 Terminal strip, Control panel</p>																																		
<table border="1"> <thead> <tr> <th colspan="2">KAESER</th> <th colspan="2">Block diagram general instructions</th> </tr> <tr> <th colspan="2">KOMPRESSOREN</th> <th colspan="2">Ursprung: AF-A1070_01</th> </tr> </thead> <tbody> <tr> <td>c</td><td>Datum: 13.02.2009</td><td>Ersatz durch:</td><td>Ersatz für:</td></tr> <tr> <td>b</td><td>Bearb. Weid</td><td colspan="2">+</td></tr> <tr> <td>a</td><td>Gehr. Weid</td><td colspan="2"></td></tr> <tr> <td>c1 Änderung</td><td>Datum Name</td><td colspan="2">Blatt 1</td></tr> <tr> <td></td><td></td><td colspan="2">Bl. 1.</td></tr> </tbody> </table>							KAESER		Block diagram general instructions		KOMPRESSOREN		Ursprung: AF-A1070_01		c	Datum: 13.02.2009	Ersatz durch:	Ersatz für:	b	Bearb. Weid	+		a	Gehr. Weid			c1 Änderung	Datum Name	Blatt 1				Bl. 1.	
KAESER		Block diagram general instructions																																
KOMPRESSOREN		Ursprung: AF-A1070_01																																
c	Datum: 13.02.2009	Ersatz durch:	Ersatz für:																															
b	Bearb. Weid	+																																
a	Gehr. Weid																																	
c1 Änderung	Datum Name	Blatt 1																																
		Bl. 1.																																
<p>UFA5764-01071.00</p>																																		


module	Electrical diagrams	Cross-reference
Cable set: connection Battery	SFA5764.BK-01071.00	BK
Cable set: connection Motor	SFA5764.IKM-01071.00	IKM
cabling Control panel	SFA5764.BT-01071.00	BT
cabling unit components 1	SFA5764.IKI-01071.00	IK1
cabling unit components 2	SFA5764.IK2-01071.00	IK2
cabling unit components 3	SFA5764.IK3-01071.00	IK3


### general instructions


This document includes a common electrical diagram, consisting of documents:


c		Datum 13.02.2009			
b		Bearb. Weid			*
a		Gegr. Weid			
c2 Änderung	Datum	Name Norm	Ersatz durch:	Ersatz für:	UFA5764-01071.00 Blatt 2 Bl.

















A Stück- zahl Qty.	B Benennung und Verwendung Description and function	C Fabrikat-schzeichnung Type notwendige Techn. Daten (z.B. Steuerspannung, Frequenz, Einstellbereich); Bestell-Nr.; Hersteller Identification data Type; basic technical data (e.g. control voltage, frequency, adjustable range); order No.; manufacturer	D Lfd. Nr. Item	E Betriebsmittel-Kennz. nach DIN 4079, Teil 2 Identifying symbol of device	F Stromlaufplan Planabschnitt	G Erbauort	H Wst.-Nr.	I Schabl. Nr.	J BZ- Pos.	VA Kz. *)	K Eingangs- vermerk
1	Ignition switch	4.7.14.08	7.2097.00020 KEV A	-S1							
1	Control voltage ON/OFF switch	26 00 00	12/24 V 15/7.5 A	8.7055.0 MERIT	-S01						
1	Illuminated pushbutton green	RKTIME+T20F5GN+BSRXU	7.9027.10010 SCHLEGEL	-S7/-H7							
1	Switching element	BT15	2W	7.9027.10030 SCHLEGEL	-S7/-H7						
1	Lamp	T5.5K-12	12 V/1.2 W	7.9027.10060 SCHLEGEL	-S7/-H7						
1	Indicator light red		12 V// red	7.9027.10200 SCHLEGEL	-H0						
1	Lamp	W2x4,6-12V	12 V/1.0 W	8.7030.0 SCHLEGEL	-H0						
2	KFZ-Relay	22 200 111	12 V, 15...70 A	8.6544.00030 WEHRLE	-K3,-K26						
3	KFZ-Relay	20 201 100	12 V, 1W, 20/30 A	8.6544.0 WEHRLE	-K4,-K9,-K29						
2	Relay socket	10 700 007		7.3411.00010 WEHRLE	-K3,-K26						
3	Relay socket	10 485 008		7.3411.0 WEHRLE	-K4,-K9,-K29						
1	Fuse socket 1-pole			7.6410.00010 L&K	-F3						
1	Fuse		50 A	7.6411.0 L&K	-F3						
1	Fuse socket 4-pole			7.6411.00010 L&K	-F1,-F4,-F5						
1	UNIVAL-Fuse		15 A	7.6411.00060 L&K	-F1						
1	UNIVAL-Fuse		25 A	7.6411.00070 L&K	-F4						
<b>model-dependent components</b>											
option 02:											
1	Battery isolating switch	DC 24 V	500 A, 2500 A 10s	7.5708.00030 HELLA	-S0						
Bei Nachbestellung von Geräten und Maschinen sind alle in den stark umrandeten Spalten B und C angegebenen Daten aufzuführen. Die Daten in den Spalten D bis G sind zusätzlich unter Nennung dieser Gerätbestückungs-Nummer anzugeben, soweit sie die Baumvorführung technischer Rückfragen erleichtern. Für Ersatzteilebestellung ist zusätzlich die Angabe der Seriennummer erforderlich, falls diese auf dem Typenschild des Erzeugnisses genannt ist.											
In Zweifelsfällen gilt die deutsche Fassung.											
c		Datum	13.02.2009								
b		Bearb.	Weid								
a		Gepr.	Weid								
F Änderung	Datum	Name	Norm	Ersatz für:	Ursprung:	AF01070_01	MOBILAIR M57, M52/64/70	KAESER KOMPRESSOREN	Equipment parts list	GF A5764-01071.00	Blatt 1 Bl.

\*) Versandanschrift – Kennzeichen

When reordering the equipment, all data enclosed by the heavy lines of columns B and C should be stated. In addition, the data in columns D to G should go together with the No. of this list of equipment, insofar as they are helpful in answering technical enquiries. When ordering spare parts, also quote the serial No. of the product if stated on the rating plate.

The German version applies in cases of doubt.

13.4.2 Option Ic  
Connection adapter for the diesel particulate filter

RAMIRENT

1	2	3	4	5	6	7	8
---	---	---	---	---	---	---	---


**Electrical diagrams**

**MOBILAIR**  
**connection – Adapter**  
**Control Diesel particulate filter**

Manufacturer: KAESER Kompressoren GmbH  
Postfach 2143  
96410 Coburg


The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.


c		Datum 20.05.2008	E				=
b		Bearb.	Weid				+
a		Gegr.	Weid				
A Änderung	Datum	Name	Norm	Ersatz durch:	Ersatz für:	Ursprung: AFa0120_00	Blatt 1 Bl.



Function:		Group of functions:	
c		Datum: 20.05.2008	
b		Bearb.: Weid	=
a		Gehr.: Weid	+
d Änderung	Datum	Name	Norm
		Ersatz durch:	Ersatz für:
			Ursprung: AF01120_00
			SFAKA.DPF-01123.00
			Blatt 1 Bl.

MOBILAIR M64, M80: Adapter connection Control Diesel particulate filter






**13.4.3 Option tc**  
**Lighting and signalling system connection**

RAMIRENT


1		2		3		4		5		6		7		8
---	--	---	--	---	--	---	--	---	--	---	--	---	--	---





Manufacturer: KAESER Kompressoren GmbH  
Postfach 2143  
96410 Coburg

The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.

c		Datum 02.07.2008	E	KAESER	Cover page	=
b		Bearb.	Weid	KOMPRESSOREN		+
a		Gepr.	Weid			
d	Änderung	Datum	Name	Ersatz für:	Ursprung: AF02003_01	Blatt 1 Bl.
			Norm		DFAEUR.BEL-02003.01	










Function:		Group of functions:		Circuit diagram		Circuit diagram	
c		Datum	07.07.2008	Bearb.	Weid	Gegr.	Weid
b							
a	Änderung	Datum	Name	Norm	Ersatz durch:	Ursprung:	AFA2003_01
d							SFAEUR.BEL-02003_01

Blatt 1

Bl.







**13.4.4 Option te  
Lighting and signalling system connection**


RAMIRENT


Electrical diagrams  
MOBILAIR  
Lighting equipment  
for USA / CAN


Manufacturer: KAESER Kompressoren GmbH  
Postfach 2143  
96410 Coburg

The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.

c		Datum 04.07.08	E	KAESER	Cover page	=
b		Bearb.	Weid	KOMPRESSOREN		+
a		Gepr.	Weid			
d	Änderung	Datum	Name	Ersatz für:	Ursprung:	
			Norm		AF-A00909_00	DFAUSA.BEL-02004.00
						Blatt 1
						Bl.







## 13.4.5 Option ga

Generator electrical diagram, 400 V, 3-ph

RAMIRENT

1	2	3	4	5	6	7	8
---	---	---	---	---	---	---	---

**Electrical diagrams**

Synchronous generator  
400V / 3~/50Hz, 8,5/13 kVA  
with Insulation monitoring

Manufacturer: KAESER Kompressoren GmbH  
Postfach 2143  
96410 Coburg


The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.


c		Datum 22.10.2010	E				=
b		Bearb.	Weid				+
a		Gepr:	Weid				
A Änderung	Datum	Name	Norm	Ersatz durch:	Ersatz für:	Ursprung: AEG0921_02	Blatt 1 Bl.


DGENGT S.4 S4-00932.00

Lfd. Nr. No.	Benennung Name	Zeichnungsnr. Drawing No. (customer)	Zeichnungsnr. (Hersteller) Drawing No. (manufacturer)	Blatt Page	Anlagenkennzeichen Unit designation
1	Cover page		DGENGT S.454-00932.00	1	
2	List of contents		ZGENT S.454-00932.00	1	
3	Circuit diagram		SGENT S.454-00932.00	1	
4	Circuit diagram		SGENT S.454-00932.00	2	
5	Circuit diagram		SGENT S.454-00932.00	4	
6	Electrical equipment identification		SGENT S.454-00932.00	01	
7	Circuit diagram		GGENT S.454-00932.00	1	
8	Component layout		AGENT S.454-00932.00	1	

c		Datum 26.10.2010			=
b		Bearb. Weid			+
a		Gepr. Weid			
B Änderung	Datum	Name	Ersatz durch:	Ersatz für:	ZGENT S.454-00932.00
		Norm			Blatt 1 Bl.








1	2	3	4	5	6	7	8
-A3	generator-Regulator						
-F01	Cut-out with overcurrent release						
-F03	Insulation monitoring						
-G3	generator						
-H03	Earth leak lamp						
-Q1	Main switch						
-S3	Test button, Insulation monitoring						
-S10	Selector switch						
-X4	connection generator						
-X5	Socket outlet 400V/3-/N/PE, 50Hz						
-X6,-X7,-X8	Socket outlet 230V/1~/N/PE,50Hz						
-X42	Terminal strip, Valve interference suppression						

Bei Nachbestellung von Gerüten und Maschinen sind alle in den stark umgedrehten Spalten B und C angegebenen Daten aufzutragen. Die Daten in den Spalten D bis G sind zusätzlich unter Nennung dieser Gerätekennziffern-Nummer anzugeben, sowie die Bezeichnung technischer Rückfragen erlaubt. Für Erstausrüstung bestellende Unternehmen ist zusätzlich die Angabe ihrer Seriennummer erforderlich, falls diese auf dem "Warenkunden" der Erstausrüstung genannt ist.

• Verzandsanschrift – Kennzeichen  
When sending the heavy lines of columns B and C should be fastened. In addition, when sending the data in columns D to G should be given together with the No. of the set of equipment issued as well as the serial No. of the equipment. When ordering technical enquiries, when ordering spare parts, also quote the serial No. of the product if stated on the technical prints.

卷之三

In Zweifelsfällen gilt die deutsche Fassung.



## 13.4.6 Option ga

Generator electrical diagram, 230 V, 3-ph

RAMIRENT

1		2		3		4		5		6		7		8
---	--	---	--	---	--	---	--	---	--	---	--	---	--	---

**Electrical diagrams**  
**Synchronous generator**  
**230V/3~/50Hz, 8,5/13kVA**  
**with Insulation monitoring**

Manufacturer: KAESER Kompressoren GmbH  
Postfach 2143  
96410 Coburg

The drawings remain our exclusive property. They are entrusted  
only for the agreed purpose. Copies or any other reproductions,  
including storage, treatment and dissemination by use of  
electronic systems must not be made for any other than the  
agreed purpose. Neither originals nor reproductions must be  
forwarded or otherwise made accessible to third parties.


c		Datum 22.02.2006	E	KAESER	Cover page	=
b		Bearb.	Weid	KOMPRESSOREN	Synchronous generator GTS	+
a		Gepr.	Weid		Ursprung: AG0924_01	
A Änderung	Datum	Name	Norm	Ersatz durch:	Ersatz für:	DGEGTS.2S3-00924_02
						Blatt 1
						Bl.

Lfd. Nr. No.	Benennung Name	Zeichnungskennzeichen Drawing No. (customer)	Zeichnungskennzeichen Drawing No. (Manufacturer)	Blatt Page	Anlagenkennzeichen Unit designation
1	Cover page		DGENGT.S.253-00924.02	1	
2	List of contents		ZGENGT.S.253-00924.02	1	
3	Circuit diagram		SGENGT.S.253-00924.02	1	
4	Circuit diagram	Insulation monitoring	SGENGT.S.253-00924.02	2	
5	Circuit diagram	socket panel	SGENGT.S.253-00924.02	3	
6	Electrical equipment identification		SGENGT.S.253-00924.02	01	
7	Equipment parts list		GGENGT.S.253-00924.02	1	
8	Component layout	front plate	AGENGT.S.253-00924.02	1	


c		Datum 22.02.2006		=
b		Bearb. Weid		+
a		Gepr. Weid		
B Änderung	Datum	Name Norm	Ersatz durch:	Ersatz für:


Blatt 1  
Bl.

ZGENGT.S.253-00924.02



Function:	Synchronous generator	Regulation	Insulation monitoring	Main switch
Function:	Compressor			Cut-out
Group of functions:			front plate Generator control box / socket panel	
c		Datum: 22.02.2006		=
b		Bearb.: Weid		+
a		Gehr.: Weid		
⊕ Änderung	Datum	Name	Ersatz durch:	Ursprung: AGE0924_01 Blatt 1 SGENGTS.2S3-00924_02 Bl. 1





1	2	3	4	5	6	7	8
-A3	generator-Regulator						
-F01	Cut-out with overcurrent release						
-F02	Cut-out						
-F03	Insulation monitoring						
-G3	generator						
-H03	Earth leak lamp						
-Q1	Main switch						
-S3	Test button, Insulation monitoring						
-S10	Selector switch						
-X4	Generator terminals						
-X5	Socket outlet 230V/3~/PE, 50Hz 16A						
-X6,-X7	Socket outlet 230V/2~/PE, 50Hz 16A						
-X9	Socket outlet 230V/3~/PE, 50Hz 32A						
-X42	Plug connection, Valve interference suppression						

c		Datum 22.02.2006		=
b		Bearb. Weid		+
a		Gegr. Weid		
E Änderung	Datum	Name Norm	Ersatz durch:	Ursprung: AEG0924_01 Blatt 01 SGEENGTS.2SS-00924_02 Bl.

Bei Nachbereitung von Gesten und Maschinen sind alle in den stark umgearbeiteten Spalten B und C angegebenen Daten in die Spalten D bis G sind zusätzlich unter Verwendung dieser Gestikstypen-Nummer einzutragen, sofern es die Bearbeitungsvorrichtung technisch Rückfrage auf dem Typenschild ist, zusätzlich alle Angabe der Zerhauung erforderlich, füllt dies auf dem Typenschild das Erzeugnisfeld genannt ist.

When reordering the equipment, all data enclosed by the heavy lines of columns B and C should be stated. In addition, the data in columns D to G should be given together with the No. of this list of equipment, insofar as they are helpful in answering technical enquiries. When ordering spare parts, also quote the serial No. of the product if stated on the rating plate.


\*) Versandanschrift - Kennzeichen

The German in Zweifelsfällen gilt die deutsche Fassung.

The German version applies in cases of doubt.

The German version applies in cases of doubt.

**KAESER**  
KOMPRESSOREN      Equipment parts list  
Synchronous generator GTS



13.4.7 Option ga  
Generator electrical diagram, 115 V, 2-ph

RAMIRENT

1	2	3	4	5	6	7	8
---	---	---	---	---	---	---	---

**Electrical diagrams**

Synchronous generator GTS  
7/5 kVA, 115 V 50Hz  
with Insulation monitoring


Manufacturer: KAESER Kompressoren GmbH  
Postfach 2143  
96410 Coburg


The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.


c		Datum 22.02.2006	E				=
b		Bearb.	Weid				+
a		Gepr:	Weid				
A Änderung	Datum	Name	Norm	Ersatz durch:	Ersatz für:	Ursprung: AEG0923_00	DGEN071S2-00923_01
							Blatt 1 B1.

Lfd. Nr. No.	Benennung Name	Zeichnungsnr. Drawing No. (customer)	Zeichnungsnr. (Hersteller) Drawing No. (manufacturer)	Blatt Page	Anlagenkennzeichen Unit designation
1	Cover page Synchronous generator		DGEN07.1S2-00923.01	1	
2	List of contents		ZGEN07.1S2-00923.01	1	
3	Circuit diagram		SGEN07.1S2-00923.01	1	
4	Circuit diagram evaluating electronics		SGEN07.1S2-00923.01	2	
5	Circuit diagram socket panel		SGEN07.1S2-00923.01	3	
6	Electrical equipment identification		SGEN07.1S2-00923.01	01	
7	Circuit diagram		GGEN07.1S2-00923.01	1	
8	Component layout front plate		AGEN07.1S2-00923.01	1	

c	b	a	Blatt 1
			=
			+
			ZGEN07.1S2-00923.01
			Bl. 1








1	2	3	4	5	6	7	8
-A3	generator-Regulator						
-F01	Cut-out with overcurrent release						
-F06,-F07	Cut-out						
-F03	Insulation monitoring						
-G3	generator						
-H3	Earth leak lamp						
-Q1	Main switch						
-S3	Test button, Insulation monitoring						
-S10	Selector switch						
-X4	Generator terminals						
-X6,-X7	Socket outlet 115V/2~/PE, 50Hz 16A						
-X9	Socket outlet 115V/2~/PE, 50Hz 32A						
-X42	Plug connection, Valve interference suppression						

Bei Nachbestellung von Geräten und Maschinen sind alle in den stark umrandeten Spalten B und C angegebenen Daten aufzuführen. Die Daten in den Spalten D bis G sind zusätzlich unter Nennung dieser Gerätbestellkenn-Nummer anzugeben, sowie die Bezeichnung technischer Rückfrage erleichtern. Für das Erzeugnisbestell-Nr. ist zusätzlich die Angabe einer Seriennummer erforderlich falls diese auf dem Typenschild des Erzeugnisses genannt ist.

• Verzandsanschrift – Kennzeichen  
When sending the heavy lines of columns B and C should be fastened. In addition, when sending the data in columns D to G should be given together with the No. of the set of equipment issued as well as the serial No. of the equipment. When ordering technical enquiries, when ordering spare parts, also quote the serial No. of the product if stated on the technical sheets.

The German version applies in cases of doubt.



## 13.4.8 Option ga

Generator electrical diagram, 230 V, 2-ph

RAMIRENT

**Electrical diagrams**

**Synchronous generator GTS  
8/5 kVA, 125/250 V 60Hz  
with Insulation monitoring**

Manufacturer: KAESER Kompressoren GmbH  
Postfach 2143  
96410 Coburg


The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.


c		Datum 24.10.2006	E	KAESER	Cover page	=
b		Bearb.	Weid	KOMPRESSOREN	MOBILAIR	+
a		Gepr.	Weid			
A Änderung	Datum	Name	Norm	Ersatz durch:	Ersatz für:	Ursprung: AG010928-00 Blatt 1 DGENGTS.1S2-00928.01 Bl.


Lfd. Nr. No.	Benennung Name	Zeichnungsummer (Kunde) Drawing No. (customer)	Zeichnungsummer (Hersteller) Drawing No. (Manufacturer)	Blatt Page	Anlagenkennzeichen Unit designation
1	Cover page	Synchronous generator	DGENGT S.IS2-00928.01	1	
2	List of contents		ZGENGT S.IS2-00928.01	1	
3	Circuit diagram		SGENGT S.IS2-00928.01	1	
4	Circuit diagram	evaluating electronics	SGENGT S.IS2-00928.01	2	
5	Circuit diagram	socket panel	SGENGT S.IS2-00928.01	3	
6	Electrical equipment identification	Electrical equipment identification	SGENGT S.IS2-00928.01	01	
7	Circuit diagram		GGENT S.IS2-00928.01	1	
8	Component layout	front plate	AGENT S.IS2-00928.01	1	

c		Datum 24.10.2006		=
b		Bearb. Weid		+
a		Gegr. Weid		
B Änderung	Datum	Name Norm	Ersatz durch:	Ersatz für: Ursprung: A&E00928_00

 ZGENGT S.IS2-00928.01  
 Blatt 1  
 Bl.







1	2	3	4	5	6	7	8
-A3	generator-Regulator						
-F01	Cut-out with overcurrent release						
-F06,-F07	Cut-out						
-F03	Insulation monitoring						
-G3	generator						
-H3	Earth leak lamp						
-Q1	Main switch						
-S3	Test button, Insulation monitoring						
-S10	Selector switch						
-X4	Generator terminals						
-X6,-X7	Socket outlet 125 V/2~/PE, 60 Hz 20 A						
-X8,-X9	Socket outlet 250 V/2~/PE, 60 Hz 20 A						
-X42	Plug connection, Valve interference suppression						

c		Datum 24.10.2006		=
b		Bearb. Weid		+
a		Gegr. Weid		
E Änderung	Datum	Name Norm	Ersatz durch:	Ursprung: AEGE0928_00
				SGENGT.S.1S2 - 00928.01
				Blatt 01 Bl.

Bei Nachbestellung von Geräten und Maschinen sind alle in den stark umrandeten Spalten B und C angegebenen Daten einzutragen und aufzuführen. Die Daten in den Spalten D bis G sind zusätzlich unter Nutzung dieser Geleitstückslisten-Kennmerke einzutragen. Bei der Auslieferung technischer Rückfragen erleichtert dies die Ersatzteilbereitstellung des Erzeugnisses.

When reordering the equipment, all data enclosed by the heavy lines of columns B and C should be stated. In addition, the data in columns D, E and F should be given together with the No. of this list of equipment, insofar as they are helpful in answering technical enquiries. When ordering spare parts, also quote the serial No. of the equipment and the serial No. of the order.


\* ) Versandanschrift = Kennzeichen

The German Translation of Zweifel's Fällen gilt die deutsche Fassung.

The German version applies in cases of doubt.


The German version applies in cases of doubt.


In Zweifelsfällen gilt die deutsche Fassung.



## 13.5 Fuel circulation diagram

RAMIRENT





13.6 Option dd

Operating instructions for compressed air filter (combination filter)

RAMIRENT


## Bedienungsanleitung Instruction Manual

Hochleistungs - Druckluftfilter

Compressed-air filters

Serie / Series

FA (D), FB (D&E), FC (D&E), FD (E), FE (D&E), FF (D&E), FG



Kaeser Kompressoren GmbH  
Postfach 2143  
96410 Coburg  
Tel.: 09561/640-0  
Fax: 09561/640130  
<http://www.kaeser.com>

**KAESER**

gültig ab 01.04.2007

D

GB

A	Kap. 9.2, 9.3 Wartungsintervalle	04.12.08	SK
Änd. Mittg.		Datum	Bearb.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

FI HANK-MOB\_02 D E

**Materialkennzeichnung**
**Sign of material**

Filter: Standard		Filter: D-Pack		Filter: Element/Cartrigde	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.
FA-6	9.4600.0	FA-6 D	9.4600.00110	E-A-6	9.4800.0
FA-10	9.4601.0	FA-10 D	9.4601.00110	E-A-10	9.4801.0
FA-18	9.4602.0	FA-18 D	9.4602.00110	E-A-18	9.4802.0
FA-28	9.4603.0	FA-28 D	9.4603.00110	E-A-28	9.4803.0
FA-48	9.4604.0	FA-48 D	9.4604.00010	E-A-48	9.4804.0
FA-71	9.4605.0	FA-71 D	9.4605.00010	E-A-71	9.4805.0
FA-107	9.4606.0	FA-107 D	9.4606.00010	E-A-107	9.4806.0
FA-138	9.4607.0	FA-138 D	9.4607.00010	E-A-138	9.4807.0
FA-177	9.4608.0	FA-177 D	9.4608.00010	E-A-177	9.4808.0
FA-221	9.4609.0	FA-221 D	9.4609.00010	E-A-221	9.4809.0
FA-185	9.4610.0	FA-185 D	9.4610.00010	E-A-185	9.4810.0
FA-283	9.4611.0	FA-283 D	9.4611.00010	E-A-283	9.4811.0
FA-354	9.4612.0	FA-354 D	9.4612.00010	E-A-185	9.4810.0
FA-526	9.4613.0	FA-526 D	9.4613.00010	E-A-185	9.4810.0
FA-708	9.4614.0	FA-708 D	9.4614.00010	E-A-185	9.4810.0
FA-885	9.4615.0	FA-885 D	9.4615.00010	E-A-185	9.4810.0
FA-1420	9.4616.0	FA-1420 D	9.4616.00010	E-A-185	9.4810.0
FA-1950	9.4617.0	FA-1950 D	9.4617.00010	E-A-185	9.4810.0
FA-2480	9.4618.0	FA-2480 D	9.4618.00010	E-A-185	9.4810.0

D-Pack: Filter mit ECO-DRAIN /

D-Pack: Filter with ECO-DRAIN

Filter: Standard		Filter: D-Pack Basic		Filter: D-Pack		Filter: E-Pack		Filter: Element/Cartrigde	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Typ/Type	Typ/Type	Nr./No.
FB-6	9.4620.0	FB-6 B	9.4620.00110	FB-6 D	9.4620.00120	FB-6 E	E-B-6	9.4812.0	
FB-10	9.4621.0	FB-10 B	9.4621.00110	FB-10 D	9.4621.00120	FB-10 E	E-B-10	9.4813.0	
FB-18	9.4622.0	FB-18 B	9.4622.00110	FB-18 D	9.4622.00120	FB-18 E	E-B-18	9.4814.0	
FB-28	9.4623.0	FB-28 B	9.4623.00110	FB-28 D	9.4623.00120	FB-28 E	E-B-28	9.4815.0	
FB-48	9.4624.0	FB-48 B	9.4624.00110	FB-48 D	9.4624.00120	FB-48 E	E-B-48	9.4816.0	
FB-71	9.4625.0	FB-71 B	9.4625.00110	FB-71 D	9.4625.00120	FB-71 E	E-B-71	9.4817.0	
FB-107	9.4626.0	FB-107 B	9.4626.00110	FB-107 D	9.4626.00120	FB-107 E	E-B-107	9.4818.0	
FB-138	9.4627.0	FB-138 B	9.4627.00110	FB-138 D	9.4627.00120	FB-138 E	E-B-138	9.4819.0	
FB-177	9.4628.0	FB-177 B	9.4628.00110	FB-177 D	9.4628.00120	FB-177 E	E-B-177	9.4820.0	
FB-221	9.4629.0	FB-221 B	9.4629.00110	FB-221 D	9.4629.00120	FB-221 E	E-B-221	9.4821.0	
FB-185	9.4630.0	-	-	FB-185 D	9.4630.00120	FB-185 E	E-B-185	9.4822.0	
FB-283	9.4631.0	-	-	FB-283 D	9.4631.00120	FB-283 E	E-B-283	9.4823.0	
FB-354	9.4632.0	-	-	FB-354 D	9.4632.00120	FB-354 E	E-B-185	9.4822.0	
FB-526	9.4633.0	-	-	FB-526 D	9.4633.00120	FB-526 E	E-B-185	9.4822.0	
FB-708	9.4634.0	-	-	FB-708 D	9.4634.00120	FB-708 E	E-B-185	9.4822.0	
FB-885	9.4635.0	-	-	FB-885 D	9.4635.00120	FB-885 E	E-B-185	9.4822.0	
FB-1420	9.4636.0	-	-	FB-1420 D	9.4636.00020	FB-1420 E	E-B-185	9.4822.0	
FB-1950	9.4637.0	-	-	FB-1950 D	9.4637.00020	FB-1950 E	E-B-185	9.4822.0	
FB-2480	9.4638.0	-	-	FB-2480 D	9.4638.00020	FB-2480 E	E-B-185	9.4822.0	

D-Pack: Filter mit Differenzdruckmanometer und ECO-DRAIN

D-pack: Filter with differential pressure gauge and ECO-DRAIN

D-Pack-Basic: Filter mit Differenzdruckmanometer und ECO-DRAIN 30

D-pack-basic: Filter with differential pressure gauge and ECO-DRAIN 30

E-Pack: Filter mit Filtermonitor und ECO-DRAIN

E-pack: Filter with filtermonitor and ECO-DRAIN

Anzahl Filterelemente siehe Kapitel 3. „Technische Daten“.

Quantity of filter cartridges see chapter 3. „Technical data“.

- 2 -

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

FI HANK-MOB\_02 D E

**Materialkennzeichnung**
**Sign of material**

Filter: Standard		Filter: D-Pack Basic		Filter: D-Pack		Filter: E-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type		Typ/Type	Nr./No.
FC-6	9.4640.0	FC-6 B	9.4640.00110	FC-6 D	9.4640.00120	FC-6 E		E-C-6	9.4824.0
FC-10	9.4641.0	FC-10 B	9.4641.00110	FC-10 D	9.4641.00120	FC-10 E		E-C-10	9.4825.0
FC-18	9.4642.0	FC-18 B	9.4642.00110	FC-18 D	9.4642.00120	FC-18 E		E-C-18	9.4826.0
FC-28	9.4643.0	FC-28 B	9.4643.00110	FC-28 D	9.4643.00120	FC-28 E		E-C-28	9.4827.0
FC-48	9.4644.0	FC-48 B	9.4644.00110	FC-48 D	9.4644.00120	FC-48 E		E-C-48	9.4828.0
FC-71	9.4645.0	FC-71 B	9.4645.00110	FC-71 D	9.4645.00120	FC-71 E		E-C-71	9.4829.0
FC-107	9.4646.0	FC-107 B	9.4646.00110	FC-107 D	9.4646.00120	FC-107 E		E-C-107	9.4830.0
FC-138	9.4647.0	FC-138 B	9.4647.00110	FC-138 D	9.4647.00120	FC-138 E		E-C-138	9.4831.0
FC-177	9.4648.0	FC-177 B	9.4648.00110	FC-177 D	9.4648.00120	FC-177 E		E-C-177	9.4832.0
FC-221	9.4649.0	FC-221 B	9.4649.00110	FC-221 D	9.4649.00120	FC-221 E		E-C-221	9.4833.0
FC-185	9.4650.0	-	-	FC-185 D	9.4650.00120	FC-185 E		E-C-185	9.4834.0
FC-283	9.4651.0	-	-	FC-283 D	9.4651.00120	FC-283 E		E-C-283	9.4835.0
FC-354	9.4652.0	-	-	FC-354 D	9.4652.00120	FC-354 E		E-C-185	9.4834.0
FC-526	9.4653.0	-	-	FC-526 D	9.4653.00120	FC-526 E		E-C-185	9.4834.0
FC-708	9.4654.0	-	-	FC-708 D	9.4654.00120	FC-708 E		E-C-185	9.4834.0
FC-885	9.4655.0	-	-	FC-885 D	9.4655.00120	FC-885 E		E-C-185	9.4834.0
FC-1420	9.4656.0	-	-	FC-1420 D	9.4656.00020	FC-1420 E		E-C-185	9.4834.0
FC-1950	9.4657.0	-	-	FC-1950 D	9.4657.00020	FC-1950 E		E-C-185	9.4834.0
FC-2480	9.4658.0	-	-	FC-2480 D	9.4658.00020	FC-2480 E		E-C-185	9.4834.0

D-Pack: Filter mit Differenzdruckmanometer und ECO-DRAIN

D-pack: Filter with differential pressure gauge and ECO-DRAIN

D-Pack-Basic: Filter mit Differenzdruckmanometer und ECO-DRAIN 30

D-pack-basic: Filter with differential pressure gauge and ECO-DRAIN 30

E-Pack: Filter mit Filtermonitor und ECO-DRAIN

E-pack: Filter with filtermonitor and ECO-DRAIN

Filter: Standard		Filter: E-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type		Typ/Type	Nr./No.
FD-6	9.4660.0	FD-6 E	E-D-6		9.4836.0
FD-10	9.4661.0	FD-10 E	E-D-10		9.4837.0
FD-18	9.4662.0	FD-18 E	E-D-18		9.4838.0
FD-28	9.4663.0	FD-28 E	E-D-28		9.4839.0
FD-48	9.4664.0	FD-48 E	E-D-48		9.4840.0
FD-71	9.4665.0	FD-71 E	E-D-71		9.4841.0
FD-107	9.4666.0	FD-107 E	E-D-107		9.4842.0
FD-138	9.4667.0	FD-138 E	E-D-138		9.4843.0
FD-177	9.4668.0	FD-177 E	E-D-177		9.4844.0
FD-221	9.4669.0	FD-221 E	E-D-221		9.4845.0
FD-185	9.4670.0	FD-185 E	E-D-185		9.4846.0
FD-283	9.4671.0	FD-283 E	E-D-283		9.4847.0
FD-354	9.4672.0	FD-354 E	E-D-185		9.4846.0
FD-526	9.4673.0	FD-526 E	E-D-185		9.4846.0
FD-708	9.4674.0	FD-708 E	E-D-185		9.4846.0
FD-885	9.4675.0	FD-885 E	E-D-185		9.4846.0
FD-1420	9.4676.0	FD-1420 E	E-D-185		9.4846.0
FD-1950	9.4677.0	FD-1950 E	E-D-185		9.4846.0
FD-2480	9.4678.0	FD-2480 E	E-D-185		9.4846.0

E-Pack: Filter mit Filtermonitor

E-Pack: Filter with filtermonitor

Anzahl Filterelemente siehe Kapitel 3. „Technische Daten“.

Quantity of filter cartridges see chapter 3. „Technical data“.

- 3 -

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

FI HANK-MOB\_02 D E

**Materialkennzeichnung**
**Sign of material**

Filter: Standard		Filter: D-Pack Basic		Filter: D-Pack		Filter: E-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.
FE-6	9.4700.0	FE-6 B	9.4700.00110	FE-6 D	9.4700.00120	FE-6 E	E-E-6	9.4860.0	
FE-10	9.4701.0	FE-10 B	9.4701.00110	FE-10 D	9.4701.00120	FE-10 E	E-E-10	9.4861.0	
FE-18	9.4702.0	FE-18 B	9.4702.00110	FE-18 D	9.4702.00120	FE-18 E	E-E-18	9.4862.0	
FE-28	9.4703.0	FE-28 B	9.4703.00110	FE-28 D	9.4703.00120	FE-28 E	E-E-28	9.4863.0	
FE-48	9.4704.0	FE-48 B	9.4704.00110	FE-48 D	9.4704.00120	FE-48 E	E-E-48	9.4864.0	
FE-71	9.4705.0	FE-71 B	9.4705.00110	FE-71 D	9.4705.00120	FE-71 E	E-E-71	9.4865.0	
FE-107	9.4706.0	FE-107 B	9.4706.00110	FE-107 D	9.4706.00120	FE-107 E	E-E-107	9.4866.0	
FE-138	9.4707.0	FE-138 B	9.4707.00110	FE-138 D	9.4707.00120	FE-138 E	E-E-138	9.4867.0	
FE-177	9.4708.0	FE-177 B	9.4708.00110	FE-177 D	9.4708.00120	FE-177 E	E-E-177	9.4868.0	
FE-221	9.4709.0	FE-221 B	9.4709.00110	FE-221 D	9.4709.00120	FE-221 E	E-E-221	9.4869.0	
FE-185	9.4710.0	-	-	FE-185 D	9.4710.00120	FE-185 E	E-E-185	9.4870.0	
FE-283	9.4711.0	-	-	FE-283 D	9.4711.00120	FE-283 E	E-E-283	9.4871.0	
FE-354	9.4712.0	-	-	FE-354 D	9.4712.00120	FE-354 E	E-E-185	9.4870.0	
FE-526	9.4713.0	-	-	FE-526 D	9.4713.00120	FE-526 E	E-E-185	9.4870.0	
FE-708	9.4714.0	-	-	FE-708 D	9.4714.00120	FE-708 E	E-E-185	9.4870.0	
FE-885	9.4715.0	-	-	FE-885 D	9.4715.00120	FE-885 E	E-E-185	9.4870.0	
FE-1420	9.4716.0	-	-	FE-1420 D	9.4716.00020	FE-1420 E	E-E-185	9.4870.0	
FE-1950	9.4717.0	-	-	FE-1950 D	9.4717.00020	FE-1950 E	E-E-185	9.4870.0	
FE-2480	9.4718.0	-	-	FE-2480 D	9.4718.00020	FE-2480 E	E-E-185	9.4870.0	

D-Pack: Filter mit Differenzdruckmanometer und ECO-DRAIN

D-pack: Filter with differential pressure gauge and ECO-DRAIN

D-Pack-Basic: Filter mit Differenzdruckmanometer und ECO-DRAIN 30

D-pack-basic: Filter with differential pressure gauge and ECO-DRAIN 30

E-Pack: Filter mit Filtermonitor und ECO-DRAIN

E-pack: Filter with filtermonitor and ECO-DRAIN

Filter: Standard		Filter: D-Pack Basic		Filter: D-Pack		Filter: E-Pack		Filter: Element/Cartridge	
Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.	Typ/Type	Nr./No.
FF-6	9.4720.0	FF-6 B	9.4720.00110	FF-6 D	9.4720.00120	FF-6 E	E-F-6	9.4872.0	
FF-10	9.4721.0	FF-10 B	9.4721.00110	FF-10 D	9.4721.00120	FF-10 E	E-F-10	9.4873.0	
FF-18	9.4722.0	FF-18 B	9.4722.00110	FF-18 D	9.4722.00120	FF-18 E	E-F-18	9.4874.0	
FF-28	9.4723.0	FF-28 B	9.4723.00110	FF-28 D	9.4723.00120	FF-28 E	E-F-28	9.4875.0	
FF-48	9.4724.0	FF-48 B	9.4724.00110	FF-48 D	9.4724.00120	FF-48 E	E-F-48	9.4876.0	
FF-71	9.4725.0	FF-71 B	9.4725.00110	FF-71 D	9.4725.00120	FF-71 E	E-F-71	9.4877.0	
FF-107	9.4726.0	FF-107 B	9.4726.00110	FF-107 D	9.4726.00120	FF-107 E	E-F-107	9.4878.0	
FF-138	9.4727.0	FF-138 B	9.4727.00110	FF-138 D	9.4727.00120	FF-138 E	E-F-138	9.4879.0	
FF-177	9.4728.0	FF-177 B	9.4728.00110	FF-177 D	9.4728.00120	FF-177 E	E-F-177	9.4880.0	
FF-221	9.4729.0	FF-221 B	9.4729.00110	FF-221 D	9.4729.00120	FF-221 E	E-F-221	9.4881.0	
FF-185	9.4730.0	-	-	FF-185 D	9.4730.00120	FF-185 E	E-F-185	9.4882.0	
FF-283	9.4731.0	-	-	FF-283 D	9.4731.00120	FF-283 E	E-F-283	9.4883.0	
FF-354	9.4732.0	-	-	FF-354 D	9.4732.00120	FF-354 E	E-F-185	9.4882.0	
FF-526	9.4733.0	-	-	FF-526 D	9.4733.00120	FF-526 E	E-F-185	9.4882.0	
FF-708	9.4734.0	-	-	FF-708 D	9.4734.00120	FF-708 E	E-F-185	9.4882.0	
FF-885	9.4735.0	-	-	FF-885 D	9.4735.00120	FF-885 E	E-F-185	9.4882.0	
FF-1420	9.4736.0	-	-	FF-1420 D	9.4736.00020	FF-1420 E	E-F-185	9.4882.0	
FF-1950	9.4737.0	-	-	FF-1950 D	9.4737.00020	FF-1950 E	E-F-185	9.4882.0	
FF-2480	9.4738.0	-	-	FF-2480 D	9.4738.00020	FF-2480 E	E-F-185	9.4882.0	

D-Pack: Filter mit Differenzdruckmanometer und ECO-DRAIN

D-pack: Filter with differential pressure gauge and ECO-DRAIN

D-Pack-Basic: Filter mit Differenzdruckmanometer und ECO-DRAIN 30

D-pack-basic: Filter with differential pressure gauge and ECO-DRAIN 30

E-Pack: Filter mit Filtermonitor und ECO-DRAIN

E-pack: Filter with filtermonitor and ECO-DRAIN

Anzahl Filterelemente siehe Kapitel 3. „Technische Daten“.

Quantity of filter cartridges see chapter 3. „Technical data“.

**Materialkennzeichnung**
**Sign of material**

<b>Filter: Standard</b>		<b>Filter: Element/Cartridge</b>	
<b>Typ/Type</b>	<b>Nr./No.</b>	<b>Typ/Type</b>	<b>Nr./No.</b>
FG-6	9.4740.0	E-G-6	9.4884.0
FG-10	9.4741.0	E-G-10	9.4885.0
FG-18	9.4742.0	E-G-18	9.4886.0
FG-28	9.4743.0	E-G-28	9.4887.0
FG-48	9.4744.0	E-G-48	9.4888.0
FG-71	9.4745.0	E-G-71	9.4889.0
FG-107	9.4746.0	E-G-107	9.4890.0
FG-138	9.4747.0	E-G-138	9.4891.0
FG-177	9.4748.0	E-G-177	9.4892.0
FG-221	9.4749.0	E-G-221	9.4893.0
FG-185	9.4750.0	E-G-185	9.4894.0
FG-283	9.4751.0	E-G-283	9.4895.0
FG-354	9.4752.0	E-G-185	9.4894.0
FG-526	9.4753.0	E-G-185	9.4894.0
FG-708	9.4754.0	E-G-185	9.4894.0
FG-885	9.4755.0	E-G-185	9.4894.0
FG-1420	9.4756.0	E-G-185	9.4894.0
FG-1950	9.4757.0	E-G-185	9.4894.0
FG-2480	9.4758.0	E-G-185	9.4894.0

<b>Filter: Standard</b>		<b>Filter: D-Pack Basic</b>		<b>Filter: D-Pack</b>		<b>Filter: E-Pack</b>
<b>Typ/Type</b>	<b>Nr./No.</b>	<b>Typ/Type</b>	<b>Nr./No.</b>	<b>Typ/Type</b>	<b>Nr./No.</b>	<b>Typ/Type</b>
FFG-6	9.4760.0	FFG-6 B	9.4760.00110	FFG-6 D	9.4760.00120	FFG-6 E
FFG-10	9.4761.0	FFG-10 B	9.4761.00110	FFG-10 D	9.4761.00120	FFG-10 E
FFG-18	9.4762.0	FFG-18 B	9.4762.00110	FFG-18 D	9.4762.00120	FFG-18 E
FFG-28	9.4763.0	FFG-28 B	9.4763.00110	FFG-28 D	9.4763.00120	FFG-28 E
FFG-48	9.4764.0	FFG-48 B	9.4764.00110	FFG-48 D	9.4764.00120	FFG-48 E
FFG-71	9.4765.0	FFG-71 B	9.4765.00110	FFG-71 D	9.4765.00120	FFG-71 E
FFG-107	9.4766.0	FFG-107 B	9.4766.00110	FFG-107 D	9.4766.00120	FFG-107 E
FFG-138	9.4767.0	FFG-138 B	9.4767.00110	FFG-138 D	9.4767.00120	FFG-138 E
FFG-177	9.4768.0	FFG-177 B	9.4768.00110	FFG-177 D	9.4768.00120	FFG-177 E
FFG-221	9.4769.0	FFG-221 B	9.4769.00110	FFG-221 D	9.4769.00120	FFG-221 E
FFG-185	9.4770.0	-	-	FFG-185 D	9.4770.00120	FFG-185 E
FFG-283	9.4771.0	-	-	FFG-283 D	9.4771.00120	FFG-283 E
FFG-354	9.4772.0	-	-	FFG-354 D	9.4772.00120	FFG-354 E
FFG-526	9.4773.0	-	-	FFG-526 D	9.4773.00120	FFG-526 E
FFG-708	9.4774.0	-	-	FFG-708 D	9.4774.00120	FFG-708 E
FFG-885	9.4775.0	-	-	FFG-885 D	9.4775.00120	FFG-885 E
FFG-1420	9.4776.0	-	-	FFG-1420 D	9.4776.00020	FFG-1420 E
FFG-1950	9.4777.0	-	-	FFG-1950 D	9.4777.00020	FFG-1950 E
FFG-2480	9.4778.0	-	-	FFG-2480 D	9.4778.00020	FFG-2480 E

Filterkombination bestehend aus Serie FF &amp; FG

Filter combination consist of series FF &amp; FG

D-Pack: Filter mit Differenzdruckmanometer und ECO-DRAIN

D-pack: Filter with differential pressure gauge and ECO-DRAIN

D-Pack-Basic: Filter mit Differenzdruckmanometer und ECO-DRAIN 30

D-pack-basic: Filter with differential pressure gauge and ECO-DRAIN 30

E-Pack: Filter Serie FF mit Filtermonitor und ECO-DRAIN

E-pack: Filter series FF with filtermonitor and ECO-DRAIN

Anzahl Filterelemente siehe Kapitel 3. „Technische Daten“.

Quantity of filter cartridges see chapter 3. „Technical data“.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**Inhaltsverzeichnis****Contents**

<b>1. Einleitung</b>	<b>1. Introduction</b>
<b>2. Sicherheitsregeln, Warnhinweise</b>	<b>2. Safety rules, warnings</b>
<b>3. Technische Daten</b>	<b>3. Technical data</b>
<b>4. Funktionsbeschreibung</b>	<b>4. Description of functions</b>
<b>5. Kondensatableiter</b>	<b>5. Condensate discharger</b>
<b>6. Transport, Wareneingangskontrolle</b>	<b>6. Transportation, checking of goods received</b>
<b>7. Montage</b>	<b>7. Assembly</b>
<b>8. Inbetriebnahme, Betrieb</b>	<b>8. Start up, operation</b>
<b>9. Wartung, Austausch der Filterelemente</b>	<b>9. Servicing, filter cartridge replacement</b>
<b>10. Garantiebedingungen</b>	<b>10. Guarantee conditions</b>
<b>11. Maßzeichnung</b>	<b>11. Dimensional drawing</b>
<b>12. Anhang (ECO-DRAIN)</b>	<b>12. Annex (ECO-DRAIN)</b>
<b>13. Einteilung nach Druckgeräterichtlinie</b>	<b>13. Grading of filters according to pressure equipment directive (PED)</b>

Wir haben den Inhalt der Bedienungsanleitung auf Übereinstimmung mit dem beschriebenen Gerät geprüft.  
Dennoch können Abweichungen nicht ausgeschlossen werden, so daß wir für die vollständige Übereinstimmung keine Gewähr übernehmen.

Technische Änderungen vorbehalten.

We have examined the content of the operating instructions for conformity with the appliance described.  
Inconsistencies cannot be ruled out, however, with the result that we do not guarantee complete conformity

We reserve the right to alter the specifications without prior notice

**1. Einleitung****1.1 Allgemeines**

Die in dieser Betriebsanleitung dokumentierten Druckluftfilter erfüllen alle Anforderungen, die an moderne Filtersysteme gestellt werden. Um Sie optimal nutzen zu können, benötigt der Anwender ausführliche Informationen.

In der vorliegenden Betriebsanleitung haben wir diese Informationen möglichst vollständig und in entsprechende Kapitel gegliedert zusammengestellt.

Lesen und beachten Sie diese Informationen. Sie helfen Ihnen auch Unfälle zu vermeiden.

**1. Introduction****1.1 General remarks**

The compressed air filters documented in these instruction manual has all requirements that can be expected from a modern filter/-system. In order to obtain maximum benefit from using the filters/-system the user should have sufficient information.

These instruction manual gave the user this information which has been divided into separate sections for easy reference.

Please read carefully before installing and operating the filter/-system.

**1.2 Erklärung der Symbole in der Bedienungsanleitung**

- Aufzählungen werden mit diesem Punkt oder Sternchen \* gekennzeichnet.

-  Mit diesem Symbol werden Textstellen gekennzeichnet, die unbedingt zu beachten sind.
- Wichtige Sicherheitshinweise
  - Wichtige Bedienungs-/Wartungshinweise
  - Warnung vor möglichen Fehlbedienungen
  - Warnung vor Gefahren

 Elektrisches Gefahrensymbol

 Ausführende Tätigkeit.  
Vom Bediener auszuführende Bedienschritte.

**1.2 Explanation to the symbols in the instruction manual**

- Technical data or instructions.

\*

-  Parts that require absolute attention
- Vital safety instructions
  - Essential operation and maintenance instructions
  - Warnings on handling or moving the dryer
  - Danger areas

 Electrical danger symbol

 Changes sequence of operation

**1.3 Erklärung der Symbole am Gerät**

-  Automatischer Kondensatablauf / Automatic Condensate Drain
-  Elektroanschluß / Electrical Supply

**1.3 Symbols used in the filter**

-  Drucklufeintritt / Compressed Air Inlet
-  Druckluftaustritt / Compressed Air Outlet

**2. Sicherheitsregeln,  
Warnhinweise****2.1 Bestimmungsgemäßer Gebrauch****Achtung!**

- Die Filter dürfen nur für die in dieser Bedienungsanleitung vorgesehenen Einsatzfälle zur Aufbereitung von Druckluft verwendet werden.
- Der einwandfreie und sichere Betrieb der Produkte erfordert sachgerechten Transport, Lagerung, Aufstellung und Montage, sowie sorgfältige Bedienung und Instandhaltung.

**2.2 Sicherheitsregeln****Warnung!**

- Die Filter dürfen nur von qualifiziertem Personal genutzt, bedient, gewartet oder instandgesetzt werden.
- Qualifiziertes Personal im Sinne der sicherheitsbezogenen Hinweise in dieser Dokumentation oder auf dem Produkt selbst, ist Personal das:
  - \* im Umgang mit Einrichtungen der Druckluft vertraut und unterwiesen sowie über die damit verbundenen Gefahren unterrichtet ist.
  - \* Den auf die Bedienung bezogenen Inhalt dieser Dokumentation kennt.
  - \* Es besitzt als solches eine zur Inbetriebnahme und Wartung derartiger Einrichtungen befähigende Ausbildung bzw. Berechtigung.

**2. Safety rules,  
warnings****2.1 Use of filter/-system****Achtung!**

- The filter must only be used for the purpose as designated in the instruction manual to upgrading the compressed air.
- To obtain maximum efficiency and operation of the filter/-system ensure all sections of the manual are read carefully.

**2.2 Safety rules****Warning!**

- The filter/-system must only be used, operated, inspected and repaired by trained personnel.
- Trained personnel are defined as follows:
  - \* Operating staff who are skilled in the field of compressed air engineering and who are familiar with the filter/-system and possible dangers in unauthorised operation or service.
  - \* Who can interpret and action the contents of this operation instruction manual.
  - \* Who have had the appropriate training and qualified as being competent in these fields.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**2. Sicherheitsregeln,  
Warnhinweise****2.3 Warnhinweise****⚠ Warning!**

Das (die) Filter beinhalten unter erhöhtem Druck stehende Systeme.  
Vor Servicearbeiten sind sie drucklos zu machen.

**⚠ Warning!**

Filtersysteme mit elektrisch gesteuerten Kondensatableitern enthalten unter elektrischer Spannung stehende Bauteile.  
Vor Servicearbeiten sind diese alle vom elektrischen Spannungsversorgungsnetz zu trennen.  
(Netzstecker ziehen, Hauptschalter ausschalten)

**ACHTUNG!**

Alle Arbeiten am elektrischen System dürfen nur von elektrotechnisch geschultem Fachpersonal, oder unter Aufsicht von diesem, durch Unterwiesene ausgeführt werden.

**⚠ Hinweis!**

Die Filter sind ausschließlich zur Aufbereitung von Druckluft einzusetzen.

**ACHTUNG!**

Die Verwendung in Verbindung mit brennbaren Gasen ist verboten!

**⚠ ACHTUNG!**

Filter/-systeme zur Aufbereitung von Atemluft dürfen nur nach Genehmigung des Herstellers der Filter/-systeme eingesetzt und betrieben werden.

**2. Safety rules,  
warnings****2.3 Security-warnings****⚠ Warning!**

The filter/-system contains components under high pressure.  
Before starting any service work turn off compressed air supply to the dryer and depressurise the system.

**⚠ Warning!**

The filter/-systems with electrical condensate discharger contains components that are electrically live and which can cause danger to life.  
Before starting any service work ensure all power is isolated from the filter/-system, mains isolator to be off, mains plug if fitted to be removed.

**ATTENTION!**

Any electrical work on the dryer must only be carried out by skilled staff - qualified electricians, or persons under supervision of qualified staff.

**⚠ Remark!**

Use filter for compressed air applications only.

**Attention!**

The use of combustible gases is prohibited.

**⚠ ATTENTION!**

Filter/-systems for breathing air applications must be approved from manufacturer.

**3. Technische Daten**
**3. Technical data**

MODEL DESIGNATION / FILTER- GRADE / GRADE	Volumenstrom / Capacity [m³/min]	Anschluß Connection [ ]	Betriebsdruck Working Pressure [max]	Abmessungen Dimensions [Höhe / Height [mm]]	Gewicht Weight [kg]	AUSTAUSCH-FILTERELEMENTE FILTER- GRAD / GRADE		FILTER- GEHÄUSE / HOUSING	Anzahl Quantity
						MODUL-BAUWEISE / MODULAR SYSTEM			
FA	-6	0.58	3/8"	16	105				
	-10	1.00	1/2"	16	105				
	-18	1.75	1/2"	16	105				
	-28	2.83	3/4"	16	133	siehe Kapitel „Maßzeichnung“			
FB	-48	4.83	1"	16	133				
	-71	7.10	1-1/2"	16	164	„Maßzeichnung“			
FC	-107	10.7	1-1/2"	16	164	see chapter „dimensional drawing“			
	-138	13.8	2	16	194	„dimensional drawing“			
FD	-177	17.7	2-1/2"	16	194				
	-221	22.1	2-1/2"	13	194				
FE	-185	18.5	DN80	16	1025	350			
FF	-283	28.3	DN80	16	1045	400			
	-354	35.4	DN80	16	1045	400			
FG	-526	52.6	DN100	16	1085	440			
	-708	70.8	DN100	16	1105	535			
	-885	88.5	DN100	16	1105	535			
	-1420	142	DN150	16	1215	600			
	-1950	195	DN150	16	1245	720			
	-2480	248	DN150	16	1245	750			

- Volumenstrom m³/h bezogen auf +20°C und 1 bar absolut, bei Betriebsüberdruck 7 bar / Air flow m³/h based on +20°C and 1 bar absolute, at working pressure 7 bar
- Größere Betriebsdrücke auf Anfrage / Contact factory for dryers with a higher working pressure
- Filtergehäuse F-185 – F-2480: Konstruktion der Behälter entspricht der EG-Richtlinie 8/40/EEC für einfache Druckbehälter und ist mit CE-Zichen versehen / Filter bowl F-185 – F-2480: Vessel construction complies with directive 87/40/EEC, simple pressure vessels, and is marked with the EC symbol

**Volumenstrom - Korrekturtabelle / Sizing**

Minimaler Betriebsdruck / Minimum working pressure bar	Korrekturfaktor / Correction factor	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
0.38	0.52	0.63	0.75	0.88	1.00	1.13	1.26	1.38	1.52	1.65	1.76	1.87	2	2.14		

**Auslegung**  
Bei Drucken abweichend von 7 bar berechnet sich der max. Volumenstrom wie folgt:  
den Korrekturfaktor des entsprechenden minimalen Betriebsdruckes mit dem gewählten Volumenstrom aus o.g. Tabelle multiplizieren.  
**Based on**  
To find the maximum flow at pressures other than 7 bar:  
multiply the flow (from table above) by the correction factor corresponding to the minimum working pressure of the filter.

**Betriebsbedingungen:**  
Min. Betriebstemperatur: +1°C  
Max. Betriebstemperatur: 66°C  
Min. Betriebsdruck mit automatischem Kondensatableiter: 2,0 bar

**Working conditions:**  
Min. Working temperature: +1°C  
Max. Working temperature: 66°C  
Min. working pressure with automatic condensate drain: 2,0 bar

**4. Funktionsbeschreibung****4. Description of operation****4.3 Serie FC****1-MIKRON-COALESING-FILTER**

- Zweistufige Tiefenfiltration bewirkt hervorragende Leistung und höhere Standzeiten des Filterelementes
- Entfernt 100% des Kondensats
- Entfernt Feststoffpartikel bis herunter zu 1 Mikron
- Restölgehalt < 1 ppm w/w
- Automatischer Kondensatableiter
- Differenzdruckanzeige am Filtergehäuse
- max. Flüssigkeitsbeladung: 2g/m<sup>3</sup>

**Anwendungen:**

- Allgemeine Filter für Werkstattluft
- Vorfilter für Hochleistungsfilter
- Nachfilter für Adsorptionstrockner
- Endstellenfiltration bei Einsatz von Nachkühlern oder Trocknern

**Funktion:**

Die Luft tritt von oben in das Filterelement FC ein und strömt radial durch den perforierten inneren Stützmantel zur 1. Filtrationsstufe. Diese Stufe besteht aus mehreren Lagen Glasfaser und einer stützenden Glasfasermatte. Gröbere Feststoffteilchen werden hier zurückgehalten. Die Luft gelangt nun in die 2. Filtrationsstufe, bestehend aus einer mehrlagigen Mischung von imprägnierten Glasfasern und Mikrofibern. In beiden Stufen werden Feststoffpartikel und Flüssigkeiten nach dem Prinzip der Tiefenfiltration sowie des Coalescings ausgefiltert. Die Luft tritt durch den perforierten äußeren Stützmantel aus.

**4.3 Series FC****1-MICRON-COALESING-FILTER**


- Two in-depth filter beds offer superior performance and extended cartridge life
- Removes 100% of liquid water
- Removes solid particles down to 1 micron
- Oil content < 1 ppm w/w
- Automatic condensate drain
- Differential pressure indicator at the filter housing
- max. liquid load: 2g/m<sup>3</sup>

**Application:**

- General filter for shop air
- Prefilter for high efficiency filters
- Afterfilter for pressure-swing desiccant dryers
- Point-of-use filter on systems utilising aftercoolers or dryers

**Operation:**

Air enters the inside of the cartridge FC and flows outwardly through two in-depth beds of glass fibres. Larger particles are collected in the first bed while all remaining particles one micron and larger are collected in the second bed. A combination of large void areas and stabilized media allows heavy particulate loading and low pressure drop resulting in a long service life for the cartridge. Throughout both stages, liquid aerosols are captured and coalesced. The coalesced liquids then drain to the bottom of the cartridge for removal.



F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**4. Funktionsbeschreibung**
**4.5 Serie FE**
**0,01-MIKRON-COALESING-FILTER  
(bei 0,01 ppm w/w max. Ölgehalt)**

DUO-System Abscheidung  
1. Stufe: flüssige Bestandteile  
2. Stufe: Ölbestandteile

- Entfernt mehr als 99,99% der Öl-Aerosole
- Entfernt Feststoffpartikel bis herunter zu 0,01 Mikron
- Restölgehalt < 0,01 ppm w/w
- Automatischer Kondensatableiter
- Differenzdruckanzeige am Filtergehäuse
- max. Flüssigkeitsbeladung: 1g/m<sup>3</sup>

**Anwendungen:**

- Vorfilter für Membrantrockner
- Vorfilter für Adsorptionstrockner
- Endstellenfiltration (falls **geringfügige** Feuchtigkeit vorhanden ist)

**Funktion:**

Die Luft tritt von oben in das Filterelement FE ein und strömt durch den inneren Stützmantel, radial durch verschiedenartige Lagen Fiberglas. Dann strömt die Luft durch ein weiteres Sieb. In dieser 1. Filtrationsstufe werden größere Partikel entfernt. In der zweiten Filtrationsstufe werden Aerosole und feste Bestandteile durch eine Mehrschicht-Membranwand aus epoxidharz verstärktem Fiberglas gefiltert, daß speziell für feinste Aerosole geeignet ist. Das Filtermedium ist ein Bett aus submikrofeinen Glasfasern und wirkt nach dem Prinzip des Coalescings sowie der Tiefenfiltration. Der innere Schaumstoffmantel gleicht Luftschwankungen und Aerosolkonzentrationen aus und gewährleistet eine gleichmäßige Verteilung. Im äußeren Schaumstoffmantel werden die Öltröpfchen gesammelt, fließen durch Schwerkraft in den unteren Teil des Filters und tropfen dann in den Filterbehälter ab.

**4. Description of operation**
**4.5 Series FE**
**0,01-MICRON-COALESING-FILTER  
(at 0,01 ppm w/w max. oil content)**

DUO-system separation  
1. Stage: liquid particles  
2. Stage: oil particles


- Removes more than 99,99% of oil aerosols
- Removes solid particles down to 0,01 microns
- Oil content < 0,01 ppm w/w
- Automatic condensate drain
- Differential pressure indicator at the filter housing
- max. liquid load: 1g/m<sup>3</sup>

**Application:**

- Prefilter for membrane dryers
- Prefilter for pressure-swing desiccant dryers
- Point-of-use filter (may be used if light liquid load is present)

**Operation:**

Air enters the inside of the cartridge FE and flows through an inner foam sleeve, radially outward through various layers of glass fibers. Then the air flows through another screen. In the first stage filter section the larger solid particles are trapped. In the second stage filter section aerosols and solid particles are trapped using a multi-layered membrane wall made of epoxy resin-reinforced glass fibres which was especially designed for the finest aerosols. The filter media is a bed of submicronic glass fibers and works to the principle of coalescing and in-depth filtration. The inner foam sleeve compensates air cycling and aerosol concentrations and maintains uniform distribution. The outer foam sleeve collects the coalesced oil droplets which then, due to gravity, travel downstream to the bottom of the sleeve and drain to the bottom of the filter bowl.



- 15 -

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

FI HANK-MOB\_02 D E

**7. Montage****7.1 Montageort**

Das Filter/-system sollte in einem trockenen, frostfreien Innenraum installiert werden.  
Zur Wartung ist genügend Freiraum vorzusehen.

**7.2 Montage**

Das Filter/-system ist senkrecht so zu montieren, daß der Druckluft-ein- und austritt waagerecht erfolgt.

Im Filtergehäuse eingebaute Filterelemente können sich während des Transportes lösen.  
Prüfen Sie den richtigen Sitz der Filterelemente vor der Inbetriebnahme.

**ACHTUNG!**

Achten Sie bei der Montage darauf, daß keine Zug- und Druckkräfte auf die Geräteanschlüsse übertragen werden.

**Hinweis!**

Bei den Standard-Filtern FB, FC, FE und FF der Größe -185 & -283 ... -2480, den D-Pack-Basic-Filttern FB, FC, FE und FF, sowie den E-Pack-Filttern FA, FB, FC, FE und FF sind die Kondensatableiter beigelegt und müssen wie in Kapitel 11. „Maßzeichnung“ angebaut werden.

**7.3 Anschluß an das Druckluftnetz**

Die Druckluftein- und -austrittsleitung sollte für Servicezwecke mit einem Bypass versehen werden.  
Die Dimensionierung der Anschlüsse entnehmen Sie bitte dem Kapitel 3. „Technische Daten“.

**ACHTUNG!**

Durchflußrichtung beachten.  
Druckluftein- und austritt dürfen nicht vertauscht werden.

**7.4 Kondensatableitung**

Für die automatische Kondensatableitung ist bei den Filtern (FA, FB, FC, FE, FF) ein Anschluß vorhanden.  
Die Dimensionierung des Anschlusses entnehmen Sie bitte Kapitel 5. „Kondensatableiter“.

**HINWEIS!**

Bei der Entsorgung des Kondensats ist der Schmutzanteil zu berücksichtigen.  
Beachten Sie die jeweils geltenden gesetzlichen Vorschriften.

Bei den Filtern FD, FG entfällt der Kondensatableitungsanschluß.

**7. Mounting****7.1 Location of mounting**

The filter/-system should be installed in a dry and frost-proof room indoors.  
Ample free, space should be allowed for the maintenance.

**7.2 Mounting**

Mount the filter/-system so that inlet and outlet connections are horizontal (filter bowl vertical).

Cartridges installed in the filter housing may become dislodged during transport.  
Make sure that the cartridge is correctly installed before use.

**ATTENTION!**

When installing the filter/-system ensure all connections are even and no pressure is placed on inlet and outlet connections.

**Remark!**

By the standard-filter FB, FC, FE and FF with the size -185 & -283 ... -2480, by the D-pack-basic-filter FB, FC, FE, FF and by the E-pack-filter FA, FB, FC, FE and FF the condensate drains are attached and must mount as shown in chapter 11. „Dimensional drawing“.

**7.3 Connection to the compressed air system**

The compressed air inlet and outlet line should be equipped with a by-pass system for the maintenance.  
For the sizing of the connections please see chapter 3. „Technical data“.

**ATTENTION!**

Pay attention to the flow direction.  
Do not exchange the compressed air inlet and outlet.

**7.4 Condensate drain**

The filters (FA, FB, FC, FE, FF) are equipped with one connection for the automatically condensate drain.  
For the sizing of the connection please see chapter 5. „Condensate discharger“.

**ACHTUNG!** When fitting the drains please see to it, that the condensate separated is drained off into a system that does not create a back pressure.

**Instruction!**

When disposing of the condensate the amount of pollution has to be taken into consideration. Please act according to the prevailing regulations of law.

Condensate drain does not exist in filters FD, FG.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**8. Inbetriebnahme, Betrieb****8.1 Bereitschaft zur Inbetriebnahme**

Druckluftfilter/-systeme sind bereit zur Inbetriebnahme, wenn:

- Der auf dem Typenschild angegebene Druck dem maximalen Betriebsdruck entspricht.
- Sie entsprechend Kapitel 7. „Montage“ installiert wurden.
- Alle Zu- und Ableitungen sachgerecht angeschlossen sind.
- Die erforderlichen Energien (Druckluft) verfügbar sind.
- Absperrorgane (z.B. Ventil, Kugelhahn) in der Druckluftleitung und austrittsleitung geschlossen sind.
- Kondensat durch die Kondensatableitung ungehindert abfließen kann.
- Der elektrisch gesteuerte Kondensatableiter an das elektrische Spannungsversorgungsnetz mit der richtigen Betriebsspannung angeschlossen ist. (Nur bei elektrisch gesteuerten Kondensatableitern)
- Das Filter/-system mit den richtigen Filterelementen ausgerüstet ist.

**8.2 Inbetriebnahme, Betrieb**

Vor der Inbetriebnahme ist sicherzustellen, daß alle Bedingungen des Abschnittes 8.1 „Bereitschaft zur Inbetriebnahme“ erfüllt sind.



Setzen Sie das Filter/-system durch langsame Öffnen der Druckluftleitungs- und austrittsleitung unter Druck.



Schließen Sie das Absperrorgan im Bypass (falls vorhanden).



Das Filter/-system ist nun in BETRIEB.

**8. Start-up, operation****8.1 Preconditions for starting the dryer**

The filter/-system is ready for starting when:

- Check unit serial number tag to verify working pressure.
- They have been installed in accordance with section 7. „Mounting“.
- All inlet and outlet lines have been correctly connected.
- The required forms of energy (compressed-air) are available.
- The shut-off devices (e.g. ball valve) in the compressed-air inlet and outlet lines are closed.
- The condensate is able to flow through the condensate discharger without obstruction.
- The electrical condensate drain has been connected to the electric power supply system with the correct operating voltage (only electrical condensate drains).
- The filter/-system is equipped with the right cartridges.

**8.2 Start up, operation**

Before starting the dryer, ensure that all the requirements specified in section 8.1 „Preconditions for starting the dryer“ have been fulfilled.



Place filter/-system under pressure gradually by slowly opening the compressed air inlet/outlet.



Close the shut-off device in the bypass (if installed).



The filter/-system is now OPERATIVE.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**8. Inbetriebnahme, Betrieb****8.3 Differenzdruckanzeige-Standard und  
D-Pack (OPTION)****8. Start-up, operation****8.3 Differential pressure indicator-  
standard and D-Pack (OPTION)**

Die Differenzdruckanzeige informiert als Störanzeige über eine atypische Verschmutzung.

**⚠️ Unabhängig von der Differenzdruckanzeige müssen die Filterelemente gemäß der Wartungsintervalle gewechselt werden. (Siehe Kapitel 9)**

**⚠️ Das Filter FG benötigt keine Differenzdruckanzeige.**

The differential pressure indicator indicates atypical contamination.

**⚠️ We recommend installing a new filter cartridge according to the maintenance periods. (See chapter 9)**

**⚠️ The FG filter does not require a differential pressure gauge.**

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**9. Wartung  
Austausch der Filterelemente**
**9.1 Standzeit der Filterelemente**

Die Standzeit der Filterelemente ist abhängig von der Beladung. Mit steigender Beladung der Elemente erhöht sich der Differenzdruck über den Filter.  
Die Filterelemente müssen gemäß unten stehender Tabelle gewechselt werden.

**9.2 Austausch der Filterelemente**
Filtergehäuse -6 bis -221

Anzahl der Filterelemente siehe Kapitel 4. „Technische Daten“.

**⚠️ WARNUNG!**

- Verwenden Sie keine Werkzeuge! (Filtergehäuse -6 bis -48)
- Öffnen und Schließen Sie das Filter nicht mit Gewalt.
- Das (die) Filter beinhaltet(n) unter erhöhtem Druck stehende Systeme.

Vor Servicearbeiten sind sie drucklos zu machen.

👉 Absperrvorrichtung im Drucklufttein- und -austritt schließen.

👉 Kondensatableitungsschlauch an (1) lösen.  
(Nur bei FB, FC, FE, FF).

👉 Rändelschraube (1) langsam im Uhrzeigersinn lösen.  
Das Filtergehäuse wird entlüftet.

**9. Servicing, filter cartridge replacement**
**9.1 Serviceable life of cartridge**

The cartridge's serviceable life depends upon the degree of contamination. As the cartridge becomes more contaminated, the differential pressure above the filter increases.  
The filterelements must be changed according to the table below.

**9.2 Replacing the cartridge**
Filter housing -6 to -221

Number of cartridges see chapter 4. „Technical data“.

**⚠️ CAUTION!**

- Do not use any tools (filter housings -6 to -48)
- Do not force the filter open or closed.
- The filter(s) contain(s) systems under high pressure.  
All pressure must be let off before servicing.

👉 Close the shut-off device in the compressed air inlet/outlet.

👉 Loosen condensate drain hose at (1) (only on FB, FC, FE, FF models).

👉 Slowly turn the knurled screw (1) clockwise. This will release the air from the housing.

**Wartungsintervalle / Maintenance-intervals**

Wartungsstiel Part of maintenance	Type	Anwendung Application	Wartungs-Intervall Maintenance-Interval
Filter-Elemente / filter cartridges	FB, FC	Vorfilter Pre-filter	6.000 Bh, max. 1 Jahr / 6.000 Bh, max. 1 year
	FE, FF	Microfilter	3.000 Bh, max. 1 Jahr/ 3.000 Bh, max. 1 year
	FEG	Filterkombination Filter combination	3.000 Bh, max. 1 Jahr (Type FE) 3.000 Bh, max. 1 year Type (FE)
			1.000 Bh, max. 1 Jahr (Type FG) 1.000 Bh, max. 1 year Type (FG)
	FFG		1.000 Bh, max. 1 Jahr/ 1.000 Bh, max. 1 year
	FD	Nachfilter After-filter	6.000 Bh, max. 1 Jahr/ 6.000 Bh, max. 1 year
Kondensatableiter / condensate drain	FG	Aktivkohlefilter Act.carbon filter	1.000 Bh
	Service-unit	Vorfilter Pre-filter	6.000 Bh
	Service-unit	Microfilter	6.000 Bh
	Service-unit	Filterkombination Filter combination	6.000 Bh

Bh = Kompressor-Betriebsstunden / Working hours



## 9. Wartung Austausch der Filterelemente

Filtergehäuse entfernen.

- **Filtergehäuse -6 bis -48 (Bajonet-Verschluß)**

- \* Das Filtergehäuse nach oben, gegen den Filterkopf drücken.
- \* Dann das Filtergehäuse im Uhrzeigersinn langsam gegen den Anschlag drehen (etwa 1/8 Drehung) und nach unten abziehen.

- **Filtergehäuse -71 bis -221 (Gewinde-Verschluß)**

- \* Schrauben Sie das Filtergehäuse gegen den Uhrzeigersinn (per Hand oder mit Hilfe eines Filterschlüssels) auf.

Filterelement gemäß unten stehender Skizze abziehen, bzw. wechseln.

**Hinweis:** Die Schaumstoffummantelung der Filterelemente Serie FE, FF und FG dürfen nicht mit den Fingern angefaßt werden.

Filtergehäuse in umgekehrter Reihenfolge zusammenbauen.

Filter durch langsame Öffnen der Absperrvorrichtung wieder mit Druck beaufschlagen.



## 9. Servicing, filter cartridge replacement

Remove housing.

- **Housing -6 to -48 (bayonet-style head)**

- \* Push housing upwards against the filter head.
- \* Then slowly turn the housing clockwise to the stop (about 1/8 of a turn) and remove by pulling downwards.

- **Housing -71 to -221 (threaded head)**


- \* Screw off the housing counter-clockwise (by hand or using a filter wrench).

Remove and replace cartridge as shown below.

**Please note:** Do not touch the foam sleeves of the cartridges from the FE, FF and FG series with your fingers.

Re-assemble the housing in the reverse order.

Place filter under pressure again by slowly opening the shut-off device.



### Filtergehäuse -185 bis -2480

Anzahl der Filterelemente siehe Kapitel 3. „Technische Daten“.

**WARNING!**

- Das (die) Filter beinhaltet(n) unter erhöhtem Druck stehende Systeme.  
Vor Servicearbeiten sind sie drucklos zu machen.

### Housing -185 to -2480

Number of cartridges see chapter 3. „Technical data“.

**CAUTION!**

- The filter(s) contain(s) systems under high pressure.  
Alle pressure must be let off before servicing


F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**9. Wartung  
Austausch der Filterelemente**

- ☞ Absperrvorrichtung im Druckluftein- und -austritt schließen.
- ☞ Kondensatableitungsschlauch an (1) lösen. (Nur bei FB, FC, FE, FF).
- ☞ Um das Filtergehäuse zu entlüften müssen Sie beim:
  - Kondensatableiter Nr. 30505 und Nr. 30506 die Entlüftungsschraube (3) entgegen dem Uhrzeigersinn lösen.
  - FG den Kugelhahn (5) öffnen.
- ☞ Schrauben der Flanschverbindung am Boden des Filtergehäuses vorsichtig lösen, da evtl. noch ein geringer Restdruck im System vorhanden ist.
- ☞ Schrauben bis auf eine entfernen und Flansch zur Seite schwenken.
- ☞ Filterelemente entgegen dem Uhrzeigersinn herausschrauben.
- ☞ Neue Filterelemente ohne Werkzeug „fingerfest“ einschrauben.
- Hinweis:** Die Schaumstoffummantelung der Filterelemente Serie FE, FF, FG dürfen nicht mit den Fingern angefaßt werden.
- ☞ Filtergehäuse in umgekehrter Reihenfolge schließen.
- ☞ Filter durch langes Öffnen der Absperrvorrichtungen wieder mit Druck beaufschlagen.

**9. Servicing, filter cartridge replacement**

- ☞ Close shut-off device in compressed air inlet/outlet.
- ☞ Loosen condensate drain hose at (1) (only on FB, FC, FE, FF models).
- ☞ Follow these steps to release the air from the housing:
  - for condensate drain no. 30505 and no. 30506, loosen the bleed screw (3) in counter-clockwise direction.
  - on FG models, open the ball valve (5).
- ☞ Gently loosen the screws at the bottom flange of the housing. Caution is necessary as the system may still be under slight residual pressure.
- ☞ Remove all screws except one and swing flange to the side.
- ☞ Screw out cartridge counter-clockwise.
- ☞ Screw in new cartridge by hand until „handtight“. Do not use a wrench.
- Please note:** Do not touch the foam sleeves of the cartridges from the FE, FF, FG series with your fingers.
- ☞ Close housing in reverse order.
- ☞ Place filter under pressure again by slowly opening the shut-off device.



F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**9. Wartung  
Austausch der Filterelemente**

**9.3 Austausch der**  
**Schwimmerableiter /**  
**ECO-DRAIN Service-unit /**  
**ECO-DRAIN Membransätze**

Die Kondensatableiter / Wartungspakete sind gemäß unten aufgeföhrter Tabelle regelmäßig zu wechseln.

**9. Servicing, filter cartridge  
replacement**

**9.3 Changing of**  
**Float drain /**  
**ECO-DRAIN Service-unit /**  
**ECO-DRAIN membrane set**

The condensate drains / service packages must be changed according to the table below.

Wartungsteil Part of maintenance	Wartungs-Intervall Maintenance-interval
Schwimmer-Kondensatableiter/ Float drain	3.000 Bh
Service-Unit (ECO DRAIN 30/31)	6.000 Bh
ECO DRAIN Verschleißteilsatz (ECO DRAIN 13/14) ECO DRAIN wearing part set (ECO DRAIN 13/14)	6.000 Bh

Nähtere Informationen finden Sie auch im Anhang ECO DRAIN.

For more details please see annex ECO DRAIN.

**10. Garantiebedingungen****10. Guarantee conditions****10.1 Allgemeines**

Die Garantie erstreckt sich, im Rahmen unserer allgemeinen Lieferbedingungen, auf das gelieferte Filter/-system.

**10.2 Garantieausschluß**

Garantieansprüche bestehen nicht,

- wenn das Filter/-system durch Einfluß höherer Gewalt oder durch Umwelteinflüsse beschädigt oder zerstört wird.
- bei Schäden, die durch unsachgemäße Behandlung, insbesondere Nichtbeachtung der Betriebs- und Wartungsanleitung aufgetreten sind (regelmäßige Kontrolle des Kondensatablitzers / regelmäßiger Wechsel der Filterelemente).
- falls das Filter/-system nicht seinen Bestimmungen entsprechend eingesetzt war (siehe Kapitel 3. „Technische Daten“).
- falls das Filter/-system durch nicht hierfür autorisierte Werkstätten oder andere Personen unsachgemäß geöffnet oder repariert wurde und/oder mechanische Beschädigungen irgendwelcher Art aufweist.

**10.1 General**

The guarantee covers the delivered device with regard to our general terms of delivery.

**10.2 Exclusion from guarantee coverage**

No guarantee claims shall be assertible,


- if the filter/-system is damaged or destroyed due to force majeurs or environmental effects.
- for damage resulting from incorrect handling, in particular failure to comply with the operating and maintenance instructions (regular inspection of the condensate discharger, regular change of the filter cartridges).
- if the filter/-system has not been used in accordance with its specifications (see section 3. „Technical data“).
- if the filter/-system has been opened or repaired by workshops or other persons unauthorised for this purpose and/or reveals any type of mechanical damage.

F0507	05.03.07	KC	05.03.07	KC	F0412	
D-Name	erstellt	Name	gepr.	Name	ersetzt f.	ersetzt d.

**13.7 Option dc**

**Operating instructions for compressed air filter (fresh air filter)**

RAMIRENT



AC010 - AC030

**OIL-X  
EVOLUTION**

Original Language EN **OIL VAPOUR & ODOUR REMOVAL FILTERS**

(NL) OLIEDAMP & GEUR VERWIJDERINGSFILTERS	(DE) FILTER ZUM ENTFERNNEN VON ÖLNEBEL UND GERÜCHEN
(FR) FILTRES D'ÉLIMINATION DES ODEURS ET DES VAPEURS D'HUILE	(FI) ÖLJYHÖYRYN JA HAJUN POISTOSUODATTIMET
(SV) FILTER FÖR AVLÄGSNING AV OLJEÅNGOR OCH LUKT	(NO) OLJEDAMP- OG OLJELUKTFJERNINGSFILTRE
(DA) FILTER FÖR AVLÄGSNING AV OLJEÅNGOR OCH LUKT	(EL) ΦΙΛΤΡΑ ΑΦΑΙΡΕΣΗΣ ΑΤΜΩΝ & ΟΣΜΩΝ ΛΑΔΙΟΥ
(ES) FILTROS DE ELIMINACIÓN DE OLORES Y VAPORES DE ACEITE	(PT) VAPOR DO ÓLEO E FILTROS DE REMOÇÃO DOS CHEIROS
(IT) FILTRI PER L'ELIMINAZIONE DEGLI ODORI E DEI VAPORI D'OLIO	(PL) FILTRY DO USUWANIA OPARÓW I ZAPACHU OLEJU
(SK) FILTRE NA ODSTRAŇOVANIE OLEJOVÝCH VÝPAROV A ZÁPACHU	(CS) OLEJOVÉ A PROTIPACHOVÉ FILTRY
(ET) ŌLISUDU JA -HAISU EEMALDUSFILTRID	(HU) OLAJGÖZ- ÉS SZAGELTÁVOLÍTÓ SZÜRŐK
(LV) EĻĻAS TVAIKU UN AROMĀTA NOVĒRŠANAS FILTRI	(LT) ALYVOS GARŪ IR KVAPO ŠALINIMO FILTRAI
(RU) ФИЛЬТРЫ ДЛЯ УСТРАНЕНИЯ ЗАПАХА И ПАРОВ МАСЛА	(SL) FILTRI ZA ODSTRANJEVANJE OLJNIH HLAPOV IN VONJAV
(TR) YAĞ BUHARI VE KOKUSU GİDERİCİ FİLTRELER	(MT) FILTRI LI JNEHHU L-FWAR TAŽ-ŽJUT U L-IRWEJJAH

RAMIRENT


**Warning**

- Highlights actions or procedures, which if not performed correctly, may lead to personal injury or death.
- Benadrukt de acties of procedures die, indien niet juist uitgevoerd, lichamelijk letsel of de dood kunnen veroorzaken.
- Weist auf Aktionen oder Verfahren hin, die bei fehlerhafter Durchführung zu Verletzungen und tödlichen Unfällen führen können.
- Met en relief les actions ou procédures qui, si elles ne sont pas exécutées correctement, peuvent entraîner des dommages corporels ou la mort.
- Osoittaa toimenpiteitä tai menettelytapoja, jotka väärin suoritettuna saattavat aiheuttaa henkilövahingon tai kuoleman.
- Anger åtgärder och metoder som kan orsaka personskador eller dödsfall hvis de inte utförs korrekt.
- Fremhever handlinger eller prosedyrer som kan føre til personskafe eller dødsfall hvis de ikke utføres på korrekt måte.
- Επισημαίνεται τις ενέργειες ή τις διαδικασίες, οι οποίες αν δεν πραγματοποιηθούν σωστά, μπορεί να οδηγήσουν σε τραυματισμό προσωπικού ή σε θάνατο.
- Destaca acciones o procedimientos que, de no realizarse correctamente, pueden ocasionar daños personales o la muerte.
- Realça as acções ou procedimentos que, se não forem executados correctamente, poderão provocar danos pessoais ou morte.
- Segnala azioni o procedure che, se non eseguite correttamente, comportano il rischio di infortuni o morte.
- Wskazuje działania i procedury, które w razie niewłaściwego wykonyania mogą prowadzić do obrażenia ciała lub śmierci.
- Zvýrazňuje činnosti alebo postupy, ktoré môžu v prípade nesprávneho vykonania viesť k zraneniu alebo usmrteniu.
- Upozornění na činnosti nebo postupy, jejichž nesprávné provádění může vést ke zranění nebo usmrcení osob.
- Töstab esile toiminguud või protseduurid, mis väärää teostamise korral võib hoiata surma.
- Olyan műveleteket vagy eljárásokat jelöl, amelyek nem megfelelő módon történő végrehajtása súlyos vagy végzetes személyi sérelmet okozhat.
- Uzsver darbības vai procedūras, kuru rezultātā, ja tās neveic pareizi, var izraisīt ievainojumus vai nāvi.
- Žymi veiksmus ar procedūras, kuriuos atlikus neteisingai, galima susizieisti ar mrtvi.
- Указывает на действия, ненадлежащее выполнение которых может привести к нанесению вреда здоровью или смерти.
- Označuje dejanja ali postopke, ki lahko ob nepravilnem izvajjanju poškodujejo človeka ali povzročijo smrt.
- Doğru bir şekilde yerine getirilmemiği takdirde bu ürüne hasar verebilecek işlem ve süreçleri vurgular.
- Tissottolinea l-azzjonijiet jew il-proceduri, li jekk ma jsirux kif suppost, jista' jkun hemm korrientej jew mewt


**Caution**

- Highlights actions or procedures, which if not performed correctly, may lead to damage to this product.
- Benadrukt de acties of procedures die, indien niet juist uitgevoerd, schade kunnen berokkenen aan dit product.
- Weist auf Aktionen oder Verfahren hin, die bei fehlerhafter Durchführung zu Schäden am Gerät führen können.
- Met en relief les actions ou procédures qui, si elles ne sont pas exécutées correctement, peuvent endommager ce produit.
- Osoittaa toimenpiteitä tai menettelytapoja, jotka väärin suoritettuna saattavat vaurioittaa täitä laitetta.
- Anger åtgärder och metoder som kan orsaka skador på den här produkten om de inte utförs korrekt.
- Fremhever handlinger eller prosedyrer som kan føre til skade på produktet hvis de ikke utføres på korrekt måte.
- Επισημαίνεται τις ενέργειες ή τις διαδικασίες, οι οποίες αν δεν πραγματοποιηθούν σωστά, μπορεί να προκαλέσουν ζημιά στο προϊόν αυτό.
- Destaca acciones o procedimientos que, de no realizarse correctamente, pueden ocasionar el deterioro del producto.
- Realça as acções ou procedimentos que, se não forem executados correctamente, poderão danificar este produto.
- Segnala azioni o procedure che, se non eseguite correttamente, comportano il rischio di danneggiare il prodotto.
- Wskazuje działania i procedury, które w razie niewłaściwego wykonyania mogą powodować uszkodzenie produktu.
- Zvýrazňuje činnosti alebo postupy, ktoré v prípade nesprávneho vykonania možu viesť k poškodeniu tohto výrobku.
- Upozornění na činnosti nebo postupy, jejichž nesprávné provádění může vést k poškození tohoto výrobku.
- Töstab esile toiminguud või protseduurid, mis väärää teostamise korral vöhjadest toodet kahjustada.
- Olyan műveleteket vagy eljárásokat jelöl, amelyek nem megfelelő módon történő végrehajtása a termék károsodásához vezethet.
- Uzsver darbības vai procedūras, kuru rezultātā, ja tās neveic pareizi, var sabojāt šo izstrādājumu.
- Žymi veiksmus ar procedūras, kuriuos atlikus neteisingai, galima sugadinti ši gamini.
- Указывает на действия, ненадлежащее выполнение которых может привести к повреждениям данного изделия.
- Označuje dejanja ali postopke, ki lahko ob nepravilnem izvajjanju poškodujejo izdelek.
- Doğru bir şekilde yerine getirilmemiği takdirde yarananma ya da ólume yol açabilecek işlem ve süreçleri vurgular.
- Tissottolinea l-azzjonijiet jew il-proceduri, li jekk ma jsirux kif suppost, tista' ssir hsara lil dan il prodott



- Suitable gloves must be worn.
- Geeignete Schutzhandschuhe tragen.
- Käytettävä asianmukaista käsineitä.
- Bruk egnede hansker.
- Απαιτείται να φοράτε κατάλληλα γάντια.
- Devem ser utilizadas luvas adequadas.
- Należy zakładać odpowiednie rękawice
- Kohustuslik kanda sobivaid kaitsekindaid
- Järvalka piemēroti cimdi.
- Работы должны проводиться в соответствующих перчатках
- Uygun eldiven giyilmelidir
- Altijd geschikte handschoenen dragen.
- Le port de gants adaptés est obligatoire.
- Använd lämpliga handskar.
- Der skal anvendes egnede handsker.
- Se deben llevar puestos guantes apropiados.
- Indossare guanti di protezione.
- Je nutné použiť vhodné rukavice.
- Viseljen megfelelő védőkesztyűt.
- Reikia művétő tinkamas pirosítás.
- Uporabit je treba ustrene rokavice.
- Għandhom jintibbu ingwanti adatti



- Highlights the requirements for disposing of used parts and waste.
- Benadrukt de vereisten voor het weggoeden van gebruikte onderdelen en afval.
- Weist auf die Anforderungen zur Entsorgung gebrauchter Teile und Abfall hin.
- Met en relief les consignes de mise au rebut des pièces usagées et des déchets.
- Osoittaa käytettyjen osien ja jätteen hävitättämistä koskevia vaatimuksia.
- Anger de krav som ställs på bortskaffande av gamla delar och avfall.
- Fremhever kravene for avhending av brukte deleier og avfall.
- Επισημαίνεται τις απαιτήσεις απόρριψης των χρησιμοποιημένων εξαρτημάτων και των απορριμάτων
- Destaca los requisitos para desechar las piezas usadas y los residuos.
- Realça os requisitos para eliminar as peças utilizadas e os desperdícios.
- Segnala i criteri per lo smaltimento di componenti usati e rifiuti.
- Wskazuje wymagania dotyczące usuwania zużytych części i odpadów.
- Zvýrazňuje požiadavky pre zneškodnenie použitých dielov a odpadu.
- Upozornění na požadavky týkající se likvidace použitych dílů a odpadu.
- Töstab esile kasutatud osade ja jätkide utiliseerimisele esitatavad nõuded
- A használt alkatrészek és a hulladék megfelelő módon történő elhelyezésére hívja fel a figyelmet.
- Uzsver prasibas tam, ka atrbivoties no lietotajam detaljam atkritumiem.
- Žymi panaudotu dalju ir atlieku išmetimo reikalavimus.
- Указывает на требования по уничтожению использованных деталей и отходов.
- Označuje zahteve za odlaganje rabljenih delov in odpadkov.
- Kullanılmış parçaların ve atıkların atılmasıyla ilişkili gereklilikleri vurgular
- Tissottolinea l-kundizzonijiet biex wieħed jarmi l-partijiet użati u l-iskart

	<ul style="list-style-type: none"> <li>Pressure.</li> <li>Paine.</li> <li>Πίεση</li> <li>Ciśnienie</li> <li>Nyomás alatt.</li> <li>Tlak</li> </ul>	<ul style="list-style-type: none"> <li>Druk.</li> <li>Tryck</li> <li>Presión.</li> <li>Tlak..</li> <li>Spiediens.</li> <li>Basinç</li> </ul>	<ul style="list-style-type: none"> <li>Druck.</li> <li>Trykk</li> <li>Pressão.</li> <li>Tlak.</li> <li>Slégis.</li> <li>Pressjoni</li> </ul>	<ul style="list-style-type: none"> <li>Pression.</li> <li>Tryk</li> <li>Pressione.</li> <li>Surve.</li> <li>Давление</li> </ul>
	<ul style="list-style-type: none"> <li>Release Pressure.</li> <li>Evacuation de pression.</li> <li>Avlst trykk</li> <li>Despresurizar.</li> <li>Ciśnienia spustowe</li> <li>Surve väljalase</li> <li>İşleksite slēgi.</li> <li>Basinci Kaldırın</li> </ul>	<ul style="list-style-type: none"> <li>Druk aflaten.</li> <li>Vapauta paine.</li> <li>Aflast trykk</li> <li>Liberta Pressão.</li> <li>Uvofnите tlak.</li> <li>Engedje ki a nyomást.</li> <li>Справить давление</li> <li>Nehli I-pressjoni</li> </ul>	<ul style="list-style-type: none"> <li>Druck ablassen.</li> <li>Tryckutsläpp.</li> <li>Εκτόνωση πίεσης</li> <li>Scaricare la pressione.</li> <li>Uvolnění tlaku.</li> <li>Pazeminiel spiedienu.</li> <li>Sprostitev tlaka.</li> </ul>	<ul style="list-style-type: none"> <li>Druck ablassen.</li> <li>Tryckutsläpp.</li> <li>Εκτόνωση πίεσης</li> <li>Scaricare la pressione.</li> <li>Uvolnění tlaku.</li> <li>Pazeminiel spiedienu.</li> <li>Sprostitev tlaka.</li> </ul>
	<ul style="list-style-type: none"> <li>Replace every year</li> <li>Remplacer tous les ans.</li> <li>Skift ut hvert år</li> <li>Sustituir anualmente</li> <li>Należy wymieniać raz w roku</li> <li>Asendage igal aastal</li> <li>Keiskite kaita per metus</li> <li>Her yil değiştirin</li> </ul>	<ul style="list-style-type: none"> <li>Elk jaar vervangen</li> <li>Vaihda vuosittain.</li> <li>Udskift en gang om året</li> <li>Substituir todos os anos</li> <li>Každý rok vymieňajte</li> <li>Eevente cserélje</li> <li>Заменять каждый год.</li> <li>Ibdel kull sena</li> </ul>	<ul style="list-style-type: none"> <li>Jährlich austauschen</li> <li>Byt varje år</li> <li>Αντικατασταση κάθε χρόνου</li> <li>Sostituire ogni anno</li> <li>Nutná výměna každý rok.</li> <li>Nomainiet reizi gada</li> <li>Zamenjajte vsako leto.</li> </ul>	<ul style="list-style-type: none"> <li>Jährlich austauschen</li> <li>Byt varje år</li> <li>Αντικατασταση κάθε χρόνου</li> <li>Sostituire ogni anno</li> <li>Nutná výměna každý rok.</li> <li>Nomainiet reizi gada</li> <li>Zamenjajte vsako leto.</li> </ul>
	<ul style="list-style-type: none"> <li>Filter housing / Model</li> <li>Logement du filtre/modèle.</li> <li>Filterhus-/modell</li> <li>Caja de filtro/modelo.</li> <li>Obudowa filtra / model.</li> <li>Filtre korpus/mudel</li> <li>Filtro korpusas / modelis</li> <li>Filtre muhafazası / Model</li> </ul>	<ul style="list-style-type: none"> <li>Filterhuis / Model</li> <li>Suodatinotelo/-malli</li> <li>Filterhus/modell</li> <li>Caixa / Modelo do filtro</li> <li>Kryt filtra / Model</li> <li>Szűrőház / típus</li> <li>Корпус фильтра / модель</li> <li>Kontenitur tal-filtri - Mudell</li> </ul>	<ul style="list-style-type: none"> <li>Filtergehäuse / Modell</li> <li>Filterhus/modell</li> <li>Υποδοχή/μοντέλο φίλτρου</li> <li>Corpo del filtro / Modello</li> <li>Kryt filtru / Model</li> <li>Filtra korpuiss / modelis</li> <li>Ohišje filtra / Model</li> </ul>	<ul style="list-style-type: none"> <li>Filtergehäuse / Modell</li> <li>Filterhus/modell</li> <li>Υποδοχή/μοντέλο φίλτρου</li> <li>Corpo del filtro / Modello</li> <li>Kryt filtru / Model</li> <li>Filtra korpuiss / modelis</li> <li>Ohišje filtra / Model</li> </ul>
	<ul style="list-style-type: none"> <li>High efficiency filter element</li> <li>Hochleistungsfilterelement</li> <li>Tehokas suodatinelementti</li> <li>Høyeffektiv filterelement</li> <li>Φίλτρο υψηλής απόδοσης</li> <li>Elemento do filtro de elevado rendimento</li> <li>Wysokowydajny wkład filtra</li> <li>Výsoce účinný filtrační prvek</li> <li>Nagy hatékonyúságú szűrélem</li> <li>Labai efektívus filtravimo elementas</li> <li>Visoko učinkovit filtrirni element</li> <li>Element tal-filtri b'efficjenza kbira</li> </ul>	<ul style="list-style-type: none"> <li>Zeer efficiënt filterelement</li> <li>Cartouche filtrante haute efficacité.</li> <li>Högeffektiv filterelement</li> <li>Høgeffektiv filterelement</li> <li>Είσπευση ψηφιακής απόδοσης</li> <li>Elemento filtrante de gran eficiencia.</li> <li>Elemento filtrante ad alta efficienza</li> <li>Vysoko účinný filtračný článok</li> <li>Kõrgtootlik filterelement</li> <li>Augstas produktivitātes filtra elements</li> <li>Высокоэффективный фильтрующий элемент</li> <li>Yüksek etkinlikli filtre ögesi</li> </ul>	<ul style="list-style-type: none"> <li>Zeer efficiënt filterelement</li> <li>Cartouche filtrante haute efficacité.</li> <li>Högeffektiv filterelement</li> <li>Høgeffektiv filterelement</li> <li>Είσπευση ψηφιακής απόδοσης</li> <li>Elemento filtrante de gran eficiencia.</li> <li>Elemento filtrante ad alta efficienza</li> <li>Vysoko účinný filtračný článok</li> <li>Kõrgtootlik filterelement</li> <li>Augstas produktivitātes filtra elements</li> <li>Высокоэффективный фильтрующий элемент</li> <li>Yüksek etkinlikli filtre ögesi</li> </ul>	<ul style="list-style-type: none"> <li>Zeer efficiënt filterelement</li> <li>Cartouche filtrante haute efficacité.</li> <li>Högeffektiv filterelement</li> <li>Høgeffektiv filterelement</li> <li>Είσπευση ψηφιακής απόδοσης</li> <li>Elemento filtrante de gran eficiencia.</li> <li>Elemento filtrante ad alta efficienza</li> <li>Vysoko účinný filtračný článok</li> <li>Kõrgtootlik filterelement</li> <li>Augstas produktivitātes filtra elements</li> <li>Высокоэффективный фильтрующий элемент</li> <li>Yüksek etkinlikli filtre ögesi</li> </ul>
	<ul style="list-style-type: none"> <li>Adsorption filter cartridge - Granular carbon</li> <li>Adsorptionsfiltereinsatz - Granulatkohle</li> <li>Adsorptionsuodateinelementti - rakeinen hiili</li> <li>Adsorpsjonsfilterpatron - Karbon i kornform</li> <li>Φυσιγύο φίλτρου προσρόφησης - Κοκκώδης άνθρακας</li> <li>Cartucho do filtro de adsorcão - Carvão granular</li> <li>Adsorpçyni wkład filtrujący z węglem ziarnistego</li> <li>Adsorpçni filtrační prvek - granulovaný uhlík</li> <li>Adsorpcíos szűróbetét - granulált szén</li> <li>Adsorbčinio filtro kasetė - anglies granulės</li> <li>Kaseta adsorpcjskega filtra - zrnasti ogljik</li> <li>Kaxxa assorbenti tal-filtri - Karbonju mrammel</li> </ul>	<ul style="list-style-type: none"> <li>Adsorptiefilter cartridge - korrelvormige actieve kool</li> <li>Cartouche filtrante d'adsorption - Charbon en granulés.</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Cartucho filtrante de adsorción, gránulos de carbón.</li> <li>Filtro a cartuccia ad adsorbimento - granuli di carbone.</li> <li>Adsorpčná filtračná kazeta - Granulovaný uhlík</li> <li>Adsorpsjonsfiltre kassett - teralne súsi</li> <li>Absorbējoša filtra kasetne - graudains oglekis</li> <li>Adsorbcionný filtry kasetne - гранулированный уголь</li> <li>Adsorpsjyon filtresi kartušu - Taneli karbon</li> </ul>	<ul style="list-style-type: none"> <li>Adsorptiefilter cartridge - korrelvormige actieve kool</li> <li>Cartouche filtrante d'adsorption - Charbon en granulés.</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Cartucho filtrante de adsorción, gránulos de carbón.</li> <li>Filtro a cartuccia ad adsorbimento - granuli di carbone.</li> <li>Adsorpčná filtračná kazeta - Granulovaný uhlík</li> <li>Adsorpsjonsfiltre kassett - teralne súsi</li> <li>Absorbējoša filtra kasetne - graudains oglekis</li> <li>Adsorbcionný filtry kasetne - гранулированный уголь</li> <li>Adsorpsjyon filtresi kartušu - Taneli karbon</li> </ul>	<ul style="list-style-type: none"> <li>Adsorptiefilter cartridge - korrelvormige actieve kool</li> <li>Cartouche filtrante d'adsorption - Charbon en granulés.</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Adsorptionsfilterkassett - Kornigt kol</li> <li>Cartucho filtrante de adsorción, gránulos de carbón.</li> <li>Filtro a cartuccia ad adsorbimento - granuli di carbone.</li> <li>Adsorpčná filtračná kazeta - Granulovaný uhlík</li> <li>Adsorpsjonsfiltre kassett - teralne súsi</li> <li>Absorbējoša filtra kasetne - graudains oglekis</li> <li>Adsorbcionný filtry kasetne - гранулированный уголь</li> <li>Adsorpsjyon filtresi kartušu - Taneli karbon</li> </ul>
	<ul style="list-style-type: none"> <li>Adsorption filter element - Wrapped carbon cloth</li> <li>Adsorptie filterelement - gewikkeld koolstofdoek</li> <li>Adsorptionsfilterelement - eingewickeltes Filtertuch aus Kohlenstoff</li> <li>Cartouche filtrante d'adsorption - Charbon entouré de tissu.</li> <li>Adsorptionsuodateinelementti - kääritty hiilikangas</li> <li>Adsorptionsfilterelement - Veckad kolfiberduk</li> <li>Adsorpsjonsfilterelement - Innpakket karbonstoff</li> <li>Adsorptionsfilterelement - Veckad kolfiberduk</li> <li>Φίλτρο προσρόφησης - Τυλιγμένο ύφασμα άνθρακα</li> <li>Elemento filtrante de adsorción, capas de tejido de carbón.</li> <li>Elemento do filtro de adsorcão - Pano revestido de carvão</li> <li>Elemento filtrante ad adsorbimento - tessuto al carbone con struttura ad avvolgimento</li> <li>Wkład adsorpcyjny filtra ze zwijanej tkaniny z włókną węglowego</li> <li>Adsorpçni filtrační článok - Zabalená uhlíková tkanina</li> <li>Adsorpçni filtrační prvek - zabalená uhlíková tkanina</li> <li>Adsorpcíos szűróelem - isoleeritud süsikirri</li> <li>Adsorpcíos szűróelem - göngölyt szénszövet</li> <li>Absorbējošs filtra elements - satīta oglekla drānīna</li> <li>Adsorbcinis filtravimo elementas - susuktas anglies audinys</li> <li>Адсорбционный фильтрующий элемент – ткань из углеродистого волокна</li> <li>Adsorpcíos filtrírni element - navita ogljkova krpa</li> <li>Adsorpsjón filtresi ögesi - Sarili karbon kumaş</li> <li>Element tal-filtri li jassorbixxi - Xoqqa tal-karbonju mgeżwra</li> </ul>	<ul style="list-style-type: none"> <li>Adsorptiefilter element - wrapped carbon cloth</li> <li>Cartouche filtrante d'adsorption - charbon en tissu.</li> <li>Adsorptionsfilterelement - enroulé dans un tissu de carbone.</li> <li>Cartucho filtrante de adsorción, tela de carbón.</li> <li>Adsorptionsuodateinelementti - kääritty hiilikangas</li> <li>Adsorptionsfilterelement - veckad kolfiberduk</li> <li>Adsorpsjonsfilterelement - innpakket karbonstoff</li> <li>Adsorptionsfilterelement - veckad kolfiberduk</li> <li>Φίλτρο προσρόφησης - τυλιγμένο ύφασμα άνθρακα</li> <li>Elemento filtrante de adsorción, capas de tejido de carbón.</li> <li>Elemento do filtro de adsorcão - Pano revestido de carvão</li> <li>Elemento filtrante ad adsorbimento - tessuto al carbone con struttura ad avvolgimento</li> <li>Wkład adsorpcyjny filtra ze zwijanej tkaniny z włókną węglowego</li> <li>Adsorpçni filtrační článok - Zabalená uhlíková tkanina</li> <li>Adsorpçni filtrační prvek - zabalená uhlíková tkanina</li> <li>Adsorpcíos szűróelem - isoleeritud süsikirri</li> <li>Adsorpcíos szűróelem - göngölyt szénszövet</li> <li>Absorbējošs filtra elements - satīta oglekla drānīna</li> <li>Adsorbcinis filtravimo elementas - susuktas anglies audinys</li> <li>Адсорбционный фильтрующий элемент – ткань из углеродистого волокна</li> <li>Adsorpcíos filtrírni element - navita ogljkova krpa</li> <li>Adsorpsjón filtresi ögesi - Sarili karbon kumaş</li> <li>Element tal-filtri li jassorbixxi - Xoqqa tal-karbonju mgeżwra</li> </ul>	<ul style="list-style-type: none"> <li>Adsorptiefilter element - wrapped carbon cloth</li> <li>Cartouche filtrante d'adsorption - charbon en tissu.</li> <li>Adsorptionsfilterelement - enroulé dans un tissu de carbone.</li> <li>Cartucho filtrante de adsorción, tela de carbón.</li> <li>Adsorptionsuodateinelementti - kääritty hiilikangas</li> <li>Adsorptionsfilterelement - veckad kolfiberduk</li> <li>Adsorpsjonsfilterelement - innpakket karbonstoff</li> <li>Adsorptionsfilterelement - veckad kolfiberduk</li> <li>Φίλτρο προσρόφησης - τυλιγμένο ύφασμα άνθρακα</li> <li>Elemento filtrante de adsorción, capas de tejido de carbón.</li> <li>Elemento do filtro de adsorcão - Pano revestido de carvão</li> <li>Elemento filtrante ad adsorbimento - tessuto al carbone con struttura ad avvolgimento</li> <li>Wkład adsorpcyjny filtra ze zwijanej tkaniny z włókną węglowego</li> <li>Adsorpçni filtrační článok - Zabalená uhlíková tkanina</li> <li>Adsorpçni filtrační prvek - zabalená uhlíková tkanina</li> <li>Adsorpcíos szűróelem - isoleeritud süsikirri</li> <li>Adsorpcíos szűróelem - göngölyt szénszövet</li> <li>Absorbējošs filtra elements - satīta oglekla drānīna</li> <li>Adsorbcinis filtravimo elementas - susuktas anglies audinys</li> <li>Адсорбционный фильтрующий элемент – ткань из углеродистого волокна</li> <li>Adsorpcíos filtrírni element - navita ogljkova krpa</li> <li>Adsorpsjón filtresi ögesi - Sarili karbon kumaş</li> <li>Element tal-filtri li jassorbixxi - Xoqqa tal-karbonju mgeżwra</li> </ul>	<ul style="list-style-type: none"> <li>Adsorptiefilter element - wrapped carbon cloth</li> <li>Cartouche filtrante d'adsorption - charbon en tissu.</li> <li>Adsorptionsfilterelement - enroulé dans un tissu de carbone.</li> <li>Cartucho filtrante de adsorción, tela de carbón.</li> <li>Adsorptionsuodateinelementti - kääritty hiilikangas</li> <li>Adsorptionsfilterelement - veckad kolfiberduk</li> <li>Adsorpsjonsfilterelement - innpakket karbonstoff</li> <li>Adsorptionsfilterelement - veckad kolfiberduk</li> <li>Φίλτρο προσρόφησης - τυλιγμένο ύφασμα άνθρακα</li> <li>Elemento filtrante de adsorción, capas de tejido de carbón.</li> <li>Elemento do filtro de adsorcão - Pano revestido de carvão</li> <li>Elemento filtrante ad adsorbimento - tessuto al carbone con struttura ad avvolgimento</li> <li>Wkład adsorpcyjny filtra ze zwijanej tkaniny z włókną węglowego</li> <li>Adsorpçni filtrační článok - Zabalená uhlíková tkanina</li> <li>Adsorpçni filtrační prvek - zabalená uhlíková tkanina</li> <li>Adsorpcíos szűróelem - isoleeritud süsikirri</li> <li>Adsorpcíos szűróelem - göngölyt szénszövet</li> <li>Absorbējošs filtra elements - satīta oglekla drānīna</li> <li>Adsorbcinis filtravimo elementas - susuktas anglies audinys</li> <li>Адсорбционный фильтрующий элемент – ткань из углеродистого волокна</li> <li>Adsorpcíos filtrírni element - navita ogljkova krpa</li> <li>Adsorpsjón filtresi ögesi - Sarili karbon kumaş</li> <li>Element tal-filtri li jassorbixxi - Xoqqa tal-karbonju mgeżwra</li> </ul>
	<ul style="list-style-type: none"> <li>Ensure correct tool is used</li> <li>Zorg dat het juiste gereedschap wordt gebruikt</li> <li>Vérifier que les outils adéquats sont utilisés.</li> <li>Se till att rätt verktyg används.</li> <li>Sørg for at benytte korrekt værkøj</li> <li>Asegúrese de que se utiliza la herramienta adecuada</li> <li>Assicurarsi di utilizzare l'utensile corretto</li> <li>Uistite sa, že používate správny nástroj</li> <li>Tagago òige tööriista kasutamine</li> <li>Izmantojiet tikai atbilstošus darbarīkus</li> <li>Убедитесь, что используется правильный инструмент</li> <li>Doğru alet kullanılmamasını sağlayın</li> </ul>	<ul style="list-style-type: none"> <li>Stellen Sie sicher, dass Sie das richtige Werkzeug verwenden.</li> <li>Käytettävä oikeaa työkalua</li> <li>Pass på att korrekt verktyg brukas</li> <li>Βεβαιωθείτε ότι χρησιμοποιείται το σωστό εργαλείο</li> <li>Certifique-se de que é utilizada a ferramenta correcta</li> <li>Należy używać odpowiedniego narzędzia.</li> <li>Zkontrolujte použití správného nástroje</li> <li>Mindig a célnak megfelelő szerszámot használja</li> <li>Istinkinkite, kad naudojamas reikiamas īrankis</li> <li>Poskrbite, da boste uporabili ustrezno orodje</li> <li>Kun žgur li tintuża l-ghoddha t-tajba</li> </ul>	<ul style="list-style-type: none"> <li>Stellen Sie sicher, dass Sie das richtige Werkzeug verwenden.</li> <li>Käytettävä oikeaa työkalua</li> <li>Pass på att korrekt verktyg brukas</li> <li>Βεβαιωθείτε ότι χρησιμοποιείται το σωστό εργαλείο</li> <li>Certifique-se de que é utilizada a ferramenta correcta</li> <li>Należy używać odpowiedniego narzędzia.</li> <li>Zkontrolujte použití správného nástroje</li> <li>Mindig a célnak megfelelő szerszámot használja</li> <li>Istinkinkite, kad naudojamas reikiamas īrankis</li> <li>Poskrbite, da boste uporabili ustrezno orodje</li> <li>Kun žgur li tintuża l-ghoddha t-tajba</li> </ul>	<ul style="list-style-type: none"> <li>Stellen Sie sicher, dass Sie das richtige Werkzeug verwenden.</li> <li>Käytettävä oikeaa työkalua</li> <li>Pass på att korrekt verktyg brukas</li> <li>Βεβαιωθείτε ότι χρησιμοποιείται το σωστό εργαλείο</li> <li>Certifique-se de que é utilizada a ferramenta correcta</li> <li>Należy używać odpowiedniego narzędzia.</li> <li>Zkontrolujte použití správného nástroje</li> <li>Mindig a célnak megfelelő szerszámot használja</li> <li>Istinkinkite, kad naudojamas reikiamas īrankis</li> <li>Poskrbite, da boste uporabili ustrezno orodje</li> <li>Kun žgur li tintuża l-ghoddha t-tajba</li> </ul>

**Warning!**

This product must be installed and maintained by competent and authorised personnel only, under strict observance of these operating instructions, any relevant standards and legal requirements where appropriate.

**Retain this user guide for future reference**

**Waarschuwing!**

Dit product mag alleen geïnstalleerd en onderhouden worden door deskundig en bevoegd personeel met strikte inachtneming van deze bedieningsinstructies en de betreffende normen en wettelijke vereisten indien van toepassing.

**Bewaar deze handleiding als naslag.**

**Warnung!**

Das Produkt darf ausschließlich von autorisiertem Fachpersonal unter strikter Befolgung dieser Betriebsanleitung, ggf. relevanter Normen sowie gesetzlicher Vorschriften installiert und gewartet werden.

**Bewahren Sie die Bedienungsanleitung zu Referenzzwecken auf.**

**Attention !**

Ce produit doit être installé et entretenu exclusivement par un personnel compétent et autorisé, dans le respect le plus strict de ce mode d'emploi et des normes applicables et exigences légales éventuelles.

**Conserver ce guide de l'utilisateur à titre de référence future**

**Varoitus!**

Tämän tuotteen saa asentaa ja huoltaa vain pätevä ja valtuutettu henkilöstö, noudattaen tarkasti näitä käyttöohjeita, kaikkia asiaankuuluvia normeja ja tarpeen vaatessa lain asettamia vaatimuksia.

**Säilytä tämä käyttöohje tulevaa tarvetta varten.**

**Varning!**

Produkten får endast installeras och underhållas av utbildad och behörig personal, som följer denna bruksanvisning och eventuella tillämpliga normer och lagföreskrifter noga i förekommande fall.

**Behåll denna användarhandbok som referens**

**Advarsel!**

Dette produktet må bare installeres og vedlikeholdes av kompetent og autorisert personale, i streng overholdelse av disse betjeningsanvisningene, alle relevante standarder og rettslige krav der det passer.

**Ta vare på denne brukerveiledningen for senere bruk**

**Advarsel!**

Dette produktet må kun installeres og vedligeholdes af autoriseret personale, under nøje overholdelse af disse driftsinstruktioner, relevante standarder og lovgivningsmæssige krav, hvor dette er aktuelt.

**Gem denne vejledning til senere reference.**

**Προειδοποίηση!**

Η εγκατάσταση και συντήρηση αυτού του προϊόντος πρέπει να γίνεται μόνο από κατάλληλα εκπαιδευμένο και εξουσιοδοτημένο προσωπικό, με αυστηρή τήρηση των οδηγιών χειρισμού, των εφαρμοζόμενων προτύπων και των νομικών απαιτήσεων όπου απαιτείται.

**Φυλάξτε αυτό το εγχειρίδιο χρήσης για μελλοντική αναφορά**

**Advertencia**

La instalación y mantenimiento de este producto debe ser efectuada únicamente por personal competente y autorizado, respetándose de forma estricta estas instrucciones de funcionamiento, así como cualquier norma y requerimiento legal que sean aplicables.

**Conserve esta guía del usuario para poder consultarla en el futuro.**

**Advertência!**

A instalação e a manutenção deste produto só deve ser realizada por pessoal autorizado e competente, sob estrita observância destas instruções de utilização e de quaisquer normas e requisitos legais relevantes, quando adequado.

**Conserve este guia do utilizador para referência futura**


**Rakkomandazzjonijiet ghall-Installazzjoni**

Nirrakkomandaw li l-arja kompressata tiġi trattata qabel ma tidhol fis-sistema ta' distribuzzjoni kif ukoll fil-punti ċi l-applikazzjonijiet kritici ta' l-užu.

L-installazzjoni ta' tagħmir li jnixxef l-arja kumpressata fuq sistema li kienet imxarba jista' jirriżulta f'aktar tagħbi ja ta' hmieġ għall-filtri li jintużaw f-punt wieħed, għall-perjodu sakemm is-sistema ta' distribuzzjoni tinxxf. L-elementi tal-filtri jista' jkollhom bżonn li jinbidlu aktar spiss matul dan il-perjodu.

Għal installazzjonijiet fejn jintużaw kumpressuri mingħajr jejt, xorta jkun hemm preżenti ajrusols u partijiet ta' l-ilma, għalhekk xorta għandhom jintużaw grad bi skop generali u b'efficċjenza kbira.

Filtru għal skopijiet generali għandu dejjem jiġi installat biex jipprotegi l-filtri ta' efficċjenza kbira mill-volum kbir ta' ajrusols likwid u partijiet solidi.

Installa tagħmir ta' purifikazzjoni fl-aktar temperatura baxxa possibbi imma b'mod li ma jkunx hemm iffrizziar, preferibilment aktar 'l-isfel mill-aftercoolers u mir-riċevituri ta' l-arja.

Tagħmir tal-purifikazzjoni fil-punt ta' l-užu għandu jiġi installat aktar 'l-isfel mill-valvs li jifthu malajr u għandu jkun protett minn possibilità ta' fluss b'lura jew kundizzjonijiet oħra stressanti.

Naddaf il-pajps kollha li jwasslu għażiex tagħmir ta' purifikazzjoni qabel tinstalla u l-pajps kollha wara li tinstalla t-tagħmir ta' purifikazzjoni u qabel ma tqabbar ma' l-applikazzjoni finali.


Jekk tififtija linji ta' by-pass madwar it-taghmir ta' purifikazzjoni, kun żgur li hemm biżżejjed filtrazzjoni ffittjata mal-linjal ta-by-pass biex ma thallix li jkun hemm kontaminazzjoni tas-sistema aktar 'l-isfel.

Ipprovi facilità biex tiddrejnejna l-likwidli li jingħabru mit-taghmir tal-purifikazzjoni. Il-likwidli li jingħabru għandhom jiġu trattati u mormija b'mod risponsabli.


Iż-żmien kemm idumu jservu l-elementi tal-filtri li jneħhi l-fwar taż-żjut huwa affettwat mill-koncentrazzjoni taż-żejt tad-dħul, l-umdiċċa relativa u t-temperatura tas-sistema ta' l-arja kumpressata. L-elementi li jneħħu l-fwar taż-żjut ikollhom bżonn jinbidlu aktar ta' sikkut mill-element shiħi ekwivalenti.

Mudelli AC010□□□ - AC030□□□ huma ffittjati b'indikatur tal-volum taż-żejt. Kemm l-elementi tal-filtri kif ukoll l-indikatur għandhom jinbidlu jekk l-indikatur isir ta' kultur blu.

**Jekk Joghġbok Innota - Dan hu indikatur tal-volum taż-żejt u ma jindikax iż-żmien li jdum iservi l-element tal-filtri.**




AC010 - AC030




**AC010 - AC030**
**5. Spare Parts (Service Kits)**
**Reserve-onderdelen (servicekits) • Ersatzteile (Service-Kits) • Pièces de rechange (nécessaires d'entretien) • Varaosat (Huoltopakkaukset)**

- Reservdelar (servicesatser) • Reservedeler (service-sett) • Reservedele (Servicekit) • Ανταλλακτικά (Πακέτα τεχνικής υποστήριξης)
- Piezas de repuesto (kits de mantenimiento) • Peças Sobressalentes (Kit de Reparação) • Ricambi (kit per l'assistenza)
- Części zamienne (zestawy serwisowe) • Náhradné diely (Servisná súprava) • Náhradní díly (Sady pro údržbu) • Varuosad (hoolekomplektid)
- Pótalkatrészek (szervizkészletek) • Rezerves daļas (apkopes komplekti) • Atsarginės dalys (priežiuros detalijų komplektai)
- Запасные части (ЗИП) • Nadomestni deli (servisni kompleti) • Yedek parça (Servis kitleri) • Partijet Għat-Tibdil (Kitts tas-Servizz)

 <b>EF1</b>	<ul style="list-style-type: none"> <li>• AUTOMATIC DRAIN</li> <li>• AUTOMATISCHER ABLAUF</li> <li>• VIDANGE AUTOMATIQUE</li> <li>• AUTOMISCHAFTAPPEN</li> <li>• DRENAJE AUTOMATICO</li> <li>• SCARIO AUTOMATICO</li> <li>• AUTOMATISK AFLØB</li> <li>• DRENO AUTOMÁTICO</li> <li>• AYTOMATH ΑΠΟΣΤΡΑΓΓΙΣΗ</li> <li>• AUTOMATDRÄNERING</li> <li>• AUTOMAATTINEN</li> <li>• TYHJENNYSKAPPALE</li> <li>• DREN AUTOMATYCZNY</li> <li>• AUTOMATICKE VYSUŠENIE</li> <li>• AUTOMATICKE VYPOUŠTĚNÍ</li> <li>• AUTOMAATNE VÄLJALASE</li> <li>• AUTOMATIKUS LEERESZTÉS</li> <li>• AUTOMÁTISKA IZTECINĀŠANA</li> <li>• AUTOMATINIS IŠLEIDIMAS</li> <li>• АВТОМАТИЧЕСКИЙ ДРЕНАЖ</li> <li>• SAMODEJNI ODTOK</li> <li>• OTOMATİK SÜZDÜRÜCÜ</li> <li>• DREJN AWATOMATIKU</li> </ul>	 <b>EM1</b>	<ul style="list-style-type: none"> <li>• MANUAL DRAIN</li> <li>• MANUELLE ABLAUF</li> <li>• VIDANGE MANUELLE</li> <li>• MANUEEL AFTAPPEN</li> <li>• DRENAJE MANUAL</li> <li>• SCARIO MANUALE</li> <li>• MANUELT AFLØB</li> <li>• DRENO MANUAL</li> <li>• ΧΕΙΡΟΚΙΝΗΤΗ ΑΠΟΣΤΡΑΓΓΙΣΗ</li> <li>• MANUELL DRÄNERING</li> <li>• KÄSIKÄYTTÖINEN</li> <li>• TYHJENNYSKAPPALE</li> <li>• DREN RĘCZNY</li> <li>• RUČNÉ VYSUŠENIE</li> <li>• RUČNÍ VYPOUŠTĚNÍ</li> <li>• KÄSITSI VÄLJALASE</li> <li>• KÉZI LEERESZTÉS</li> <li>• MANUĀLA IZTECINĀŠANA</li> <li>• RANKINIS IŠLEIDIMAS</li> <li>• ДРЕНАЖ ВРУЧНЮЮ</li> <li>• ROČNÍ ODTOK</li> <li>• ELLE KULLANILACAK SÜZDÜRÜCÜ</li> <li>• DREJN MANWALI</li> </ul>
---	---	---	---


 <b>010 A</b>
 <b>010 B</b>
 <b>010 C</b>
 <b>015 B</b>
 <b>015 C</b>
 <b>020 C</b>
 <b>020 D</b>
 <b>020 E</b>
 <b>025 D</b>
 <b>025 E</b>
 <b>030 E</b>
 <b>030 F</b>
 <b>030 G</b>

 <b>010AA</b>	 <b>010AC</b>
 <b>015AA</b>	 <b>015AC</b>
 <b>020AA</b>	 <b>020AC</b>
 <b>025AA</b>	 <b>025DAC</b>
 <b>025AA</b>	 <b>025EAC</b>
 <b>030AA</b>	 <b>030AC</b>



**AC010 - AC030**
**6. Maintenance**

Onderhoud • Wartung • Entretien • Kunnossapito • Underhåll • Vedlikehold • Vedlikeholdelse • Συντήρηση • Mantenimiento • Manutenção • Manutenzione • Konserwacja • Údržba • Údržba • Hooldus • Karbantartás • Tehnická akope • Techniné priežúra • Обслуживание • Vzdrževanja • Bakım • Manutenzioni



Models AC010□□□I - AC030□□□I are fitted with a bulk oil indicator. Both filter elements and indicator should be changed if indicator is blue in colour.

**Please Note - This is a bulk oil indicator, it does not indicate filter element life.**

Modellen AC010□□□I - AC030□□□I zijn uitgerust met een bulk olie indicator. Zowel de filterelementen als de indicator moeten vervangen worden als de indicator blauw van kleur is.

**N.B. - Dit is een bulk olie indicator, het is geen indicator voor de levensduur van het filterelement.**

Die Modelle AC010□□□I - AC030□□□I sind mit einer Ölanzeige ausgestattet. Sowohl die Filterelemente also auch die Anzeige sollte ausgetauscht werden, wenn sich die Anzeige blau färbt.

**Bitte beachten - Es handelt sich hier um eine Ölwanzeige. Diese gibt keinen Hinweis auf die Lebensdauer des Filterelements.**

Les modèles AC010□□□I - AC030□□□I sont fournis avec un indicateur de présence massive d'huile. Lorsque l'indicateur est bleu, il est nécessaire de remplacer les cartouches et l'indicateur.

**Remarque : Il s'agit d'un indicateur de présence massive d'huile, et non pas de la durée de vie des cartouches.**

Malleissa AC010□□□I - AC030□□□I on öljynilmäisin. Sekä suodatinelementit että ilmäisin on vaihdettava, jos ilmäisin on sininen.

**Huomautus – Tämä on öljynilmäisin. Se ei ilmaise suodatinelementin ikää.**

Modell AC010□□□I - AC030□□□I har en indikator för större mängder olja. Både filterelement och indikator ska bytas om indikatorn har blå färg.

**Observera — indikatorn visar oljeförekomst, den indikerar inte filterelementets livslängd.**

Modell AC010□□□I - AC030□□□I er montert med bulkvolum oljeindikator. Både filterelementer og indikator skal skiftes når indikatoren er blå.

**Merk – Dette er en bulkvolum oljeindikator, den indikerer ikke filterelementets levetid.**

Modell AC010□□□I - AC030□□□I har en indikator för större mängder olja. Både filterelement och indikator ska bytas om indikatorn har blå färg.

**Observera — indikatorn visar oljeförekomst, den indikerar inte filterelementets livslängd.**

Ta μοντέλα AC010□□□I - AC030□□□I διαθέτουν ένα δείκτη παρουσίας λαδιού. Όταν ο δείκτης είναι μπλε πρέπει να αλλάζονται τόσο τα φίλτρα όσο και οι δείκτες.

**Παρακαλούμε σημειώστε ότι - Αυτός είναι ένας δείκτης παρουσίας λαδιού, δεν υποδεικνύει τη διάρκεια ζωής του φίλτρου.**

Los modelos AC010□□□I - AC030□□□I disponen de un indicador de presencia de aceite. Si el indicador se vuelve azul deben cambiarse tanto los elementos filtrantes como el indicador.


**Nota importante: se trata de un indicador de presencia de aceite. No indica la vida del elemento filtrante.**

Modelos AC010□□□I - AC030□□□I são instalados com um indicador do óleo em bruto. Ambos os elementos do filtro e o indicador deverão ser mudados se o indicador estiver azul.


**Nota - Este é um indicador do óleo em bruto, não indica a vida útil do elemento do filtro.**

I modelli AC010□□□I - AC030□□□I sono provvisti di un indicatore degli oli misti. Sostituire gli elementi filtranti e l'indicatore quando il secondo assume una colorazione blu.


**Nota - L'indicatore segnala la presenza di oli misti, ma non la durata dell'elemento filtrante.**




7




8




9




10




11




12




13



14



15



<b>Declaration of Conformity</b>		<b>Verklaring van Conformiteit</b>		<b>NL</b>	
Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ, UK <b>AC010, 015, 020 025, 030</b>		domnick hunter Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ, GB <b>AC010, 015, 020 025, 030</b>		domnick hunter Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ GROSSBRITANNIEN <b>AC010, 015, 020 025, 030</b>	
<b>Directives</b>	97/23/EC.	<b>Richtlijnen</b>	97/23/EC.	<b>Richtlijnen</b>	97/23/EC.
<b>Standards used</b>	Generally in accordance with ASME/VIII Div 1 : 2004.	<b>Gehanteerde normen</b>	Gewoonlijk volgens ASME/VIII Div 1 : 2004. Artikel 3.3 (AC010, 015, 020, 025) Module A (AC030)	<b>Angewandte Normen</b>	Allgemein in Übereinstimmung mit ASME/VIII Div 1 : 2004.
<b>PEI Assessment Route:</b>	Article 3.3 (AC 030)	<b>PED-beoordelingstraject:</b>	N/A	<b>Beurteilungsroute der Druckgeräterichtlinie:</b>	Artikel 3.3 (AC010, 015, 020, 025) Modul A (AC030)
<b>Notified body for PED:</b>	N/A	<b>Aangemelde instantie voor PED:</b>	N/A	<b>Benannte Stelle für die Druckgeräterichtlinie:</b>	N/A
<b>EC Type-examination Certificate:</b>	N/A	<b>EC Type onderzoeks certificaat:</b>	N/A	<b>EG-Baumusterprüfungsberechtigung:</b>	N/A
<b>Authorised Representative</b>	Barry Wade Business Systems Improvement Manager domnick hunter ltd	<b>Bevoegde vertegenwoordiger</b>	Barry Wade Manager Bedrijfsysteemverbetering domnick hunter ltd	<b>Bevorwijkende Vertreter</b>	Barry Wade Business Systems Improvement Manager domnick hunter ltd
<b>Declaration</b>		<b>Verklaring</b>		<b>Erklärung</b>	
I declare that as the authorised representative, the above information in relation to the supply / manufacture of this product, is in conformity with the standards and other related documents following the provisions of the above Directives.		Als bevoegde vertegenwoordiger verklaar ik dat bovenstaande informatie met betrekking tot de levering / verkoop van dit product overeenstemt met de normen en andere bijbehorende documentatie volgens de bepalingen van bovengenoemde richtlijnen.		Hiermit erkläre ich als bevollmächtigter Vertreter die Konformität der oben aufgeführten Informationen in Bezug auf die Lieferung/Herstellung dieses Produkts mit den Normen und anderen zugehörigen Dokumenten gemäß den Bestimmungen der oben genannten Richtlinien.	
<b>Signature:</b>	<i>Domnick Hunter</i>	<b>Date:</b>	28 / 09 / 05	<b>Unterschrift:</b>	<i>Domnick Hunter</i>
		<b>Declaration Number:</b>	<b>Verklaringnummer:</b>	<b>Nummer der Erklärung:</b>	
			<b>0001/280905</b>	<b>0001/280905</b>	

<b>Declaration of Conformité</b>		<b>Vatitustenmukaisuusvakuutus</b>		<b>FI</b>	
Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ, UK <b>AC010, 015, 020 025, 030</b>		domnick hunter Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ ISO-BRITANNIA <b>AC010, 015, 020 025, 030</b>		domnick hunter Dukesway, TV/TE, Gateshead, Tyne & Wear, NE11 0PZ, Storbritannien <b>AC010, 015, 020 025, 030</b>	
<b>Directives</b>	97/23/EC.	<b>Direktivit</b>	97/23/EC., Yleensä seuraavan standardin mukaisesti: ASME/VIII Div 1: 2004. Artikel 3.3 (AC010, 015, 020, 025, 030) Module A (AC030)	<b>Direktiv</b>	97/23/EC., Generell i enlighet med ASME/VIII Div 1: 2004. Artikel 3.3 (AC010, 015, 020, 025, 030) Modul A (AC030)
<b>Normes utilisées</b>	Généralement conforme à ASME/VIII Div 1 : 2004. Article 3.3 (AC010, 015, 020, 025, 030) Module A (AC030)	<b>Méthode d'évaluation de la directive d'équipements de pression :</b>	Käytetty standardi PED-avaintunnistetieto:	<b>Använda standarder</b>	Fastställdningsväg för PED:
<b>Organisme de notification pour la directive d'équipement sous pression :</b>	N/A	<b>Certificat d'examen de type CE :</b>	PED-säännösten ilmoitettu laitos: EU-typpihyväksymän sertifikaatti: Vahvuuttetu edustaja	<b>Ämält organ för PED:</b>	Ett intyg om typrovnning: Auktoriserad representant
<b>Représentant agréé</b>	Barry Wade Business Systems Improvement Manager domnick hunter ltd		N/A Barry Wade Yritysjärjestelmien kehittyspäällikkö domnick hunter ltd		
<b>Declaration</b>		<b>Vakuutus</b>		<b>Förståkran om överensstämmelse</b>	
Je déclare à titre de représentant agréé que les informations ci-dessus liées à la fourniture/fabrication de ce produit sont en conformité avec les normes et autres documents lis déclarés selon les dispositions des directives susmentionnées.		Vahvistetaan edustajana vakuutuksen, että yllä olevat tiedot, joita liittyy tämän tuotteen toimitamiseen tai valmistamiseen, ovat standardien ja muiden asianmukaisten asiasopimusten mukaisia ja noudattavat yllä mainittuja direktivejä.		Jag försäkrar i egenskap av autoriseras representant att ovannämnda information avseende leverans/ tillverkning av detta produkt överensstämmer med standarder och övriga relevanta dokument enligt vilket en lovanslände direktiv.	
<b>Signature :</b>	<i>Domnick Hunter</i>	<b>Date :</b>	28 / 09 / 05	<b>Underskrift:</b>	<i>Domnick Hunter</i>
		<b>Vakuutuksen numero:</b>	<b>0001/280905</b>	<b>Förståkran nummer:</b>	
				<b>0001/280905</b>	

## **13.8 Option Ic**

### **Service tasks on the diesel particulate filter**

To ensure the proper functioning of the diesel particulate filter, an authorised service technician must perform annual maintenance.

Have the following tasks performed by a specialist shop or the KAESER Service:

- Pressure lines:
  - Check for tight joints, wear and leaks.
- Solenoid valve
  - Check that all electrical connections are tight.
  - Undo fittings and hoses and clean the inside of the valve.
  - Check for leaks.
- Fuel pump(s)
  - Make a visual and auditory check.
  - Check that all electrical connections are tight.
  - Check fuel hoses for leaks.
- Aerosol generator
  - Check that all electrical connections are tight.
  - Check fuel connection for leaks.
  - Clean the injector nozzle.
- Filter module
  - Visually inspect for damage, inside and outside.
  - Check monoliths for cracks/soot emissions.
  - Remove dirt with industrial vacuum cleaner.
  - Check tightness of straps and/or clamps.

## **13.9 Option ga**

### **Service tasks - Generator**

In order to ensure a safe operation of the machine, the generator must be inspected once every year by a trained and authorised electrician.

Have the following tasks performed by a specialist electrician or the KAESER Service:

- Inspection of the generator and generator control cubicle for mechanical damages.
- Inspection of the protective conductor.
- Measurement of the dielectric resistance.
- Measurement of the substitute leakage current.
- Inspection of generator functionality.
- Inspection of the proper functioning of the generator fan and cleaning, if required.
- Cleaning the cooling air apertures.
- Check all screwed connections on the generator and control box and tighten if necessary.
- Check covers and power socket caps for damage and good sealing.
- Check that all warning and other labels are complete and undamaged.