

# Operating manual

Rotary screw compressor

MOBILAIR M81.2

902508 02 E

Manufacturer:

**KAESER KOMPRESSOREN SE**

96410 Coburg • PO BOX 2143 • GERMANY • Tel. +49-(0)9561-6400 • Fax +49-(0)9561-640130

[www.kaeser.com](http://www.kaeser.com)



# Contents

|   |    |
|---|----|
| <b>1 About this document</b>  |    |
| 1.1 Further documents .....   | 7  |
| 1.2 Warning notices .....   | 7  |
| 1.3 Symbols and pictograms .....  | 8  |
| 1.4 Material damage warnings .....                                      | 8  |
| 1.5 Warranty .....  | 9  |
| 1.6 Protected brands and trademarks .....                               | 9  |
| 1.7 Copyright .....   | 9  |
| <b>2 Technical data</b>   |    |
| 2.1 Identification markings .....                                       | 10 |
| 2.1.1 Vehicle identification number .....                               | 10 |
| 2.1.2 Nameplate .....   | 10 |
| 2.1.3 Options label .....   | 11 |
| 2.2 Machine .....   | 12 |
| 2.2.1 Weight .....  | 12 |
| 2.2.2 Noise emission .....  | 13 |
| 2.2.3 Tightening torque .....   | 13 |
| 2.2.4 Ambient conditions .....  | 14 |
| 2.2.5 Additional information as per the machine operating licence ..... | 14 |
| 2.3 Compressor .....  | 14 |
| 2.3.1 Working pressure, pressure rating .....                           | 14 |
| 2.3.2 Variable pressure-flow rate control .....                         | 15 |
| 2.3.3 Compressed air outlet .....                                       | 16 |
| 2.3.4 Safety valve actuating pressure .....                             | 16 |
| 2.3.5 Temperature .....   | 17 |
| 2.3.6 Compressor oil .....  | 17 |
| 2.4 Drive engine .....  | 19 |
| 2.4.1 Engine specification .....  | 19 |
| 2.4.2 Engine oil recommendation .....                                   | 19 |
| 2.4.3 Fuel specification .....  | 20 |
| 2.4.4 Fill volumes .....  | 20 |
| 2.4.5 Carbon dioxide emissions .....                                    | 21 |
| 2.4.6 Battery .....   | 21 |
| 2.5 Options .....   | 21 |
| 2.5.1 ba bb Low-temperature equipment .....                             | 21 |
| 2.5.2 da Heating for compressed air condensate separator .....          | 22 |
| 2.5.3 ea ec Tool lubricator .....                                       | 22 |
| 2.5.4 ga Generator .....  | 22 |
| 2.5.5 oc Telematics .....   | 25 |
| 2.5.6 od Battery trickle charging .....                                 | 27 |
| <b>3 Safety and responsibility</b>                                      |    |
| 3.1 Intended use .....  | 28 |
| 3.2 Improper use .....  | 28 |
| 3.3 Dangers .....   | 28 |
| 3.4 Danger areas .....  | 32 |
| 3.5 Safety and information signs .....                                  | 33 |
| 3.6 Operator responsibilities .....                                     | 36 |
| 3.6.1 Determining suitable personnel .....                              | 37 |
| 3.6.2 Organisational measures .....                                     | 37 |
| 3.6.3 Complying with inspection intervals .....                         | 37 |
| 3.7 Emergencies .....   | 37 |
| 3.7.1 Correct conduct in the event of fire .....                        | 37 |
| 3.7.2 First aid measures following contact with compressor oil .....    | 38 |
| 3.8 Environmental protection .....                                      | 38 |
| 3.9 ga Operating the generator .....                                    | 39 |

|          |  |    |
|----------|--|----|
| 3.9.1    | Protective measures against shock currents .....       | 39 |
| 3.9.2    | Operating the generator safely .....                   | 39 |
| 3.9.3    | Connecting an extension cable .....                    | 39 |
| 3.9.4    | Do not exceed the maximum network load .....           | 40 |
| 3.9.5    | Performing regular checks on the generator .....       | 40 |
| <b>4</b> | <b>Design and function</b>                             |    |
| 4.1      | Bodywork .....   | 41 |
| 4.2      | Machine layout .....                                   | 42 |
| 4.3      | Machine function .....                                 | 43 |
| 4.4      | Operating points and control modes .....               | 44 |
| 4.4.1    | Machine operating points .....                         | 44 |
| 4.4.2    | MODULATING CONTROL .....                               | 45 |
| 4.5      | Safety devices .....                                   | 45 |
| 4.5.1    | Monitoring function with shutdown .....                | 45 |
| 4.5.2    | Further safety devices .....                           | 45 |
| 4.6      | SIGMA CONTROL SMART control unit .....                 | 45 |
| 4.6.1    | Controller overview .....                              | 45 |
| 4.6.2    | Operating elements .....                               | 46 |
| 4.6.3    | Display elements .....                                 | 47 |
| 4.7      | Variable pressure-flow rate control .....              | 49 |
| 4.8      | Exhaust gas after-treatment .....                      | 49 |
| 4.8.1    | Drive engine specification according to version .....  | 49 |
| 4.9      | Options function .....                                 | 50 |
| 4.9.1    | ba bb Low-temperature equipment .....                  | 50 |
| 4.9.2    | da db dd df dg Compressed air treatment .....          | 50 |
| 4.9.3    | ga Generator .....                                     | 52 |
| 4.9.4    | la lb Operation in fire hazard areas .....             | 54 |
| 4.9.5    | oa Battery isolating switch .....                      | 55 |
| 4.9.6    | ob Automatic START/STOP .....                          | 55 |
| 4.9.7    | oc TELEMATICS .....                                    | 56 |
| 4.9.8    | od Battery trickle charging .....                      | 58 |
| 4.9.9    | oe Closed floor pan .....                              | 58 |
| 4.9.10   | sf Anti-theft device .....                             | 58 |
| 4.9.11   | ua Hose reel .....                                     | 59 |
| 4.9.12   | Document bag .....                                     | 59 |
| <b>5</b> | <b>Transport and storage</b>                           |    |
| 5.1      | Transport damage .....                                 | 60 |
| 5.2      | Transporting the machine by crane .....                | 60 |
| 5.2.1    | Attaching a crane hook and lifting the machine .....   | 60 |
| 5.3      | rw Transporting the machine by forklift .....          | 61 |
| 5.4      | Transporting as a load .....                           | 61 |
| 5.4.1    | Load securing for mobile machines .....                | 61 |
| 5.4.2    | Load securing for stationary machines .....            | 62 |
| 5.4.3    | Transporting the machine by air freight .....          | 63 |
| 5.5      | Decommissioning the machine .....                      | 63 |
| 5.5.1    | Temporary decommissioning .....                        | 63 |
| 5.5.2    | Long-term decommissioning .....                        | 64 |
| <b>6</b> | <b>Installation and operating conditions</b>           |    |
| 6.1      | Installation conditions at installation location ..... | 66 |
| 6.2      | Ensuring accessibility .....                           | 67 |
| <b>7</b> | <b>Assembly and installation</b>                       |    |
| 7.1      | Determining anti-vibration elements .....              | 68 |
| 7.2      | Installing vibration elements .....                    | 68 |
| 7.3      | Performing assembly work on the chassis .....          | 69 |
| <b>8</b> | <b>Commissioning</b>                                   |    |
| 8.1      | To be observed during initial commissioning .....      | 70 |

|           |  |     |
|-----------|--|-----|
| 8.2       | Recommissioning following storage or decommissioning .....               | 70  |
| 8.2.1     | Checking the condition of the drive engine .....                         | 70  |
| 8.2.2     | Checking the condition of the compressor .....                           | 71  |
| 8.2.3     | Maintaining the bodywork .....   | 71  |
| 8.2.4     | Arranging for the technical condition of the machine to be checked ..... | 71  |
| 8.3       | Checking installation and operating conditions .....                     | 71  |
| 8.4       | To be observed during operation at low temperatures .....                | 72  |
| 8.4.1     | Checking the warm-up function in low temperatures .....                  | 72  |
| 8.4.2     | Starting assistance .....  | 73  |
| <b>9</b>  | <b>Operation</b>   |     |
| 9.1       | Starting and stopping .....  | 76  |
| 9.1.1     | Following the quick reference guide .....                                | 77  |
| 9.1.2     | Control panel .....  | 77  |
| 9.1.3     | Start the machine .....  | 78  |
| 9.1.4     | Setting the compressed air discharge pressure .....                      | 79  |
| 9.1.5     | Stopping the machine .....   | 79  |
| 9.1.6     | Closing daily operation .....  | 80  |
| 9.1.7     | Shutting the machine down in an emergency .....                          | 80  |
| 9.2       | Filling the fuel tank with fuel .....                                    | 81  |
| 9.2.1     | Using the proper fuel type .....   | 81  |
| 9.2.2     | Correctly filling the fuel tank .....                                    | 82  |
| 9.3       | Using the options .....  | 82  |
| 9.3.1     | bb Using the coolant preheating .....                                    | 82  |
| 9.3.2     | da dg Compressed air aftercooler with bypass .....                       | 83  |
| 9.3.3     | df Switching on the heat exchanger .....                                 | 84  |
| 9.3.4     | ea ec Using the tool lubricator .....                                    | 86  |
| 9.3.5     | ga Operating the generator .....   | 87  |
| 9.3.6     | ua Using the hose reel .....   | 89  |
| <b>10</b> | <b>Fault recognition and rectification</b>                               |     |
| 10.1      | Evaluating drive engine errors and faults .....                          | 91  |
| 10.2      | Evaluating compressor errors and faults .....                            | 92  |
| 10.3      | ga Evaluating generator errors and faults .....                          | 94  |
| <b>11</b> | <b>Maintenance</b>   |     |
| 11.1      | Ordering spare parts and operating fluids/materials .....                | 98  |
| 11.2      | Following the maintenance schedule .....                                 | 98  |
| 11.2.1    | Logging maintenance work .....   | 98  |
| 11.2.2    | Regular maintenance intervals .....                                      | 99  |
| 11.2.3    | Maintenance schedule following initial commissioning .....               | 99  |
| 11.2.4    | Machine maintenance schedule .....                                       | 99  |
| 11.2.5    | Options maintenance schedule .....                                       | 103 |
| 11.3      | Servicing the drive engine .....   | 104 |
| 11.3.1    | Checking the coolant .....   | 104 |
| 11.3.2    | Engine air filter maintenance .....                                      | 107 |
| 11.3.3    | Servicing the fuel system .....  | 111 |
| 11.3.4    | Servicing the engine oil circuit .....                                   | 116 |
| 11.3.5    | Servicing the drive belt .....   | 121 |
| 11.3.6    | Servicing the exhaust gas after-treatment .....                          | 125 |
| 11.3.7    | Servicing the battery .....  | 127 |
| 11.4      | Servicing the compressor .....   | 132 |
| 11.4.1    | Servicing the compressor oil circuit .....                               | 132 |
| 11.4.2    | Dirt trap maintenance on the fluid distribution module .....             | 136 |
| 11.4.3    | Replacing the oil separator cartridge .....                              | 137 |
| 11.4.4    | Servicing the compressor air filter .....                                | 138 |
| 11.5      | Cleaning the coolers .....   | 143 |
| 11.6      | Checking screw connections .....   | 144 |
| 11.6.1    | General guideline values for tightening torques .....                    | 144 |
| 11.6.2    | Specific guideline values for tightening torques .....                   | 145 |
| 11.6.3    | Sealed screw connections .....   | 145 |
| 11.7      | Check sound insulation material .....                                    | 145 |

|               |  |            |
|---------------|--|------------|
| 11.8          | Checking the wing doors .....                                  | 146        |
| 11.8.1        | Maintaining the rubber seals .....                             | 146        |
| 11.8.2        | Checking the closing function of the wing doors .....          | 146        |
| 11.8.3        | Checking the connection elements on the wing doors .....       | 147        |
| 11.9          | Checking or replacing hose lines .....                         | 147        |
| 11.9.1        | Replacing the drive engine fuel hoses .....                    | 147        |
| 11.9.2        | Replacing the pressure hoses on the drive engine .....         | 148        |
| 11.9.3        | Replace the pressure hoses of the compressor .....             | 148        |
| 11.10         | Testing the safety functions .....                             | 148        |
| 11.10.1       | Checking the EMERGENCY STOP device .....                       | 148        |
| 11.10.2       | Testing the safety valve actuating pressure .....              | 149        |
| 11.10.3       | Testing the excess temperature safety shutdown .....           | 149        |
| 11.11         | Servicing the options .....                                    | 150        |
| 11.11.1 da    | Servicing the compressed air aftercooler .....                 | 150        |
| 11.11.2 da    | Servicing the dirt trap on the water separator .....           | 151        |
| 11.11.3 dd    | Servicing the filter combination .....                         | 153        |
| 11.11.4 ea ec | Maintaining the tool lubricator .....                          | 156        |
| 11.11.5 ga    | Servicing the generator .....                                  | 157        |
| 11.11.6 la    | Servicing the spark arrester .....                             | 158        |
| 11.11.7 lb    | Maintaining the engine air shut-off valve .....                | 159        |
| 11.11.8 oe    | Servicing the closed floor pan .....                           | 161        |
| 11.12         | Cleaning the machine .....                                     | 161        |
| 11.12.1       | Cleaning the exterior of the machine .....                     | 162        |
| 11.12.2       | Cleaning the interior of the machine .....                     | 162        |
| 11.13         | Maintenance log .....  | 164        |
| <b>12</b>     | <b>Disposal</b> .....  | <b>165</b> |
| 12.1          | Disposal .....   | 165        |
| <b>13</b>     | <b>Documents and drawings</b> .....                            | <b>166</b> |
| 13.1          | rb Dimensional drawing overview .....                          | 166        |
| 13.2          | rw rx Dimensional drawing overview .....                       | 169        |
| 13.3          | Flow diagram .....   | 172        |
| 13.4          | Fuel circuit diagram .....                                     | 177        |
| 13.5          | Electrical diagrams .....                                      | 180        |
| 13.5.1        | Wiring diagram .....   | 180        |
| 13.5.2        | tc Connecting the lighting and signalling system .....         | 208        |
| 13.6          | Assembly drawings .....  | 212        |
| <b>14</b>     | <b>Glossary</b> .....  | <b>214</b> |
| <b>15</b>     | <b>Annexe</b> .....  | <b>219</b> |
| 15.1          | Code .....   | 219        |
| 15.1.1        | Labelling on the machine .....                                 | 219        |
| 15.1.2        | Drive engine identification .....                              | 219        |
| 15.2          | Coolant recommendation .....                                   | 220        |
| 15.2.1        | Water quality .....  | 220        |
| 15.2.2        | Coolant quality .....  | 220        |
| 15.2.3        | Initial fill of anti-corrosion agent/antifreeze .....          | 220        |
| 15.2.4        | Miscibility with other anti-corrosion agents/antifreezes ..... | 221        |
| 15.3          | dd Operating manual for the compressed air filter .....        | 221        |
| <b>Index</b>  | .....  | <b>296</b> |

# 1 About this document



Read the operating manual carefully and ensure you are familiar with the contents before using machine.

The operating manual is an integral part of the product and describes the machine at the point of initial delivery following completion. Keep the operating manual throughout the entire lifetime of the machine and pass it on to any subsequent owner or user.

For reasons of improved readability, the simultaneous use of the male, female and plural language forms has been dispensed with. All personal designations apply equally to all genders.

Supplement the manual with any amendments that may be provided by KAESER. Provide the data from the nameplate wherever you are asked to do so. This simplifies orientation for every user.

The illustrations in this manual are basic representations, which may differ from the actual in minor details.

## 1.1 Further documents

Further documents included with this operating manual:

- Pressure vessel Certificate of Acceptance / operating manual
- Declaration of Conformity in accordance with the applicable directive
- Machine controller user manual
- Chassis documentation for mobile machines

Check that all documents are complete.

Missing documents can be requested from KAESER. Ensure that you provide the nameplate data when ordering documents.

## 1.2 Warning notices

Warning notices warn of hazards that can lead to personal injury and provide instructions on how to avoid damage. Warning notices precede actions associated with hazards and also apply to sub-chapters if they precede the chapter.

Warning notices indicate three levels of hazard identified by the corresponding signal word:

| Signal word | Consequence if the hazard is not avoided  |
|-------------|---|
| DANGER      | Hazard with a high level of risk that will result in death or serious injury if not avoided |
| WARNING     | Hazard with a medium level of risk that may lead to death or serious injury if not avoided  |
| CAUTION     | Hazard with a low level of risk that may lead to minor or moderate injury if not avoided    |

Tab. 1 Signal words and their consequences

Example:


















### **WARNING**

**Description of the hazard, cause and consequences**

- ▶ Instructions on how to avoid the hazard

## 1.3 Symbols and pictograms

Symbols and pictograms in this document draw your attention to information that requires special attention. Follow all instructions provided to prevent damage.

| Representation  | Meaning  | Representation  | Meaning  |
|---|--|---|--|
|    | Section or information relating to an optional equipment feature                                       |    | Software-dependent button on display for triggering an operating function                    |
|    | This symbol indicates an individual action requirement   | 1. ...<br>2. ...<br>3. ...  | A series of action requirements are numbered consecutively. Follow the sequence accordingly. |
| «Operating element»   | Visualisation of an operating element, e.g. a key  | <i>Display element</i>  | Visualisation of a display element, e.g. a control indicator                                 |
|    | Safety-related condition that must be fulfilled in order to be able to perform the subsequent activity |    | Prerequisite that must be met in order to be able to perform the subsequent activity         |
|   | Useful information or information that needs to be observed  |   | Reference to another source of information   |
|  | Materials and tools  |  | Spare parts  |
|  | Tool   |  | Information or action relating to environmental protection                                   |
|  | Assistance relating to an activity   |  | Assistance relating to an individual action step   |
|  | Result of an implemented activity  |  | Result of an individual action step  |

Tab. 2 Symbols and pictograms

## 1.4 Material damage warnings

Material damage warnings warn of situations that can lead to material/property damage and provide instructions on how to avoid damage. Material damage warnings precede actions associated with risks and also apply to sub-chapters if they precede the chapter.

Material damage warnings are identified by their signal word NOTICE.

Example:

### NOTICE

#### Description of the hazard, cause and consequences

- ▶ Instructions on how to avoid the damage

## 1.5 Warranty

This manual does not contain any independent warranty commitment. Our general terms and conditions apply with regard to the warranty.

The provision of warranty by KAESER is conditional upon the machine being used only for the purposes for which it is intended. As the operator, you are responsible for ensuring that the machine is used only for the purposes for which it is intended in the context of your specific application.

## 1.6 Protected brands and trademarks

All brands and trademarks mentioned in this operating manual and (where applicable) protected by third parties, are subject without restriction to the stipulations of the applicable trademark law, as well as the ownership rights of the respective registered owner. The mention of a trademark alone does not imply that the trademark in question is not protected by the rights of a third party.

## 1.7 Copyright

This manual is copyright protected. Should you have any queries relating to usage and duplication of this documentation, please contact KAESER. KAESER will be glad to provide advice regarding the appropriate use of the information.

## 2 Technical data

### 2.1 Identification markings



The machine is clearly labelled by means of identification markings.

Always use this information when contacting the machine manufacturer or a specialist workshop.

Providing detailed machine information will ensure that every customer query is answered as quickly and accurately as possible.

Overview:

- Vehicle identification number
- Nameplate
- Options label



For positions of the machine identification markings, see chapter [15.1 Code](#).

#### 2.1.1 Vehicle identification number

The vehicle identification number is the only unmodifiable and therefore the most important identification feature on the machine.

The vehicle identification number is stamped into the bodywork of the machine and therefore remains associated with the machine throughout its entire service life.

#### 2.1.2 Nameplate

The following information can be found on the machine's nameplate:

- Machine type
- Important technical data for the machine

Fill the nameplate data in here for reference.

| Characteristic                   |  |
|----------------------------------|--|
| Portable rotary screw compressor |  |
| Material no. / Serial no.        |  |
| Actual total weight              |  |
| Lifting point load capacity      |  |
| Rated power                      |  |
| Maximum working pressure PS      |  |

### 2.1.3 Options label

Each of the installed options is represented by a code and indicated on the options label for your machine.




Fig. 1 Example options label: MOBILAIR M81.2 with options information

1 Chassis options

An overview of the installed options helps you to correlate the information in this operating manual. The corresponding code is displayed on the options label for your machine.



You can find the option code for the chassis in the separate operating manual supplied with the machine.

Fill in the options in the table below for reference.

#### Options reference

| Option   | Code | Installed? <sup>1)</sup> |
|--|------|--------------------------|
| Compressor air filter with mechanical maintenance indicator          | aa   |                          |
| Low-temperature equipment  | ba   |                          |
| Coolant preheating   | bb   |                          |
| Unloaded engine warm-up  | cc   |                          |
| Compressed air aftercooler and centrifugal separator                 | da   |                          |
| Heat exchanger   | db   |                          |
| Filter combination   | dd   |                          |
| Heat exchanger with bypass   | df   |                          |
| Compressed air aftercooler with bypass                               | dg   |                          |
| Tool lubricator, compressed air outlet not isolated                  | ea   |                          |
| Tool lubricator, compressed air outlet isolated upstream from option | eb   |                          |

1) Installed: ✓, Not available: —

| Option   | Code | Installed? <sup>1)</sup> |
|--|------|--------------------------|
| Tool lubricator, compressed air outlet isolated downstream from option | ec   |                          |
| Compressed air lines not isolated                                      | fa   |                          |
| Compressed air lines isolated downstream from option                   | fc   |                          |
| Compressed air outlet, additional and/or alternative                   | fe   |                          |
| Generator without flow rate limiter                                    | ga   |                          |
| Minimum pressure check valve filter combination                        | hc   |                          |
| Minimum pressure check valve with filter combination                   | hd   |                          |
| Minimum pressure check valve isolated upstream from option             | he   |                          |
| Spark arrester   | la   |                          |
| Spark arrester and engine air shut-off valve                           | lb   |                          |
| Battery isolation switch   | oa   |                          |
| Automatic start/stop   | ob   |                          |
| TELEMATICS   | oc   |                          |
| Battery trickle charging   | od   |                          |
| Closed floor pan   | oe   |                          |
| Control panel cover  | pa   |                          |
| Anti-theft device  | sf   |                          |
| Hose reel  | ua   |                          |
| EC-12 V  | tc   |                          |
| USA-12 V, DOT-compliant  | te   |                          |

1) Installed: ✓, Not available: —

Tab. 3 Options reference

## 2.2 Machine

### 2.2.1 Weight

The values indicated are maximum values. The actual weight of the machine depends on its specific configuration.

The actual weight of the machine can be found on the nameplate.

| Characteristic |      |
|----------------|------|
| Weight [kg]    | 1800 |

Tab. 4 Weight

### 2.2.2 Noise emission

Guaranteed sound power level in accordance with directive 2000/14/EC.

The guaranteed sound power level applies exclusively to machines fitted with soundproofing material.

| Characteristic  |      |
|---|------|
| Guaranteed sound power level [dB(A)]                    | 98.0 |
| Emission sound pressure level <sup>1), 2)</sup> [dB(A)] | 81.0 |
| Measuring distance d [m]                                | 1.0  |
| Measuring surface dimension Q2 [dB(A)]                  | 17.0 |

1) as per EN ISO 11203

2) calculated from the guaranteed sound power level (directive 2000/14/EC, basic noise measuring standard ISO 3744)

Tab. 5 Guaranteed sound power level

### 2.2.3 Tightening torque

#### 2.2.3.1 Screw connections with standard threads

The reference values for the tightening torques are dependent upon the size of the screw connection, the strength class, the screw material and the friction coefficient.



Tightening torque reference values for the screw connections used.

- Standard threads M4 – M8 of strength class 8.8, bright zinc-plated, see table.
- Standard threads M10 – M24 of strength class 8.8, matte zinc-flake coating, see table.

Set the torque as appropriate for the surface finish and friction coefficient (e.g.  $\mu = 0.12$ ).

Standards based on VDI 2230

#### Reference values for screw connections with standard threads

| Standard threads       | M4  | M5  | M6   | M8   |
|------------------------|-----|-----|------|------|
| Tightening torque [Nm] | 3,0 | 5,9 | 10,0 | 24,5 |

Screw surface finish: Bright galvanised

Strength class 8.8

Tab. 6 Defined tightening torques, standard threads M4...M8

| Standard threads       | M10  | M12  | M14   | M16   | M20   | M24   |
|------------------------|------|------|-------|-------|-------|-------|
| Tightening torque [Nm] | 40.0 | 70.0 | 105.0 | 160.0 | 320.0 | 550.0 |

Screw surface finish: Matte zinc-flake coating

Strength class 8.8

Tab. 7 Defined tightening torques, standard threads M10...M24

**2.2.3.2 Crane suspension fixing bolts**

| Thread size | Flat-head screw | Hexagon bolt | Stud | Strength class | Tightening torque [Nm] |
|-------------|-----------------|--------------|------|----------------|------------------------|
| M 12        | ●               | ○            | ○    | 8.8            | 70                     |
| M 16        | ●               | ○            | ○    | 8.8            | 160                    |

- : Applicable
- : Not applicable

Tab. 8 Specific tightening torques for the crane suspension fixing bolts

**2.2.4 Ambient conditions**

| Characteristic   |          |
|--|----------|
| Maximum installation elevation <sup>1)</sup> <sup>2)</sup> [m] | 1000     |
| Temperature range [°C]   | -10– +45 |

1) above sea level

2) Higher installation locations only possible following consultation with KAESER

Tab. 9 Ambient conditions at installation location

**2.2.5 Additional information as per the machine operating licence**

In the dimensional drawing for your machine, you can find:

- Additional information regarding specific technical data:
  - Dimensions
  - Track width
  - Machine footprint
- Positions of relevant inlet and outlet openings:
  - Cooling air inlet and outlet
  - Compressed air outlet
  - Exhaust gas outlet

 The dimensional drawing for your machine, as well as further drawing documents, can be found in chapter [13 Documents and drawings](#).

**2.3 Compressor**
**2.3.1 Working pressure, pressure rating**

A specific pressure rating applies to your machine, which is defined by the maximum working pressure of the system. This value determines further characteristics of your machine, such as the pressure adjustment range or the pV control range. Check the maximum working pressure value on your machine nameplate.

Dependent on the maximum working pressure, the version characteristics for your machine are indicated in one of the “Pressure rating” columns in the table below. One of the pressure ratings indicated is applicable to your machine.

| Pressure rating                       | 1           | 2           |
|---------------------------------------|-------------|-------------|
| <b>Maximum working pressure [bar]</b> | <b>10,3</b> | <b>14,0</b> |
| Pressure adjustment range [bar]       | 6,0– 10,3   | 6,0– 14,0   |
| pV control range [bar]                | 7,0– 10,3   | 10,0– 14,0  |

Tab. 10 Maximum working pressure, pressure adjustment range and pV control range in accordance with pressure rating.



The nominal pressure of the system can also be set below a specified control range for the pV Control.

### 2.3.2 Variable pressure-flow rate control

In the diagram, the relationship is illustrated between pressure (p) and flow rate (V) in relation to the variable pressure-flow rate control and the pressure adjustment range.

Only one of the diagrams below is applicable to your machine.

#### Pressure rating 1




Fig. 2 Pressure–Flow rate–diagram 6,0– 10,3bar

| Working pressure [bar]<br>(nominal pressure control range) | Flow rate [m³/min] | Engine speed [min <sup>-1</sup> ] |
|--|--------------------|-----------------------------------|
| 7,0  | 8,3                | 2600                              |
| 10,3   | 6,8                | 2200                              |

Tab. 11 Flow rate dependent on nominal system pressure and engine speed.


**Pressure rating 2**


Fig. 3 Pressure–Flow rate–diagram 6.0– 14.0 bar

| Working pressure [bar]<br>(nominal pressure control range) | Flow rate [m³/min] | Engine speed [min <sup>-1</sup> ] |
|--|--------------------|-----------------------------------|
| 10,0   | 6,4                | 2600                              |
| 14,0   | 5,3                | 2300                              |

Tab. 12 Flow rate dependent on nominal system pressure and engine speed.



The flow rate as per ISO 1217:2009 (Annexe D) is the continuously delivered volume in relation to intake conditions.

**2.3.3 Compressed air outlet**

| Connection size                | Quantity |
|--------------------------------|----------|
| G <sup>3</sup> / <sub>4</sub>  | 3        |
| G1 <sup>1</sup> / <sub>2</sub> | 1        |

Tab. 13 Air distributor

**2.3.4 Safety valve actuating pressure**

Maximum working pressure, see machine nameplate.

| Maximum working pressure [bar] | Safety valve actuating pressure [bar] |
|--------------------------------|---------------------------------------|
| 10,3                           | 15.9                                  |

| Maximum working pressure [bar] | Safety valve actuating pressure [bar] |
|--------------------------------|---------------------------------------|
| 14,0                           | 15.9                                  |

Tab. 14 Actuating pressure on the safety valve

### 2.3.5 Temperature

| Standby temperature for LOAD operating point [°C] |    |
|---|----|
| Airend discharge temperature (ADT)                | 20 |
| Engine coolant temperature (ECT)                  | 20 |

Tab. 15 Standby temperatures

| Airend discharge temperature (ADT) [°C]                             |         |
|---|---------|
| Typical airend discharge temperature during operation               | 75– 100 |
| Maximum airend discharge temperature with automatic safety shutdown | 117     |

Tab. 16 Airend discharge temperature

### 2.3.6 Compressor oil

#### 2.3.6.1 Compressor oil recommendation

The type of compressor oil used is marked near the filler neck on the oil separator tank.

#### Compressor oils for general applications

|                     | SIGMA FLUID  |  |  |
|---------------------|--|--|--|
|                     | MOL  | S-460  | S-570  |
| Description         | Mineral oil  | Synthetic oil  | Synthetic oil  |
| Application area    | Standard oil for all applications except the processing of food products.<br>Particularly suitable for machines with a low duty cycle. | Standard oil for all applications except for the processing of food products.<br>Particularly suitable for machines with high duty cycle. Not suitable for East/Southeast Asian countries. | Special oil for ambient conditions with high temperatures and humidity.<br>Suitable for all applications except for the processing of food products.<br>Particularly suitable for machines with high duty cycle. |
| Viscosity at 40 °C  | 46 mm <sup>2</sup> /s<br>(ASTM D445)   | 46 mm <sup>2</sup> /s<br>(ASTM D445)   | 53 mm <sup>2</sup> /s<br>(ASTM D445)   |
| Viscosity at 100 °C | 6.9 mm <sup>2</sup> /s<br>(ASTM D445)  | 7.2 mm <sup>2</sup> /s<br>(ASTM D445)  | 8.0 mm <sup>2</sup> /s<br>(ASTM D445)  |
| Flash point         | 230 °C<br>(ASTM D92)   | 251 °C<br>(ASTM D92)   | 258 °C<br>(ASTM D92)   |
| Density at 15 °C    | 0.868 g/cm <sup>3</sup><br>(ASTM D1298)  | 0.860 g/cm <sup>3</sup><br>(ASTM D1298)  | 0.869 g/cm <sup>3</sup><br>(ASTM D1298)  |

|            | SIGMA FLUID          |                      |                      |
|------------|----------------------|----------------------|----------------------|
|            | MOL                  | S-460                | S-570                |
| Pour point | -30 °C<br>(ASTM D97) | -27 °C<br>(ASTM D97) | -54 °C<br>(ASTM D97) |

Tab. 17 Compressor oil recommendation

**Compressor oils for food-processing applications**

|                     | SIGMA FLUID   |   |
|---------------------|---|---|
|                     | FG-460  | FG-680  |
| Description         | Synthetic oil   | Synthetic oil   |
| Application area    | Compressor oil for machines that require a lubricant approved in accordance with NSF H1 | Compressor oil for machines that require a lubricant approved in accordance with NSF H1 |
| Approval            | NSF H1  | NSF H1  |
| Viscosity at 40 °C  | 46 mm <sup>2</sup> /s<br>(ASTM D445)  | 68 mm <sup>2</sup> /s<br>(ASTM D445)  |
| Viscosity at 100 °C | 8.0 mm <sup>2</sup> /s<br>(ASTM D445)   | 10.5 mm <sup>2</sup> /s<br>(ASTM D445)  |
| Flash point         | 246 °C<br>(ASTM D92)  | 238 °C<br>(ASTM D92)  |
| Density at 15 °C    | 0.842 g/cm <sup>3</sup><br>(ASTM D1298)   | 0.854 g/cm <sup>3</sup><br>(ASTM D1298)   |
| Pour point          | -39 °C<br>(ASTM D97)  | -39 °C<br>(ASTM D97)  |

Tab. 18 Compressor oil recommendation (food-processing applications)

The term "food processing" encompasses all procedures that alter the original, raw form of a food item to make it suitable for consumption.

**2.3.6.2 Compressor oil fill volume**

| Version  | Fill volumes [l] |
|--|------------------|
| Machine  | 20               |
| Machine + <b>db</b> heat exchanger             | 20               |
| Machine + <b>df</b> heat exchanger with bypass | 20               |

Tab. 19 Compressor oil fill volume

## 2.4 Drive engine

### 2.4.1 Engine specification

| Characteristic                                      |  |
|---|--|
| Engine manufacturer                                 | HATZ                                   |
| Type  | 4H50TICD                               |
| Exhaust gas after-treatment                         | DOC <sup>1)</sup><br>DPF <sup>2)</sup> |
| Rated engine power [kW]                             | 55.4                                   |
| Speed in LOAD [min <sup>-1</sup> ]                  | 2600–2300                              |
| Speed in IDLE [min <sup>-1</sup> ]                  | 1800                                   |
| Fuel type   | Diesel <sup>3)</sup>                   |
| Fuel consumption in LOAD for pressure stage 1 [l/h] | 14.1–14.0                              |
| Fuel consumption in LOAD for pressure stage 2 [l/h] | 13.1–13.0                              |
| Oil to fuel consumption ratio [Vol. %]              | Approx. 0.5                            |
| Number of cylinders                                 | 4                                      |

1) Diesel Oxidation Catalytic Converter

2) Diesel Particulate Filter

3) Only use diesel fuels in accordance with EN 590 or EN 15940.

Tab. 20 Engine specification

### 2.4.2 Engine oil recommendation

The engine oil used must comply with the following classifications: **ACEA E6** „Low SAPS“ (bevorzugt), **E9, C3 / C4** (HTHS  $\geq 3.5$  mPas)



Only use engine oils with low white ash build-up. Engine oils that do not meet this condition can reduce the useful life of the drive engine.

A perfectly functioning engine is dependent on the quality of the engine oil used. The use of unlisted engine oils requires prior approval from KAESER.

#### 2.4.2.1 Viscosity class for initial fill

For the initial fill, the drive engine is filled with engine oil of the following viscosity class:

| Characteristic                 |            |
|--------------------------------|------------|
| Viscosity class                | SAE 10W-40 |
| Ambient temperature range [°C] | -20– 45    |

Tab. 21 Engine oil viscosity class for initial fill

**2.4.2.2 Engine oil viscosity class**

Viscosity:

The ambient temperature at the installation location and in the application area is decisive when selecting the appropriate viscosity class. Excess viscosity can cause difficulties when starting up, whilst too low a viscosity reduces the lubricating effect of the engine oil, leading to high oil consumption. Viscosity is classified by SAE.

| Ambient temperatures [°C] | Viscosity class                     |
|---------------------------|-------------------------------------|
| -35– 30                   | SAE 0W-30<br>SAE 5W-40<br>SAE 5W-30 |
| -35– 45                   | SAE 5W-40<br>SAE 0W-40              |
| -30– 30                   | SAE 5W-30                           |
| -30– 45                   | SAE 5W-40                           |

Tab. 22 Engine oil viscosity classes

**2.4.3 Fuel specification**

To comply with emissions legislation, diesel engines equipped with an exhaust gas after-treatment system must be operated using low-sulphur diesel fuel only. Compliance with the emission requirements but also the durability of the individual exhaust gas treatment components is not assured if this requirement is ignored!

The following fuel specifications are approved:

- Diesel fuels in accordance with EN 590
- Paraffinic diesel fuel in accordance with EN 15940



Never store fuel in galvanised containers.

If the machine is to be fuelled using barrels or jerrycans, the fuel must first be filtered. This helps to avoid faults in the fuel system caused by contamination.

**Biodiesel**

As per EN 590, a certain proportion of biodiesel is permitted in the fuel.

Depending on the country of origin, biodiesel may be produced from a variety of plant-based raw materials and may therefore possess differing properties. Exposure to temperature, atmospheric oxygen, and time can cause these biodiesel components in the fuel to degrade and damage the fuel system.

**2.4.4 Fill volumes**

| Operating fluids/materials | Fill volumes [l] |
|----------------------------|------------------|
| Engine oil                 | 7                |
| Coolant <sup>1)</sup>      | 15               |
| Fuel                       | 130              |

1) mixing ratio, see [11.3.1.3 Correctly mixing the coolant](#).

Tab. 23 Operating fluid fill volumes

### 2.4.5 Carbon dioxide emissions

CO<sub>2</sub> emissions are the mass of carbon dioxide produced when substances containing carbon are burnt.

The CO<sub>2</sub> measurements result from testing a (parent) engine over fixed test cycles, under laboratory conditions.

This engine is representative of the engine family, and can neither imply nor guarantee the performance of an individual engine.

| Characteristic                    |                 |
|-----------------------------------|-----------------|
| Engine manufacturer / type        | HATZ / 4H50TICD |
| CO <sub>2</sub> emissions [g/kWh] | 787.30          |

Tab. 24 CO<sub>2</sub> emissions value

### 2.4.6 Battery

Depending on the equipment fitted to the machine, a higher battery capacity may be required. See chapter [2.5.1 ba bb Low-temperature equipment](#)

| Characteristic                                |     |
|---|-----|
| Voltage [V]                                   | 12  |
| Capacity [Ah]                                 | 85  |
| Cold discharge test current <sup>1)</sup> [A] | 800 |

1) Capacity as per DIN EN 50342-1

Tab. 25 Starter battery

## 2.5 Options

### 2.5.1 **ba** **bb** Low-temperature equipment

#### 2.5.1.1 **ba** Low-temperature equipment

##### Ambient conditions

| Characteristic                                       |           |
|--|-----------|
| Maximum installation elevation ASL <sup>1)</sup> [m] | 1000      |
| Temperature range [°C]                               | -25 – +45 |

1) Higher installation locations only possible following consultation with KAESER

Tab. 26 Ambient conditions: Low-temperature equipment

**2.5.1.2** **bb** Coolant preheating

**Electrical connection data**

| Characteristic  |         |
|---|---------|
| Mains voltage [V]   | 240     |
| Frequency [Hz]  | 50      |
| Connection type   | 1~/N/PE |
| Connection cross section <sup>1)</sup> [mm <sup>2</sup> ] | 3 x 2,5 |
| Maximum cable length [m]                                  | 50      |
| Power [W]   | 600     |
| Customer-provided fuse protection [A]                     | 16      |

1) Cu multicore cable

Tab. 27 Electrical connection data for coolant preheating device

**2.5.2** **da** Heating for compressed air condensate separator

**Electrical connection data**

| Characteristic |    |
|----------------|----|
| Voltage [V]    | 12 |
| Power [W]      | 3  |

Tab. 28 Electrical connection data for heating, compressed air condensate separator heating mat

**2.5.3** **ea ec** Tool lubricator

**Lubricant recommendation**

| Characteristic                 |           |
|--------------------------------|-----------|
| Special lubricant for breakers |           |
| Temperature range [°C]         | -25 – +50 |
| Fill volume [l]                | 2,5       |

Tab. 29 Lubricant recommendation for breakers

**2.5.4** **ga** Generator

**2.5.4.1** Generator specification

| Characteristic                       | 400 V / 3~ |     |
|--------------------------------------|------------|-----|
| Rated power [kVA]<br>3-phase/2-phase | 13.0       | 8.5 |
| Nominal power [kVA]                  | 7.0        | 5.0 |

| Characteristic                                       | 400 V / 3~  |      |
|--|---|------|
| Voltage constancy<br>Symmetrical load                | ±5 %  |      |
| Voltage constancy<br>Single-phase, asymmetrical load | +6/-10 %  |      |
| Rated current [A]<br>3-phase/2-phase                 | 18.8  | 12.3 |
| Rated current [A]<br>Single-phase                    | 30.4  | 21.7 |
| Rated current [A]<br>Short circuit                   | 300   | 260  |
| cos phi  | 0.8-1   |      |
| Frequency [Hz]                                       | 50  |      |
| Speed [min <sup>-1</sup> ]                           | 3000  |      |
| Distortion factor                                    | < 5 %   |      |
| Type   | Electronically controlled synchronous internal pole |      |
| Protection class                                     | IP54  |      |

Tab. 30 Generator specification

**2.5.4.2 Compressed air flow rate during generator operation**

| Nominal power [kVA] | Nominal system pressure 7.0 – 10.3bar  |   |
|---------------------|--|---|
|                     | Flow rate [m <sup>3</sup> /min] at 7.0 | Flow rate [m <sup>3</sup> /min] at 10.0 |
| 0                   | 7.1                                    | 5.2                                     |
| 2                   | 7.1                                    | 4.3                                     |
| 4                   | 7.1                                    | 3.4                                     |
| 8                   | 5.3                                    | 1.5                                     |
| 10                  | 4.3                                    | 0.5                                     |
| 12                  | 3.2                                    | 0                                       |
| 13                  | 2.7                                    | 0                                       |

Tab. 31 Compressed air flow rate pressure range 7.0 – 10.3bar

| Nominal power [kVA] | Nominal system pressure 10 – 14 bar     |   |
|---------------------|---|---|
|                     | Flow rate [m <sup>3</sup> /min] at 10,0 | Flow rate [m <sup>3</sup> /min] at 14,0 |
| 0                   | 5.3                                     | 5.0                                     |
| 2                   | 5.3                                     | 4.1                                     |
| 4                   | 5.3                                     | 3.1                                     |
| 8                   | 4.8                                     | 1.2                                     |
| 10                  | 3.7                                     | 0.2                                     |

| Nominal power [kVA] | Nominal system pressure 10 – 14 bar |   |
|---------------------|-------------------------------------|---|
| 12                  | 2.5                                 | 0 |
| 13                  | 1.9                                 | 0 |

Tab. 32 Compressed air flow rate pressure range 10 – 14 bar



When the generator is activated, the compressed air flow rate of the compressor may be below the nominal value – even if no electrical load is connected to the generator. For the intended use of the compressor, the compressed air flow rate values without activated generator are decisive, see chapter [2.3.2 Variable pressure-flow rate control](#)

#### 2.5.4.3 Consumer plug sockets

| Type                      | 400 V / 3~ |
|---------------------------|------------|
| 16 A, 230V / 1~ / N / PE  | 3          |
| 16 A, 400 V / 3~ / N / PE | 1          |

Tab. 33 Number of plug sockets for consumers

#### 2.5.4.4 Circuit breaker

| Type | 400V / 3~ |
|------|-----------|
| 16 A | 1         |
| 32 A | —         |

Tab. 34 Number of safety cut-outs

#### 2.5.4.5 Operating limits

| Characteristic                     |      |
|------------------------------------|------|
| Performance class                  | G3   |
| Voltage adjustment range [%]       | 5    |
| Static voltage deviation [%]       | 1    |
| Maximum dynamic voltage drop [%]   | -15  |
| Maximum dynamic voltage rise [%]   | 20   |
| Maximum voltage settling time [ms] | 1500 |
| Maximum voltage asymmetry [%]      | 1    |

Tab. 35 Operating limits

#### 2.5.4.6 Maximum network load from current consumers

##### Examples of current consumers:

Ohmic consumers include: Electric light bulbs and heating devices

Inductive consumers include: Electric motors and transformers

| Characteristic                                  |        |
|---|--------|
| Maximum installation altitude <sup>1)</sup> [m] | 1000 m |
| Ambient temperature [°C]                        | 25 °C  |

1) above sea level

Tab. 36 Nominal conditions

| Generator                | 400V / 3~ | 400V / 3~ |
|--------------------------|-----------|-----------|
| Nominal power [kVA]      | 13.0      | 8.5       |
| Ohmic consumers [kW]     | 11        | 8.5       |
| Inductive consumers [kW] | 7.5       | 5.0       |

Tab. 37 Three-phase current

| Generator                | 400V / 3~ | 400V / 3~ |
|--------------------------|-----------|-----------|
| Nominal power [kVA]      | 13.0      | 8.5       |
| Ohmic consumers [kW]     | 6.4       | 6.4       |
| Inductive consumers [kW] | 6.4       | 6.4       |

Tab. 38 Alternating current

### 2.5.4.7 Power reduction at increased ambient temperatures

| Ambient temperature [°C] | Generator power                                 |
|--------------------------|---|
| ≤30 °C                   | Full power available                            |
| >30 °C                   | Reduction of 10% per 10 °C temperature increase |

Tab. 39 Power reduction at increased ambient temperatures

## 2.5.5 Telematics

| Characteristic          |                     |
|-------------------------|---------------------|
| Supplier / Manufacturer | Proemion            |
| Type                    | CANlink mobile 3653 |

Tab. 40 TELEMATICS: GSM/GPS unit

### TELEMATICS frequency bands

| Frequency band | Frequency range (uplink, downlink) [MHz] |
|----------------|--|
| GSM850         | 824 – 849, 869 – 894                     |
| EGSM900        | 880 – 915, 925 – 960                     |
| DCS1800        | 1710 – 1785, 1805 – 1880                 |
| PCS1900        | 1850 – 1910, 1930 – 1990                 |

| Frequency band | Frequency range (uplink, downlink) [MHz] |
|----------------|--|
| WCDMA B1       | 1920 – 1980, 2110 – 2155                 |
| WCDMA B2       | 1850 – 1910, 1930 – 1990                 |
| WCDMA B4       | 1710 – 1755, 2110 – 2155                 |
| WCDMA B5       | 824 – 849, 869 – 894                     |
| WCDMA B8       | 880 – 915, 925 – 960                     |
| LTE-FDD B1     | 1920 – 1980, 2110 – 2170                 |
| LTE-FDD B2     | 1850 – 1910, 1930 – 1990                 |
| LTE-FDD B3     | 1710 – 1785, 1805 – 1880                 |
| LTE-FDD B4     | 1710 – 1755, 2110 – 2155                 |
| LTE-FDD B5     | 824 – 849, 869 – 894                     |
| LTE-FDD B7     | 2500 – 2570, 2620 – 2690                 |
| LTE-FDD B8     | 880 – 915, 925 – 960                     |
| LTE-FDD B12    | 699 – 716, 729 – 746                     |
| LTE-FDD B13    | 777 – 787, 746 – 756                     |
| LTE-FDD B18    | 815 – 830, 860 – 875                     |
| LTE-FDD B19    | 830 – 845, 875 – 890                     |
| LTE-FDD 20     | 832 – 862, 791 – 821                     |
| LTE-FDD B25    | 1850 – 1915, 1930 – 1995                 |
| LTE-FDD B26    | 814 – 849, 859 – 894                     |
| LTE-FDD B28    | 703 – 748, 758 – 803                     |
| LTE-TDD B38    | 2570 – 2620                              |
| LTE-TDD B39    | 1880 – 1920                              |
| LTE-TDD B40    | 2300 – 2400                              |
| LTE-TDD B41    | 2496 – 2690                              |

Tab. 41 TELEMATICS frequency bands

| Mains | Maximum transmitting power [dBm] |
|-------|----------------------------------|
| GPRS  | 33                               |
| Edge  | 27                               |
| UMTS  | 24                               |
| HSPA  | 24                               |
| LTE   | 23                               |

Tab. 42 Maximum transmitting power

Supported satellite systems:

- GPS/QZSS L1 C/A
- GLOSNASS L10F
- BeiDou B1I
- Galileo E1B/C

**2.5.6 od Battery trickle charging****Electrical connection data**

| <b>Characteristic</b>        |             |
|------------------------------|-------------|
| Type                         | 12V DC / 5A |
| Charging voltage [V]         | 14.0        |
| Charging current [A]         | >0,5        |
| Maximum charging current [A] | 5           |
| Protection class             | IP54        |

Tab. 43 Electrical connection data for battery charger

## 3 Safety and responsibility

The machine is manufactured to the latest engineering standards and recognised safety regulations. Nevertheless, dangers can arise through its use:

- Danger to life and limb for the operator or third parties.
- Damage to the machine and other material assets



To prevent injury, follow all safety instructions.

Only use the machine as intended.

Only use the machine if it is in perfect technical condition. Faults that could impair safety must be rectified immediately.

### 3.1 Intended use

The machine is designed for the use of specialist personnel in trades or industrial applications.

The function of the machine is to compress ambient air.

**ga** The additional generator is designed to supply portable operating equipment with electrical power.

Any other use shall be considered improper. The manufacturer shall not be liable for any damage that may result from improper use. The operator shall be solely liable for any risks incurred.

In particular, please note the following:

- Follow the instructions in this operating manual; only operate the machine within the specified performance limits and in accordance with the permissible ambient conditions.
- The use of compressed air as breathing air or in contact with food products is permitted only in combination with the appropriate treatment.
- The use of exhaust heat is only permitted in conjunction with suitable measures which preclude any health risk for humans and animals.
- Only use genuine KAESER spare parts for pressure-bearing components.

### 3.2 Improper use

No toxic, acidic, alkaline, inflammable or explosive gases or vapours may be drawn in for compression.

Modifications to the machine or controller can result in unforeseen dangers. The operator shall be solely liable for any risks incurred.

In particular, please note the following:

- Never direct compressed air at people or animals.
- It is prohibited to operate the machine in potentially explosive areas.
- Do not make any unauthorised modifications or conversions to the machine.
- **ga** Do not use the generator to supply fixed electrical installations.

### 3.3 Dangers

This section provides information regarding the various types of danger that can arise in connection with operating the machine.

Observe the following whenever any work is performed on the machine:

- Allow work to be performed by authorised personnel only.
- Fully vent all pressurised components and enclosures, and verify the absence of all pressure.
- Do not use any part of the machine as a climbing aid.

- Pay strict attention to cleanliness during all work.
- To prevent dirt ingress, cover components and exposed openings with clean cloths, paper, or masking tape.
- Do not leave any loose components, tools, or cleaning cloths on or in the machine.
- Do not open or destroy any dismantled components.
- Check the following regularly on the machine:
  - For visible damage
  - Safety devices
  - Components that require monitoring

Wear your personal protective equipment for all work, e.g.:

- Approved, long-sleeved work clothing, close-fitting and flame-retardant
- Protective gloves
- Safety shoes
- Eye protection
- Ear protection

#### **Pressure**

Compressed air is stored energy. Release of this energy can cause serious injury or death:

- Verify that all enclosures are completely free from pressure.
- Install pressure lines only when they are in a pressure-free state.
- Close shut-off valves or otherwise isolate the machine from the compressed air network so as to ensure that no compressed air can flow back into the machine.
- Do not carry out welding, heat treatment or mechanical modifications on pressure-bearing components (e.g. piping, pressure vessels).

#### **Compressed air quality**

The composition of the compressed air must be suitable for the actual application in question, in order to preclude health and life-threatening dangers

- Use suitable compressed air treatment systems when using compressed air from this machine for the purposes of supplementary ventilation with fresh air or for the processing of food products.
- Use food-grade compressor oil for applications where the compressed air may come into contact with food products.

#### **Spring tension**

Springs under tension store energy. Release of this energy can cause serious injury or death. Minimum pressure check valves, safety valves and inlet valves are all under powerful spring tension.

- Do not dismantle any valves.
- Return removed valves to KAESER or an authorised service partner.

#### **Rotating components**

Touching rotating components whilst the machine is switched on can result in serious injury:

- Ensure that safety guards and covers are fitted properly before switching on the machine.
- Ensure that the bodywork remains closed.
- If you wear your hair long, use protective clothing and a suitable hairnet.

#### **Heat**

High temperatures are generated during the compression of gases. Touching hot components may lead to injury.

- Allow the machine to cool down sufficiently.
- Wear protective gloves in the event that it is necessary to handle the compressed air outlet.
- When performing welding work on or in the vicinity of the machine, take suitable measures to prevent sparks or high temperatures from igniting oil vapours or machine components.

**Sound**

Machine noise is suppressed to a low level. This sound insulation is only effective when the bodywork is closed.

- Only operate the machine when the bodywork is closed.
- Wear ear protection. In particular, the safety valve blow-off results in high noise emission.

**Exhaust gases**

Exhaust gases from internal combustion engines contain carbon monoxide and soot. Soot contains particles that are hazardous to the health. Carbon monoxide is a colourless and odourless but highly toxic gas. Carbon monoxide can be fatal even in the smallest quantities:

- Park the machine in such a manner that exhaust gases cannot reach the operating personnel.
- Only use the machine outdoors.
- Do not inhale exhaust gases.

**Fire and explosion**

Fires resulting from spontaneous ignition of fuel can cause serious injury or death. Ensure that there are no open flames or sparks at the installation location:

- Do not smoke when refuelling.
- Only refuel when the machine is switched off and has cooled down.
- When refuelling, do not allow fuel to overflow.
- Wipe up spilled fuel immediately.
- Keep suitable fire-extinguishing media close to hand.

**Hot coolant**

The cooling system of a liquid-cooled engine at operating temperature is under pressure. When opening the cover cap on the coolant expansion tank, hot coolant can spray out and cause burns:

- Allow the machine to cool down before opening the cooling system.
- Loosen the cover cap by a maximum of a quarter to a half turn.
- Allow excess pressure to be released.
- Fully loosen and remove the cover cap.

**Electricity**

Touching live components can result in electric shocks, burns or death:

- Allow only qualified and authorised certified electricians or trained personnel under the supervision of a qualified and authorised certified electrician to carry out work on electrical equipment in accordance with electrical engineering regulations.
- As the operator, before each commissioning of the machine you must establish and check protection against direct or indirect touch voltages.
- Verify the absence of voltage from any external voltage sources.  
External voltage sources could include connections to floating contacts or electrical coolant preheating, for example.
- Regularly check that all electrical connections are tightened and in proper condition.

**Transportation**

In order to prevent accidents, the weight and size of the machine require that safety measures be taken during transportation:

- Ensure that the danger zone is clear of personnel.
- Ensure that the machine is transported only by personnel who, due to their training, possess the appropriate authorisation for safe handling of motor vehicles and transported goods.
- When transporting by crane:
  - Use suitable hoists that comply with local safety regulations.
  - The lifting eye is intended exclusively for the attachment of a crane hook.
  - Do not interfere with the fastening points on the crane eye.
  - After dismantling the crane suspension, use new, self-locking nuts.
  - Never lift and move the machine over people or residential buildings.



- Extreme centre of gravity shifts due to excessive loads or add-on equipment (tilting) must be avoided.
- Do not exceed the load capacity of the lifting point on the machine (crane suspension).
- Avoid jolting during lifting, as this may damage components.
- Loads must be lifted slowly and set down carefully.
- Never leave the load hanging from the hoist.

The following are prohibited:

- Transport by air (lifting the machine by helicopter via the lifting eye).
- Dropping the machine by parachute.
- When transporting as a trailer:
  - The maximum permissible trailer load for the towing vehicle and the maximum permissible load for the trailer coupling must not be exceeded.
  - Extreme centre of gravity shifts due to excessive or incorrectly distributed loads must be avoided.
  - Do not tow in a manner that imposes excessive stress on the machine, or the chassis in particular.
  - Adjust driving speed in accordance with the prevailing road conditions. This applies particularly to unpaved roads and when negotiating bends.
  - Do not attach the machine at an inclined angle and transport it, since this can lead to problems with driving dynamics (unsafe driving characteristics) and cause damage to the towing vehicle and / or the machine.
  - Before moving the machine, ensure any immobiliser devices (e.g. anti-theft chain) are removed or deactivated. Use suitable tension belts that comply with local safety regulations.
- When transporting as a trailer on public roads:
  - Do not tow machines without lighting and signalling devices on public roads.
  - Ensure that all running gear (e.g. chassis, wheels, brakes, signalling and lighting devices) on the trailer is in a safe condition.
  - National laws and regulations pertaining to safe transportation on public roads must be adhered to.
- When transporting by forklift:
  - Use a suitable forklift that complies with local safety regulations.
  - Never lift mobile machines using a forklift.
  - Only lift stationary machines equipped with option **rw** by forklift.
  - Insert the full length of both forks into both lifting pockets.
- When transporting as a load:
  - Use suitable tension belts that comply with local safety regulations.
  - Never arrange tension belts across enclosures, doors or bodywork components.
  - Lash a machine exclusively at the designated lashing points.
  - On mobile machines, relieve the load on the support stand.
  - Never use the lashing points as crane lifting points.

### Installation

A suitable installation location prevents accidents and helps to ensure reliable operation of the machine:

- Install the machine on a level surface capable of bearing the weight.
- Secure mobile machines against rolling away.
- Ensure a minimum distance from the exhaust outlet to walls or covers, in order to prevent heat build-up due to the hot exhaust gases.
- Ensure that sufficient cooling air can flow through the interior of the machine.
- Ensure that hot exhaust air can flow out from the interior of the machine.
- Ensure clean intake air with no damaging contaminants. Damaging contaminants include, for example:
  - Explosive or chemically unstable gases and vapours
  - Acids or base-forming chemicals such as ammonia, chlorine, or hydrogen sulphide

- Ensure suitable accessibility so that all work on the machine can be carried out without danger or hindrance.
- Ensure that the working conditions in the immediate vicinity of the machine are not impaired.
- Do not operate the machine in areas where specific requirements apply in relation to explosion protection. For example, the requirements for “proper use in potentially explosive atmospheres” as per 2014/34/EU<sup>1)</sup>

**Installation**

Note the following when performing installation work:

- Only use pressure lines that are suitable and approved for the maximum working pressure and the intended medium.
- Compensate for the force exerted by pipework on the machine, so that no forces are transferred to the connection points.

**Operating fluids/materials**

The operating fluids and materials used can cause adverse health effects. To prevent injury, take the appropriate precautionary measures:

- Follow all safety regulations relating to fuel, oils, lubricants, antifreeze, or chemical substances.
- Avoid contact with the skin and eyes.
- Do not inhale fuel vapours.
- Do not inhale oil mist or oil vapours.
- Do not eat or drink if you have been handling fuel, oils, lubricants, antifreeze, or chemical substances.
- Fire, naked flame, and smoking must all be prohibited.
- Keep suitable fire-extinguishing media close to hand.
- Only use KAESER-approved operating fluids/materials.
- Dispose of used operating fluids/materials via a certified disposal specialist, in accordance with the applicable local regulations.

**Spare parts**

Unsuitable spare parts compromise the safety of the machine.

- Only use spare parts approved by KAESER for use in this machine.
- Only use genuine KAESER spare parts on pressure-bearing components.
- Dispose of any spare parts contaminated with environmentally harmful operating fluids/materials in accordance with the applicable local regulations.

**Machine modifications**

Modifications to the machine or controller can result in unforeseen dangers.

- Do not make modifications to the machine.
- Obtain written approval from KAESER prior to making any technical modifications or enhancements to the machine, the controller, or the control programs.

**Expanding or modifying the compressed air station**

When appropriately dimensioned, safety valves reliably prevent impermissible pressure rise.

- Check the actuating pressure and blow-off capacity of the safety valves in the downstream compressed air network prior to installing any additional compressed air generators.
- Install appropriately dimensioned safety valves.

## 3.4 Danger areas

The following table provides information regarding the areas which are potentially dangerous to personnel.

---

<sup>1)</sup> ATEX Directive

Only authorised personnel may access these areas:

| Task           | Danger area   | Authorised personnel   |
|----------------|---|--|
| Transportation | 3 m radius around the machine   | Installation personnel for transport preparation<br>No personnel during transportation |
|                | Beneath the raised machine  | No personnel   |
| Installation   | Inside the machine<br>1 m radius around the machine and its power supply cables | Installation personnel   |
| Operation      | 1 m radius around the machine   | Operating personnel  |
| Maintenance    | Inside the machine  | Maintenance personnel  |
|                | 1 m radius around the machine   |  |

Tab. 44 Danger areas

## 3.5 Safety and information signs

In the following illustrations, you will find the locations of the signs used on the exterior and interior of the machine.

### NOTICE

#### Damage due to cleaning

During maintenance or cleaning work, it must be ensured that the attached safety signs are not damaged.

- ▶ It must furthermore be ensured that any removed or poorly legible safety signs (e.g. that have faded outdoors) are replaced.

The meaning of the signs used is explained in the respective table beneath each illustration.

Overview of safety and information signs on the machine exterior:













Fig. 4 Location of safety and information signs on the machine exterior

| Item | Symbol  | Meaning   |
|------|---|---|
| 265  |    | <b>Danger of injury from incorrect operation</b> <ul style="list-style-type: none"> <li>▶ Ensure that you have read and understood the operating manual and all related safety information before starting this machine.</li> </ul>   |
| 310  |    | <b>Danger of injury from operating the machine with the doors or cover panels open</b> <ul style="list-style-type: none"> <li>▶ Only operate the machine with the enclosure fully closed.</li> <li>▶ Only transport the machine with the enclosure fully closed.</li> </ul>   |
| 330  |    | <b>Danger of injury from hot components</b> <ul style="list-style-type: none"> <li>▶ Do not touch hot surfaces.</li> <li>▶ Allow the machine to cool down.</li> <li>▶ Wear long-sleeved clothing and protective gloves.</li> </ul>  |
| 331  |   |   |
| 332  |   |   |
| 333  |   |   |
| 380  |    | <b>Danger of injury to respiratory organs from released exhaust gases</b> <ul style="list-style-type: none"> <li>▶ Only use the machine outdoors.</li> <li>▶ Never operate the machine in enclosed spaces.</li> <li>▶ Do not inhale exhaust gases.</li> </ul>   |
| 450  |   | <b>Danger of injury from loud noise and compressed air blast</b> <p>Damage to hearing and injuries are possible if the ball valve is opened without a compressed air hose being connected.</p> <ul style="list-style-type: none"> <li>▶ Wear ear protection.</li> <li>▶ Connect a compressed air hose.</li> <li>▶ Open the ball valve.</li> </ul>   |
| 620  |  | <b>Danger of injury to hands or severing of limbs from rotating components</b> <ul style="list-style-type: none"> <li>▶ Operate the machine exclusively with the safety guards installed and the doors and cover panels closed.</li> <li>▶ Stop and shut down the machine before opening the doors or cover panels.</li> <li>▶ When opening or closing doors and cover panels, keep your hands clear of the crushing zone.</li> </ul> |
| 621  |   |   |
| 710  |  | <b>Danger of injury from machine tilting or tipping over</b> <ul style="list-style-type: none"> <li>▶ Never use lashing points as crane lifting points.</li> <li>▶ Read the operating manual.</li> </ul>  |
| 711  |   |   |
| 850  |  | <b>Danger of fatal injury from contact with live components</b> <ul style="list-style-type: none"> <li>▶ Observe protective measures before switching on the generator.</li> </ul>  |
| 851  |   |   |
| 1710 |  | <b>Danger of injury from automatic start-up of the machine</b> <p>Prior to starting any work on the machine:</p> <ul style="list-style-type: none"> <li>▶ Stop the machine</li> <li>▶ Switch off the «Controller ON/OFF» switch.</li> <li>▶ Only operate the machine with the doors and cover panels closed.</li> </ul>   |

Tab. 45 Meaning of safety and information signs on the machine exterior

**Overview of safety and information signs on the machine interior:**




Fig. 5 Location of safety and information signs on the machine interior

| Item       | Symbol | Meaning   |
|------------|--------|---|
| 320<br>321 |        | <b>Danger of injury from loud noise and hot oil mist</b><br>Risk of hearing damage and burns.<br>▶ Wear ear protection and protective clothing.<br>▶ Close the enclosure or doors.<br>▶ Proceed with caution.   |
| 600<br>601 |        | <b>Danger of fatal injury from spring force and pressure</b><br>▶ Do not open or disassemble valves.<br>▶ Call an authorised service agent in the event of a fault.   |
| 700        |        | <b>Use the crane lifting point as instructed when transporting by crane</b><br>▶ Open the cover over the machine crane lifting point.<br>▶ Correctly insert the crane hook into the lifting eye indicated as the crane lifting point.                 |
| 1650       |        | <b>Damage to the machine from switching off when the drive engine is running</b><br>▶ Only activate the battery isolating switch when the drive engine is at standstill.<br>▶ Do not use the battery isolating switch as an emergency or main switch. |

Tab. 46 Meaning of safety and information signs on the machine interior

### 3.6 Operator responsibilities

Observe the relevant statutory regulations and recognised technical rules when installing, operating and performing maintenance on the machine.

Statutory regulations and recognised rules are, for example, the European directives implemented in national law, or the laws, safety regulations and accident prevention regulations applicable in the country of use.

### 3.6.1 Determining suitable personnel

The machine may only be operated by specialists who are of legal age and who have read and understood these instructions. Personnel must have specialist training, experience and knowledge of the relevant regulations and therefore be able to perform work accordingly, as well as to recognise dangers.

Personnel tasked with commissioning, operation and maintenance must be familiar with the safety concepts and regulations relating to the following technical fields:

- Compressed air technology
- Electrical engineering
- Automotive technology

Ensure that personnel entrusted with commissioning, operation and maintenance have the relevant qualifications and authorisation required for the respective task.

### 3.6.2 Organisational measures

As the operator, you must take the following organisational measures:

- Determine personnel and regulate responsibilities.
- Regulate the obligation to report any faults with or damage to the machine.

### 3.6.3 Complying with inspection intervals

The machine is subject to national inspection regulations. Determine the regulations applicable at the installation site and organise the necessary measures.

#### 3.6.3.1 Regular inspection of crane suspension

The operator must ensure that, in accordance with national regulations, the crane suspension is inspected at regular intervals for wear and damage.

#### 3.6.3.2 **lc** Checking the diesel particulate filter

The machine is subject to local inspection intervals.

Arrange for the recurring inspection to be carried out as per [Tab. 47 Checking the diesel particulate filter](#).

| Exhaust emissions inspection as per | Inspection interval | Inspection authority        |
|-------------------------------------|---------------------|-----------------------------|
| TRGS 554                            | Annually            | Authorised service partners |
| Legislative authority               | 2-yearly            | Approved inspection body    |

Tab. 47 Checking the diesel particulate filter

## 3.7 Emergencies

### 3.7.1 Correct conduct in the event of fire

In the event of a fire, calm and considered action can save lives:

- Remain calm.
- Report the fire:

- Give your name and location.
- Provide a telephone number on which you can be reached.
- Describe what has occurred, what is on fire, who is injured or in need of help and where.
- Give the location of the fire as precisely as possible and provide directions for the fire brigade.
- If any people are in danger, warn them or assist them to safety.
- Close all doors and windows.

Only attempt to extinguish a fire using the following media if you possess sufficient knowledge of how to do so:

- Extinguishing foam
- Carbon dioxide
- Sand or earth

### **3.7.2 First aid measures following contact with compressor oil**

In the event of accident or illness, call a doctor immediately. In case of doubt or should symptoms appear, always consult a doctor.

#### **Contact with the eyes**

Compressor oil can cause irritation to the eyes:

- If contact lenses are worn, remove them if possible and gently rinse the eyes with water for a few minutes.
- In the event of eye irritation, consult a doctor.

#### **Skin contact**

Compressor oil can cause irritation following prolonged contact with the skin:

- Remove dirty clothing or clothes soaked with compressor oil.
- Wash the skin gently with water.
- In the event of skin irritation, consult a doctor.

#### **Inhalation**

Oil mist can impair the breathing and cause breathing difficulties:

- Move outside to fresh air and allow injured persons to breathe without hindrance.
- In the event of breathing difficulties or respiratory arrest, begin artificial respiration.

#### **Ingestion**

In the event of ingestion, compressor oil can cause irritation to the mucous membranes:

- Immediately rinse the mouth and drink plenty of water.
- DO NOT induce vomiting.
- Never administer anything by mouth to an unconscious person or someone who is experiencing convulsions.

## **3.8 Environmental protection**

Operating fluids/materials, particularly oils and greases, must not be released into the environment or sewer system. Store and dispose of all operating fluids/materials and used parts in accordance with the applicable national environmental protection regulations.

Batteries contain substances that are harmful to living things and the environment. For this reason, batteries must not be disposed of with unsorted municipal waste. They must be delivered to a national battery collection system. This facilitates the correct handling and recycling of batteries. Directive (EU) 2023/1542 stipulates that, in EU member states, used batteries must be returned to the point of sale or delivered to a designated disposal system.

Components containing batteries are labelled as follows:




Fig. 6 Battery labelling

## 3.9 **ga** Operating the generator

### 3.9.1 Protective measures against shock currents

Protection against shock currents is regulated by the “Low Voltage Electrical Installations” Directive IEC 60364–5–551 (DIN VDE 0100–551). The protective measure “Protective separation, insulation monitoring and shutdown” is applied here. In accordance with this protective measure, the electricity producer (generator) is equipped with a safety cut-out with shunt release for all poles and an insulation monitoring device.

Comply with the regulations relating to “protection against shock currents” when operating the generator.

### 3.9.2 Operating the generator safely

Observe the following in order to ensure safe machine operation with the generator:

- Check daily that the insulation monitoring device is functioning properly.
- Do not earth the neutral line (N) or connect it to the protective conductor/potential equaliser (PE).
- Ensure that potential equalisation is without interruption (generator/machine through cables to electrical consumer).
- Only operate the generator in an IT power network.
- Work on the generator or generator control box must only be performed by a certified electrician. This certified electrician is responsible for the effectiveness of the protective measures.
- Do not use the generator for feeding power distributors on construction sites.
- A generator with insulation monitoring must not be connected to any other insulation monitoring device, as the monitoring devices can then influence one another.
- Do not use residual current devices (RCDs), as they are inherently non-functional in unearthed networks (IT power network, such as that supplied by the generator) due to the lack of earthing. The “protective separation” protective measure provided by the generator, however, renders downstream protection via an RCD unnecessary.
- Follow the regulations of the local electricity supplier and obtain any necessary approvals.
- When cleaning the interior of the machine, do not direct water or steam jets at the generator or its terminal box.
- Regularly check electrical connections for secure seating and proper condition.

### 3.9.3 Connecting an extension cable

In order to comply with the regulations for connecting extension cables or portable distribution networks during operation of the generator, the following must be observed:

In accordance with DIN 6280-10, their total length:

- must not exceed 60 m for a cross section of 1.5 mm<sup>2</sup>.
- must not exceed 100 m for a cross section of 2.5 mm<sup>2</sup>.

- ▶ For portable distribution networks, use H07RN-F cables as a minimum in accordance with DIN VDE 0282, Part 4 (IEC 60245-4/HD 22.4).

### **3.9.4 Do not exceed the maximum network load**

In order to avoid exceeding the maximum network load via the connected consumers when operating the generator, the following must be observed:

- The power consumption values of simultaneously operating consumers must be added up.
- The maximum continuous power load of the generator by the connected consumers is limited by the circuit breakers.

### **3.9.5 Performing regular checks on the generator**

Arrange for the generator to be checked daily by authorised operating personnel prior to commissioning.

- Check that the insulation monitoring device is functioning properly.

Arrange for the generator to be inspected annually by a trained and authorised, certified electrician.

- Inspect the generator and generator control box for mechanical damage.
- Inspect the protective conductor.
- Check that the generator is functioning correctly.
- Check that the generator fan is functioning correctly.
- Clean the cooling air openings.
- Check the screw connections on the generator and generator control box.
- Check the protective cover on the safety cut-out for damage.
- Check that the protective covers on the plug-in sockets for consumers are not damaged.
- Check that the protective covers on the plug-in sockets for consumers are tightly sealed.
- Check that all signs and warning labels are present and complete.

## 4 Design and function

### 4.1 Bodywork

The bodywork is the external structure of the machine atop the chassis.




Fig. 7 Bodywork

- |                            |                            |
|----------------------------|----------------------------|
| 1 Control panel with cover | 5 Cooling air outlet       |
| 2 Left-hand wing door      | 6 Lower body               |
| 3 Lifting eye with cover   | 7 Handle with toggle latch |
| 4 Right-hand wing door     | 8 Cooling air inlet        |

The bodywork fulfils several functions when closed:

- Weather protection
- Sound insulation
- Contact protection
- Cooling air flow

The bodywork is fundamentally unsuitable for the following uses:

- Walking on, standing on or sitting on
- Placing or storing any kind of load

Each wing door is equipped with a handle. The handle is the suitable add-on part to use for correctly swinging open the wing door. Gas-pressure springs facilitate manual opening of the wing doors and ensure they remain open independently.

The wing door handles also serve as attachment points for the flexible toggle latches. The flexible toggle latches secure both closed wing doors in place.

## 4.2 Machine layout




Fig. 8 Overview: Machine without options

- |   |                          |    |                             |
|---|--------------------------|----|-----------------------------|
| 1 | Control panel cover      | 10 | Exhaust gas after-treatment |
| 2 | Oil separator cartridges | 11 | Fuel tank                   |
| 3 | Oil filter               | 12 | Oil cooler                  |
| 4 | Compressor air filter    | 13 | Coolant cooler              |
| 5 | Lifting eye              | 14 | Charge air cooler           |
| 6 | Coolant expansion tank   | 15 | Engine air filter           |
| 7 | Fan wheel                | 16 | Drive engine                |
| 8 | Air end                  | 17 | Exhaust gas pipe            |
| 9 | Compressed air outlet    | 18 | Oil separator tank          |

### 4.3 Machine function




Fig. 9 Unit without options

- |   |                             |    |                              |
|---|-----------------------------|----|------------------------------|
| 1 | Coolant cooler              | 10 | Airend                       |
| 2 | Charge air cooler           | 11 | Minimum pressure check valve |
| 3 | Engine air filter           | 12 | Safety valve                 |
| 4 | Exhaust gas after-treatment | 13 | Oil separator cartridges     |
| 5 | Compressor air filter       | 14 | Oil filter                   |
| 6 | Fan wheel                   | 15 | Air distributor              |
| 7 | Combustion engine           | 16 | Fuel-water separator         |
| 8 | Fluid distribution module   | 17 | Oil cooler                   |
| 9 | Oil separator tank          |    |                              |

A combustion engine 7 drives the airend.

A diesel oxidation catalytic converter and a diesel particulate filter provide the exhaust gas after-treatment **4**.

The airend **10** draws in ambient air via the compressor air filter **5** and then compresses it. The compressor air filter cleans the intake air.

The compressor oil injected into the airend lubricates moving parts and forms a seal between the rotors and between the rotors and the housing. This direct cooling inside the compression chamber ensures a very low airend discharge temperature.

The oil separator tank **9** separates the compressor oil from the compressed air. The oil cooler **17** cools the compressor oil. The compressor oil flows through the oil filter **14** and returns to the point of injection. The machine's internal pressure keeps the oil circulating through the compressor oil circuit. A separate pump is not required. The thermostatic valve integrated into the fluid distribution module **8** regulates and optimises the compressor oil flow and compressor oil temperature. The fluid distribution module is located on the cover of the oil separator tank.

The oil separator cartridges **13** reduce the oil content of the compressed air. The compressed air then passes through the minimum pressure check valve **11** to the air distributor **15**. The minimum pressure check valve always maintains a minimum system pressure so as to ensure a continuous flow of cooling oil inside the machine.

The flow direction of the fan wheel **6** and the layout of the cooling air inlet and outlet determine the machine's cooling air flow within the closed bodywork. The cooling air flows continuously through the oil cooler, coolant cooler and charge air cooler.

## 4.4 Operating points and control modes

### 4.4.1 Machine operating points

#### STANDSTILL

The machine is in the STANDSTILL operating point:

- The inlet valve is closed.
- The venting valve is open.
- The machine is vented.
- The drive engine is at standstill.
- Drive engine speed  $0 \text{ min}^{-1}$ .

#### READY

The machine controller voltage has been switched on with the Controller «ON/OFF» key:

- The *Controller voltage* indicator is illuminated in green.
- The *Ready* indicator flashes green.
- The drive engine is at standstill.
- Drive engine speed  $0 \text{ min}^{-1}$ .

#### IDLE

The drive engine runs unloaded and consumes little fuel:

- The inlet valve is closed.
- The recirculation valve opens, allowing the compressed air inside the oil separator tank to flow into the inlet valve.
- This compressed air is then directed in a closed circuit through the airend, oil separator tank and recirculation valve.
- The pressure in the oil separator tank remains constant.
- The drive engine runs at minimum speed.

#### LOAD

The drive engine runs under load:

- The inlet valve is open.
- The drive engine runs at maximum speed.
- The airend delivers compressed air.

#### 4.4.2 MODULATING CONTROL

MODULATING CONTROL continuously adjusts the machine's flow rate in line with compressed air demand. The proportional controller adjusts the degree of opening for the inlet valve whilst the machine is delivering compressed air. The generated compressed air is adjusted according to actual air demand.

This infinitely variable regulation of the flow rate minimises drive engine fuel consumption. The load and fuel consumption of the drive engine rise and fall with the compressed air demand.

### 4.5 Safety devices

#### 4.5.1 Monitoring function with shutdown

The SIGMA CONTROL SMART controller monitors important machine parameters.

The machine is shut down automatically should a fault occur.

The SIGMA CONTROL SMART message memory saves the fault.

#### 4.5.2 Further safety devices



Modifications to the following safety devices are prohibited:

| Safety device   | Function  |
|---|---|
| «EMERGENCY STOP» button   | Shuts the machine down safely in an emergency situation: <ul style="list-style-type: none"> <li>▪ The drive engine is shut down immediately</li> <li>▪ The pressure system is vented</li> </ul> |
| Safety valve / safety valves  | Protect(s) the pressure system against an impermissible pressure rise   |
| <ul style="list-style-type: none"> <li>▪ Wing doors</li> <li>▪ Safety guard</li> <li>▪ Covers</li> <li>▪ Removable access panels</li> </ul> | Protect against accidental contact with components: <ul style="list-style-type: none"> <li>▪ Moving parts</li> <li>▪ Electrical connections</li> <li>▪ Hot surfaces</li> </ul>                  |

Tab. 48 Machine safety devices

### 4.6 SIGMA CONTROL SMART control unit

#### 4.6.1 Controller overview

SIGMA CONTROL SMART controls, regulates, monitors, and protects the machine.

The SIGMA CONTROL SMART is used to display and set all of the parameters required for machine operation. Various user-dependent password levels protect the parameters from unauthorised modification.

The control and regulating function enables optimal duty cycles for the combustion engine with lowest possible energy consumption, adapted to the actual compressed air demand of the connected consumers.

The monitoring function enables:

- Monitoring of maintenance-relevant components in the combustion engine and compressor via interval counters.
- Display of warning messages or maintenance messages, as an indication of upcoming maintenance tasks.

The protection function enables automatic shutdown in the event of a fault, such as excessive temperature or overpressure, that could result in damage to the machine.

### 4.6.2 Operating elements




Fig. 10 Operating elements

| Item | Operating element | Symbol | Function  |
|------|-------------------|--------|---|
| ①    | «Up»              |        | <ul style="list-style-type: none"> <li>▪ Scrolls the menu up</li> <li>▪ Increases a parameter value</li> </ul>      |
| ②    | «Down»            |        | <ul style="list-style-type: none"> <li>▪ Scrolls the menu down</li> <li>▪ Reduces a parameter value</li> </ul>      |
| ③    | «Enter»           |        | <ul style="list-style-type: none"> <li>▪ Opens the selected submenu</li> <li>▪ Exits Edit mode and saves</li> </ul> |
| ④    | «LOAD/IDLE»       |        | Switches between the «LOAD/IDLE» operating points   |
| ⑤    | «OFF»             |        | Switches the machine off  |
| ⑥    | «ON»              |        | Switches the machine on   |

Tab. 49 Operating elements

### 4.6.3 Display elements
























Fig. 11 Display elements


| Item | Display element | Symbol  | Function   |
|------|-----------------|---|--|
| ①    | Menu bar        |    | <b>Main menu</b><br>Displays current operating data  |
|      |                 |  | <b>Error memory</b><br>Displays current faults and warnings  |
|      |                 |  | <b>Settings menu</b><br>Displays the current parameters  |
|      |                 |  | <b>System information</b><br>Displays data relating to the machine and software  |
|      |                 |  | <b>Maintenance</b><br>Displays time remaining until next maintenance due   |
| ②    | Navigation menu |  | <b>Escape</b> <ul style="list-style-type: none"> <li>▪ Navigates to the next menu level up</li> <li>▪ Operation with the «Enter» key enabled</li> </ul>  |
|      |                 |  | <b>Up/Down</b><br>Navigation by means of the «Up» and «Down» keys enabled  |
|      |                 |  | <b>Enter</b><br>Operation with the «Enter» key enabled   |
| ③    | Password level  |  | Displays the current password level (password level 1 shown)   |
| ④    | Current page    |  | Displays the current page  |
| ⑤    | Status bar      |  | <b>Controller voltage</b> <ul style="list-style-type: none"> <li>▪ Illuminates in green when the controller voltage is switched on</li> <li>▪ Is extinguished when maintenance is pending</li> </ul> |

| Item | Display element | Symbol  | Function   |
|------|-----------------|---|--|
|      |                 |    | <b>Maintenance</b> <ul style="list-style-type: none"> <li>• Illuminates in orange when maintenance is pending</li> <li>• In this case, replaces the Controller voltage symbol</li> </ul>   |
|      |                 |    | <b>Warning</b> <ul style="list-style-type: none"> <li>• Illuminates in orange when a warning is pending</li> <li>• Is extinguished when a fault is pending</li> <li>• The machine is not shut down</li> </ul>  |
|      |                 |    | <b>Fault</b> <ul style="list-style-type: none"> <li>• Illuminates in red when a fault is pending</li> <li>• In this case, replaces the Warning symbol</li> <li>• The machine is shut down</li> </ul>   |
|      |                 |    | <b>Compressor</b> <ul style="list-style-type: none"> <li>• Illuminates in orange when a compressor warning is pending</li> <li>• Illuminates in red when a compressor fault has occurred</li> </ul>  |
|      |                 |   | <b>Combustion engine</b> <ul style="list-style-type: none"> <li>• Illuminates in orange when a combustion engine warning is pending</li> <li>• Illuminates in red when a combustion engine fault has occurred</li> </ul>   |
|      |                 |  | <b>Diesel particulate filter</b> <ul style="list-style-type: none"> <li>• Illuminates in green during "normal operation"</li> <li>• Illuminates in green and orange with "Active regeneration request"</li> <li>• Illuminates in orange when a warning is pending</li> <li>• Illuminates in orange and red when "Parked regeneration" requested</li> <li>• Illuminates in red when a fault has occurred</li> </ul> |
|      |                 |  | <b>Ready to start</b> <ul style="list-style-type: none"> <li>• Flashes green when ready to start</li> <li>• Illuminates in green when combustion engine running</li> <li>• Is extinguished in the event of a fault</li> <li>• Inactive when restart inhibitor activated</li> </ul>   |

Tab. 50 Display elements

**Status display in menu bar**

| Symbol  | Symbol display   | Menu bar                   |
|---|------------------|----------------------------|
|  | Black            | Active                     |
|  | Grey             | Passive                    |
|  | Black background | Active and selected symbol |

| Symbol  | Symbol display  | Menu bar                           |
|---|-----------------|------------------------------------|
|  | Grey background | Selected symbol and activated menu |

Tab. 51 Example: Status display of system information symbol on machine

## 4.7 Variable pressure-flow rate control

The machine is equipped with variable pressure-flow rate control.

The flow rate can be flexibly adjusted dependent on the preselected pressure setting and the respective engine speed. This allows the machine to be operated in the minimum pressure range as well as at maximum working pressure.

The air pressure and flow rate are continuously controlled according to the current system requirement.

The maximum limit for the nominal pressure is set via the SIGMA CONTROL SMART control unit.

As soon as the lowest engine speed is reached, inlet valve control is additionally applied.



You can find technical data for the pressure-flow rate control in chapter [2.3 Compressor](#).

## 4.8 Exhaust gas after-treatment

The exhaust gases from a diesel engine contain invisible particles that are damaging to health.

State-of-the-art engine technology is used to reduce emissions of these harmful substances and thereby meet the strictest exhaust gas standards.

In order to achieve the right balance, all of the parameters that influence combustion must be optimally matched to one another. Particularly when used in conjunction with fuel injection and turbocharging, exhaust gas recirculation produces combustion with significantly lower levels of nitrogen oxide.

Furthermore, the drive engine is equipped as standard with different after-treatment devices in accordance with the respective version. All of these measures contribute collectively to the protection of health and the environment.

### 4.8.1 Drive engine specification according to version

| Version (EU)2016/1628 - 5            | Abbreviation |
|--------------------------------------|--------------|
| Exhaust gas turbocharger             | —            |
| Charge air cooling                   | —            |
| Exhaust gas recirculation            | EGR          |
| Diesel oxidation catalytic converter | DOC          |
| Diesel particulate filter            | DPF          |

Tab. 52 Specification version

## 4.9 Options function

### 4.9.1 **ba bb** Low-temperature equipment

#### 4.9.1.1 **ba** Ambient conditions

Your machine is provided with low-temperature equipment for operation at extremely cold ambient temperatures.

The compressed air hoses for control air are manufactured from polyamide with increased material strength. This increased material strength effectively insulates the control air against low ambient temperatures.

The electrical system starts your machine's drive engine at ambient temperatures down to -10 °C.

#### 4.9.1.2 **bb** Coolant preheating



Improve the cold-start characteristics at low ambient temperatures by preheating the drive engine coolant.

An electric preheater is installed. The heating element for the preheater protrudes directly into the drive engine coolant. A fuse protects against overheating.

The ideal preheating time depends on the ambient temperature. Approx. 3 Hours of pre-heating time results in thermal balance. This means that any subsequent heat input serves only to maintain the existing temperature. The remainder of the heat input is emitted into the surrounding environment.

To commission the pre-heating device you only need to connect the power cable to the machine's connection and the user's power socket.

### 4.9.2 **da db dd df dg** Compressed air treatment

#### 4.9.2.1 Compressed air quality classification at the compressed air outlet

| Compressed air quality |   | Compressed air treatment  |                     |
|------------------------|---|---|---------------------|
| Code                   | Characteristics   | Components  | Code                |
| A                      | <ul style="list-style-type: none"> <li>▪ Cool</li> <li>▪ Condensate-free</li> </ul>                     | <ul style="list-style-type: none"> <li>▪ Compressed air aftercooler</li> <li>▪ Water separator</li> </ul>   | <b>da</b>           |
| B                      | <ul style="list-style-type: none"> <li>▪ Dry</li> <li>▪ Warm</li> </ul>                                 | <ul style="list-style-type: none"> <li>▪ Compressed air aftercooler</li> <li>▪ Water separator</li> <li>▪ Heat exchanger</li> </ul>                               | <b>da + df</b>      |
| F                      | <ul style="list-style-type: none"> <li>▪ Dry</li> <li>▪ Technically oil-free</li> </ul>                 | <ul style="list-style-type: none"> <li>▪ Compressed air aftercooler</li> <li>▪ Water separator</li> <li>▪ Filter combination</li> </ul>                           | <b>da + dd</b>      |
| G                      | <ul style="list-style-type: none"> <li>▪ Dry</li> <li>▪ Technically oil-free</li> <li>▪ Warm</li> </ul> | <ul style="list-style-type: none"> <li>▪ Compressed air aftercooler</li> <li>▪ Water separator</li> <li>▪ Filter combination</li> <li>▪ Heat exchanger</li> </ul> | <b>da + dd + df</b> |

| Compressed air quality |                      | Compressed air treatment |          |
|------------------------|----------------------|--------------------------|----------|
| Code                   | Characteristics      | Components               | Code     |
| E                      | Containing lubricant | Tool lubricator          | ea eb ec |

Tab. 53 Compressed air quality classification

#### 4.9.2.2 **da** Compressed air aftercooler

The compressed air aftercooler cools the compressed air temperature down to only around 5 K to 10 K above ambient.

- The compressed air temperature is reduced via an exchange of heat.
- The moisture contained in the compressed air condenses into water.
- A large part of the moisture in the compressed air is removed.
- The water collects in the water separator.

#### 4.9.2.3 **da** Water separator

The water separator is positioned at the lowest point of the compressed air aftercooler.

The accumulating condensate collects in the water separator.

#### 4.9.2.4 **da** Dirt trap with condensate drain line

A dirt trap is located beneath the water separator.

- The condensate flows through the dirt trap.
- The dirt trap filters out any existing dirt particles.
- The condensate flows through the condensate drain line into the exhaust pipe.
- The condensate is completely evaporated due to the high exhaust temperatures.

#### 4.9.2.5 **da dg** Compressed air aftercooler with bypass

To obtain condensate-free compressed air, the compressed air flows through a compressed air aftercooler. The compressed air is cooled down. The cooling process condenses a large portion of the moisture contained in the compressed air. This accumulated condensate is removed via the downstream centrifugal separator.

Should compressed air treatment not be required, the bypass can be used to circumvent the compressed air aftercooler.

The compressed air aftercooler with bypass is available exclusively in combination with options **ba** low-temperature equipment or **bb** coolant preheating. Options **dd** prefilter with microfilter and **df** heat exchanger are not available in this version.

Availability of this application depends on the relevant country-specific variant.

#### 4.9.2.6 **dd** Filter combination

A filter combination consisting of prefilter and microfilter removes any remaining oil from the moisture-reduced compressed air.

- The moisture-reduced compressed air flows through the combined prefilter and microfilter.
- The combined prefilter and microfilter removes solid particles and any remaining oil from the moisture-reduced compressed air.

**4.9.2.7 df Heat exchanger**

You can activate or bypass the heat exchanger by adjusting a directional control valve.

If the heat exchanger is bypassed, the cooled, moisture-reduced compressed air is conveyed directly to the compressed air outlet.

If the heat exchanger is activated, the cooled, moisture-reduced compressed air is conveyed through the heat exchanger via another bypass. In this way, the cool compressed air is heated by the hot compressor oil. This heated, dry compressed air is ideal for applications such as sandblasting.

**4.9.2.8 ea ec Tool lubricator**

If you are using air tools that require lubrication, the compressed air must be enriched with lubricant.

Switch the lubricant on or off for each specific application by means of the shut-off valve.

Select the lubricant dosage for each specific application by means of the metering wheel.

| Lubricant content | Function   |
|-------------------|--|
| Less lubricant    | <ul style="list-style-type: none"> <li>▪ Lubricating the air tool</li> <li>▪ Protecting the air tool from corrosion</li> </ul> |
| More lubricant    | <ul style="list-style-type: none"> <li>▪ Cleaning the air tool</li> <li>▪ Protecting the air tool from icing</li> </ul>        |

Tab. 54 Adjusting the lubricant content

Should the air flow rate change, the lubricant volume is automatically adapted to the new air volume, e.g. when multiple tools are operated simultaneously.

**4.9.3 ga Generator**

A generator is installed to provide a power supply for individual electrical consumers. The generator is driven by the drive engine via a drive belt. A tensioning element automatically ensures optimum belt tension.

| Option code | Version                             | Description  |
|-------------|-------------------------------------|--|
| ga          | Generator without flow rate limiter | Switching on the generator does not limit the compressed air flow rate. The compressor delivers its full compressed air flow rate regardless of whether the generator is switched on or not. |

Tab. 55 Generator versions

**4.9.3.1 Operating instruments**

The switches and sockets for connection of electrical consumers are located on the generator control box. Individual consumers are connected exclusively via these sockets. The fuses are located inside the machine.




Fig. 12 Generator control box

- |                                    |                                       |
|------------------------------------|---------------------------------------|
| 1 Generator control box            | 4 «Operating mode» selector switch    |
| 2 Socket panel                     | 5 «Main switch»                       |
| 3 «Insulation monitoring» test key | 6 Protective cover for safety cut-out |

#### 4.9.3.2 Operating modes

There are two operating modes for the generator:

- Automatic cut-in
- Continuous load

Automatic cut-in operating mode:

The drive engine runs automatically at maximum speed if the electrical power consumption is more than 100 VA. The drive engine runs on at maximum speed for approx. 2 Minutes if the power consumption is below the minimum value. The drive engine consumes less fuel, since continuous switching between maximum and minimum speed is avoided.

Continuous load operating mode:

The drive engine runs continually at maximum speed. This ensures that the generator delivers constant power without delay.

| What do you wish to supply?         | Main switch | Operating mode selector switch |
|-------------------------------------|-------------|--------------------------------|
| Compressed air                      | OFF         | —                              |
| Compressed air and electrical power | ON          | Position 1<br>Automatic cut-in |
| Electrical power and compressed air | ON          | Position 2<br>Continuous load  |

Tab. 56 Operating mode preselection

#### 4.9.3.3 Electrical protection measures



Generators without the “Insulation monitoring with shutdown function” option comply with the protective measure “Protective separation with potential equalisation conductor” in accordance with DIN VDE 0100, Part 728  
Generators with the “Insulation monitoring with shutdown function” option comply with the higher-grade protective measure “Protective separation with insulation monitoring” in accordance with DIN VDE 0100, Part 728.

It is not necessary to earth the generator (e.g. via an earth rod) for proper function of the electrical protection measures mentioned. However, should earthing still be desired, or required in specific cases, a defined earthing of the generator housing must be implemented, or the generator housing

must be incorporated into the potential equalisation of other devices. For this purpose, use only the designated earthing points marked with the earthing symbol.



**⚠ DANGER**

**Danger of fatal injury from electric shock**

- ▶ Never earth the neutral conductor for the generator.
- ▶ Should the neutral conductor require earthing in spite of this, it must be performed exclusively by a qualified and certified electrician. An earth leakage circuit breaker (ELCB) must be connected downstream from the generator output. Confirm the effectiveness of the electrical protection measures by taking corresponding measurements.

**4.9.3.4 IT power network connection**



Operate the generator exclusively in an IT power network.




Fig. 13 IT power network connection

- |                    |               |
|--------------------|---------------|
| <b>A</b> Generator | <b>2</b> 50 m |
| <b>B</b> Consumer  | <b>3</b> 10 m |
| <b>1</b> 100 m     |               |

**4.9.3.5 Commissioning the generator**

If portable generators of version A are being operated with only one consumer, no further protective measures are required. Commissioning of the generator can be performed without a certified electrician.

If portable generators of version A are being operated with multiple consumers, additional protective measures are required:

- Residual current protective device (RCD) with a rated differential current of  $\leq 30$  mA for every additional consumer.
- Isolating transformer for every additional consumer in cases of increased electrical hazard due to a conductive environment with limited freedom of movement.

**4.9.4 1a 1b Operation in fire hazard areas**

Diesel engines represent a potential source of ignition in environments where concentrations of gas, vapour or dust are present and can cause fires.

For operation in fire hazard areas, the machine is equipped with the following additional equipment:

- 1a Spark arrestor
- 1b Spark arrestor + engine air shut-off valve

### Spark arrestor

A spark arrestor for the exhaust silencer is required when operating a diesel engine in a fire hazard area, or in forestry and agricultural applications. In such applications, a spark can ignite inflammable materials.

The spark arrestor is a safety device that prevents any glowing combustion residue from being emitted via the exhaust silencer.

### Engine air shut-off valve

Diesel engines are usually stopped by interrupting the fuel supply. When a combustible gas mixture is drawn into the air inlet of a diesel engine, interrupting the fuel supply is no longer sufficient to stop the engine. In order to reliably stop the diesel engine, the intake of combustion air must be shut off.

The self-closing engine air shut-off valve is a safety device for shutting off the supply of combustion air.

Should the diesel engine exceed the maximum permissible speed, the engine air shut-off valve will close automatically:

- The intake air supply is blocked
- The diesel engine comes to a standstill

## 4.9.5 **oa** Battery isolating switch

The machine is equipped with a battery isolating switch, so that the battery can be disconnected completely from the machine's electrical system (fire prevention, battery discharge protection).

### NOTICE

#### Danger of short circuit!

- ▶ Damage to the machine's electrical system is possible.
- ▶ Use the battery isolation switch only when the machine is shut down.
- ▶ Do not use the battery isolation switch as an emergency or main switch.




Fig. 14 Battery isolating switch

1 Battery isolating switch

## 4.9.6 **ob** Automatic START/STOP

An automatic START/STOP function can be configured via the SIGMA CONTROL SMART controller to enable automatic start-up of the machine.

**4.9.7 oc TELEMATICS**

Telematics is a technology that links the fields of telecommunications and information technology. Applications such as fleet and vehicle park management are concerned with the administration, planning, control and monitoring of vehicle fleets.

Determine the status of your portable machines by means of telemetric data from the GLOBAL POSITIONING SYSTEM, as well as technical data regarding the current condition of the vehicle.



The machine is intended for use in all EU member states.



The machine must only be operated with the antenna provided. Non-compliance may result in the loss of CE certification.



Personnel should remain a distance of 20 cm from the machine.




Fig. 15 Location of modem inside the machine

- 1 Modem
- 2 Signal cable
- 3 Modem bracket

- 4 Control box
- 5 Antenna
- 6 Central section of enclosure

4.9.7.1 Interfaces and indicator elements







Fig. 16 Interfaces and indicator elements

- 1 View – Interfaces
- 2 View – Indicator elements
- 3 GNSS antenna connection
- 4 Mobile communications antenna connection
- 5 Micro USB connection
- 6 Main plug connector
- 7 Protective cap for micro USB connection
- 8 *ON* LED indicator element
- 9 *STATUS* LED indicator element

4.9.7.2 **ON LED indicator element**

The *ON*LED indicates the status of the power supply.

| Colour   | Status   | Meaning   |
|--|----------|---|
| —  | Off      | Device is switched off or in Sleep mode.  |
| Green<br> | On       | Device is switched on.<br>Terminal 30 voltage is in the permissible range.      |
| Red<br>   | On       | Device is switched on.<br>Terminal 30 voltage is outside the permissible range. |
| Green<br> | Flashing | Device is in Diagnostics or Update mode.  |

Tab. 57 *ON*LED indicator element

4.9.7.3 **STATUS LED indicator element**






The *STATUS*LED indicates the operating status of the active connections.

The different colours are displayed in order of priority.

- The highest priority is Level 1
- The lowest priority is Level 5

If more than one operating status is active at the same time, the *STATUS*LED will always display the status with the highest priority level.

| Colour | Status | Connection | Priority | Meaning                 |
|--------|--------|------------|----------|-------------------------|
| —      | Off    | —          | —        | Device is switched off. |

| Colour   | Status | Connection                        | Priority | Meaning                           |
|--|--------|-----------------------------------|----------|-----------------------------------|
| Green<br>   | On     | Various                           | —        | Connected to PROEMION server.     |
| Blue<br>    | On     | Mobile communications<br>Internet | 1        | Not connected to PROEMION server. |
| Red<br>     | On     | CAN 1                             | 2        | Connection error.                 |
| Orange<br>  | On     | CAN 2                             | 3        | Connection error.                 |
| Magenta<br> | On     | GNSS                              | 4        | No status / antenna found.        |

 Tab. 58 *Status* LED indicator element

#### 4.9.8 **od** Battery trickle charging

At all times, the battery must be sufficiently charged to start the machine. To ensure that this is the case, a battery charger must be used.

The battery charger is pre-wired ready for operation. Voltage is supplied via a separate mains supply. A flexible mains connector cable is provided for the connection.

#### 4.9.9 **oe** Closed floor pan

The closed floor pan prevents small leakages of operating fluids or fuel inside the machine from reaching the outside environment.

Bung plugs provide oil-tight sealing of the maintenance holes in the floor panel in order to ensure the floor pan remains leak-free.

#### 4.9.10 **sf** Anti-theft device

The machine is fitted with a security chain for anti-theft protection.




Fig. 17 Container for security chain

- |   |                           |   |                                 |
|---|---------------------------|---|---------------------------------|
| 1 | Front end of machine      | 4 | Security chain                  |
| 2 | Indicating label location | 5 | Security chain indicating label |
| 3 | Container                 |   |                                 |

#### 4.9.11 **ua** Hose reel

For flexible connection of air tools operated at distance from the machine, a compressed air extension hose is provided.

A user-friendly hose reel facilitates rolling up and unrolling of the compressed air extension hose. The hose reel also provides secure storage for the compressed air extension hose.

#### 4.9.12 Document bag

Store important accompanying documents for the machine safely and cleanly inside the document bag. This ensures that operating personnel always have access to the accompanying documents for the mobile machine, regardless of location.

You can find the document bag on the inside of the right-hand wing door.

- The document bag does not constitute part of the standard equipment
- The document bag can be selected optionally

## 5 Transport and storage

### 5.1 Transport damage

The machine is shipped in perfect condition. Nevertheless, damage may have occurred during transportation.

Check the machine for visible transport damage. If damage has occurred, report it immediately to the carrier or supplier.

### 5.2 Transporting the machine by crane



A lifting eye is positioned inside the machine as the central lifting point for transportation by crane. The lifting eye is indicated by a mandatory sign, see [Fig. 18 Lifting eye mandatory sign](#).

The position of the lifting eye ensures that the machine remains level when lifted. The lifting eye is rated for the permissible total weight of the machine.

Only a crane hook should be inserted through the lifting eye, in accordance with the mandatory sign.



Fig. 18 Lifting eye mandatory sign

Snow or ice on the machine can have the following effects:

- Unfavourable shift in the machine's centre of gravity
- Permissible load of the crane and machine hoists exceeded

Remove any snow or ice from the machine.

Ensure that the lifting eye cover is freely accessible and can be opened.

#### 5.2.1 Attaching a crane hook and lifting the machine

The lifting eye is positioned inside the machine, in the central section of the enclosure.



#### **WARNING**

##### **Danger of falling when lifting**

- ▶ Use a crane hook of the correct dimensions for the size of the lifting eye.
- ▶ Correctly insert the crane hook into the lifting eye.

1. Open the lifting eye cover.
2. Position the crane hook vertically above the lifting eye.
3. Lower the crane hook.
4. Manually insert the crane hook into the lifting eye.
  - ✓ The crane hook remains movable within the lifting eye.
5. Slowly raise the crane hook until the cable is taut.
  - ✓ The crane hook automatically aligns itself vertically.
6. Lift and lower slowly and with care.

### 5.3 **rw** Transporting the machine by forklift



Only transport stationary machines fitted with skids by forklift. Stationary machines fitted with skids are equipped with two lifting pockets for a suitable forklift.




Fig. 19 Lifting pockets for transport by forklift

- ① Skid
- ② Lifting pocket

- ▶ Drive the full length of both forks carefully into the lifting pockets on the skids.

### 5.4 Transporting as a load

The type of packing and securing required is determined by the mode of transport. Packing and securing methods are designed so that, with proper handling, the goods arrive at their destination in perfect condition.

Always observe the applicable accident prevention and safety regulations during transportation.



National guidelines and regulations for the securing of loads during transportation must be adhered to. The load must be secured in such a manner that it cannot slide, fall, roll around or cause avoidable noise in case of emergency braking or sudden turns.

Responsibility for proper securing of the load rests with the driver, owner and carrier.

Example for Germany: Guideline CTU/VDI 2700

- ▶ Observe the recognised technical rules.

#### 5.4.1 Load securing for mobile machines

Attach tension belts exclusively at the designated lashing points.



#### **WARNING**

**Danger of crushing due to machine slipping, tipping over or rolling away**

- ▶ Ensure that tensions belts are rated correctly.
- ▶ Use squared timbers.

#### **NOTICE**

**Damage due to incorrect bracing**

Damage to parts of the bodywork and the chassis support device is possible.

- ▶ Only brace mobile machines using the lashing points indicated.
- ▶ Protect the jockey wheel/support stand against overload when lashing.




Fig. 20 Example of proper load securing

- |                                  |                              |
|----------------------------------|------------------------------|
| ① Properly relieved jockey wheel | ④ Squared timber             |
| ② Squared timber                 | ⑤ Lashing points on load bed |
| ③ Proper bracing                 |                              |

1. Crank the jockey wheel/prop stand in or out until the machine is standing level.
2. Position a squared timber ② in front of and behind the wheels.
3. Position a squared timber ④ by the jockey wheel/prop stand beneath the drawbar tube.
4. Crank in the jockey wheel/prop stand as far as the limit stop.
5. Lash the machine down properly with all of the tension belts.



The lashing forces on the forward area of the machine are acting on the drawbar tube and the squared timber.

The jockey wheel/prop stand is relieved.

The mobile machine is secured against sliding, tipping over and rolling.

### 5.4.2 Load securing for stationary machines

If required, attach tension belts at the four lashing points.



#### **WARNING**

**Danger from machine tilting or tipping over**

- ▶ Do not use lashing points as crane lifting points.



#### **WARNING**

**Danger of crushing due to machine slipping or tipping over**

- ▶ Ensure that tensions belts are rated correctly.

#### **NOTICE**

**Damage due to bracing**

Forces of movement cause damage to the bodywork.

- ▶ Only brace stationary machines using the lashing points provided.




Fig. 21 Bracing as load securing for stationary versions of a machine

- ▶ Lash the machine down properly with all of the tension belts.



The stationary machine is secured against sliding and tipping over.

### 5.4.3 Transporting the machine by air freight

Transporting the machine by air freight requires it to be classified as dangerous goods. Non-compliance with this can result in high penalties.



#### **! WARNING**

**Danger of fire or explosion from operating fluids/materials**

- ▶ Remove all dangerous materials before transporting by air freight.

1. Remove all fuel.
2. Remove all fuel gases.
3. Remove all lubricating oil from the drive engine.
4. Remove electrolyte from rechargeable batteries.
5. Remove all lubricating oil from the compressor.
6. Remove any residual quantities of lubricant from the tool lubricator.

## 5.5 Decommissioning the machine

Decommission the machine in the following circumstances:

- The machine is to be temporarily taken out of commission
- The machine is to be taken out of commission for an extended period of time
- The machine is to be permanently taken out of commission and scrapped



- Plastic sheeting
- Moisture-resistant adhesive tape
- Desiccant
- Preservative

1. Carry out the activities described each time the machine is decommissioned.
2. Attach a notice to the control panel indicating the decommissioning measures taken.

### 5.5.1 Temporary decommissioning

## 5 Transport and storage

### 5.5 Decommissioning the machine

Decommissioning the machine for periods of up to approximately 4 Months.

1. Fully disconnect the battery.
2. Close all discharge valves at the compressed air outlet.
3. Seal off the following openings on the machine using plastic sheeting and adhesive tape:
  - a) Seal off the air intake for the engine air filter.
  - b) Seal off the air intake for the compressor air filter.
  - c) Seal off the exhaust outlet.
4. Attach the following notice to the control panel indicating the decommissioning measures taken.

#### **Caution!**

1. Machine has been temporarily decommissioned.
2. The following openings have been sealed off:
  - Air intake on engine air filter
  - Air intake on compressor air filter
  - Exhaust gas outlet
3. Recommission in accordance with the operating manual.

Date and signature:

Tab. 59 Example notice in the event of temporary decommissioning

### 5.5.2 Long-term decommissioning

Decommissioning the machine for periods of approximately 5 Months.

1. Check the drive engine coolant.
2. Arrange for preservation measures to be carried out on the drive engine by a specialist workshop.
3. Fully disconnect the battery and store in a frost-protected location.
4. Close all discharge valves at the compressed air outlet.
5. Seal off the following openings on the machine using plastic sheeting and adhesive tape:
  - a) Seal off the air intake for the engine air filter.
  - b) Seal off the air intake for the compressor air filter.
  - c) Seal off the exhaust outlet.
6. Clean the bodywork.
7. Apply a preservative to the bodywork.
8. Attach the following notice to the control panel indicating the decommissioning measures taken.

#### **Caution!**

1. Machine has been decommissioned.
2. Preservation measures have been carried out on the drive engine.
3. The following openings have been sealed off:
  - Air intake on engine air filter
  - Air intake on compressor air filter
  - Exhaust outlet

**Caution!**

4. To recommission:

- Recommission in accordance with the operating manual.
- Carry out measures for recommissioning following long-term decommissioning.

Date and signature

---

Tab. 60 Example notice in the event of long-term decommissioning

## 6 Installation and operating conditions

The operator is responsible for correct installation of the portable machine designed for outdoor use. Since the operating location for this machine can change frequently, the installation conditions must be complied with at each location.

Set up the portable machine correctly at each operating location. For each installation, observe the information contained in [Tab. 61 Installation conditions at installation location](#).

Secure mobile machines against rolling away.

### 6.1 Installation conditions at installation location

| Installation condition  | Measure   |
|---|---|
| Level installation surface <sup>1)</sup>                              | Find a suitable installation surface.   |
| Stable ground <sup>2)</sup>   | Check that the ground is capable of bearing the weight.   |
| Minimum distance from excavation pits $\geq 1.5$ m                    | Check the minimum distance from any excavation pits, see <a href="#">Fig. 22 Example: Minimum distance from excavation pits and slopes</a> .          |
| Minimum distance from slopes $\geq 1.5$ m                             | Check the minimum distance from any slopes, see <a href="#">Fig. 22 Example: Minimum distance from excavation pits and slopes</a> .                   |
| Minimum distance between exhaust outlet and walls = $L^3) \times 1.5$ | Check the minimum distance from any walls, see <a href="#">Fig. 23 Example: Minimum distance from exhaust outlet to walls</a> .                       |
| Cooling air inlet pointing in direction of wind                       | Position the cooling air inlet in the direction of the wind, see <a href="#">Fig. 24 Example: Note the direction of the wind when positioning</a> .   |
| Exhaust outlet positioned against direction of wind.                  | Position the exhaust outlet against the direction of the wind, see <a href="#">Fig. 24 Example: Note the direction of the wind when positioning</a> . |

1) Temporary operation at a maximum incline of 15° is possible

2) Ground is capable of bearing the weight of the machine

3) Length of machine without drawbar tube

Tab. 61 Installation conditions at installation location




Fig. 22 Example: Minimum distance from excavation pits and slopes

- ① Minimum distance from excavation pits
- ② Minimum distance from slopes




Fig. 23 Example: Minimum distance from exhaust outlet to walls

- ① Exhaust outlet side
- ② Wall




Fig. 24 Example: Note the direction of the wind when positioning

- ① Wind direction
- ② Machine cooling air inlet

## 6.2 Ensuring accessibility

Ensure the following points when installing the machine:

- Control panel accessibility
- Full opening and closing of the enclosure
- Full opening and closing of all cover panels

## 7 Assembly and installation

### 7.1 Determining anti-vibration elements

Metal anti-vibration elements and rubber buffers isolate machine vibrations and reduce acceleration.

Fix your stationary machine in place using metal anti-vibration elements or rubber buffers.

This will increase the service life of the machine and protect the immediate surroundings.

Metal anti-vibration elements and rubber buffers:

- Are not included in the standard equipment supplied by the machine manufacturer
- Can be optionally selected

**Determine anti-vibration elements in accordance with the specific installation conditions**

| Installation condition   | Measure                                      |
|--|--|
| Installation surface subject to acceleration<br>Example: HGV loading bed | Use machine feet                             |
| Example: Static installation   | Use optional machine feet or rubber buffers. |

Tab. 62 Determining anti-vibration elements for stationary machines

1. Check the installation conditions for the machine.
2. Determine suitable anti-vibration elements.

### 7.2 Installing vibration elements

In the machine support frame, you will find fixing bores for bolt-down machine feet or rubber buffers.




Fig. 25 Example: Installing vibration elements on stationary machines

- |                                    |                 |
|------------------------------------|-----------------|
| ① Machine                          | ④ Fixing screw  |
| ② Stationary machine support frame | ⑤ Washer        |
| ③ Machine foot                     | ⑥ Rubber buffer |

1. Lift the machine correctly.
2. Position the machine foot beneath the corresponding bore in the support frame.
3. Insert the fixing screw through the bore in the support frame.

## 7 Assembly and installation

### 7.3 Performing assembly work on the chassis

---

4. Establish the screw connection with the machine foot.
5. Correctly tighten all fixing screws.
6. Mount and tighten all of the other machine feet in the same way.



You can find information regarding the dimensions of the bore in the support frame in the separate document Drawings and Plans.

### 7.3 Performing assembly work on the chassis

A chassis operating manual is included amongst the documents supplied with your machine.

The manner in which the machine is delivered determines the assembly work required.

Machines that are only partially assembled at despatch must be completed by trained personnel before final delivery to the customer.



See the separate chassis operating manual document for instructions regarding assembly work on the chassis.

## 8 Commissioning

Incorrect or improper commissioning can cause injury to personnel and damage to the machine. Allow only trained and authorised installation personnel to perform all commissioning activities. Comply with all information signs on the machine.

### NOTICE

#### Danger of short circuit when connecting the starter battery

- ▶ First check that the Controller ON/OFF switch is switched off.
- ▶ Then connect the negative cable to the battery.

### 8.1 To be observed during initial commissioning

Initial commissioning of the machine takes place at the manufacturer's facility. Every machine undergoes an extensive test run and a meticulous inspection.

1. Remove all transport and packaging materials on and inside the machine.
2. Monitor the machine during the first few hours of operation in order to identify any errors.

### 8.2 Recommissioning following storage or decommissioning

| Storage or decommissioning                                       |  |
|--|--|
| More than 5Months  | More than 36Months   |
| <a href="#">8.2.1 Checking the condition of the drive engine</a> | <a href="#">8.2.4 Arranging for the technical condition of the machine to be checked</a> |
| <a href="#">8.2.2 Checking the condition of the compressor</a>   | —  |
| <a href="#">8.2.3 Maintaining the bodywork</a>                   | —  |

Tab. 63 Recommissioning following long-term storage or decommissioning

- ▶ Properly carry out the following recommissioning tasks.

#### 8.2.1 Checking the condition of the drive engine

1. Take note of the information sign regarding long-term storage/decommissioning.
  - a) Check whether preservation measures have been carried out on the drive engine.
  - b) If preservation measures have been carried out, arrange for the entire oil reserve in the drive engine to be replaced by a specialist workshop.
2. Check the engine oil filter.
3. Check the engine oil level.
4. Remove any desiccant from the engine air filter.
5. Check the engine air filter.
6. Check the coolant level.
7. Check the battery charge level.
8. Connect the battery.
9. Check all fuel hoses for leaks, loose connections, wear and damage.
10. Check all pressure hoses on the drive engine for leaks, loose connections, wear and damage.

### 8.2.2 Checking the condition of the compressor

1. Remove any desiccant from the compressor air filter.
2. Check the compressor air filter.
3. Check the compressor oil filter.
4. Check the compressor oil level.
5. If required, replenish the compressor oil.
6. Check all pressure hoses/lines on the compressor for leaks, loose connections, wear and damage.

### 8.2.3 Maintaining the bodywork

1. Clean the exterior of the machine with a grease- and dirt-removing agent.
2. Check the labelling for legibility.
3. Clean the labelling.

### 8.2.4 Arranging for the technical condition of the machine to be checked

- ▶ Arrange for the overall technical condition to be checked by an authorised SP<sup>1)</sup>.

## 8.3 Checking installation and operating conditions

Check and confirm that all of the items on the checklist have been fulfilled before commissioning the machine.

| Component   | Task   | See chapter  | Fulfilled? |
|-------------|--|--|------------|
| —           | Operating personnel are fully conversant with the safety regulations.  | <a href="#">3 Safety and responsibility</a>                |            |
| Machine     | All installation conditions have been fulfilled.                       | <a href="#">6 Installation and operating conditions</a>    |            |
|             | All assembly conditions been fulfilled.                                | <a href="#">7 Assembly and installation</a>                |            |
| Drive motor | There is sufficient oil in the drive engine.                           | <a href="#">11.3.4 Servicing the engine oil circuit</a>    |            |
|             | The maintenance indicator for the drive engine air filter is in order. | <a href="#">11.3.2 Engine air filter maintenance</a>       |            |
|             | There is sufficient coolant in the coolant expansion tank.             | <a href="#">11.3.1 Checking the coolant</a>                |            |
|             | There is sufficient fuel in the fuel tank.                             | <a href="#">9.2 Filling the fuel tank with fuel</a>        |            |
| Compressor  | There is sufficient compressor oil in the oil separator tank.          | <a href="#">11.4.1.1 Checking the compressor oil level</a> |            |

<sup>1)</sup> Service Partner

## 8 Commissioning

### 8.4 To be observed during operation at low temperatures

| Component | Task  | See chapter  | Fulfilled? |
|-----------|---|--|------------|
|           | The maintenance indicator for the compressor air filter is in order.  | <a href="#">11.4.4 Servicing the compressor air filter</a> |            |
| Bodywork  | All wing doors are closed.  | —  |            |
|           | All body panels are attached: <ul style="list-style-type: none"> <li>▪ Covers</li> <li>▪ Removable access panels</li> </ul> | —  |            |

Tab. 64 Checklist for installation and operating conditions

### 8.4 To be observed during operation at low temperatures



- Comply with the permissible total weight of the machine
- Check the function of the EMERGENCY STOP device
- Adjust operating fluids/materials and components accordingly at low ambient temperatures
- If required, activate the automated start-up procedure

| Designation   | Measure   |
|---|---|
| Comply with the permissible total weight of the machine | Remove snow or ice from the machine.  |
| Check the function of the EMERGENCY STOP device         | Defrost the «EMERGENCY STOP» button.  |
| Adjust the operating fluids/materials                   | <ul style="list-style-type: none"> <li>▪ Use winter engine oil</li> <li>▪ Use low-viscosity compressor oil</li> <li>▪ Use winter diesel fuel</li> </ul> |
| Adjust the components                                   | Use short compressed air hoses.   |
| Check the warm-up function when temperatures are low    | Activate the automated start-up procedure.  |

Tab. 65 Measures to be taken at low ambient temperatures

#### 8.4.1 Checking the warm-up function in low temperatures

In low ambient temperatures, SIGMA CONTROL SMART starts the machine by means of an automated start-up procedure.

SIGMA CONTROL SMART starts the drive engine in a maximum of three automatic start cycles of 30 Seconds each.

Following every false start, the machine is vented.

After each venting of the machine, the next start-up cycle begins automatically.

Should the third start-up cycle end with another false start, the operator must manually switch off the controller voltage and, after a defined time interval, switch it back on again.

##### 8.4.1.1 Activating the automated start-up procedure

The following indicators on the SIGMA CONTROL SMART control unit signal that the machine is ready to start:

## 8 Commissioning

### 8.4 To be observed during operation at low temperatures

- The *Controller voltage* indicator is illuminated.
- The *READY* indicator flashes.
- ▶ Press the «START» key on the SIGMA CONTROL SMART control panel.
  - ✓ The machine begins a maximum of three automatic start-up cycles of 30 Seconds each. The machine is automatically vented should a false start occur. After the machine has been vented, a new start-up cycle begins automatically.



The automated start-up process for low-temperature conditions ends after three automatic start-up cycles with false starts.

- Reactivate the automated start-up procedure.

#### 8.4.1.2 Reactivating the automated start-up procedure

1. Switch off the «Controller ON/OFF» switch.
2. 20 Seconds Wait.
3. Switch the «Controller ON/OFF» switch back on.
  - ✓ The *Controller voltage* indicator is illuminated. The *READY* indicator flashes.
4. Press the «START» key on the SIGMA CONTROL SMART control panel.



Three more automatic start-up cycles are available.

One of the three automatic start-up cycles successfully starts up the machine.

#### 8.4.2 Starting assistance

Should the charge level of your battery be insufficient, start your machine with the aid of a suitable jump starter battery.



Do not attempt starting assistance if any of the following deficiencies apply to your battery:

- Receiver battery is deeply discharged.
- Receiver battery is frozen.
- Receiver battery housing is damaged.
- Receiver battery housing is leaking electrolyte.



#### **! DANGER**

##### **Danger of explosion due to oxyhydrogen gas mixture**

Hydrogen and oxygen gas are produced when jump starting.

- ▶ Prevent fire, sparks and open flames.
- ▶ Do not smoke.
- ▶ Do not bend directly over the battery.
- ▶ Prevent short circuits.
- ▶ Adhere to the correct sequence when connecting and disconnecting the jump leads.
- ▶ Do not connect the black jump lead to the negative terminal on the receiver battery.



#### **! WARNING**

##### **Danger of chemical burns from leaking electrolyte**

- ▶ Wear face and eye protection.
- ▶ Wear personal protective equipment.
- ▶ Wear acid-proof protective gloves.



- Jump leads with insulated cable clamps.
- Jump leads with minimum cable cross section of 50 mm<sup>2</sup>.

## 8 Commissioning

### 8.4 To be observed during operation at low temperatures



- The nominal voltage for both batteries is the same.
- The capacity of both batteries is roughly the same.
- The charge level of the jump starter battery is 100 %.
- The controller voltage for the other vehicle with the jump starter battery is switched off.
- The controller voltage for the receiver machine is switched off.
- The bodywork of the jump starter vehicle and the receiver machine are not in physical contact.
- All terminal protector caps on both batteries have been removed.




Fig. 26 Connecting the red jump lead

- |                               |   |
|-------------------------------|---|
| <b>A</b> Jump starter battery | <b>2</b> Jump starter battery positive terminal |
| <b>B</b> Receiver battery     | <b>3</b> Receiver battery positive terminal     |
| <b>1</b> Red jump lead        |   |

1. Connect the red jump lead:

- a) Connect the first cable clamp to the positive terminal **2** on the jump starter battery.
  - b) Connect the second cable clamp to the positive terminal **3** on the receiver battery.
- ✓ The red jump lead is connected properly.



Use a bare metal point on the engine block **6** as an earth connection.

## 8 Commissioning

### 8.4 To be observed during operation at low temperatures




Fig. 27 Connecting the black jump lead

- |                               |   |
|-------------------------------|---|
| <b>A</b> Jump starter battery | <b>4</b> Black jump lead                        |
| <b>B</b> Receiver battery     | <b>5</b> Jump starter battery negative terminal |
| <b>1</b> Red jump lead        | <b>6</b> Receiver machine earth connection      |

2. Connect the black jump lead:
  - a) Connect the first cable clamp to the negative terminal **5** on the jump starter battery.
  - b) Connect the second cable clamp to the earth connection **6** on the receiver machine.
  - ✓ The black jump lead is connected properly.
3. Start the other vehicle with the jump starter battery.
4. Start the machine with the receiver battery:
  - a) Switch on the controller voltage.
  - b) Start the machine and run it for approx. 2 Minutes.
5. First disconnect the black jump lead in the order **6**, then **5**.
6. Next disconnect the red jump lead in the order **3**, then **2**.
7. Reattach all terminal protector caps.

## 9 Operation

Only operate the machine outdoors.

Always operate the machine with the doors and body panels closed.

Do not perform inspection work or adjust settings when the machine is running.

Only activate the discharge valves at the compressed air outlet when wearing protective gloves.

Only fill the fuel tank when the machine is switched off and has cooled down.



### **DANGER**

#### **Danger of poisoning from released exhaust gases**

- ▶ Only use the machine outdoors.
- ▶ Never operate the machine in enclosed spaces.
- ▶ Do not inhale exhaust gases.



### **WARNING**

#### **Danger of burns from fuel igniting**

- ▶ Only refuel the machine after switching it off and allowing it to cool down.
- ▶ Never refuel the machine in the vicinity of open flames or sparks.
- ▶ Do not overfill the fuel tank.
- ▶ Do not spill fuel.
- ▶ Do not smoke.



### **WARNING**

#### **Danger of shearing and crushing from contact with rotating components**

- ▶ Keep all machine doors and cover panels closed.
- ▶ Do not perform inspections and adjustments whilst the machine is running.
- ▶ Stop the machine before opening any doors or cover panels.



### **WARNING**

#### **Danger of injury from loud noise and compressed air blast**

Damage to hearing and injuries possible if discharge valves are opened without a consumer being connected.

- ▶ Wear ear protection.
- ▶ Keep discharge valves closed when no consumer is connected.



### **CAUTION**

#### **Danger of burns from hot surfaces**

- ▶ Keep all machine doors and cover panels closed.
- ▶ Wear personal protective equipment.
- ▶ Maintain your distance.

### **NOTICE**

#### **Damage to air receivers and compressed air tools from corrosion**

- ▶ Use the shortest compressed air hoses possible.
- ▶ Drain the condensate regularly.

## 9.1 Starting and stopping

In this chapter, you will find out how to start and stop the machine correctly.

### 9.1.1 Following the quick reference guide

Numbered pictograms guide you through the start-up and stop procedure.

You can find the quick reference guide as a sticker directly above the control panel cover.




Fig. 28 Start-up procedure




Fig. 29 Stop procedure

### 9.1.2 Control panel

To ensure material-friendly operation, always stop the machine using the «STOP» key.

Use the «EMERGENCY STOP» button for emergencies only.




Fig. 30 Control panel overview

- |  |   |
|--|---|
| 1 Control panel                        | 5 Navigation keys                               |
| 2 «EMERGENCY STOP» button              | 6 Operating keys                                |
| 3 Compressed air outlet pressure gauge | 7 <i>START</i> and <i>STOP</i> indicating label |
| 4 SIGMA CONTROL SMART control unit     | 8 «Controller ON/OFF» switch                    |

The switch for the controller voltage is located on the control panel. The controller voltage is switched on when you turn the «Controller ON/OFF» switch to the *ON* position.

To ensure material-friendly operation, always stop the machine using the «STOP» key.

Use the «EMERGENCY STOP» button for emergencies only.

### 9.1.3 Start the machine

#### NOTICE

##### Damage due to cold-start aids

Cold start sprays, such as ether or engine start sprays, can cause damage to the drive engine.

- ▶ Do not use cold-start aids.

#### 9.1.3.1 Ensuring the machine is ready to start




Fig. 31 Indicators at 'Ready' status

- |                                       |
|---------------------------------------|
| 1 Display                             |
| 2 <i>Controller voltage</i> indicator |
| 3 <i>Ready</i> indicator              |

- ▶ Switch on the «Controller ON/OFF» switch.



The controller voltage is switched on.

The *Controller voltage* indicator is illuminated.

The *Ready* indicator flashes provided that no errors are present in the SIGMA CONTROL SMART.

### 9.1.3.2 Starting the drive engine

- ▶ Press the «START» key on the SIGMA CONTROL SMART control panel.
  - ✓ The drive engine initially runs in the warm-up phase in the IDLE operating point. The drive engine is then switched to the LOAD operating point when the setpoint for the airdend discharge temperature is reached.



The drive engine does not start at low ambient temperatures.

- Activate the automated low-temperature start-up procedure, see chapter [8.4 To be observed during operation at low temperatures](#).

### 9.1.4 Setting the compressed air discharge pressure

The SIGMA CONTROL SMART display indicates the setting value.

It is possible to enter a setting when the controller is switched on and the drive engine is stopped, as well as during operation of the machine. You can only set the compressed air discharge pressure to a value below the maximum working pressure.

1. Open the separate user manual for the SIGMA CONTROL SMART controller.
2. Read and comply with the instructions for {9]Setting the compressed air discharge pressure{10}.

### 9.1.5 Stopping the machine

Two alternative shutdown procedures are available for stopping the machine properly.

- Shut the machine down using AUTO OFF
- Shut the machine down with the SIGMA CONTROL SMART controller

#### NOTICE

##### Thermal overload from stopping the drive engine at high load

Failure of or damage to the turbocharger is possible.

- ▶ Shut the machine down properly.
- ▶ Only use the «EMERGENCY STOP» button in the event of an emergency.



KAESER recommends using the AUTO OFF shutdown procedure.

#### 9.1.5.1 Shutting the machine down using AUTO OFF

The automated AUTO OFF shutdown procedure properly shuts down your machine with a single press of the «Controller ON/OFF» switch.



- The machine is switched on
- The SIGMA CONTROL SMART control panel cover is open
- ▶ Switch the «Controller ON/OFF» switch to the *OFF* position.
  - ✓ The machine switches to the AUTO OFF shutdown procedure.
    - The machine switches to the IDLE operating point and begins to vent.
    - The machine switches to the STANDSTILL operating point and vents completely.

- The controller voltage switches itself off automatically.



The automated AUTO OFF shutdown procedure switches the controller voltage off. Battery starting capacity and performance are assured.

#### 9.1.5.2 Shutting the machine down with the SIGMA CONTROL SMART controller.



- The machine is switched on
- The SIGMA CONTROL SMART control panel cover is open

1. Actuate the «LOAD/IDLE» key.
  - ✓ The machine switches to the unloaded run-on phase.
2. Wait for approx. 3 MinutenMinutes until the turbocharger has cooled down sufficiently.
3. Press and hold down the «STOP» key for longer than 1 SekundeSecond
  - ✓ The drive engine stops.

#### 9.1.5.3 Switching off the controller voltage

##### **NOTICE**

##### **Damage to the engine electronics and controller due to memory error**

- ▶ Only switch off the controller voltage once the engine control unit has completed the saving procedure.

1. Wait for approx. 30 Seconds until the engine control unit's back-up procedure has completed.
2. Switch the «Controller ON/OFF» switch to off.

#### 9.1.6 Closing daily operation

1. Close all compressed air discharge valves at the compressed air outlet.
2. Close the control panel cover for SIGMA CONTROL SMART.
3. Set the «battery isolation switch» to position **0**.
4. Close and lock both wing doors.
5. Secure each wing door with a lock.
  - ✓ The machine is secured against unauthorised use.

#### 9.1.7 Shutting the machine down in an emergency



An emergency can occur with the machine or in its immediate vicinity. Shut the machine down using the «EMERGENCY STOP» button.




Fig. 32 «EMERGENCY STOP» safety device button

- ① «EMERGENCY STOP» button
- ② Unlock the «EMERGENCY STOP» button in the direction of the arrow

1. Press the «EMERGENCY STOP» button.
  - ✓ Drive engine stopped.  
Machine pressure system vented.  
«EMERGENCY STOP» button is locked.  
Machine is secured against reactivation.
2. Ensure operational safety of the machine and its immediate environment:
  - a) Determine the cause of the fault.
  - b) Rectify the fault appropriately.
3. Commissioning the machine:
  - a) Turn the «EMERGENCY STOP» button in the direction of the arrow until it unlocks automatically.
  - b) Press the «Enter» key to confirm the fault message.
  - c) Restart the SIGMA CONTROL SMART.
    - ✓ The fault message is acknowledged.  
The machine is ready for operation.

## 9.2 Filling the fuel tank with fuel

Accidents caused by igniting fuel can be avoided by exercising special care when filling the fuel tank.



### **! WARNING**

#### **Danger of burns from fuel igniting**

- ▶ Only refuel the machine after switching it off and allowing it to cool down.
- ▶ Never refuel the machine in the vicinity of open flames or sparks.
- ▶ Do not overfill the fuel tank.
- ▶ Do not spill fuel.
- ▶ Do not smoke.



### **! CAUTION**

#### **Danger of environmental pollution from fuel**

- ▶ Do not overfill the fuel tank.
- ▶ Do not spill fuel.

### 9.2.1 Using the proper fuel type

Fill the fuel tank exclusively with liquid fuel of the proper fuel type. A label on the fuel tank in the vicinity of the filler port indicates the proper fuel type.

Super unleaded petrol lacks the specific lubricating qualities of diesel fuel. Operation with super unleaded petrol will result in immediate damage to the precision components in the injection system.

## NOTICE

### Damage from using an incorrect fuel type

- ▶ Do not start the drive engine.
  - ▶ Empty the fuel tank and arrange for it to be cleaned.
  - ▶ Arrange for the fuel system to be cleaned if the drive engine was started.
- ▶ Check that the fuel you fill the tank with is of the proper type.



For the required measures following use of an improper fuel type, see chapter [10.1 Evaluating drive engine errors and faults](#).

## 9.2.2 Correctly filling the fuel tank



Liquid fuels expand at high ambient temperatures.

In order to prevent the fuel from overflowing, only fill the fuel tank as far as the *maximum fill level* marking [2](#).




Fig. 33 Refilling the tank with the proper fuel type

- |                              |                      |
|------------------------------|----------------------|
| 1 Fuel tank                  | 4 Fuel type label    |
| 2 Maximum fill level marking | 5 Refuelling label   |
| 3 Cover cap                  | 6 Diesel fuel nozzle |

1. Loosen and remove the cover cap for the fuel tank.
2. Insert the diesel fuel nozzle into the filler port and activate.
3. Fill with diesel up to the *maximum fill level* marking.
4. Shut off and remove the fuel nozzle.
5. Close the fuel tank filler port with the cover cap.



No fuel nozzle is available at the installation location.

- Use a funnel to fill with diesel fuel directly from a jerrycan.

## 9.3 Using the options

### 9.3.1 **bb** Using the coolant preheating

You can find the corresponding mains supply cable inside the machine.




Fig. 34 Using the coolant preheating

- |   |             |   |                       |
|---|-------------|---|-----------------------|
| 1 | Socket      | 3 | Mains connector cable |
| 2 | Device plug | 4 | Mains plug            |

1. Open the protective cap for the socket and insert the device connector into the socket.
2. Insert the mains plug into the user-end mains socket.  
 The drive engine coolant is preheated.
3. Preheat the coolant for approx. 3 Hours.

### 9.3.2 **da dg** Compressed air aftercooler with bypass

The compressed air generated by the machine is cooled via the compressed air aftercooler. This treatment stage can be circumvented by means of the optional compressed air aftercooler bypass. A directional control valve is installed in the machine for this purpose.

Adjust the directional control valve in accordance with your requirements.




Fig. 35 Compressed air aftercooler with bypass

- |   |  |   |  |
|---|--|---|--|
| 1 | Compressed air aftercooler               | 3 | Bypass line  |
| 2 | Supply line for generated compressed air | 4 | Directional control valve in position: Bypass activated (ON) |

The following options can be selected for the compressed air treatment:

| Position | Compressed air quality at compressed air outlet  |
|----------|--|
|          | <b>Bypass OFF</b><br>Compressed air is conveyed through the compressed air aftercooler and cooled, thereby removing a large proportion of the condensable moisture contained in the air. Accumulating condensate is separated via the water separator. Cool, dry compressed air is available from the air distributor. |
|          | <b>Bypass ON</b><br>Compressed air generated by the compressor is not conveyed through the compressed air aftercooler. Only untreated compressed air is available from the air distributor.  |

Tab. 66 Directional control valve position and selected compressed air quality

The directional control valve should be either fully open or fully closed.

### **dg** Activating the bypass

Adjust the directional control valve in accordance with your requirements.



At low ambient temperatures:

- Start the machine with Option **da** activated, without bypass
- Allow the machine to warm up at IDLE speed for a few minutes



### **!** CAUTION

**Danger of burns from hot surfaces**

- ▶ Wear personal protective equipment.
- ▶ Always wear protective gloves when adjusting the directional control valve lever.



- The machine is switched off
- Compressed air consumers are disconnected
- The discharge valve is open
- The machine is fully vented, the pressure gauge reads 0 bar.

- ▶ Actuate the directional control valve as far as the limit stop.

### **9.3.3 df** Switching on the heat exchanger

You have the option of conveying the treated compressed air through the heat exchanger via a bypass.

The bypass enables infinitely variable setting of the compressed air discharge temperature, from 7 °C above ambient to approximately 85 °C.

For this purpose, a directional control valve is fitted, which can be adjusted manually via a lever on the exterior of the machine. The directional control valve can conveniently be adjusted during operation in accordance with the requirements of your application.



### **!** CAUTION

**Danger of burns from hot surfaces**

- ▶ Wear personal protective equipment.
- ▶ Always wear protective gloves when adjusting the directional control valve lever.




Fig. 36 Bypassing or activating the heat exchanger

- ① Directional control valve lever
- ② Right-hand side of machine
- ③ Location of lever on machine

### 9.3.3.1 Selecting compressed air quality B or A

| Switch position<br>Directional control valve | Compressed air quality  | Code for<br>compressed air quality |
|--|---|------------------------------------|
| I  | <ul style="list-style-type: none"> <li>▪ Condensate-free</li> <li>▪ Warm</li> </ul> | B                                  |
| 0  | Condensate-free   | A                                  |

Tab. 67 Directional control valve switch position and compressed air quality

1. Decide upon compressed air quality based on the application.
2. Set the directional control valve according to the compressed air quality.

### 9.3.3.2 Selecting compressed air quality G or F

| Switch position<br>Directional control valve | Compressed air quality   | Code for<br>compressed air quality |
|--|--|------------------------------------|
| I  | <ul style="list-style-type: none"> <li>▪ Moisture-reduced</li> <li>▪ Technically oil-free</li> <li>▪ Warm</li> </ul> | G                                  |
| 0  | <ul style="list-style-type: none"> <li>▪ Moisture-reduced</li> <li>▪ Technically oil-free</li> </ul>                 | F                                  |

Tab. 68 Directional control valve switch position and compressed air quality

1. Decide upon compressed air quality based on the application.
2. Set the directional control valve according to the compressed air quality.

9.3.4 **ea ec** Using the tool lubricator

**NOTICE**

**Damage from compressed air containing lubricant**

- ▶ Read the operating instructions for the air tool.
- ▶ Block lubricant additive for unsuitable air tools.
- ▶ Blow lubricant residue out of the air line.




Fig. 37 Using the tool lubricator

- |                   |                         |
|-------------------|-------------------------|
| 1 Tool lubricator | 4 Shut-off valve open   |
| 2 Metering wheel  | 5 Shut-off valve closed |
| 3 Shut-off valve  | 6 Compressed air outlet |

1. Read the operating instructions for the air tool.
2. Check whether the air tool must be operated with or without lubricant additive.



Service the tool lubricator, see chapter [11.11 Servicing the options](#).

9.3.4.1 **Switching on the lubricant additive**

You can open the shut-off valve by turning the shut-off valve knob in the direction of flow.

- ▶ Open the shut-off valve.
  - ☑ Connected air tools will be operated with compressed air containing lubricant.

9.3.4.2 **Metering the lubricant content**

The lubricant content in the compressed air is dependent upon the specific application.

The lubricant content in the compressed air depends on:

- The air tools used
- The compressed air hoses connected

Select the lubricant dosage in the compressed air in accordance with your specific application by turning the metering wheel:

| Action                                   | Result                          |
|--|---------------------------------|
| Turning the metering wheel clockwise     | Reduces the lubricant content   |
| Turning the metering wheel anticlockwise | Increases the lubricant content |

- ▶ Set the lubricant content via the metering wheel in accordance with your specific application.

### 9.3.4.3 Blocking the lubricant additive

You can close the shut-off valve by turning the shut-off valve knob at right angles to the direction of flow.

- ▶ Close the shut-off valve.
  - ☑ Connected air tools will be operated without compressed air containing lubricant.

## 9.3.5 **ga** Operating the generator

Carry out the steps in the following sequence:

- Test the insulation monitoring device
- Install the electrical equipment
- Switch on the generator to generate electricity
- Switch on the electrical equipment
- Ensure material-friendly shutdown of the generator
- ▶ Follow all instructions carefully.

### 9.3.5.1 Testing the insulation monitoring device



#### **⚠ DANGER**

**Danger of fatal injury from contact with live components**

- ▶ Always test the insulation monitoring device first.
- ▶ Only activate the generator after successfully testing the insulation monitoring device.

Test the insulation monitoring device every day with the drive engine running.

The «insulation monitoring test key» is equipped with an integrated *warning lamp*.

You can also find the test instructions directly on the machine's generator control box.




Fig. 38 Testing the insulation monitoring device

- |                                  |                                  |
|----------------------------------|----------------------------------|
| ① Generator control box          | ⑥ Shunt release                  |
| ② Operating mode selector switch | ⑦ Sockets 230 V/N/PE, 16 A       |
| ③ Main switch                    | ⑧ Socket 400 V/3/N/PE, 16 A      |
| ④ Safety cut-out cover           | ⑨ Insulation monitoring test key |
| ⑤ Main fuse                      |                                  |

1. Start the machine.
2. Testing the insulation monitoring device:
  - a) Switch on the main fuse ⑤.
  - b) Actuate the test key ⑨ for three Seconds.



The main fuse is tripped.  
The generator can be used to generate electricity.



The main fuse is not tripped.  
The integrated warning lamp on the test key is illuminated.

- Decommission the generator and contact an authorised KAESER SERVICE agent.

### 9.3.5.2 Installing electrical equipment

Each socket on the machine's socket panel is clearly labelled.

1. Check that the electrical equipment and its connecting cable are in perfect condition.
2. Check that the electrical equipment is switched off.
3. Insert the plug for the electrical equipment into a suitable socket on the socket panel.

### 9.3.5.3 Activating the generator to generate electricity

You can use the generator without earthing.

1. Switch the machine to LOAD.
2. Switch on the «generator main switch».
3. Switch on the «main fuse».
4. Set the «operating mode selector switch» to the specific operating mode.

#### 9.3.5.4 Using electrical equipment

Proceed as follows:

- Switch equipment with a high starting current on first
- Always switch multiple electrical equipment on one after the other



### **WARNING**

**Danger of injury from electrical equipment starting up in an uncontrolled manner**

- ▶ Only switch on stationary equipment when the danger area is clear of personnel.
  - ▶ Hold hand-held equipment before switching on.
1. Correctly switching on stationary electrical equipment:
    - a) Ensure that the danger area is clear of personnel.
    - b) Switch on the stationary electrical equipment.
    - c) Start up the stationary electrical equipment under visual monitoring.
  2. Correctly switching on hand-held electrical equipment:
    - a) Firstly, hold the hand-held electrical equipment.
    - b) Switch on the hand-held electrical equipment.
    - c) Start up the hand-held electrical equipment in a controlled manner.

#### 9.3.5.5 Shutting down the generator

### **NOTICE**

**Thermal overload from shutting down the generator at high load**

Failure of or damage to the generator is possible.

- ▶ Switch the machine first to the unloaded run-on phase.
1. Turn the «main switch» to position 0.
  2. Turn the «generator main switch» to position 0.
  3. Activate the «LOAD/IDLE» key.
    - ☑ The machine switches to the unloaded run-on phase.
  4. Wait for approx. 2 Minutes until the generator has cooled down sufficiently.

#### 9.3.6 Using the hose reel

At the front end of the machine is a hose reel equipped with a compressed air extension hose. A crank handle is provided for user-friendly unreeling of the compressed air extension hose to the required length.



### **WARNING**

**Danger of impact from loose hose ends whipping around in an uncontrolled manner**

- ▶ Do not pressurise loose compressed air hoses.
- ▶ Only pressurise compressed air hoses when the air tool has been connected.
- ▶ Only detach air tools when the compressed air hose has been vented.
- ▶ At a working pressure of >7 bar, compressed air hoses should be secured to the discharge valve by a cable.




Fig. 39 Hose reel with compressed air extension hose

|   |                         |    |                               |
|---|-------------------------|----|-------------------------------|
| 1 | Front end of machine    | 6  | Hose drum                     |
| 2 | Discharge valve         | 7  | Claw coupling                 |
| 3 | Clamping screw          | 8  | Compressed air extension hose |
| 4 | Compressed air hose     | 9  | Crank handle                  |
| 5 | Transport locking screw | 10 | Bracket                       |

1. Remove the claw coupling for the compressed air extension hose from the bracket.
  - a) Loosen the transport locking screw.
  - b) Loosen the clamping screw.
2. Swing out the crank handle.
  - a) Unreel the compressed air extension hose to the required length.
  - b) Tighten the clamping screw.
  - c) Swing the crank handle back in.
3. Attach the air tool to the claw coupling.
4. Start the machine.
  - a) Hold the air tool by its handle.
  - b) Open the discharge valve 2 for the compressed air extension hose.



The air tool is ready for operation.

## 10 Fault recognition and rectification

### 10.1 Evaluating drive engine errors and faults

| Error                                 | Possible cause   | Measure  |
|---------------------------------------|--|--|
| Drive engine does not start or stops. | «EMERGENCY STOP» button is locked.                             | Unlock the «EMERGENCY STOP» button.  |
|                                       | Starter defective.   | Contact a SW <sup>3)</sup>   |
|                                       | ECU fault.   | Contact a SW <sup>3)</sup>   |
|                                       | Fuel tank empty.   | Refill the fuel tank.  |
|                                       | Air pockets in fuel line between fuel tank and injection pump. | Vent the fuel line.  |
|                                       | Fuel line broken.  | Contact an authorised SP <sup>2)</sup>   |
|                                       | Fuel filter clogged.   | Clean or replace the fuel filter.  |
|                                       | Control fuse or relay defective.                               | Contact a SW <sup>3)</sup>   |
|                                       | ADT <sup>1)</sup> too high.                                    | Contact an authorised SP <sup>2)</sup>   |
|                                       | SCS controller defective.                                      | Contact an authorised SP <sup>2)</sup>   |
|                                       | Electrical connections and/or cables loose or broken.          | <ul style="list-style-type: none"> <li>▪ Tighten</li> <li>▪ Contact an authorised SP<sup>2)</sup></li> </ul>   |
|                                       | Battery defective or charge too low.                           | Service the battery.   |
| Drive engine not reaching LOAD speed. | Air pockets in fuel line between fuel tank and injection pump. | Vent the fuel line.  |
|                                       | Fuel filter clogged.   | Clean or replace the fuel filter.  |
|                                       | Fuel line broken.  | Contact a SW <sup>3)</sup>   |
|                                       | ECU fault.   | Contact a SW <sup>3)</sup>   |
|                                       | SCS controller defective.                                      | Contact an authorised SP <sup>2)</sup>   |
| Drive engine losing power.            | Engine air filter clogged.                                     | <ul style="list-style-type: none"> <li>▪ Check the maintenance indicator</li> <li>▪ Clean the filter element or</li> <li>▪ replace the filter element</li> </ul> |
|                                       | Turbocharger defective.  | Contact a SW <sup>3)</sup>   |
|                                       | Turbocharger hoses leaking.                                    | Check the turbocharger hoses.  |
|                                       | Injector malfunctioning.                                       | SW <sup>3)</sup>   |

1) Airend Discharge Temperature

2) Service Partner

3) Specialist Workshop

| Error  | Possible cause   | Measure  |
|--|--|--|
| Error noticed when refuelling.                   | Fuel tank filled with incorrect, "Super" fuel type.                          | Arrange for the fuel tank to be drained / pumped out by a SW <sup>3)</sup>   |
| Drive engine knocks, splutters or fails to start | Fuel tank filled with incorrect, "Super" fuel type and drive engine started. | <ul style="list-style-type: none"> <li>▪ Stop the machine immediately</li> <li>▪ Arrange for the fuel tank to be drained / pumped out by a SW<sup>3)</sup></li> <li>▪ Arrange for the injection pump to be replaced by a SW<sup>3)</sup></li> <li>▪ Arrange for the drive engine to be checked by a SW<sup>3)</sup></li> </ul> |

1) Airend Discharge Temperature

2) Service Partner

3) Specialist Workshop

Tab. 69 Drive engine errors and faults

## 10.2 Evaluating compressor errors and faults

| Error                     | Possible cause                                     | Action  |
|---------------------------|--|---|
| Working pressure too high | Proportional controller defective.                 | Contact an authorised SP <sup>3)</sup>  |
|                           | Inlet valve not closing.                           | Arrange for the regulator, control line and inlet valve to be checked by an authorised SP <sup>3)</sup> |
|                           | Pressure gauge displaying incorrect reading.       | Contact an authorised SP <sup>3)</sup>  |
|                           | Venting valve not blowing off.                     | Arrange for the connections and function to be checked by an authorised SP <sup>3)</sup>                |
| Working pressure too low  | Proportional controller defective.                 | Contact an authorised SP <sup>3)</sup>  |
|                           | Inlet valve not opening or only partially opening. | Contact an authorised SP <sup>3)</sup>  |
|                           | Pressure gauge displaying incorrect reading.       | Contact an authorised SP <sup>3)</sup>  |
|                           | Safety valve incorrectly adjusted or leaking.      | Contact an authorised SP <sup>3)</sup>  |
|                           | Venting valve blowing off.                         | Contact an authorised SP <sup>3)</sup>  |

1) Oil Separator Cartridge

2) Oil Separator Tank

3) Service Partner

| Error                              | Possible cause  | Action   |
|------------------------------------|---|--|
|                                    | Drive engine not running at LOAD operating point.                             | See chapter <a href="#">10.1 Evaluating drive engine errors and faults</a>   |
|                                    | Compressor air filter clogged.  | Clean or replace.  |
|                                    | OSC <sup>1)</sup> heavily contaminated.                                       | Replace OSC <sup>1)</sup> .  |
| Safety valve blowing off           | OSC <sup>1)</sup> heavily contaminated.                                       | Replace OSC <sup>1)</sup> .  |
|                                    | Inlet valve not closing.  | Arrange for the regulator, control line and inlet valve to be checked by an authorised SP <sup>3)</sup> .  |
|                                    | Safety valve incorrectly adjusted or leaking.                                 | Contact an authorised SP <sup>3)</sup>   |
| Machine overheating                | Fan wheel defective.  | Arrange for the blades or complete fan wheel to be replaced by an authorised SP <sup>3)</sup> .  |
|                                    | Oil cooler surface contaminated.  | Clean oil cooler.  |
|                                    | Working element in thermostatic valve defective.                              | Contact an authorised SP <sup>3)</sup>   |
|                                    | Working pressure too high due to incorrectly adjusted proportional controller | Contact an authorised SP <sup>3)</sup>   |
|                                    | OSC <sup>1)</sup> heavily contaminated.                                       | <ul style="list-style-type: none"> <li>▪ Measure differential pressure</li> <li>▪ If the pressure differential is greater than 1 bar, replace</li> </ul> |
|                                    | Compressor oil filter cartridge clogged.                                      | Replace compressor oil filter cartridge  |
|                                    | Compressor oil level low.   | Replenish compressor oil   |
|                                    | Oil lines leaking.  | Tighten or arrange replacement by an authorised SP <sup>3)</sup>   |
|                                    | Drive engine cooling system defective.  | Contact an authorised SP <sup>3)</sup>   |
|                                    | Cooling air blower defective.   | Contact an authorised SP <sup>3)</sup>   |
|                                    | Residue in coolant cooler.  | Clean coolant cooler.  |
|                                    | Ambient temperature too high.   | Check ambient temperature at installation location   |
| High oil content in compressed air | Oil return line for OSC <sup>1)</sup> contaminated.                           | <ul style="list-style-type: none"> <li>▪ Clean dirt trap for oil separator cartridge</li> <li>▪ Replace strainer and nozzle if required</li> </ul>       |
|                                    | OSC <sup>1)</sup> torn.   | Replace oil separator cartridge  |

1) Oil Separator Cartridge

2) Oil Separator Tank

3) Service Partner

| Error   | Possible cause                                       | Action                                 |
|---|--|--|
|   | Compressor oil level too high in OST <sup>2)</sup> . | Reduce compressor oil level to maximum |
| Oil leaking from compressor air filter after machine has been shut down | Non-return function on inlet valve defective.        | Contact an authorised SP <sup>3)</sup> |
| High moisture content in compressed air                                 | Condensate drain on water separator contaminated.    | Clean dirt trap on water separator     |

1) Oil Separator Cartridge

2) Oil Separator Tank

3) Service Partner

Tab. 70 Compressor errors and faults

## 10.3 **ga** Evaluating generator errors and faults

| Error  | Possible cause  | Measure   |
|--|---|---|
| Generator producing no or too little voltage | Drive belt defective.   | Contact an authorised SP <sup>1)</sup>  |
|  | Generator / regulator defective.  | Contact an authorised SP <sup>1)</sup>  |
|  | Circuit breaker triggered due to overload or defect.  | <ul style="list-style-type: none"> <li>▪ Check the power of the connected consumers</li> <li>▪ Reduce the power of the connected consumers</li> <li>▪ Arrange for the consumers to be checked for short circuit by an authorised SP<sup>1)</sup></li> <li>▪ Arrange for the circuit breaker to be checked by an authorised SP<sup>1)</sup></li> </ul> |
|  | Drive engine speed too low.   | Arrange for the rated speed to be adjusted by an authorised SP <sup>1)</sup>  |
|  | Generator not switched on.  | Switch the generator on.  |
|  | <ul style="list-style-type: none"> <li>▪ Working pressure for compressor set too high</li> <li>▪ Speed dropping due to engine overload</li> </ul> | Arrange for the working pressure to be adjusted by an authorised. SP <sup>1)</sup> .  |
|  | Drive engine power reduced due to climatic or other influences.   | Do not load the generator and compressor up to their rated power.   |
| Generator voltage too high                   | Generator / regulator defective.  | Contact an authorised SP <sup>1)</sup>  |

1) Service Partner

| Error | Possible cause               | Measure  |
|-------|------------------------------|--|
|       | Drive engine speed too high. | Arrange for the rated speed to be adjusted by an authorised SP <sup>1)</sup> |

1) Service Partner

---

Tab. 71 Generator errors and faults

# 11 Maintenance

Proper maintenance ensures safe and effective operation of the machine.

Perform maintenance work only when the machine has been shut down, is fully vented and has cooled down. Park mobile machines levelly and secure against rolling away.

For the sake of your own health and to protect the environment, exercise caution when handling fuel, operating fluids or batteries.

Permit work on live components to be performed by a certified electrician only.



## **DANGER**

### **Danger of force being exerted on the body due to sudden release of pressure**

- ▶ Stop the machine and wait until it has vented.
- ▶ Open all discharge valves at the compressed air outlet.
- ▶ Check that the pressure gauge reads 0 bar.
- ▶ Ensure that all pressurised components are fully vented.



## **DANGER**

### **Danger of poisoning from released exhaust gases**

- ▶ Only use the machine outdoors.
- ▶ Never operate the machine in enclosed spaces.
- ▶ Do not inhale exhaust gases.



## **WARNING**

### **Danger of injury from careless use of personal protective equipment**

- ▶ Wear suitable personal protective equipment when performing all maintenance work.



## **WARNING**

### **Danger of burns from fuel igniting**

- ▶ Stop the drive engine and allow it to cool down.
- ▶ Keep fuel away from hot machine components.
- ▶ Wipe up spilled fuel immediately.
- ▶ Do not smoke.



## **WARNING**

### **Danger of shearing and crushing from contact with rotating components**

- ▶ Stop the machine.
- ▶ Secure the machine against being restarted.
- ▶ Only remove safety guards and cover panels after securing the machine against being restarted.



## **CAUTION**

### **Danger of burning from hot surfaces**

- ▶ Stop the machine and allow it to cool down.
- ▶ Wear personal protective equipment.





## **CAUTION**

### **Danger from contact with live components**

- ▶ Disconnect the negative cable from the battery before performing any work on electrical components.

**Labelling the machine**

Warn third persons in particular by blocking off access to the work area and displaying appropriate signage whilst work is being performed on the machine:

| Symbol  | Meaning   |
|---|---|
|  | Do not switch on the machine                                  |
|  | Work taking place on the machine<br>Machine not ready for use |

Tab. 72 Labelling the machine

**Perform a test run:**

The test run is the first run of the machine following completion of a maintenance task. The test run serves to test the functions and performance of the machine.

**Test run following completion of a maintenance task**

|  |  |
|--|--|
| Prepare for operation:   | <ul style="list-style-type: none"> <li>▪ Connect the negative cable to the battery.</li> <li>▪ Switch on the «Controller ON/OFF» switch.</li> <li>▪ Close both wing doors.</li> </ul>  |
| Open the control panel cover:                                      | Press the «START» key on the SIGMA CONTROL SMART control panel.  |
| Run the machine for approx. 5 Minutes in the IDLE operating point. |  |
| Check the operating characteristics of the machine:                | <ul style="list-style-type: none"> <li>▪ Check the running characteristics.</li> <li>▪ Check the running noise.</li> <li>▪ Check smoke emission from the exhaust.</li> <li>▪ Visually check for leaks outside the machine.</li> </ul>  |
| Stop the machine:  | <ul style="list-style-type: none"> <li>▪ Press the «STOP» key on the SIGMA CONTROL SMART control panel.</li> <li>▪ Wait until the machine has vented automatically, Pressure gauge reads 0 bar.</li> <li>▪ Open all discharge valves at the compressed air outlet.</li> <li>▪ Allow the machine to cool down.</li> <li>▪ Switch off the «Controller ON/OFF» switch.</li> </ul>   |
| Check the interior of the machine:                                 | <ul style="list-style-type: none"> <li>▪ Visually check for leaks.</li> <li>▪ Check all of the newly serviced components again for the following:                             <ul style="list-style-type: none"> <li>▪ Operating fluid fill levels</li> <li>▪ Tightness and secure fit</li> <li>▪ Correct belt tension</li> </ul> </li> <li>▪ Check all safety devices for secure fit:                             <ul style="list-style-type: none"> <li>▪ Heat shield</li> <li>▪ Belt guard</li> <li>▪ Fan wheel guard</li> <li>▪ Covers for electrical connections</li> </ul> </li> </ul> |

Tab. 73 Performing a test run

## 11.1 Ordering spare parts and operating fluids/materials

### Compressor

| Designation                           | Unit/quantity | Number |
|---------------------------------------|---------------|--------|
| Primary filter element, air filter    | 1             | 1260   |
| Secondary filter element, air filter  | 1             | 1261   |
| Filter element, oil filter            | 1             | 1210   |
| Oil separator cartridge, complete set | 1             | 1455   |
| Compressor oil                        | 1             | 1600   |

Tab. 74 Ordering spare parts and operating fluids/materials for the compressor

### HATZ drive engine

| Designation                          | Unit/quantity | Number |
|--------------------------------------|---------------|--------|
| Primary filter element, air filter   | 1             | 1280   |
| Secondary filter element, air filter | 1             | 1281   |
| Fuel-water separator                 | 1             | 1980   |
| Fuel filter (cartridge)              | 1             | 1920   |
| Oil filter (cartridge)               | 1             | 1905   |
| Injector nozzle                      | 3             | 4475   |
| Injector nozzle seal                 | 3             | 4476   |
| Engine belt                          | 1             | 4470   |
| Glow plug                            | 3             | 4466   |
| Engine oil                           | 1             | 1925   |

Tab. 75 Ordering spare parts and operating fluids/materials for the drive engine

## 11.2 Following the maintenance schedule

### 11.2.1 Logging maintenance work

The maintenance intervals are recommended intervals for genuine KAESER parts. These recommendations apply to average operating conditions. In the event of unfavourable operating conditions, maintenance intervals for e.g. oil changes and filter replacement are reduced.

Unfavourable operating conditions include, for example:

- Heavy dust content in the ambient air
- High / low ambient temperatures
- Poor fuel quality
- Heavy use

1. Adjust maintenance intervals in accordance with the local operating conditions.
2. Log all maintenance work in order to identify any deviations from manufacturer recommendations.

### 11.2.2 Regular maintenance intervals

Regular machine maintenance intervals can be found in the following table.

| Maintenance interval                                   | Short description |
|--|-------------------|
| Daily  | —                 |
| Every 250 operating hours, every year at a minimum     | A250              |
| Every 500 operating hours, every year at a minimum     | A500              |
| Every 1000 operating hours, every 2 years at a minimum | A1000             |
| Every 1500 operating hours, every 3 years at a minimum | A1500             |
| Every 3000 operating hours, every 6 years at a minimum | A3000             |

Tab. 76 Regular maintenance intervals

1. Maintenance tasks should be carried out in a timely manner in accordance with the prevailing ambient and operating conditions.
2. Replace spare parts and operating fluids/materials in accordance with their respective service lives.

### 11.2.3 Maintenance schedule following initial commissioning

Carry out maintenance tasks on time, in accordance with the maintenance schedule.

| Assembly Task  | E10 <sup>1)</sup> | E50 <sup>2)</sup> | Note |
|--|-------------------|-------------------|------|
| <b><u>11.3 Servicing the drive engine:</u></b>                                 |                   |                   |      |
| Check fuel lines and hose clamps.<br>Tighten hose clamps if required.          | ○                 | ●                 |      |
| <b><u>11.11.5 ga Servicing the generator:</u></b>                              |                   |                   |      |
| Check belt tension   | ●                 | ○                 |      |
| 1) after the first 10 operating hours<br>2) after the first 50 operating hours |                   |                   |      |

Tab. 77 Maintenance tasks following initial commissioning

### 11.2.4 Machine maintenance schedule

Carry out maintenance tasks on time, in accordance with the maintenance schedule.

| Assembly Task  | Daily | A250 | A500 | A1000 | A1500 | A3000 | Note |
|--|-------|------|------|-------|-------|-------|------|
| <b><u>11.3 Servicing the drive engine:</u></b>                               |       |      |      |       |       |       |      |
| 1) Exhaust Gas Recirculation<br>2) Specialist Workshop<br>3) Service Partner |       |      |      |       |       |       |      |

# 11 Maintenance

## 11.2 Following the maintenance schedule

| Assembly Task  | Daily | A250 | A500 | A1000 | A1500 | A3000 | Note                                |
|--|-------|------|------|-------|-------|-------|-------------------------------------|
| <a href="#">11.3.2.1 Checking the engine air filter maintenance indicator</a>                              | ●     | ○    | ○    | ○     | ○     | ○     |                                     |
| <a href="#">11.3.4.1 Checking the engine oil level</a>   | ●     | ○    | ○    | ○     | ○     | ○     |                                     |
| <a href="#">11.3.4.3 Changing the engine oil</a>   | ○     | ○    | ●    | ○     | ○     | ○     |                                     |
| <a href="#">11.3.4.4 Replacing the engine oil filter</a>   | ○     | ○    | ●    | ○     | ○     | ○     |                                     |
| <a href="#">11.3.5.3 Checking the belt tension</a>   | ○     | ○    | ●    | ○     | ○     | ○     | SW <sup>2)</sup>                    |
| <a href="#">11.3.5.5 Replace drive belt</a>  | ○     | ○    | ○    | ○     | ○     | ●     | SW <sup>2)</sup>                    |
| <a href="#">11.3.2.7 Cleaning the primary filter element in the engine air filter, replace if required</a> | ○     | ●    | ○    | ○     | ○     | ○     |                                     |
| Replace primary filter element, see <a href="#">11.3.2 Engine air filter maintenance</a>                   | ○     | ○    | ●    | ○     | ○     | ○     |                                     |
| Replace secondary filter element, see <a href="#">11.3.2 Engine air filter maintenance</a>                 | ○     | ○    | ●    | ○     | ○     | ○     |                                     |
| Check intake air line between air filter and drive engine  | ○     | ○    | ●    | ○     | ○     | ○     | SW <sup>2)</sup>                    |
| <a href="#">11.3.1.1 Checking the coolant level</a>  | ●     | ○    | ○    | ○     | ○     | ○     |                                     |
| <a href="#">11.3.1.2 Checking the coolant quality</a>  | ○     | ○    | ●    | ○     | ○     | ○     | SW <sup>2)</sup> , SP <sup>3)</sup> |
| <a href="#">11.3.1.5 Changing the coolant</a>  | ○     | ○    | ○    | ○     | ●     | ○     | SW <sup>2)</sup> , SP <sup>3)</sup> |
| <a href="#">11.3.1.6 Removing residue from the coolant cooler</a>  | ○     | ○    | ○    | ○     | ●     | ○     | SW <sup>2)</sup> , SP <sup>3)</sup> |
| Clean coolant cooler, see <a href="#">11.5 Cleaning the coolers</a>  | ○     | ●    | ○    | ○     | ○     | ○     |                                     |
| Clean charge air cooler, see <a href="#">11.5 Cleaning the coolers</a>                                     | ○     | ●    | ○    | ○     | ○     | ○     |                                     |
| Fill fuel tank   | ●     | ○    | ○    | ○     | ○     | ○     |                                     |
| <a href="#">11.3.3.2 Emptying the fuel-water separator</a>   | ●     | ○    | ○    | ○     | ○     | ○     |                                     |
| <a href="#">11.3.3.3 Replace fuel prefilter</a>  | ○     | ○    | ●    | ○     | ○     | ○     |                                     |

1) Exhaust Gas Recirculation

2) Specialist Workshop

3) Service Partner

# 11 Maintenance

## 11.2 Following the maintenance schedule

| Assembly Task   | Daily | A250 | A500 | A1000 | A1500 | A3000 | Note                                |
|---|-------|------|------|-------|-------|-------|-------------------------------------|
| <a href="#">11.3.3.4 Replacing the fuel filter cartridge</a>  | ○     | ○    | ●    | ○     | ○     | ○     | SW <sup>2)</sup> , SP <sup>3)</sup> |
| Check fuel tank for contamination.  | ○     | ○    | ●    | ○     | ○     | ○     |                                     |
| <a href="#">11.3.3.1 Cleaning the tank strainer</a>   | ○     | ○    | ●    | ○     | ○     | ○     |                                     |
| <a href="#">11.3.7 Servicing the battery</a>  | ○     | ○    | ●    | ○     | ○     | ○     |                                     |
| <b><a href="#">11.3.6 Servicing the exhaust gas after-treatment:</a></b>  |       |      |      |       |       |       |                                     |
| Check exhaust system for leaks, including exhaust gas after-treatment components.                               | ●     | ○    | ○    | ○     | ○     | ○     |                                     |
| Service exhaust gas after-treatment components  | ○     | ○    | ●    | ○     | ○     | ○     | SW <sup>2)</sup> , SP <sup>3)</sup> |
| Arrange for EGR <sup>1)</sup> to be cleaned   | ○     | ○    | ○    | ○     | ○     | ●     | SW <sup>2)</sup> , SP <sup>3)</sup> |
| <b><a href="#">11.4 Servicing the compressor:</a></b>   |       |      |      |       |       |       |                                     |
| <a href="#">11.4.4.1 Checking the compressor air filter maintenance indicator</a>                               | ●     | ○    | ○    | ○     | ○     | ○     |                                     |
| <a href="#">11.4.1.1 Checking the compressor oil level</a>  | ●     | ○    | ○    | ○     | ○     | ○     |                                     |
| Clean compressor oil cooler, see <a href="#">11.5 Cleaning the coolers</a>                                      | ○     | ●    | ○    | ○     | ○     | ○     |                                     |
| <a href="#">11.4.2 Dirt trap maintenance on the fluid distribution module</a>                                   | ○     | ○    | ○    | ●     | ○     | ○     |                                     |
| <a href="#">11.4.4.7 Cleaning the primary filter element in the compressor air filter</a> , replace if required | ○     | ○    | ●    | ○     | ○     | ○     |                                     |
| Replace primary filter element, see <a href="#">11.4.4 Servicing the compressor air filter</a>                  | ○     | ○    | ○    | ●     | ○     | ○     |                                     |
| Replace secondary filter element, see <a href="#">11.4.4 Servicing the compressor air filter</a>                | ○     | ○    | ○    | ●     | ○     | ○     |                                     |
| <a href="#">11.4.1.3 Changing the compressor oil</a>  | ○     | ○    | ○    | ●     | ○     | ○     |                                     |
| <a href="#">11.4.1.4 Replacing the compressor oil filter</a>  | ○     | ○    | ○    | ●     | ○     | ○     |                                     |
| <a href="#">11.4.3 Replacing the oil separator cartridge</a>  | ○     | ○    | ○    | ●     | ○     | ○     |                                     |

1) Exhaust Gas Recirculation

2) Specialist Workshop

3) Service Partner

# 11 Maintenance

## 11.2 Following the maintenance schedule

| Assembly Task  | Daily | A250 | A500 | A1000 | A1500 | A3000 | Note                                |
|--|-------|------|------|-------|-------|-------|-------------------------------------|
| <b>11.10 Testing the safety functions:</b>   |       |      |      |       |       |       |                                     |
| <a href="#">11.10.1 Checking the EMERGENCY STOP device</a>   | ●     | ○    | ○    | ○     | ○     | ○     |                                     |
| Test EMERGENCY STOP device.  | ○     | ○    | ●    | ○     | ○     | ○     | SW <sup>2)</sup> , SP <sup>3)</sup> |
| <a href="#">2.3.4 Safety valve actuating pressure</a>  | ○     | ○    | ●    | ○     | ○     | ○     | SW <sup>2)</sup> , SP <sup>3)</sup> |
| <a href="#">11.10.3 Testing the excess temperature safety shutdown</a>   | ○     | ○    | ●    | ○     | ○     | ○     | SW <sup>2)</sup> , SP <sup>3)</sup> |
| <b>11.8 Checking the wing doors:</b>   |       |      |      |       |       |       |                                     |
| <a href="#">11.8.1 Maintaining the rubber seals</a>  | ○     | ○    | ●    | ○     | ○     | ○     |                                     |
| <a href="#">11.8.2 Checking the closing function of the wing doors</a>   | ○     | ○    | ●    | ○     | ○     | ○     |                                     |
| <a href="#">11.8.3 Checking the connection elements on the wing doors</a>  | ○     | ○    | ●    | ○     | ○     | ○     |                                     |
| <b>Bodywork</b>  |       |      |      |       |       |       |                                     |
| <a href="#">11.7 Check sound insulation material</a>   | ○     | ○    | ●    | ○     | ○     | ○     |                                     |
| Arrange for crane suspension to be checked   | ○     | ○    | ●    | ○     | ○     | ○     | SW <sup>2)</sup> , SP <sup>3)</sup> |
| <b>11.9 Checking or replacing hose lines:</b>  |       |      |      |       |       |       |                                     |
| Check all pipes and hose lines are tightly seated and without leaks or wear; replace if necessary  | ○     | ○    | ●    | ○     | ○     | ○     | SW <sup>2)</sup> , SP <sup>3)</sup> |
| <b>Other maintenance tasks:</b>  |       |      |      |       |       |       |                                     |
| Check all accessible screw connections, lines and clamps on the machine are free from wear and tightly seated, see <a href="#">11.6 Checking screw connections</a> | ○     | ○    | ●    | ○     | ○     | ○     |                                     |
| Check electrical connections for tightness.  | ○     | ○    | ●    | ○     | ○     | ○     |                                     |
| <p>●: Applicable<br/> ○: Not applicable</p>  |       |      |      |       |       |       |                                     |
| <p>1) Exhaust Gas Recirculation<br/> 2) Specialist Workshop<br/> 3) Service Partner</p>  |       |      |      |       |       |       |                                     |

**11.2.5 Options maintenance schedule**

Carry out maintenance tasks on time, in accordance with the maintenance schedule.

| Option designation<br>Task   | Daily | A250 | A500 | A1000 | A1500 | A20000 | Note                                   |
|--|-------|------|------|-------|-------|--------|--|
| <b><u>11.11.1 da Servicing the compressed air aftercooler:</u></b>       |       |      |      |       |       |        |  |
| Clean compressed air aftercooler   | ○     | ●    | ○    | ○     | ○     | ○      |  |
| <b><u>11.11.2 da Servicing the dirt trap on the water separator:</u></b> |       |      |      |       |       |        |  |
| Clean dirt trap  | ○     | ○    | ●    | ○     | ○     | ○      |  |
| <b><u>11.11.3 dd Servicing the filter combination:</u></b>               |       |      |      |       |       |        |  |
| Blow out condensate  | ●     | ○    | ○    | ○     | ○     | ○      |  |
| Replace filter elements  | ○     | ○    | ●    | ○     | ○     | ○      |  |
| Replace filter element seal  | ○     | ○    | ●    | ○     | ○     | ○      |  |
| <b><u>11.11.4 ea ec Maintaining the tool lubricator:</u></b>             |       |      |      |       |       |        |  |
| Check supply vessel fill level   | ●     | ○    | ○    | ○     | ○     | ○      |  |
| <b><u>11.11.5 ga Servicing the generator:</u></b>                        |       |      |      |       |       |        |  |
| Check drive belt   | ○     | ○    | ●    | ○     | ○     | ○      |  |
| Arrange for generator and generator control box to be checked            | ○     | ○    | ●    | ○     | ○     | ○      |  |
| Replace drive belt   | ○     | ○    | ○    | ●     | ○     | ○      |  |
| Arrange for generator bearings to be checked                             | ○     | ○    | ●    | ○     | ○     | ○      | SW <sup>1)</sup> ,<br>SP <sup>2)</sup> |
| Arrange for generator bearings to be replaced                            | ○     | ○    | ○    | ○     | ○     | ●      | SW <sup>1)</sup> ,<br>SP <sup>2)</sup> |
| <b><u>11.11.6 la Servicing the spark arrester:</u></b>                   |       |      |      |       |       |        |  |
| Blow out soot  |       |      |      |       |       |        |  |
| <b><u>11.11.7 lb Maintaining the engine air shut-off valve:</u></b>      |       |      |      |       |       |        |  |
| Clean and check engine air shut-off valve.                               | ○     | ○    | ●    | ○     | ○     | ○      | SW <sup>1)</sup> ,<br>SP <sup>2)</sup> |
| <b><u>11.11.8 oe Servicing the closed floor pan:</u></b>                 |       |      |      |       |       |        |  |
| Check machine interior for liquid accumulation.                          | ●     | ○    | ○    | ○     | ○     | ○      |  |

●: Applicable  
○: Not applicable

1) Specialist Workshop

2) Service Partner

## 11.3 Servicing the drive engine

Carry out maintenance in accordance with chapter [11.2 Following the maintenance schedule](#).

### 11.3.1 Checking the coolant



#### **WARNING**

##### **Danger of scalding from hot coolant**

- ▶ Stop the machine and allow it to cool down.
- ▶ Open the cover cap on the coolant expansion tank slowly.



#### **CAUTION**

##### **Danger of chemical burns from coolants containing antifreeze**

- ▶ Wear eye protection.
- ▶ Wear protective gloves.

#### **NOTICE**

##### **Damage caused by drive engine overheating**

- ▶ Check the coolant level on a daily basis.



1. Compressed air consumers are disconnected
2. Compressed air discharge valves on the compressed air outlet are open
3. The machine has been fully vented
4. The pressure gauge reads 0bar

- ▶ Switch off the «Controller ON/OFF» switch.

#### 11.3.1.1 Checking the coolant level

You can view the fill level in the transparent coolant expansion tank.




Fig. 40 Checking the coolant level

- |   |                        |   |           |
|---|------------------------|---|-----------|
| 1 | Minimum coolant level  | 4 | Cover cap |
| 2 | Maximum coolant level  | 5 | Overflow  |
| 3 | Coolant expansion tank |   |           |

- ▶ Perform a visual check of the coolant level every day.

**11.3.1.2 Checking the coolant quality**

In order to ensure the quality and service life of the coolant, check the coolant in accordance with the maintenance schedule.

The following parameters determine the quality of the coolant:

- Visual check
  - Antifreeze concentration measurement
1. Loosen the cover cap from the filler port.
  2. Remove the cover cap.

**Visually checking the coolant quality**

Proceed as follows:

1. Extract a coolant sample from the coolant expansion tank.
2. Check the coolant sample for discolouration.
3. Check the coolant sample for loose, floating particles.

**Checking the antifreeze content**


The coolant is a mixture of clean, fresh water with special additives.

These consist of corrosion protection/antifreeze and other additives.

A minimum antifreeze percentage of 33 % guarantees sufficient corrosion protection inside the cooling circuit.

Check the antifreeze content of the coolant using a suitable coolant testing device.

For example, a refractometer is a suitable coolant testing device.

Read and observe the manufacturer's test instructions.

To test the antifreeze content of the coolant, proceed as follows:

1. Extract a coolant sample from the coolant expansion tank.
2. Use the refractometer in accordance with the manufacturer's test instructions.
3. Check the antifreeze content of the coolant using the refractometer.
4. Change the coolant if the test value is below the minimum level.

**11.3.1.3 Correctly mixing the coolant**

The mixing ratio determines the degree of frost protection.

| Designation                  | Frost protection up to approx. [°C] | Medium                          | Proportion [%] |
|------------------------------|-------------------------------------|---------------------------------|----------------|
| Recommended frost protection | -37                                 | Anti-corrosion agent/antifreeze | 50             |
|                              |                                     | Water                           | 50             |
| Max. frost protection        | -45                                 | Anti-corrosion agent/antifreeze | 55             |
|                              |                                     | Water                           | 45             |

Tab. 78 Coolant mixing ratio

An adhesive label with the machine manufacturer's recommended mixing ratio is positioned in the immediate vicinity of the coolant expansion tank.

To mix the coolant correctly, proceed as follows:




Fig. 41 Machine manufacturer recommended mixing ratio

- ① Anti-corrosion agent/antifreeze
- ② Proportion of water

1. Take note of the mixing ratio.
2. Mix the coolant correctly.

### 11.3.1.4 Replenishing the coolant

The coolant expands as it heats up.

Ensure sufficient expansion space so that the coolant does not overflow.

To replenish the coolant, proceed as follows:

1. Loosen and remove the coolant expansion tank cover cap.
2. Fill with fresh coolant up to the *max. fill level* mark.
3. Replace the cover cap.

### 11.3.1.5 Changing the coolant

The coolant cooler is equipped with a hose coupling for user-friendly coolant drainage.

The hose coupling is located on the right-hand side of the coolant cooler.

The maintenance opening in the floor pan is located directly beneath the hose coupling.

For user-friendly drainage of the coolant, proceed as follows:




Fig. 42 Draining the coolant via the hose coupling

- ① Coolant cooler
- ② Hose coupling
- ③ Male hose coupling

1. Place a receptacle beneath the maintenance opening.
2. Loosen and remove the cover cap on the coolant expansion tank.
3. Suspend and fasten the free end of the male hose coupling in the receptacle.
4. Loosen and remove the protective cap from the hose coupling.
5. Attach the male hose coupling to the hose coupling.
  - ✓ The hose coupling is open.  
The coolant drains completely.
6. Remove the male hose coupling from the hose coupling.
  - ✓ The hose coupling is closed.
7. Refit the protective cap on the hose coupling.
8. Correctly fill with fresh coolant.
9. Close the cover cap on the coolant expansion tank.



Dispose of used coolant in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

### **11.3.1.6 Removing residue from the coolant cooler**

Following extended periods of machine use, scaling may form inside the coolant cooler.

Residue inside the coolant cooler impairs heat dissipation. It is possible that the drive engine may overheat.

#### **NOTICE**

##### **Damage caused by drive engine overheating**

- ▶ Remove calcification from the coolant cooler.

To remove calcification from inside the coolant cooler, proceed as follows:

1. Drain the coolant.
2. Read and adhere to the manufacturer's instructions regarding the use of cooler cleaning agent.
3. Use a cooler cleaning agent to remove calcification from the coolant cooler.

### **11.3.2 Engine air filter maintenance**

Operating the drive engine without filter elements fitted is not permitted.

Replace the filter element after the following occurrences:

- The maintenance indicator is actuated.
- The maintenance interval has expired in the maintenance schedule.
- A maintenance message is indicated on the SIGMA CONTROL SMART display

#### **NOTICE**

##### **Damage caused by destroyed filter element**

Drive engine wear from contaminated intake air.

- ▶ Do not try to clean the filter element by striking or tapping it.
- ▶ Do not wash the filter element.



1. The machine is stopped
2. Compressed air consumers are disconnected
3. Compressed air discharge valves on the compressed air outlet are open
4. The machine has been fully vented

5. Pressure gauge reads 0 bar

1. Switch off the «Controller ON/OFF» switch.
2. Set the «battery isolation switch» to position 0.

### 11.3.2.1 Checking the engine air filter maintenance indicator

Carry out maintenance on the engine air filter as soon as the yellow maintenance indicator piston reaches the red zone of the indicator scale.




Fig. 43 Checking the maintenance indicator in the intake air line for the engine air filter

- |                           |                               |
|---------------------------|-------------------------------|
| 1 Maintenance indicator   | 3 Red zone of indicator scale |
| 2 Yellow indicator piston | 4 Reset knob                  |

► Check the position of the yellow indicator piston.

### 11.3.2.2 Cleaning the dust evacuator valve

Coarse dirt particles in the intake air fall to the base of the filter housing and are deposited in the area around the dust evacuator valve.

To clean the dust evacuator valve, proceed as follows:




Fig. 44 Cleaning the dust evacuator valve

- |                        |                         |
|------------------------|-------------------------|
| 1 Filter cap           | 4 Valve area            |
| 2 Dust evacuator valve | 5 Cleaning procedure    |
| 3 Sealing lips         | 6 Coarse dirt particles |

1. Squeeze the valve area to remove coarse dirt particles.
2. Clean both sealing lips.

3. Check that the two sealing lips remain in contact.

### 11.3.2.3 Removing the filter cap




Fig. 45 Removing the filter cap

- 1 Filter housing
- 2 Retaining clamp
- 3 Filter cap

1. Unlock all three retaining clips 2.
2. Remove the filter cap 3.

### 11.3.2.4 Replacing the filter elements

The engine air filter is fitted with a primary filter element and a secondary filter element.

Replace the secondary filter element at every third change of the primary filter element, or after two years at the latest. The secondary filter element cannot be cleaned and reused.




Fig. 46 Replacing the filter elements

- 1 Filter cap
- 2 Primary filter element
- 3 Secondary filter element

1. Remove both used filter elements.
2. Clean the filter housing, filter cap and sealing surfaces with a damp cloth.
3. Insert a new secondary filter element into the filter housing.
4. Insert a new primary filter element into the filter housing.



Dispose of used filter elements and filter dust in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

### 11.3.2.5 Fitting the engine air filter cap

Align the filter cap so that the dust evacuator valve is pointing vertically downwards.

A deflection of  $\pm 30^\circ$  to the vertical axis is permitted.

1. Align the filter cap and position in front of the filter housing.
2. Place the filter cap on the filter housing and press down lightly.
3. Secure the filter cap with all three retaining clamps.

### 11.3.2.6 Resetting the engine air filter maintenance indicator

- ▶ Press the reset button for the maintenance indicator repeatedly.
  - ✓ The maintenance indicator is ready for operation.

### 11.3.2.7 Cleaning the primary filter element in the engine air filter



Always use new filter elements if possible.

Reuse cleaned primary filter elements only in exceptional cases.

To clean the primary filter element, proceed as follows:




Fig. 47 Cleaning the primary filter element

- |   |                          |
|---|--------------------------|
| 1 Cleaning the primary filter element   | 4 Primary filter element |
| 2 Checking the primary filter element   | 5 Torch                  |
| 3 Compressed air gun with blow-out pipe |                          |

1. Use dry compressed air 5 bar to blow out dirt from the primary filter element at an angle, from the inside to the outside.
2. Blow out the primary filter element until no more dust appears.
3. In a darkened room, use a suitable torch to shine a light through the cleaned primary filter element.
  - ✓ The cleaned primary filter element displays no cracks or holes.
  - The cleaned primary filter element is in the correct condition.
4. Insert the cleaned and checked primary filter element into the filter housing.

### 11.3.3 Servicing the fuel system

Loosen old filter cartridges with a filter key or strap.

Fit new filter cartridges using manual force. Use a filter key if you cannot bring sufficient manual force due to an unfavourable installation position. Observe any additional installation information from the filter cartridge manufacturer.



#### **! WARNING**

##### **Danger of burns from fuel igniting**

- ▶ Stop the drive engine and allow it to cool down.
- ▶ Keep fuel away from hot machine components.
- ▶ Wipe up spilled fuel immediately.
- ▶ Do not smoke.

#### **NOTICE**

##### **Damage to property caused by dirt particles**

Unclean surroundings and dirt particles can damage the fuel system.

- ▶ Clean removed parts and the working environment before disassembling.




Fig. 48 Fuel system overview

- |                  |                 |
|------------------|-----------------|
| 1 Fuel prefilter | 4 Fuel filter   |
| 2 Drain plug     | 5 Fuel strainer |
| 3 Fuel pump      | 6 Fuel tank     |



- Filter key
- Strap
- Receptacle
- Cleaning cloth



- Fuel prefilter cartridge
- Fuel filter cartridge



1. Compressed air consumers are disconnected
2. Compressed air discharge valves on the compressed air outlet are open
3. The machine has been fully vented
4. The pressure gauge reads 0bar

► Switch off the «Controller ON/OFF» switch.

### 11.3.3.1 Cleaning the tank strainer

1. Open the fuel tank cover cap.
2. Pull out the tank strainer and clean it.
3. Insert a suitable tank strainer into the filler port.
4. Close the fuel tank with the cover cap.

### 11.3.3.2 Emptying the fuel-water separator

The fuel-water separator is an integral part of the fuel prefilter cartridge. Water and contaminants are trapped by the water collector in the filter cartridge.

The water separator is connected to the controller via a level sensor. Should the water level rise above a certain value, a warning message is triggered.

The SIGMA CONTROL SMART display indicates the warning message *Fuel filter water level*.

Empty the water separator when the SIGMA CONTROL SMART displays this warning message.




Fig. 49 Emptying the fuel-water separator

- |  |                           |
|--|---------------------------|
| ① Removing the level sensor connector plug | ⑤ Drain plug              |
| ② Opening the drain plug                   | ⑥ Receptacle              |
| ③ Fuel prefilter cartridge                 | ⑦ "Open" direction arrow  |
| ④ Level sensor connector plug              | ⑧ "Close" direction arrow |

1. Remove the level sensor connector plug.
2. Open the drain plug:
  - a) Turn the drain plug a maximum of two rotations in the direction of arrow ⑦.
  - b) Allow the water and any contaminants to drain away.

3. Close the drain plug:
  - a) Turn the drain plug in the direction of arrow 8.
  - b) Clean the drain plug.
4. Insert the level sensor connector plug.
5. Acknowledge the *Fuel filter water level* warning message with the «Enter» key.



Dispose of water and contaminated fuel in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

### 11.3.3.3 Replace fuel prefilter




Fig. 50 Replacing the fuel prefilter cartridge

- 1 Fuel prefilter
- 2 Hose clamps
- 3 Fuel line

1. Remove the fuel prefilter 1 from the bracket.
2. Position a receptacle under the fuel prefilter.
3. Loosen the hose clamps 2.
4. Pull out the fuel lines 3 and secure against leakage.
5. Remove the old fuel prefilter
6. Insert a new filter into the fuel lines, taking the direction of flow into account.
7. Affix the fuel prefilter to the bracket.
8. Tighten the hose clamps.

9. Vent the fuel system as described.



Dispose of old fuel prefilters, collected fuel, and contaminated working materials in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

### 11.3.3.4 Replacing the fuel filter cartridge




Fig. 51 Replacing the fuel filter cartridge

- |                                  |                                    |
|----------------------------------|------------------------------------|
| ① Removing the filter cartridge  | ④ Filter cartridge                 |
| ② Inserting the filter cartridge | ⑤ Loosening in direction of arrow  |
| ③ Filter holder                  | ⑥ Tightening in direction of arrow |

1. Position a receptacle.
2. Remove the old filter cartridge:
  - a) Turn the filter cartridge in the direction of the arrow ⑤.
  - b) Remove the filter cartridge.
  - c) Catch escaping fuel in the receptacle.
3. Clean the sealing surface of the filter holder.
4. Moisten the seal on the new filter cartridge with engine oil.
5. Insert the new filter cartridge:
  - a) Hold the new filter cartridge underneath the filter holder.
  - b) Turn the new filter cartridge in the direction of the arrow ⑥ until the seal is touching it.
  - c) Hand-tighten the new filter cartridge.



Dispose of old fuel filter cartridges, collected fuel, and contaminated working materials in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

### 11.3.3.5 Venting the fuel system

Air enters the fuel system during the following maintenance tasks:

- Replacing the fuel prefilter cartridge

- Replacing the fuel filter cartridge
- Replacing the fuel pump
- Work on the fuel lines



When the controller voltage is switched on, the electric fuel pump starts and vents the fuel system.

- ▶ Perform a test run, see [Tab. 73 Performing a test run](#).

### 11.3.4 Servicing the engine oil circuit

- ▶ Always carry out maintenance tasks in clean surroundings.

#### 11.3.4.1 Checking the engine oil level

Check the engine oil level using the dipstick on the drive engine.



#### ⚠ CAUTION

##### Danger of burning from hot surfaces

- ▶ Stop the machine and allow it to cool down.
- ▶ Wear personal protective equipment.

#### NOTICE

##### Damage to the drive engine from insufficient oil level

- ▶ Check the engine oil level correctly.
- ▶ Only check the engine oil level when the machine is standing level.




Fig. 52 Checking the engine oil level

- |                          |                           |
|--------------------------|---------------------------|
| ① Dipstick               | ③ Minimum oil level mark  |
| ② Maximum oil level mark | ④ Correct oil level range |



- The machine is standing level
- The drive engine has cooled down for 5 Minutes



1. Compressed air consumers are disconnected
2. Compressed air discharge valves on the compressed air outlet are open
3. The machine has been fully vented
4. The pressure gauge reads 0bar

1. Switch off the «Controller ON/OFF» switch.
2. Pull out the dipstick.
3. Wipe the dipstick with a cleaning cloth.
4. Push the dipstick back in.
5. Pull the dipstick out again.
6. Read off the actual oil level from the dipstick.
7. Take appropriate measures, see chapter [11.3.4.2 Filling with and replenishing the engine oil](#).

**11.3.4.2 Filling with and replenishing the engine oil**

**CAUTION**
**Danger of burning from hot surfaces**

- ▶ Stop the machine and allow it to cool down.
- ▶ Wear personal protective equipment.




Fig. 53 Filling with engine oil

- ① Oil filler cap
- ② Oil filler opening



- Fresh engine oil
- Cleaning cloth

1. Switch off the «Controller ON/OFF» switch.
2. Loosen and remove the oil filler cap.
3. Fill with a suitable quantity of fresh engine oil.
4. Wait for at approx. five minutes.
5. Check the engine oil level correctly.
6. Replace the cap on the oil filler opening.
7. Perform a test run, see [Tab. 73 Performing a test run](#).

**11.3.4.3 Changing the engine oil**

The following components ensure user-friendly drainage of the engine oil:

- Hose coupling on drive engine oil pan
- Male hose coupling

The male hose coupling is supplied loose inside the machine.


**CAUTION**
**Danger of burns from hot surfaces and escaping engine oil**

- ▶ Stop the machine and allow it to cool down.
- ▶ Wear personal protective equipment.

To change the engine oil, proceed as follows:




Fig. 54 Draining the engine oil

- |   |                |   |                    |
|---|----------------|---|--------------------|
| 1 | Oil filler cap | 3 | Hose coupling      |
| 2 | Oil pan        | 4 | Male hose coupling |



- Fresh engine oil
- Cleaning cloth



- The machine is standing level
- The drive engine is at operating temperature



1. Compressed air consumers are disconnected
2. Compressed air discharge valves on the compressed air outlet are open
3. The machine has been fully vented
4. The pressure gauge reads 0 bar

1. Switch off the «Controller ON/OFF» switch.
2. Loosen and remove the oil filler cap.
3. Suspend and fasten the free end of the male hose coupling in the receptacle.
4. Loosen and remove the protective cap from the hose coupling.
5. Attach the male hose coupling to the hose coupling.
6. Allow the engine oil to drain out completely.
7. Loosen and remove the male hose coupling.
8. Close the hose coupling with the protective cap.
9. Fill with new engine oil, see chapter [11.3.4.2 Filling with and replenishing the engine oil](#).



Dispose of used engine oil and contaminated working materials in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

### 11.3.4.4 Replacing the engine oil filter

Loosen the old engine oil filter with a filter key or strap.

Fit the new engine oil filter using manual force. Use a filter key if you cannot bring sufficient manual force due to an unfavourable installation position. Observe any additional installation information from the engine oil filter manufacturer.

Replace the engine oil filter after the following occurrences:

- A maintenance message with a specific message code is indicated on the SIGMA CONTROL SMART display.

- The interval has expired in the maintenance schedule.



**CAUTION**

**Danger of burns from hot surfaces and escaping engine oil**

- ▶ Stop the machine and allow it to cool down.
- ▶ Wear personal protective equipment.




Fig. 55 Replacing the engine oil filter

- |                          |                         |
|--------------------------|-------------------------|
| ① Filter key             | ④ Sealing surface       |
| ② Direction of arrow     | ⑤ Seal                  |
| ③ Used engine oil filter | ⑥ New engine oil filter |



- Filter key
- Strap



- Engine oil filter



- The machine is standing level
- The drive engine is at operating temperature
- The old engine oil is past the expiry date, see chapter [11.3.4.3 Changing the engine oil](#)
- The hose coupling on the oil pan is closed



1. Compressed air consumers are disconnected
2. Compressed air discharge valves on the compressed air outlet are open
3. The machine has been fully vented
4. The pressure gauge reads 0 bar

1. Switch off the «Controller ON/OFF» switch.
2. Remove the engine oil filter:
  - a) Attach the filter key.
  - b) Turn the engine oil filter in the direction of the arrow and remove.
  - c) Clean the sealing surface on the drive engine.
3. Fit the new engine oil filter:
  - a) Lightly oil the seal on the new engine oil filter.
  - b) Position the new engine oil filter before the sealing surface.
  - c) Turn the new engine oil filter clockwise until the seal touches the sealing surface.
  - d) Hand-tighten the new engine oil filter clockwise.
4. Fill with new engine oil, see chapter [11.3.4.2 Filling with and replenishing the engine oil](#).
5. Perform a test run, see [Tab. 73 Performing a test run](#).



Dispose of collected engine oil, old engine oil filters, and contaminated working materials in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

### 11.3.4.5 Maintaining the crankcase oil separator



The oil separator for the crankcase is made of plastic.

Adhere to the defined tightening torque of 4 Nm for the four fixing screws.



#### **CAUTION**

##### **Danger of burning from hot surfaces**

- ▶ Stop the machine and allow it to cool down.
- ▶ Wear personal protective equipment.




Fig. 56 Replacing the oil separating element

- |                           |                               |
|---------------------------|-------------------------------|
| 1 Drive engine            | 5 Fixing screw                |
| 2 Crankcase oil separator | 6 Used oil separating element |
| 3 Housing, upper section  | 7 New oil separating element  |
| 4 Housing, lower section  |                               |



1. Compressed air consumers are disconnected
2. Compressed air discharge valves on the compressed air outlet are open
3. The machine has been fully vented
4. The pressure gauge reads 0 bar

1. Switch off the «Controller ON/OFF» switch.
2. Remove the upper section of the housing:
  - a) Loosen and remove all four fixing screws.
  - b) Detach and remove the venting hose.
  - c) Lift off the upper section of the housing.
  - d) Remove the used oil separating element.
3. Properly clean both housing sections of the oil separator:
  - a) Remove any oil or grease residue from the lower section of the housing.
  - b) Remove any oil or grease residue from the upper section of the housing.
4. Insert a new oil separating element into the lower section of the housing.
5. Reinstall the oil separator:
  - a) Place the upper section of the housing on top of the lower section.
  - b) Attach the venting hose.
  - c) Place all four fixing screws in position.
  - d) Tighten all four fixing screws with the defined tightening torque.

6. Perform a test run, see [Tab. 73 Performing a test run](#)



Dispose of old oil separating elements and contaminated working materials in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

### 11.3.5 Servicing the drive belt



#### **WARNING**

**Danger of shearing and crushing from contact with rotating components**

- ▶ Stop the machine.
- ▶ Secure the machine against being restarted.
- ▶ Only remove safety guards and cover panels after securing the machine against being restarted.



#### **CAUTION**

**Danger of burning from hot surfaces**

- ▶ Stop the machine and allow it to cool down.
- ▶ Wear personal protective equipment.

#### **NOTICE**

**Danger of irreparable damage to the retainers**

- ▶ Only loosen the fixing screws.
- ▶ Do not remove the fixing screws from the belt guard grille.



1. Compressed air consumers are disconnected
2. Compressed air discharge valves on the compressed air outlet are open
3. The machine has been fully vented
4. The pressure gauge reads 0 bar

- ▶ Switch off the «Controller ON/OFF» switch.

#### 11.3.5.1 Removing the belt guard grille

Each screw connection is fitted with a clamping ring which functions as a retainer.




Fig. 57 Detaching the belt guard grille

- |                       |                   |
|-----------------------|-------------------|
| 1 Belt guard          | 5 Screw           |
| 2 Drive belt          | 6 Distance sleeve |
| 3 Belt guard grille   | 7 Washer          |
| 4 Screw with retainer | 8 Clamping ring   |

► Loosen all screws on the belt guard grille.

### 11.3.5.2 Performing a visual inspection

The drive belt on your machine is of the V-ribbed belt type.




Fig. 58 Damage to the V-ribbed belt

- |                                 |                                     |
|---------------------------------|-------------------------------------|
| 1 Damage                        | 6 Fraying at flanks                 |
| 2 Proper seating                | 7 Transverse tears to multiple ribs |
| 3 Rear side                     | 8 Broken ribs                       |
| 4 Ribbed side                   | 9 Belt pulley                       |
| 5 Transverse tears on rear side | 10 V-ribbed belt                    |

1. Inspect the full length of the V-ribbed belt for damage.
2. Check the V-ribbed belt for proper seating.

### 11.3.5.3 Checking the belt tension

Always allow the drive belt to warm up before checking the belt tension.



- Manufacturer-recommended belt tension measuring device




Fig. 59 Checking the belt tension

- |   |   |
|---|---|
| ① Drive belt                              | ⑤ Measuring point                                 |
| ② Belt tension measuring device           | ⑥ <i>New belt</i> indicator                       |
| ③ Three-phase alternator belt pulley      | ⑦ <i>Following maintenance interval</i> indicator |
| ④ Belt tension measuring device indicator | ⑧ <i>Minimum tension</i> indicator                |

► Check the belt tension using the belt tension measuring device.

#### 11.3.5.4 Tensioning the drive belt

The belt tension affects the service life of the drive belt.

Insufficient belt tension will cause the belt to slip and the drive engine to overheat. Too much belt tension will cause excessive stretching and high stress on the shaft bearings.




Fig. 60 Tensioning the drive belt

- |                  |                          |
|------------------|--------------------------|
| ① V-ribbed belt  | ④ Three-phase alternator |
| ② Clamping screw | ⑤ Direction of arrow     |
| ③ Fixing screw   | ⑥ Direction of arrow     |

1. Loosen the clamping screw and fixing screw on the three-phase alternator.
2. Push the three-phase alternator in the direction of the arrow ⑤ until the drive belt is sufficiently tensioned:
  - a) Leave the three-phase alternator in this position.
  - b) Tighten the clamping screw and fixing screw.
3. Check the belt tension.

11.3.5.5 Replace drive belt




Fig. 61 Replace drive belt

- |                            |                          |
|----------------------------|--------------------------|
| ① Removing the cover plate | ⑥ Clamping screw         |
| ② Replacing the drive belt | ⑦ Three-phase alternator |
| ③ Cooler shroud            | ⑧ Fixing screw           |
| ④ Cover plate              | ⑨ Antriebsriemen         |
| ⑤ Screw with retainer      |                          |



- Drive belt: V-belt

1. Remove the cover plate from the cooling shroud.
2. Remove the old drive belt:
  - a) Loosen the fixing screw and clamping screw on the three-phase alternator.
  - b) Push the three-phase alternator in the direction of the arrow until the limit stop.
  - c) Remove the loosened drive belt from the belt pulley.
  - d) Lift the drive belt over one blade of the fan wheel.
  - e) Turn the fan wheel further in an anticlockwise direction.
  - f) Lift the drive belt over all of the fan wheel blades by continuing to turn it in this fashion.
  - g) Remove the old drive belt.
3. Check the belt pulleys:
  - a) Clean the pulleys if they are dirty.
  - b) Arrange replacement of worn pulleys.
4. Installing a new drive belt:
  - a) Lift the new drive belt over one wing of the fan wheel.
  - b) Turn the fan wheel further in a clockwise direction.
  - c) Lift the drive belt over all of the fan wheel blades by continuing to turn it in this fashion.
  - d) Position the new drive belt over the pulleys by hand, without using force.
  - e) Check correct seating on the belt pulleys.
  - f) Tension the drive belt.
5. Perform a test run, see chapter [Tab. 73 Performing a test run](#).



Dispose of old drive belts in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

### 11.3.6 Servicing the exhaust gas after-treatment

Components in the exhaust gas after-treatment reach extremely high temperatures during machine operation. To protect against contact with extremely hot surfaces, a number of heat shields are fitted around the exhaust gas after-treatment.



#### **CAUTION**

##### **Danger of burns from hot surfaces**

- ▶ Stop the machine and allow it to cool down.
- ▶ In particular, allow all components in the exhaust gas after-treatment system to cool down.
- ▶ Wear personal protective equipment.

#### **NOTICE**

##### **Irreparable damage to the retainers**

- ▶ Do not remove the fixing screws from the heat shield.



1. Compressed air consumers are disconnected
2. Compressed air discharge valves on the compressed air outlet are open
3. The machine has been fully vented
4. The pressure gauge reads 0 bar

- ▶ Switch off the «Controller ON/OFF» switch.

#### 11.3.6.1 Removing the heat shield

Each fixing screw is fitted with a clamping ring, which functions as a retainer.




Fig. 62 Removing the heat shield

- |   |                   |
|---|-------------------|
| 1 Exhaust gas after-treatment                             | 6 Screw           |
| 2 Heat shield, diesel particulate filter exhaust manifold | 7 Distance sleeve |
| 3 Heat shield, exhaust gas pipe                           | 8 Washer          |
| 4 Heat shield, diesel particulate filter                  | 9 Clamping ring   |
| 5 Screw with retainer                                     |                   |

- ▶ If necessary, remove all heat shields so as to be able to conduct the following checks correctly.

## 11.3.6.2 Checking the diesel particulate filter housing




Fig. 63 Checking the diesel particulate filter housing

- |                                     |                      |
|-------------------------------------|----------------------|
| 1 Diesel particulate filter housing | 4 Stepped band clamp |
| 2 Flange connection                 | 5 Pipe clamp         |
| 3 Exhaust gas pipe                  | 6 Screw connection   |

1. Check that the diesel particulate filter housing is securely seated and free from damage.
2. Check the flange connection:
  - a) Check the flange connection between the exhaust manifold and the diesel particulate filter.
  - b) Retighten the screw connection if required.
3. Checking the fixing elements:
  - a) Check all pipe clamps are tightly fitted; tighten if necessary.
  - b) Check that all stepped band clamps are securely seated; retighten if required.
4. Check that the exhaust manifold insulation is securely seated and free from damage.
5. Correctly install all heat shields.

### 11.3.7 Servicing the battery



#### **WARNING**

**Danger of chemical burns from leaking electrolyte!**

- ▶ Wear face and eye protection.
  - ▶ Wear protective clothing, including acid-proof gloves.
  - ▶ Do not tip the battery.
- ▶ Work with caution.

#### 11.3.7.1 Observing the safety signs on the battery




Fig. 64 Safety signs on the battery

| No. | Meaning   | Measure   |
|-----|---|---|
| ①   | Fire, sparks, open flame and smoking prohibited               | Comply with the prohibition   |
| ②   | Danger of chemical burns from electrolyte                     | Wear safety glasses and face protection                                 |
| ③   | Remove children from the electricity and chemical danger area | Keep children away from batteries                                       |
| ④   | Batteries contain caustic electrolyte                         | Wear protective gloves  |
| ⑤   | Follow the instructions of the battery manufacturer           | Comply with the instructions  |
| ⑥   | Explosion hazard  | Ensure sufficient ventilation before initiating the charging procedure. |

Tab. 79 Safety signs and their meanings

- ▶ Follow the measures for handling batteries.

#### 11.3.7.2 Properly ensuring the battery charge level

The battery may self-discharge if the machine has been out of operation for an extended period. There may be insufficient power to start the drive engine when required.



**⚠ DANGER**

**Danger of explosion due to oxyhydrogen gas mixture**

Hydrogen and oxygen gas are produced during charging.

- ▶ Clean all degassing openings.
- ▶ Ensure sufficient ventilation during charging.

| Charge level [%] | Charge level [V] | Electrolyte density [kg/l] | Note                                  |
|------------------|------------------|----------------------------|---------------------------------------|
| 100              | 12.7 – 12.85     | 1,27                       | Battery properly charged              |
| 75               | 12,5             | 1,24                       | Recharge required                     |
| 65               | 12,4             | 1,22                       |                                       |
| 50               | 12,3             | 1,21                       | Starting capacity limit               |
| 25               | 12.0             | 1,16                       | Charge limit exceeded                 |
| 20               | 11,9             | 1,14                       |                                       |
| 0                | 11,6             | 1,09                       | Battery damaged due to deep discharge |

Values valid for 25 °C

Tab. 80 Battery charge levels

Check the electrolyte level before charging the battery. Only charge the battery with the correct electrolyte level.

1. Check the battery charge level.
  - ☑ The charge level is 75%.  
Battery charging required.
2. Check the battery electrolyte level.
  - ☑ The battery electrolyte level is correct.
3. Properly charge the battery:
  - a) Remove the battery.
  - b) Clean all degassing openings in the screw plugs.
  - c) Do not open the screw plugs.
  - d) Charge the battery using a suitable charger, see manufacturer user manual.

**11.3.7.3 Checking and maintaining standard batteries**

Maintain the battery on your machine, even if the battery is designated as maintenance-free. Regular maintenance prevents leakage currents and minimises self-discharge.

Check the electrolyte level on the battery in accordance with the maintenance schedule. Replenish exclusively with distilled water if the electrolyte level falls below the minimum mark on the battery housing.



- Antistatic cloth



- Terminal grease
- Distilled water

Proceed as follows:

1. Remove both terminal protector caps.

2. Remove both terminal connections:
  - a) First remove the terminal connection from the negative terminal.
  - b) Then remove the terminal connection from the positive terminal.
  - c) Clean both terminal connections.
  - d) Clean the battery housing with an antistatic cloth.
  - e) Clean both terminals.
  - f) Lightly grease both terminals with terminal grease.
  - g) Check that the battery is securely seated.
3. Check the electrolyte level:
  - a) Check that the electrolyte level is between the minimum and maximum marks.
  - b) Replenish with distilled water if required.
4. Attach both terminal connections:
  - a) First attach the terminal connection to the positive terminal.
  - b) Then attach the terminal connection to the negative terminal.
  - c) Check that both terminal connections are securely seated.
5. Fit both terminals with terminal protector caps.



For replenishing with distilled water, see [11.3.7.4 Replenishing the distilled water in lead-acid batteries](#).

### 11.3.7.4 Replenishing the distilled water in lead-acid batteries

#### NOTICE

##### Danger of irreparable damage to the battery

Replenishing with pure acid will increase the electrolyte concentration.

- ▶ Only replenish the battery with distilled water.




Fig. 65 Screw plug location on lead-acid batteries

- |                              |                |
|------------------------------|----------------|
| 1 Example: Battery top side  | 4 Minimum mark |
| 2 Battery cell screw plug    | 5 Maximum mark |
| 3 Example: Battery side view |                |



- Distilled water

Proceed as follows:

1. Clean the top side of the lead-acid battery.
2. Loosen and remove the screw plug 2 from each of the individual battery cells.

3. Clean all screw plugs.
4. Replenish each battery cell with distilled water up to the minimum mark.
5. Refit all screw plugs and tighten correctly.



The liquid level in the lead-acid battery is in the correct range.

### 11.3.7.5 Checking and maintaining GEL batteries

The machine can be optionally specified with a maintenance-free GEL battery, which also contributes to weight optimisation.

To maintain the GEL battery, proceed as follows:

- ▶ Carry out steps 1, 2 and 4 from chapter [11.3.7.3 Checking and maintaining standard batteries](#).

### 11.3.7.6 Maintaining the battery at low ambient temperatures

The battery charge level drops at low ambient temperatures and during long periods of downtime.

#### **NOTICE**

##### **Danger of battery freezing**

A discharged battery is endangered by frost and can freeze at temperatures below 0 °C.

- ▶ Check the battery charge level using an acid density tester.
  - ▶ Clean the terminal connections and apply terminal grease.
  - ▶ Charge the battery.
1. Check the battery charge level on a weekly basis.
  2. Charge the battery when the current charge level requires it.
  3. Should you plan not to operate the machine for a number of weeks, proceed as follows:
    - a) Remove the battery.
    - b) Store the battery in a frost-free room.



For checking the battery charge level, see [Tab. 80 Battery charge levels](#).

### 11.3.7.7 Installing and removing the battery



#### **WARNING**

##### **Danger of battery exploding**

A short-circuited battery heats up quickly and can burst.

- ▶ Do not short-circuit the battery.
  - ▶ Wear face and eye protection and protective gloves.
1. Removing the battery:
    - a) Remove the terminal protector cap from the negative terminal.
    - b) Remove the terminal connection from the negative terminal.
    - c) Remove the terminal protector cap from the positive terminal.
    - d) Remove the terminal connection from the positive terminal.
    - e) Remove the battery mounting.
    - f) Remove the battery levelly from the machine.

2. Installing the battery:
  - a) Position the battery levelly in the machine.
  - b) Install the battery mounting.
  - c) Check the battery for secure seating.
  - d) Attach the terminal connection to the positive terminal.
  - e) Fit the terminal protector cap to the positive terminal.
  - f) Attach the terminal connection to the negative terminal.
  - g) Fit the terminal protector cap to the negative terminal.

#### **11.3.7.8 Replacing the battery**

Proceed as follows:

1. Determine the technical data for the original battery:
  - a) Note the voltage of the old battery.
  - b) Note the capacity of the old battery.
  - c) Note the cold discharge test current of the old battery.
2. Determine the type of the original battery.
3. Correctly replace the original battery with a new one.



For technical data of the original battery, see chapter [2.4 Drive engine](#).

## 11.4 Servicing the compressor

- ▶ Carry out maintenance in accordance with chapter [11.2 Following the maintenance schedule](#).

### 11.4.1 Servicing the compressor oil circuit

- ▶ Always carry out maintenance tasks in clean surroundings.

#### 11.4.1.1 Checking the compressor oil level

The compressor oil level is correct when compressor oil is visible in the open oil filler port.



#### **CAUTION**

##### **Danger of burning from hot surfaces**

- ▶ Stop the machine and allow it to cool down.
- ▶ Wear personal protective equipment.




Fig. 66 Checking the compressor oil level correctly

- |                      |                                |
|----------------------|--------------------------------|
| 1 Oil separator tank | 4 Seal                         |
| 2 Oil filler         | 5 Maximum compressor oil level |
| 3 Screw plug         | 6 Minimum compressor oil level |



- The machine is standing level
- The compressor has cooled down for approx. 5 Minutes



1. Compressed air consumers are disconnected
2. Compressed air discharge valves on the compressed air outlet are open
3. The machine has been fully vented
4. The pressure gauge reads 0bar

1. Switch off the «Controller ON/OFF» switch.
2. Loosen and remove the screw plug.
3. Check the compressor oil level:
  - a) Check whether compressor oil is visible in the filler port.
  - b) Take appropriate measures, see chapter [11.4.1.2 Filling with or replenishing the compressor oil](#).
4. Check that the seal is in the correct condition.
5. Insert the screw plug and hand-tighten.

### 11.4.1.2 Filling with or replenishing the compressor oil

You can find a sticker on the oil separator tank specifying the type of compressor oil used.

#### NOTICE

##### Damage to the machine caused by incompatible compressor oils

- ▶ Never mix different types of compressor oil.
- ▶ Only replenish using the same type of compressor oil already used in the machine.



- Fresh compressor oil
- Cleaning cloth

1. Replenish with a suitable quantity of fresh compressor oil.
2. After approx. five minutes, correctly check the compressor oil level.
3. Check the O-ring for external damage.
4. Insert the screw plug.
5. Hand-tighten the screw plug.
6. Perform a test run, see chapter [Tab. 73 Performing a test run](#).

### 11.4.1.3 Changing the compressor oil

Change the compressor oil after the following occurrences:

- A maintenance message with a specific message code is indicated on the SIGMA CONTROL SMART display
- The interval has expired in the maintenance schedule.



#### CAUTION

##### Danger of burns from hot components and escaping compressor oil

- ▶ Stop the machine and allow it to cool down.
- ▶ Wear personal protective equipment.



- Fresh compressor oil
- Cleaning cloth



- New seal for screw plug



- The machine is standing level
- The compressor is at operating temperature



1. Compressed air consumers are disconnected
2. Compressed air discharge valves on the compressed air outlet are open
3. The machine has been fully vented
4. The pressure gauge reads 0bar

- ▶ Switch off the «Controller ON/OFF» switch.

#### Draining the compressor oil

Fully drain the compressor oil from the following components:

- Oil separator tank
- Oil cooler

- Airend
- Oil lines




Fig. 67 Draining the compressor oil

- |                              |                                       |
|------------------------------|---------------------------------------|
| 1 Oil separator tank         | 5 Hose coupling on oil separator tank |
| 2 Oil cooler                 | 6 Hose coupling on oil cooler         |
| 3 Airend                     | 7 Hose coupling on airend             |
| 4 Oil filler port screw plug | 8 Male hose coupling                  |

1. Remove the screw plug from the oil filler port on the oil separator tank.
2. Drain the compressor oil from the oil separator tank:
  - a) Loosen and remove the protective cap from the hose coupling 5.
  - b) Attach the male hose coupling to the hose coupling.
3. Drain the compressor oil from the oil cooler:
  - a) Loosen and remove the protective cap from the hose coupling 6.
  - b) Attach the male hose coupling to the hose coupling.
4. Drain the compressor oil from the airend:
  - a) Loosen and remove the protective cap from the hose coupling 7.
  - b) Attach the male hose coupling to the hose coupling.
5. For removing compressor oil filter components, see chapter [11.4.1.4 Replacing the compressor oil filter](#).
6. Close the hose couplings:
  - a) Loosen and remove the male hose coupling from the oil separator tank.
  - b) Secure the hose coupling with the protective cap.
  - c) Loosen and remove the male hose coupling from the oil cooler.
  - d) Secure the hose coupling with the protective cap.
  - e) Loosen and remove the male hose coupling from the airend.
  - f) Secure the hose coupling with the protective cap.
7. For installing compressor oil filter components, see chapter [11.4.1.4 Replacing the compressor oil filter](#).

#### 11.4.1.4 Replacing the compressor oil filter

Loosen the old compressor oil filter with a filter key or strap.

Fit the new compressor oil filter using manual force. Use a filter key if you cannot bring sufficient manual force due to an unfavourable installation position.

Observe any additional installation information from the compressor oil filter manufacturer.

Replace the compressor oil filter after the following occurrences:

- A maintenance message with a specific message code is indicated on the SIGMA CONTROL SMART display
- The interval has expired in the maintenance schedule.



**CAUTION**

**Danger of burns from hot components and escaping compressor oil**

- ▶ Stop the machine and allow it to cool down.
- ▶ Wear personal protective equipment.




Fig. 68 Replacing the compressor oil filter

- |   |                             |
|---|-----------------------------|
| 1 Removing the compressor oil filter    | 5 Direction of arrow        |
| 2 Fitting the compressor oil filter     | 6 New compressor oil filter |
| 3 Fluid distribution module, oil filter | 7 Direction of arrow        |
| 4 Old compressor oil filter             |                             |



- Compressor oil filter



- The machine is standing level
- The compressor is at operating temperature
- The old compressor oil is past the expiry date, see chapter [11.4.1.3 Changing the compressor oil](#)
- The hose couplings on the oil separator tank and oil cooler are closed
- The screw plug on the airend is closed



1. Compressed air consumers are disconnected
2. Compressed air discharge valves on the compressed air outlet are open
3. The machine has been fully vented
4. The pressure gauge reads 0 bar

1. Switch off the «Controller ON/OFF» switch.
2. Remove the old compressor oil filter:
  - a) Turn the old compressor oil filter in the direction of the arrow 5.
  - b) Detach and remove the compressor oil filter.
  - c) Clean the sealing surface.

3. Fit the new compressor oil filter:
  - a) Lightly oil the seal on the new compressor oil filter.
  - b) Position the compressor oil filter.
  - c) Turn the compressor oil filter in the direction of the arrow 7 until the seal is touching the sealing surface.
  - d) Hand-tighten the compressor oil filter.
4. Fill with fresh compressor oil.
5. Perform a test run, see [Tab. 73 Performing a test run](#).



Dispose of collected compressor oil, old compressor oil filters, and contaminated working materials in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

### 11.4.2 Dirt trap maintenance on the fluid distribution module

The fluid distribution module is located on the oil separator tank cover.

The fluid distribution module is equipped with two dirt traps:

- Dirt trap, oil return line
- Dirt trap, proportional controller

Replace the nozzle and strainer on both dirt traps as soon as signs of wear are visible.

Take note of the specific tightening torque for the screw plug.



#### **CAUTION**

**Danger of burning from hot surfaces**

- ▶ Stop the machine and allow it to cool down.
- ▶ Wear personal protective equipment.




Fig. 69 Servicing the dirt traps on the fluid distribution module

- A** Dirt trap, oil return line  
**B** Dirt trap, proportional controller
- |   |                           |    |              |
|---|---------------------------|----|--------------|
| 1 | Fluid distribution module | 7  | Strainer     |
| 2 | Oil separator tank cover  | 8  | Sealing ring |
| 3 | Oil return line           | 9  | Screw plug   |
| 4 | Clamping nut              | 10 | O-ring       |
| 5 | Nozzle                    | 11 | Strainer     |
| 6 | Screw-in connector        |    |              |



- Benzine
- Spirit



- KIT Oil return line dirt trap
- KIT Proportional controller dirt trap



1. Compressed air consumers are disconnected
2. Compressed air discharge valves on the compressed air outlet are open
3. The machine has been fully vented
4. The pressure gauge reads 0 bar

1. Switch off the «Controller ON/OFF» switch.
2. Service the dirt trap on the oil return line **A**:
  - a) Remove the clamping nut **4** and nozzle **5**.
  - b) Remove the screw-in connector **6** and strainer **7**.
  - c) Clean all components with benzine or spirit.
  - d) Check the nozzle and strainer for wear.
  - e) Correctly position the nozzle and strainer.
  - f) Install the screw-in connector, ensuring that the sealing ring **8** sits in the correct position.
  - g) Fit the clamping nut on the oil return line **3**.
3. Service the dirt trap on the proportional controller **B**:
  - a) Remove the screw plug **9**.
  - b) Clean the screw plug, strainer **11** and O-ring **10** with benzine or spirit.
  - c) Check the strainer and O-ring for wear.
  - d) Position the O-Ring and strainer.
  - e) Insert the screw plug.
  - f) Tighten the screw plug with the specific tightening torque of 15–20 Nm.
4. Perform a test run, see [Tab. 73 Performing a test run](#).



Dispose of wearing parts in the dirt trap in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

### 11.4.3 Replacing the oil separator cartridge

Loosen the old oil separator cartridge with a filter key or strap.

Insert the new oil separator cartridge using manual force.

Observe any additional installation information from the oil separator cartridge manufacturer.



#### **CAUTION**

##### **Danger of burning from hot surfaces**

- ▶ Stop the machine and allow it to cool down.
- ▶ Wear personal protective equipment.




Fig. 70 Replacing the oil separator cartridge

- |   |                               |
|---|-------------------------------|
| ① Removing the oil separator cartridge  | ⑤ Fluid distribution module   |
| ② Inserting the oil separator cartridge | ⑥ Oil separator tank          |
| ③ Direction of rotation                 | ⑦ New oil separator cartridge |
| ④ Old oil separator cartridge           | ⑧ Direction of rotation       |



- Oil separator cartridge



1. Compressed air consumers are disconnected
2. Compressed air discharge valves on the compressed air outlet are open
3. The machine has been fully vented
4. The pressure gauge reads 0bar

1. Switch off the «Controller ON/OFF» switch.
2. Remove the old oil separator cartridge:
  - a) Turn the oil separator cartridge in the direction of the arrow ④.
  - b) Remove the oil separator cartridge when the filter thread has no further contact.
  - c) Clean the thread and sealing surface.
3. Lightly oil the seal on the new oil separator cartridge.
4. Insert the new oil separator cartridge:
  - a) Position the oil separator cartridge until the filter thread has contact.
  - b) Turn the oil separator cartridge in the direction of the arrow ⑧ until the seal is touching the sealing surface.
  - c) Hand-tighten the oil separator cartridge.
5. Check the compressor oil level.
6. Perform a test run, see [Tab. 73 Performing a test run.](#)



Dispose of collected compressor oil, old oil separator cartridges, and contaminated working materials in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

### 11.4.4 Servicing the compressor air filter

Operating the machine without filter element fitted is not permitted.

Replace the filter element after the following occurrences:

- The maintenance indicator is actuated.
- The maintenance interval has expired in the maintenance schedule.
- A maintenance message is indicated on the SIGMA CONTROL SMART display

**NOTICE**

**Damage caused by destroyed filter element**

Compressor wear from contaminated intake air.

- ▶ Do not try to clean the filter element by striking or tapping it.
- ▶ Do not wash the filter element.



1. The machine is stopped
2. Compressed air consumers are disconnected
3. Compressed air discharge valves on the compressed air outlet are open
4. The machine has been fully vented
5. Pressure gauge reads 0bar

1. Switch off the «Controller ON/OFF» switch.
2. Set the «battery isolation switch» to position 0.

**11.4.4.1 Checking the compressor air filter maintenance indicator**

Carry out maintenance on the compressor air filter as soon as the yellow maintenance indicator piston reaches the red zone of the indicator scale.




Fig. 71 Checking the maintenance indicator in the intake air line for the compressor air filter

- |                           |                               |
|---------------------------|-------------------------------|
| 1 Maintenance indicator   | 3 Red zone of indicator scale |
| 2 Yellow indicator piston | 4 Reset knob                  |

- ▶ Check the position of the yellow indicator piston.

**11.4.4.2 Cleaning the dust evacuator valve**

Coarse dirt particles in the intake air fall to the base of the filter housing and are deposited in the area around the dust evacuator valve.

To clean the dust evacuator valve, proceed as follows:




Fig. 72 Cleaning the dust evacuator valve

- |                        |                         |
|------------------------|-------------------------|
| ① Filter cap           | ④ Valve area            |
| ② Dust evacuator valve | ⑤ Cleaning procedure    |
| ③ Sealing lips         | ⑥ Coarse dirt particles |

1. Squeeze the valve area to remove coarse dirt particles.
2. Clean both sealing lips.
3. Check that the two sealing lips remain in contact.

#### 11.4.4.3 Removing the filter cap




Fig. 73 Removing the filter cap

- |                   |
|-------------------|
| ① Filter housing  |
| ② Retaining clamp |
| ③ Filter cap      |

1. Unlock all three retaining clips ②.
2. Remove the filter cap ③.

#### 11.4.4.4 Replacing the filter elements

The compressor air filter is fitted with a primary filter element and a secondary filter element.

Replace the secondary filter element at every third change of the primary filter element or after two years at the latest. The secondary filter element cannot be cleaned and reused.




Fig. 74 Replacing the filter elements

- ① Filter cap
- ② Primary filter element
- ③ Secondary filter element

1. Remove both used filter elements.
2. Clean the filter housing, filter cap and sealing surfaces with a damp cloth.
3. Insert a new secondary filter element into the filter housing.
4. Insert a new primary filter element into the filter housing.



Dispose of used filter elements and filter dust in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

#### 11.4.4.5 Fitting the compressor air filter cap

Align the filter cap so that the dust evacuator valve is pointing vertically downwards.

A deflection of  $\pm 30^\circ$  to the vertical axis is permitted.

1. Align the filter cap and position in front of the filter housing.
2. Place the filter cap on the filter housing and press down lightly.
3. Secure the filter cap with all three retaining clamps.

#### 11.4.4.6 Resetting the compressor air filter maintenance indicator

- ▶ Press the reset button for the maintenance indicator repeatedly.
  - ☑ The maintenance indicator is ready for operation.

#### 11.4.4.7 Cleaning the primary filter element in the compressor air filter



Always use new filter elements if possible.

Reuse cleaned primary filter elements only in exceptional cases.

To clean the primary filter element, proceed as follows:




Fig. 75 Cleaning the primary filter element

- |   |                          |
|---|--------------------------|
| ① Cleaning the primary filter element   | ④ Primary filter element |
| ② Checking the primary filter element   | ⑤ Torch                  |
| ③ Compressed air gun with blow-out pipe |                          |

1. Use dry compressed air 5 bar to blow out dirt from the primary filter element at an angle, from the inside to the outside.
2. Blow out the primary filter element until no more dust appears.
3. In a darkened room, use a suitable torch to shine a light through the cleaned primary filter element.
  - ✓ The cleaned primary filter element displays no cracks or holes.
  - The cleaned primary filter element is in the correct condition.
4. Insert the cleaned and checked primary filter element into the filter housing.

## 11.5 Cleaning the coolers

The three coolers for the drive engine and compressor are arranged in a radiator core.

Heavy contamination of the three coolers causes the machine to overheat. The required cleaning frequency depends on local ambient conditions at the installation location.

Check the three coolers regularly for contamination.

Clean the cooler fins with compressed air, water or steam jet in the opposite direction to that of the cooling air flow. This means that you clean all of the coolers from the outside to the inside.

Always park your machine levelly so that accumulated water can flow away.

Arrange for heavy contamination to be removed by an authorised service partner.



### ⚠ CAUTION

#### Danger from swirling dust particles

- ▶ Use a breathing mask when cleaning with compressed air.

### NOTICE

#### Damage caused by water or steam jets

- ▶ Cover sensitive electrical components.
- ▶ Do not direct high-pressure jets at sensitive components or display instruments.
- ▶ Adhere to the minimum distance and suitable angle of approach to the cooler surface.

### NOTICE

#### Damage caused by incorrect cleaning

- ▶ Do not clean the cooler using hard objects.




Fig. 76 Cleaning the charge air cooler, oil cooler and coolant cooler

- |                         |                              |
|-------------------------|------------------------------|
| 1 Front end of machine  | 6 Radiator core              |
| 2 Charge air cooler     | 7 Minimum distance 50 cm     |
| 3 Coolant cooler        | 8 Attack angle               |
| 4 Oil cooler            | 9 High-pressure washer lance |
| 5 Direction of cleaning |                              |





1. The machine is stopped
2. Compressed air consumers are disconnected
3. Compressed air discharge valves on the compressed air outlet are open
4. The machine has been fully vented
5. Pressure gauge reads 0 bar

1. Switch off the «Controller ON/OFF» switch.

## 11 Maintenance

### 11.6 Checking screw connections

---

2. Disconnect the negative cable from the battery.
3. Open all of the bung plugs in the closed floor pan.
4. Cover up the electric starter for the drive engine.
5. Cover up electrical components such as the generator and generator control box.
6. Cover up the intake openings for both the drive engine and compressor air filters.
7. Remove the exhaust air grating:
  - a) Loosen and remove all of the screws on the exhaust air grating.
  - b) Remove the exhaust air grating.
8. Cleaning the charge air cooler, oil cooler and coolant cooler:
  - a) Adhere to the minimum distance  and attack angle  to the cooler surface.
  - b) Clean the cooling fins with compressed air, water or steam jet from the outside to the inside.
9. Refit the exhaust air grating:
  - a) Position the exhaust air grating.
  - b) Position all screws and tighten.
10. Remove the covers from the intake openings for both the drive engine and compressor air filters.
11. Remove all other covers used inside the machine.
12. Seal the floor pan with all of the bung plugs.
13. Perform a test run, see [Tab. 73 Performing a test run](#).



Only steam-clean dirty cooling fins at cleaning areas equipped with an oil separator.

## 11.6 Checking screw connections

Overview:

- Guideline values for tightening torques
    - General guideline values for tightening torques
    - Specific guideline values for tightening torques
  - Sealed screw connections
    - The machine has stopped and cooled down
    - Compressed air consumers are disconnected
    - The compressed air discharge valves at the compressed air outlet are open
    - The machine has been fully vented
    - The pressure gauge reads 0bar
- ▶ Switch off the «Controller ON/OFF» switch.



### 11.6.1 General guideline values for tightening torques

Guideline values for the required tightening torques are dependent upon the size of the screw connection, the strength class of the screw material and the friction coefficient.

1. Determine the thread size for the screw connection.
2. For determining the defined torque, see [2.2.3 Tightening torque](#).
3. Tighten all screw connections with the defined torque.

### 11.6.2 Specific guideline values for tightening torques

Tighten screw connections for components that either relate to safety or are under particular stress load with the specific tightening torque.

- For specific tightening torque values, see chapter [2.2.3 Tightening torque](#).
  - E.g. Screw connections for the crane suspension
  - E.g. Cover screws on the oil separator tank
- Values for further specific tightening torques can be found directly with the information for the relevant maintenance task



#### CAUTION

##### **Danger from broken or loose screw connections**

Damage due to leakages is possible

- ▶ Screw connections for components that either relate to safety or are under particular stress load must be tightened exclusively with the specific tightening torque.
1. Determine the specific tightening torque.
  2. Tighten the screw connections with the specific tightening torque.

### 11.6.3 Sealed screw connections

Do not adjust any screw connections that are sealed with coloured locking varnish.

Failure to comply will invalidate all warranty claims.

#### **NOTICE**

##### **Damage to the machine caused by adjusting the settings**

- ▶ Leave sealed screw connections in their original condition.
- ▶ Do not retighten or adjust sealed setting screws.

## 11.7 Check sound insulation material

Sound insulation material reduces machine noise emissions to a minimum. Check your machine's sound insulation material according to the maintenance schedule.

Dismantle the cooling air inlet and outlet grilles to properly inspect the sound insulation material. Have damaged sound insulation material replaced immediately.

Sound insulation material is installed, for example, in the following positions within the machine:

- Cooling air inlet and outlet
  - Enclosure, gull-wing doors and swing doors
  - Bulkheads
- The machine has stopped and cooled down
  - Compressed air consumers are disconnected
  - The compressed air discharge valves at the compressed air outlet are open
  - The machine has been fully vented
  - The pressure gauge reads 0 bar



1. Switch off the «Controller ON/OFF» switch.
2. Dismantle cooling air inlet and outlet grilles.
3. Check the sound insulation material in the cooling air inlet and outlet.

## 11 Maintenance

### 11.8 Checking the wing doors

---

4. Check all sound insulation material inside the machine.
5. Check sound insulation material for condition, attachment and dirt.



The sound insulation material is porous, cracked, no longer exists or is severely contaminated with oil, fuel or cleaning agent.

- Have a KAESER SERVICE technician replace sound insulation material that can no longer be used.

### 11.8 Checking the wing doors



The closed wing doors on the machine fulfil the following functions: Contact protection, cooling air flow, sound insulation and weather protection.

Check that the wing doors and their connection elements are in perfect condition in accordance with the maintenance schedule.



- The machine has stopped and cooled down
- Compressed air consumers are disconnected
- The compressed air discharge valves at the compressed air outlet are open
- The machine has been fully vented
- The pressure gauge reads 0bar

Switch off the «Controller ON/OFF» switch.

#### 11.8.1 Maintaining the rubber seals

The rubber seals fitted to the wing doors serve to protect against rainwater ingress and to reduce noise emission.

Maintain the rubber seals in particular before the onset of winter, in order to prevent them from becoming stuck or torn.



- Silicone oil
- Vaseline

1. Clean all rubber seals.
2. Check all rubber seals for tears, holes and other damage.
3. Oil or grease all rubber seals.



Rubber seals are damaged.

- Arrange for an authorised KAESER SERVICE agent to replace the damaged rubber seals.

#### 11.8.2 Checking the closing function of the wing doors

1. Close all wing doors.
2. Lock all toggle latches.



One or more wing doors do not close perfectly or cannot be latched.

- Contact an authorised KAESER SERVICE agent.

### 11.8.3 Checking the connection elements on the wing doors

In order to ensure lubrication of the connecting rod, the connecting rod must be always aligned downwards.




Fig. 77 Connecting rod alignment

- |                                |                  |
|--------------------------------|------------------|
| 1 Gas-pressure spring cylinder | 3 Connecting rod |
| 2 Ball cup                     | 4 Lubrication    |

1. Check all connection elements for damage, wear and secure seating.
2. Lubricate all hinges.
3. Check all gas-pressure springs:
  - a) Check that the gas-pressure springs open the unlocked wing doors properly.
  - b) Check that the wing doors remain at the maximum opening angle when opened.



Wing doors do not open properly or do not remain open.

- Replace defective gas-pressure springs.

## 11.9 Checking or replacing hose lines

The hose lines are subject to natural ageing, regardless of proper storage or permissible load during operation. This ageing changes the material and compound properties, and reduces the performance capability of the hose lines. As a result, the period of use for hose lines is limited.

Check your machine's hose lines in accordance with the maintenance schedule.



- The machine has stopped and cooled down
- Compressed air consumers are disconnected
- The compressed air discharge valves at the compressed air outlet are open
- The machine has been fully vented
- The pressure gauge reads 0 bar

- ▶ Switch off the «Controller ON/OFF» switch.

### 11.9.1 Replacing the drive engine fuel hoses

- ▶ Arrange for an authorised KAESER SERVICE agent to replace the fuel hoses on the drive engine.

### 11.9.2 Replacing the pressure hoses on the drive engine

Overview of all pressure hoses on the drive engine:

- Engine oil
- Coolant for the coolant cooler
- Charge air for the charge air cooler
- ▶ Arrange for a KAESER SERVICE agent to replace the pressure hoses on the drive engine.

### 11.9.3 Replace the pressure hoses of the compressor

Overview of all pressure hoses on the compressor:

- Compressor oil
- Compressed air
- Control air
- Condensate
- ▶ Have a KAESER SERVICE technician replace the pressure hoses of the compressor.

## 11.10 Testing the safety functions

- ▶ Carry out the test work steps in accordance with chapter [11.2.4 Machine maintenance schedule](#).

### 11.10.1 Checking the EMERGENCY STOP device

Check the mechanical function of the «EMERGENCY STOP» button on a daily basis with the machine switched off.




Fig. 78 Checking the EMERGENCY STOP device

- ① «EMERGENCY STOP» button
- ② Unlock the «EMERGENCY STOP» button in the direction of the arrow.

1. Actuate the «EMERGENCY STOP» button.
2. Check to ensure that the «EMERGENCY STOP» button locks properly and remains locked.
3. Turn the «EMERGENCY STOP» button in the direction of the arrow.
4. Check to ensure that the «EMERGENCY STOP» button unlocks properly.



The «EMERGENCY STOP» button does not lock or remain locked.

- Do not start the machine.
- Arrange for an authorised KAESER SERVICE agent to replace the «EMERGENCY STOP» button.

### 11.10.2 Testing the safety valve actuating pressure

Test the actuating pressure for the safety valve as per the separate SIGMA CONTROL SMART user manual. The machine must stop when the actuating pressure reaches  $P_{\max}$ .

Value for the actuating pressure, see [Tab. 14 Actuating pressure on the safety valve](#).



#### **WARNING**

**Danger of hearing damage from noise when safety valve blows off**

- ▶ Keep enclosures, doors and all cover panels closed.
- ▶ Wear ear protection.
  
- ▶ Check the actuating pressure for the safety valve.

### 11.10.3 Testing the excess temperature safety shutdown

Test the safety shutdown at excessive airend discharge temperatures as per the SIGMA CONTROL SMART user manual. The machine must stop when the airend discharge temperature reaches  $T_{\max}$ .

Value for the maximum airend discharge temperature with automatic safety shutdown, see [Tab. 16 Airend discharge temperature](#).

- ▶ Test the safety shutdown at excess airend discharge temperature.

## 11.11 Servicing the options

- ▶ Carry out maintenance in accordance with chapter [11.2.5 Options maintenance schedule](#).

### 11.11.1 **da** Servicing the compressed air aftercooler

The required cleaning frequency depends heavily on the local ambient conditions at the installation location.

Check the compressed air aftercooler regularly for contamination.

Always park your machine levelly so that accumulated water can flow away.

Arrange for heavy contamination to be removed by KAESER SERVICE.



#### **CAUTION**

##### **Danger from swirling dust particles**

- ▶ Use a breathing mask when cleaning with compressed air.

#### **NOTICE**

##### **Damage caused by water or steam jets**

- ▶ Cover sensitive electrical components.
- ▶ Do not direct high-pressure jets at sensitive components or display instruments.
- ▶ Adhere to the minimum distance and suitable angle of approach to the cooler surface.

#### **NOTICE**

##### **Damage caused by incorrect cleaning**

- ▶ Do not clean the cooler using hard objects.






Fig. 79 Cleaning the compressed air aftercooler

- |                              |                              |
|------------------------------|------------------------------|
| ① Compressed air aftercooler | ④ Minimum distance           |
| ② Direction of cleaning      | ⑤ Attack angle               |
| ③ Dirt trap                  | ⑥ High-pressure washer lance |



- The machine has stopped and cooled down
- Compressed air consumers are disconnected
- The compressed air discharge valves at the compressed air outlet are open
- The machine has been fully vented

- The pressure gauge reads 0 bar
1. Switch off the «Controller ON/OFF» switch.
  2. Disconnect the negative cable from the battery.
  3. Open all of the bung plugs in the closed floor pan.
  4. Cover up electrical components such as the generator and generator control box.
  5. Cover up the intake openings for both the drive engine and compressor air filters.
  6. Clean the compressed air aftercooler:
    - a) Adhere to the minimum distance  and attack angle  to the cooler surface.
    - b) Clean the cooler fins with compressed air, water or steam jet in the opposite direction to that of the cooling air flow.
  7. Remove the covers from the intake openings for both the drive engine and compressor air filters.
  8. Remove all other covers used inside the machine.
  9. Seal the floor pan with all of the bung plugs.
  10. Perform a test run, see [Tab. 73 Performing a test run](#).



Only steam-clean dirty cooling fins at cleaning areas equipped with an oil separator.

### 11.11.2 Servicing the dirt trap on the water separator

Clean the dirt trap in accordance with the options maintenance schedule.

You can find the dirt trap underneath the water separator.



#### **CAUTION**

##### **Danger of burning from hot surfaces**

- ▶ Stop the machine and allow it to cool down.
- ▶ Wear personal protective equipment.




Fig. 80 Servicing the dirt trap

- |   |           |   |                           |
|---|-----------|---|---------------------------|
| 1 | Dichtring | 5 | Angled screw-in connector |
| 2 | Strainer  | 6 | Clamping nut              |
| 3 | Nozzle    | 7 | Condensate drain line     |
| 4 | Reducer   |   |                           |



- Benzine
- Spirit



- KIT Dirt trap



1. Compressed air consumers are disconnected
2. Compressed air discharge valves on the compressed air outlet are open
3. The machine has been fully vented
4. The pressure gauge reads 0bar

1. Switch off the «Controller ON/OFF» switch.
2. Remove the dirt trap:
  - a) Remove the clamping nut and condensate drain line.
  - b) Remove the angled screw-in connector.
  - c) Unscrew the reducer.
  - d) Unscrew the strainer.
  - e) Loosen the nozzle with a screwdriver.
  - f) Remove the nozzle from the reducer.
3. Clean and inspect the components:
  - a) Clean the nozzle, strainer and male stud fitting.
  - b) Check the nozzle and strainer for wear.
  - c) Replace any damaged or worn components.
4. Reinstall the dirt trap:
  - a) Position the strainer in the reducer and screw in place.
  - b) Position the strainer in the reducer and screw in place.
  - c) Fit the reducer with a sealing ring.
  - d) Refit the angled screw-in connector.
  - e) Fit the clamping nut to the condensate drain line and tighten.
5. Perform a test run, see [Tab. 73 Performing a test run](#).



Dispose of wearing parts in the dirt trap and of condensate in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

### 11.11.3 **dd** Servicing the filter combination

Overview:

- Blowing out condensate
- Replacing the filter elements
- ▶ Only replace the filter elements for the filter combination in a clean environment.

#### 11.11.3.1 Blowing out condensate

To guarantee perfect function of the filter combination, blow out the condensate from the prefilter and fine filter in accordance with the options maintenance schedule.




Fig. 81 Blowing out condensate

- |                      |                                   |
|----------------------|-----------------------------------|
| 1 Filter combination | 4 Shut-off valve                  |
| 2 Prefilter          | 5 Example: Shut-off valve blocked |
| 3 Fine filter        | 6 Example: Shut-off valve open    |



1. The machine is stopped
2. Compressed air consumers are disconnected
3. Compressed air discharge valves on the compressed air outlet are open
4. The machine has been fully vented
5. Pressure gauge reads 0 bar

1. Place a receptacle under the condensate drain.
2. Open both shut-off valves 4.
3. Switch on the «Controller ON/OFF» switch.
4. Start the machine and run it in the IDLE operating point.
  - ✓ The condensate is blown out.
5. Wait until only compressed air is emitted.

6. Stop the machine.
  - a) Wait until the machine has vented automatically.
  - b) Open the compressed air discharge valves at the compressed air outlet.
7. Switch off the «Controller ON/OFF» switch.
8. Close both condensate drain shut-off valves.
9. Remove the receptacle from the machine.



Dispose of condensate in accordance with local disposal regulations and the applicable environmental protection regulations for the country of operation.

### 11.11.3.2 Replacing the filter elements

The prefilter and fine filter are equipped with different filter elements. Check the two filter elements for their specific usage. Always replace the filter elements for the prefilter and fine filter as a pair.



#### **WARNING**

##### **Danger of injury due to residual pressure**

- ▶ Vent the filter combination.
- ▶ Open both shut-off valves on the condensate drain.

#### **NOTICE**

##### **Danger of contamination from skin contact with the filter surface**

- ▶ Only handle new filter elements when wearing cloth gloves.



- Acid-free petroleum jelly



- Prefilter element with O-ring
- Fine filter element with O-ring



- The machine has stopped and cooled down
- Compressed air consumers are disconnected
- The compressed air discharge valves at the compressed air outlet are open
- The machine has been fully vented
- The pressure gauge reads 0bar

- ▶ Switch off the «Controller ON/OFF» switch.

**Removing the filter housing**




Fig. 82 Example: Removing the prefilter housing

- |                               |                  |
|-------------------------------|------------------|
| 1 Removing the clamping nut   | 5 Filter head    |
| 2 Removing the filter housing | 6 Filter bowl    |
| 3 Filter housing              | 7 O-ring         |
| 4 Hose line clamping nut      | 8 Filter element |

1. Open both shut-off valves on the condensate drain.
2. Loosen and remove the clamping nut on the hose line.
3. Remove the filter housing:
  - a) Loosen and remove the filter bowl.
  - b) Remove the filter element and the old O-ring.
4. Clean the filter head and filter bowl.
5. Remove and clean the filter housing for the fine filter in the same way.

**Replacing the filter element on the prefilter**




Fig. 83 Example: Replacing the filter element on the prefilter

- |   |                           |
|---|---------------------------|
| 1 Replacing the filter element and O-ring | 7 Filter bowl             |
| 2 Installing the filter bowl              | 8 Marking on filter head  |
| 3 Installing the clamping nut             | 9 Marking on filter bowl  |
| 4 O-ring                                  | 10 Filter housing         |
| 5 Filter element                          | 11 Hose line clamping nut |
| 6 Filter head                             |                           |

1. Prepare the filter head:
  - a) Lubricate the thread and the new O-ring with petroleum jelly.
  - b) Insert the new O-ring into the filter head.
2. Put on cloth gloves.
3. Prepare the filter bowl:
  - a) Handle the new filter element with the cloth gloves.
  - b) Align the guides on the new filter element with the grooves in the filter bowl.
  - c) Insert the new filter element into the filter bowl.
4. Mount the filter bowl on the filter head:
  - a) Turn the thread on the filter bowl fully into the filter head.
  - b) Continue turning the filter bowl until the pawl snaps into place.
  - ✓ The marking on the filter bowl is positioned beneath the marking on the filter head.
5. Fit the clamping nut to the hose line and tighten correctly.
6. Replace the filter element for the fine filter in the same way.
7. Close both shut-off valves on the condensate drain.
8. Perform a test run, see [Tab. 73 Performing a test run](#).



Dispose of used filter elements, condensate and contaminated working materials in accordance with local disposal regulations and the applicable environmental protection regulations for the country of operation.

### 11.11.4 **ea ec** Maintaining the tool lubricator

Check the maximum and recommended fill level for the supply vessel on a daily basis.




Fig. 84 Maintaining the tool lubricator

- |   |                            |   |               |
|---|----------------------------|---|---------------|
| 1 | Screw plug                 | 5 | Filler port   |
| 2 | Dipstick                   | 6 | Supply vessel |
| 3 | Maximum fill level         | 7 | O-ring        |
| 4 | Tool lubricator upper part | 8 | Lubricant     |



- The machine has stopped and cooled down
- Compressed air consumers are disconnected
- The compressed air discharge valves at the compressed air outlet are open
- The machine has been fully vented
- The pressure gauge reads 0bar

1. Switch off the «Controller ON/OFF» switch.
2. Check the fill level:
  - a) Loosen and remove the screw plug.
  - b) Wipe the dipstick with a cleaning cloth.
  - c) Insert the screw plug.
  - d) Remove the screw plug again.
  - e) Read off the fill level from the dipstick.
3. Replenish the lubricant:
  - a) Replenish the lubricant to the maximum level.
  - b) Check the fill level.
  - c) Check that the O-ring is in the correct condition.
  - d) Insert the screw plug.
4. Perform a test run, see [Tab. 73 Performing a test run](#).



For suitable lubricants and the maximum fill level, see chapter [2.5 Options](#).

### 11.11.5 **ga** Servicing the generator

A spring-supported tensioning frame automatically sets the correct belt tension.  
Replace the generator drive belt if transverse tears, frays or stretching are visible.



#### **! WARNING**

**Danger of shearing and crushing from contact with rotating components**

- ▶ Stop the machine.
- ▶ Secure the machine against being restarted.
- ▶ Only remove safety guards and cover panels after securing the machine against being restarted.




Fig. 85 Replacing the generator drive belt

- |                          |                            |
|--------------------------|----------------------------|
| 1 Drive belt pulley      | 5 Tensioning frame         |
| 2 Drive belt             | 6 Tensioning frame fulcrum |
| 3 Generator drive pulley | 7 Hexagon head             |
| 4 Generator              | 8 Generator control box    |



1. Compressed air consumers are disconnected
2. Compressed air discharge valves on the compressed air outlet are open
3. The machine has been fully vented
4. The pressure gauge reads 0bar

1. Switch off the «Controller ON/OFF» switch.
2. Disconnect the negative cable from the battery.
3. Remove the heat shield
4. Remove the belt safety guard
5. Remove the old generator drive belt:
  - a) Fit the hexagon wrench onto the tool holder on the tensioning frame.
  - b) Pull the tensioning frame in the direction of the arrow and hold it.
  - c) Pull the loosened drive belt from the generator belt pulley.
  - d) Allow the tensioning frame to spring back slowly.
  - e) Remove the drive belt from the drive engine belt pulley.
6. Check both belt pulleys for dirt and wear:
  - a) Clean the pulleys if they are dirty.
  - b) Arrange replacement of worn belt pulleys.
7. Install a new generator drive belt:
  - a) Manually position the new drive belt over both belt pulleys without using force.
  - b) Fit the hexagon wrench onto the tool holder on the tensioning frame.
  - c) Pull the tensioning frame in the direction of the arrow and hold it.
  - d) Push the drive belt downwards and guide it under the tension pulley on the tension frame.
  - e) Allow the tensioning frame to spring back slowly.
  - f) Check whether the drive belt is correctly fitted in the guidance grooves on both belt pulleys.
  - g) Check whether the drive belt is correctly fitted in the guidance grooves on both tension pulleys.
8. Perform a test run, see [Tab. 73 Performing a test run](#).

### 11.11.6 **1a** Servicing the spark arrester

Remove the accumulated soot from the spark arrester around every two months.

This will prevent glowing combustion residue being emitted from the exhaust silencer.

The spark arrester is integrated into the exhaust silencer.



#### **WARNING** **Danger of poisoning from exhaust gases and soot**

- ▶ Only blow out soot outdoors.
- ▶ Do not inhale exhaust gases and soot.



- Heat-resistant spiral hose




Fig. 86 Servicing the spark arrester

- |                    |                  |
|--------------------|------------------|
| 1 Exhaust inlet    | 3 Sealing plug   |
| 2 Exhaust silencer | 4 Exhaust outlet |



- The machine has stopped and cooled down
- Compressed air consumers are disconnected
- The compressed air discharge valves at the compressed air outlet are open
- The machine has been fully vented
- The pressure gauge reads 0bar

1. Carry out the following preliminary tasks:
  - a) Remove the sealing plug from the soot trap.
  - b) Feed the end of the hose through the opening in the floor panel.
  - c) Attach the end of the hose to the discharge port.
  - d) Place the open end of the hose in the soot receptacle.
2. Start the machine.
3. Blow out the soot:
  - a) Partially cover the exhaust outlet with a fireproof object to increase the pressure in the exhaust system.
  - b) Allow the machine to run until there are no more soot particles visible in the exhaust gas.
4. Switch the machine off:
  - a) Press the «STOP» key on the control panel.
  - b) Allow the machine to cool down.
5. Close the soot trap:
  - a) Remove the end of the hose from the discharge port.
  - b) Return the sealing plug to the discharge port.
  - c) Remove the cover from the exhaust outlet.



Dispose of collected soot in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

### 11.11.7 **lb** Maintaining the engine air shut-off valve

#### **NOTICE**

##### **Damage to the drive engine**

- ▶ Do not adjust the set screw for the engine air shut-off valve.
- ▶ Arrange for the engine air shut-off valve to be adjusted by a specialist workshop or KAESER SERVICE technician.
- ▶ Do not grease the engine air shut-off valve.




Fig. 87 Maintaining the engine air shut-off valve

- |   |             |   |                           |
|---|-------------|---|---------------------------|
| 1 | Hose length | 3 | Engine air shut-off valve |
| 2 | Adapter     | 4 | Bracket                   |



- The machine has stopped and cooled down
- Compressed air consumers are disconnected
- The compressed air discharge valves at the compressed air outlet are open
- The machine has been fully vented
- The pressure gauge reads 0bar

1. Switch off the «Controller ON/OFF» switch.
2. Remove the engine air shut-off valve from the air intake tract:
  - a) Loosen and remove both hoses 1.
  - b) Pull the adapter 2 out of the engine air shut-off valve 3.
  - c) Remove the engine air shut-off valve from the bracket 4.
3. Check that the interior of the engine air shut-off valve is clean:
  - a) Lightly blow out any dirt with compressed air.
  - b) Remove persistent dirt with benzine or spirit.
4. Check the function and mobility of the engine air shut-off valve:
  - a) Check the engine air shut-off valve for signs of excessive wear.
  - b) Check that the closing flap in the engine air shut-off valve is functioning perfectly.
5. Reinstall the engine air shut-off valve in the air intake tract.
6. Perform a test run, see [Tab. 73 Performing a test run](#).



The drive engine stops during LOAD operation.

- Arrange for the engine air shut-off valve to be adjusted by KAESER SERVICE or a specialist workshop.

**11.11.8 oe Servicing the closed floor pan**
**NOTICE**
**Danger of corrosion and short circuit from accumulated liquids**

- ▶ Check the interior of the machine on a daily basis.
- ▶ Remove accumulated liquids immediately.




Fig. 88 Bung plug example

- ① Bung plug
- ② Seal



- The machine has stopped and cooled down
- Compressed air consumers are disconnected
- The compressed air discharge valves at the compressed air outlet are open
- The machine has been fully vented
- The pressure gauge reads 0 bar

1. Switch off the «Controller ON/OFF» switch.
2. Perform a visual inspection for accumulated liquids.
  - a) Identify the leakage area inside the machine.
  - b) Identify the leaking component.
  - c) Correctly resolve the cause of the leak.
3. Identify the maintenance opening below the leakage area or leaking component.
  - a) Position a receptacle.
  - b) Loosen and remove the bung plug from the identified maintenance opening.
  - c) Collect the accumulated liquid.
  - d) If necessary, loosen and remove multiple bung plugs.
  - e) Wait until all of the accumulated liquid has drained.
4. Remove any contamination inside the machine.
  - a) Clean the maintenance openings.
  - b) Clean the bung plugs.
  - c) Check the seals for damage.
  - d) If necessary, replace damaged seals.
5. Properly close all cleaned maintenance openings with seals and bung plugs.



Dispose of any accumulated liquids in the closed floor pan in accordance with local disposal regulations and the applicable environmental protection laws for the country of operation.

**11.12 Cleaning the machine**

For the machine to be in proper technical condition, it must be clean. In particular, the interior of the machine must not be heavily contaminated with oil.

Take suitable measures to effectively prevent the ingress of jet water into electrical components when cleaning the machine interior using a high-pressure washer.

Ensure the machine is cleaned by authorised and trained personnel only.

- ▶ Clean the machine carefully.

### 11.12.1 Cleaning the exterior of the machine



To prevent damage when cleaning with a high-pressure washer, take note of the information in the manufacturer operating manual.

1. **oe** Open the closed floor pan:
  - a) Remove all bung plugs.
  - b) Clean all bung plugs.
2. Check that the protective covers are closed over all of the sockets:
  - **tc** Lighting socket
  - **te** Lighting socket
  - **bb** Coolant preheating socket
  - **od** Battery trickle charging socket
  - **ga** Electrical consumer socket
3. Close the control panel cover for the SIGMA CONTROL SMART.
4. Clean the machine from the outside:
  - a) Do not use jet water to clean sockets.
  - b) Do not use jet water to clean the «insulation monitoring» test key.
  - c) Deploy the lance on the high-pressure washer to maintain a minimum distance from the object being cleaned.
  - d) Keep the high-pressure washer lance in constant motion.
5. Clean all electrical components manually using a cleaning cloth.
6. Clean sensitive indicating instruments manually using a cleaning cloth.

### 11.12.2 Cleaning the interior of the machine

Set the high-pressure washer as per [Tab. 81 High-pressure washer setting](#).

| Characteristic                           |     |
|--|-----|
| Interior diameter of the jet nozzle [mm] | 6.3 |
| Flow rate [l/h]                          | 750 |

Tab. 81 High-pressure washer setting

1. Cover the intake openings on both air filters:
  - a) Cover the intake opening on the engine air filter.
  - b) Cover the intake opening on the compressor air filter.
2. Cover sensitive components:
  - a) Close the control panel cover.
  - b) Cover the generator control box with a plastic sheet and close off with adhesive tape.

3. Do not direct jet water at sensitive components:
  - Starter, control box or display instruments
  - Solenoid valves and electrical plug-in connections
  - Battery
  - Generator and its connector box
  - Generator control box
4. Clean the interior of the machine:
  - a) Clean non-sensitive components and surfaces inside the machine.
  - b) Keep the extension pole of the high-pressure washer in constant motion.
5. Remove all covers:
  - a) Remove the cover from the engine air filter intake opening.
  - b) Remove the cover from the compressor air filter intake opening.
  - c) Remove the cover from the generator control box.
  - ☑ The plastic sheeting and adhesive tape are removed from the interior of the machine.
6. Clean sensitive components using a cleaning cloth:
  - Generator
  - Generator connector box
  - Generator control box
  - Solenoid valves
  - Electrical plug-in connections
7. Seal the floor pan.
  - a) If required, remove any remaining contaminants with a cleaning cloth.
  - b) Reinsert all bung plugs.



## 12 Disposal

### 12.1 Disposal

Proper disposal is required by law.

Separate harmful substances and components in to order ensure treatment or controlled disposal.

Deliver all collected operating fluids/materials and removed components to the designated disposal system in accordance with environmental regulations. Finally, hand the machine over to a certified disposal agent.

1. Starter batteries must be delivered to the national battery collection system.
2. Device batteries, if present, must be disposed of via the national battery collection system.
3. Deliver collected operating fluids/materials to the designated disposal system.
4. Dispose of components and cleaning cloths contaminated with oil, fuel or coolant in accordance with environmental regulations.
5. Deliver the machine to a certified disposal agent.


## 13 Documents and drawings

### 13.1 **rb** Dimensional drawing overview

| Option             | Description  |
|--------------------|--|
| <b>rb rk rm rs</b> | <ul style="list-style-type: none"><li>▪ Chassis – EC version</li><li>▪ Chassis with low axle load</li><li>▪ Chassis with height adjustment</li><li>▪ Chassis with service brake</li></ul>  |
| <b>rb rl rm rs</b> | <ul style="list-style-type: none"><li>▪ Chassis – EC version</li><li>▪ Chassis with high axle load</li><li>▪ Chassis with height adjustment</li><li>▪ Chassis with service brake</li></ul> |

Tab. 82 Dimensional drawing overview for EC versions






Stand: 08.12.2024

## 13.2 **rw rx** Dimensional drawing overview


| Option    | Description            |
|-----------|------------------------|
| <b>rw</b> | Chassis frame on skids |
| <b>rx</b> | Chassis frame          |

Tab. 83 Dimensional drawing overview for stationary version





## 13.3 Flow diagram



| 1     | 2   | 3 | 4 | 5   | 6  | 7 | 8 |
|-------|---|---|---|---|--|---|---|
| 1     | Compressor - Air filter                           |   |   |   |  |   |   |
| 1.2   | Dust collector                                    |   |   |   |  |   |   |
| 2     | Maintenance indicator, Compressor -Air filter     |   |   |   |  |   |   |
| 3     | Inlet valve                                       |   |   |   |  |   |   |
| 4     | Rotary screw airend                               |   |   |   |  |   |   |
| 5     | Oil separator tank                                |   |   |   |  |   |   |
| 5.1   | Hose coupling - Oil drain device                  |   |   |   |  |   |   |
| 5.13  | Pressure transducer - Internal pressure           |   |   |   |  |   |   |
| 6     | Oil reserve                                       |   |   |   |  |   |   |
| 7     | Oil separator cartridge                           |   |   |   |  |   |   |
| 11    | Oil filler with screw plug                        |   |   |   |  |   |   |
| 12.3  | Temperature sensor - Airend discharge temperature |   |   |   |  |   |   |
| 13    | Safety valve                                      |   |   |   |  |   |   |
| 14    | Pressure gauge Compressed air - Control panel     |   |   |   |  |   |   |
| 15    | Diesel engine                                     |   |   |   |  |   |   |
| 15.1  | Hose coupling - Oil drain device                  |   |   |   |  |   |   |
| 16    | Oil return line                                   |   |   |   |  |   |   |
| 17    | Dirt trap   |   |   |   |  |   |   |
| 17.1  | Nozzle  |   |   |   |  |   |   |
| 19    | Thermostatic valve                                |   |   |   |  |   |   |
| 20    | Oil cooler  |   |   |   |  |   |   |
| 20.1  | Hose coupling - Oil drain device                  |   |   |   |  |   |   |
| 21    | Oil filter  |   |   |   |  |   |   |
| 23    | Electric proportional controller                  |   |   |   |  |   |   |
| 24    | Motor - Air filter                                |   |   |   |  |   |   |
| 24.2  | Dust collector                                    |   |   |   |  |   |   |
| 25    |   |   |   | Maintenance indicator, Motor - Air filter             |  |   |   |
| 27    |   |   |   | Venting valve   |  |   |   |
| 28    |   |   |   | Fan   |  |   |   |
| 29    |   |   |   | Exhaust silencer                                      |  |   |   |
| 30    |   |   |   | Coupling  |  |   |   |
| 46    |   |   |   | Nozzle (Secondary side Proportional controller)       |  |   |   |
| 52    |   |   |   | Control valve   |  |   |   |
| 56    |   |   |   | Coolant cooler  |  |   |   |
| 56.1  |   |   |   | Coolant expansion tank                                |  |   |   |
| 56.3  |   |   |   | Hose coupling - Water drain device                    |  |   |   |
| 56.10 |   |   |   | Coolant filler with screw plug and overpressure valve |  |   |   |
| 63    |   |   |   | Regulating valve (Recirculation valve)                |  |   |   |
| 64    |   |   |   | Generator   |  |   |   |
| 72    |   |   |   | Coolant pre-heating device                            |  |   |   |
| 83    |   |   |   | Engine air shut-off valve (automatic shut-off)        |  |   |   |
| 84    |   |   |   | Spark arrester  |  |   |   |
| 93    |   |   |   | Particulate filter with integrated exhaust silencer   |  |   |   |
| 94    |   |   |   | Charge air cooler                                     |  |   |   |
|       |   |   |   | Option  |  |   |   |
|       |   |   |   | bb  | Coolant pre-heating  |   |   |
|       |   |   |   | ga  | Generator  |   |   |
|       |   |   |   | la  | Spark arrester   |   |   |
|       |   |   |   | lb  | Spark arrester +   |   |   |
|       |   |   |   |   | Engine air shut-off valve (automatic, closes via EMERGENCY STOP) |   |   |


|      |          |            |  |
|------|----------|------------|--|
| Date |          | 06.11.2024 |  |
| c    | Drawn    | Phau       |  |
| b    | Released | Muller     |  |
| a    | Revision |            |  |
| Name |          |            |  |

**KAESER**  
KOMPRESSOREN  
FFMM/81ST-01146.00

P&I diagram legend  
MOBILAIR  
M81

FFMM81ST-01146.00

Sheet 2  
E




|                    |  |                       |  |
|--------------------|--|-----------------------|--|
| Date               |  | 08.11.2024            |  |
| Drawn              |  | Prau                  |  |
| Released           |  | Mahrer                |  |
| Revision           |  | Name                  |  |
| A-Nr.: 59705/59704 |  | FFMM7681DLAO-01147.00 |  |
| Sheet              |  | 1                     |  |
| Revision           |  | E                     |  |

| 1    | 2                               | 3 | 4 | 5      | 6  | 7 | 8 |
|------|---------------------------------|---|---|--------|--|---|---|
| 9    | Tool lubricator                 |   |   | 39     | Check valve  |   |   |
| 9.1  | Shut-off valve                  |   |   | 49     | 3/2-Directional control valve                      |   |   |
| 10   | Air distributor                 |   |   | Option |  |   |   |
| 10.8 | Shut-off valve                  |   |   | da     | Compressed air aftercooler + Centrifugal separator |   |   |
| 32   | Air cooler                      |   |   | dd     | Filter combination                                 |   |   |
| 33   | Centrifugal separator           |   |   | df     | Heat exchanger with bypass                         |   |   |
| 33.1 | Dirt trap                       |   |   | dg     | Compressed air aftercooler with bypass             |   |   |
| 33.2 | Nozzle                          |   |   | ea     | Tool lubricator, with option fa                    |   |   |
| 34   | Heat exchanger                  |   |   | ec     | Tool lubricator, with option fc                    |   |   |
| 34.4 | Screw plug - Oil drain device   |   |   | fa     | Direct air flow                                    |   |   |
| 36   | Filter combination              |   |   | fc     | Air flow split downstream of treatment options     |   |   |
| 36.1 | Condensate drain shut-off valve |   |   | ua     | Hose reel  |   |   |
| 37   | Minimum pressure check valve    |   |   |        |  |   |   |

|                               |  |                       |  |
|-------------------------------|--|-----------------------|--|
| <b>KAESER</b><br>KOMPRESSOREN |  | FFMM7681DLAO-01147.00 |  |
| P&I diagram legend            |  | FFMM7681DLAO-01147.00 |  |
| MOBILAIR M76 / M81            |  | Sheet 2               |  |
| Compressed air outlet-options |  | E                     |  |

## 13.4 Fuel circuit diagram





## **13.5 Electrical diagrams**

### **13.5.1 Wiring diagram**

|  |          |            |                |            |   |   |   |                |
|--|----------|------------|----------------|------------|---|---|---|----------------|
| 1  | 2        | 3          | 4              | 5          | 6 | 7 | 8 |                |
| <div style="border: 1px solid black; padding: 10px; margin: 0 auto; width: 80%;"> <p style="text-align: center; margin: 0;">Electrical diagrams</p> <p style="text-align: center; margin: 0;">MOBILAIR M81.2 - SCS</p> <p style="text-align: center; margin: 0;">HATZ Engine stage V</p> <p style="text-align: center; margin: 0;">SIGMA CONTROL SMART</p> </div>  |          |            |                |            |   |   |   |                |
| <p style="text-align: right;">Manufacturer: KAESER KOMPRESSOREN SE<br/>Postfach 2143<br/>96410 Coburg</p>  |          |            |                |            |   |   |   |                |
| <p style="font-size: small;">The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.</p> |          |            |                |            |   |   |   |                |
| c  | Date     | 30.06.2025 | E              | Cover page |   |   |   | =              |
| b  | Drawn    | Seubert    | MOBILAIR M81.2 |            |   |   | + | DFA81-03062.01 |
| a  | Released | Schnöder   | M81.2          |            |   |   | - | 1              |
| A  | Change   | Date       | Name           | 1 Sht.     |   |   |   | 1              |


| Lfd. Nr.<br>No. | Benennung<br>Name  | Zeichnungsnummer (Kunde)<br>Drawing No. (customer) | Zeichnungsnummer (Hersteller)<br>Drawing No. (manufacturer) | Blatt<br>Page | Anlagenkennzeichen<br>Unit designation |
|-----------------|--|--|---|---------------|--|
| 1               | Cover page   |  | DFA81-03062.01  | 1             |  |
| 2               | List of contents   |  | ZFA81-03062.01  | 1             |  |
| 3               | Block diagram  |  | UFA81-03062.01  | 1             |  |
| 4               | Block diagram  |  | UFA81-03062.01  | 2             |  |
| 5               | Block diagram<br>cabling   |  | UFA81-03062.01  | 3             |  |
| 6               | Circuit diagram  |  | SFA81.BK-03062.01   | 1             | =BK                                    |
| 7               | Circuit diagram  |  | SFA81.IKM-03062.01  | 1             | =IKM                                   |
| 8               | Circuit diagram  |  | SFA81.IKM-03062.01  | 2             | =IKM                                   |
| 9               | Circuit diagram  |  | SFA81.IKM-03062.01  | 3             | =IKM                                   |
| 10              | Circuit diagram<br>analogue input building group                       |  | SFA81.SK-03062.01   | 6             | =SK                                    |
| 11              | Circuit diagram<br>Control board EMR 4                                 |  | SFA81.SK-03062.01   | 8             | =SK                                    |
| 12              | Circuit diagram  |  | SFA81.SK-03062.01   | 1             | =SK                                    |
| 13              | Circuit diagram<br>analogue input building group                       |  | SFA81.SK-03062.01   | 2             | =SK                                    |
| 14              | Circuit diagram<br>analogue input building group                       |  | SFA81.SK-03062.01   | 3             | =SK                                    |
| 15              | Circuit diagram<br>analogue input building group                       |  | SFA81.SK-03062.01   | 4             | =SK                                    |
| 16              | Circuit diagram<br>Digital output assembly                             |  | SFA81.SK-03062.01   | 5             | =SK                                    |
| 17              | Circuit diagram  |  | SFA81.SK-03062.01   | 7             | =SK                                    |
| 18              | Equipment parts list<br>Control cabinet                                |  | GFA81-03062.01  | 1             |  |
| 19              | Equipment parts list<br>Control cabinet/Control panel                  |  | GFA81-03062.01  | 2             |  |
| 20              | Equipment parts list<br>unit components/model-dependent components     |  | GFA81-03062.01  | 3             |  |
| 21              | Terminal schedule<br>Terminal strip -X1                                |  | KFA81-03062.01  | 1             | =SK                                    |
| 22              | Terminal schedule<br>Plug connection -X21                              |  | KFA81-03062.01  | 10            | =IKM                                   |
| 23              | Terminal schedule<br>Plug connection -X24                              |  | KFA81-03062.01  | 11            | =IKM                                   |
| 24              | Terminal schedule<br>Plug connection -X25                              |  | KFA81-03062.01  | 12            | =SK                                    |
| 25              | Terminal schedule<br>Plug connection -X31                              |  | KFA81-03062.01  | 20            | =SK                                    |
| 26              | Component layout<br>Switchboard / Side panel<br>rear panel Switchboard |  | AFA81-03062.01  | 1             |  |
| 27              | Component layout   |  | AFA81-03062.01  | 2             |  |

|          |  |                  |  |
|----------|--|------------------|--|
| Date     |  | 30.06.2025       |  |
| Drawn    |  | Seubert          |  |
| Released |  | Schroder         |  |
| Name     |  |                  |  |
| Date     |  |                  |  |
| Change   |  |                  |  |
|          |  | List of contents |  |
|          |  | MOBILAIR M81.2   |  |
|          |  | =                |  |
|          |  | +                |  |
|          |  | ZFA81-03062.01   |  |
|          |  | page             |  |
|          |  | 1                |  |
|          |  | 1 Stk.           |  |









|           |          |            |      |  |   |   |                |      |   |
|-----------|----------|------------|------|--|---|---|----------------|------|---|
| c         | Date     | 30.06.2025 |      |  | = | + | UFA81-03062.01 | page | 3 |
| b         | Drawn    | Schubert   |      |  |   |   |                |      |   |
| a         | Released | Schubert   |      |  |   |   |                |      |   |
| Cl Change |          | Date       | Name |  |   |   |                |      |   |


Block diagram  
MOBILAIR M81.2  
cabling









|                     |                                 |                     |                 |                 |              |                        |
|---------------------|---------------------------------|---------------------|-----------------|-----------------|--------------|------------------------|
| Function:           | Power supply unit Control board | CAN-Bus             | KL.50           | KL.15           | Relay ECU ON | Diagnostic socket Halz |
| Function:           | Control voltage ON              | CAN-Bus Halz        | Relay fuel pump | Relay fuel pump |              |                        |
| Group of functions: | ECU ON                          |                     |                 |                 |              |                        |
| c                   | Date                            | 30.06.2025          |                 |                 |              |                        |
| b                   | Drawn                           | Seubert             |                 |                 |              |                        |
| a                   | Released                        | Schroder            |                 |                 |              |                        |
| Change              | Date                            | Name                |                 |                 |              |                        |
|                     |                                 | Circuit diagram     |                 | MOBILAIR M81.2  |              | page 1                 |
|                     |                                 | KAESER KOMPRESSOREN |                 | M81.2           |              | 3.Stl.                 |
|                     |                                 | SFA81.1KM-03062.01  |                 |                 |              |                        |




|                           |           |                           |                    |           |
|---------------------------|-----------|---------------------------|--------------------|-----------|
| Function:                 | option oa | preheat attachment        | High-pressure pump | fuel pump |
| Function:                 |           | Pressure regulating valve | Relay Starter      |           |
| Group of functions:       |           | Filler maintenance fuel   |                    |           |
| c                         | Date      | 30.06.2025                |                    |           |
| b                         | Drawn     | Schubert                  |                    |           |
| a                         | Released  | Schubert                  |                    |           |
| Change                    | Date      | Name                      |                    |           |
| Circuit diagram           |           |                           | SFA81.1KM-03062.01 |           |
| MOBILAIR M81.2            |           |                           | page 2             |           |
| KAESER KOMPRESSOREN M81.2 |           |                           | 3. Sht.            |           |




|                     |                              |                           |   |                |
|---------------------|------------------------------|---------------------------|---|----------------|
| Function:           | sensor differential pressure | differential pressure DPF | Exhaust temperature upstream of the diesel particulate filter | Air flow meter |
| Function:           |                              | Air filter Engine         | Exhaust temp. upstream from oxi. cat. convert.                |                |
| Group of functions: |                              |                           |   |                |
| c                   | Date                         | 30.06.2025                |   |                |
| b                   | Drawn                        | Schubert                  |   |                |
| a                   | Released                     | Schubert                  |   |                |
| Change              | Date                         | Name                      |   |                |
|                     |                              |                           | Circuit diagram<br>MOBILAIR M81.2<br>M81.2                    |                |
|                     |                              |                           | SFA81.1KM-03062.01  | page 3         |
|                     |                              |                           |   | 3. Sht.        |



|                     |                |                          |                           |                                 |                         |
|---------------------|----------------|--------------------------|---------------------------|---------------------------------|-------------------------|
| Function:           | Control ON-OFF | Diagnostic socket KAESER | Voltage transformer DC/DC | CAN-interface KAESER            | interface GSM/GPS/Modem |
| Function:           | Starter ON     | Self-holding Control     | CAN-interface KAESER      | Power supply unit Control board |                         |
| Group of functions: |                |                          |                           |                                 |                         |
| c                   | Date           | 30.06.2025               |                           |                                 |                         |
| b                   | Drawn          | Schubert                 |                           |                                 |                         |
| a                   | Released       | Schubert                 |                           |                                 |                         |
| Change              | Date           | Name                     |                           |                                 |                         |
|                     |                |                          | SFA81.SK-03062.01         |                                 |                         |
|                     |                |                          | page 1                    |                                 |                         |
|                     |                |                          | 8.Stl.                    |                                 |                         |





Function: sensor fuel level

Function: Alternator

Group of functions: Control board inputs

|        |          |            |
|--------|----------|------------|
| c      | Date     | 30.06.2025 |
| b      | Drawn    | Schubert   |
| a      | Released | Schubert   |
| Change | Date     | Name       |

EMERGENCY STOP


Circuit diagram  
MOBILAIR M81.2  
analogue input building group


KAESER  
KOMPRESSOREN

M81.2


SFA81.SK-03062.01

page 3  
8.Sit.






|                         |                       |                   |
|-------------------------|-----------------------|-------------------|
| Function:               | Control valve         | Alternator        |
| Function:               | Inlet valve           | Venting valve     |
| Group of functions:     | Control board outputs |                   |
| c                       | Date                  | 30.06.2025        |
| b                       | Drawn                 | Schubert          |
| a                       | Released              | Schnöder          |
| Change                  | Date                  | Name              |
| Circuit diagram         |                       | -SK               |
| MOBILAIR M81.2          |                       | +                 |
| Digital output assembly |                       | SFA81.SK-03062.01 |
| page                    | 5                     | 8 Stl.            |



|                     |          |                      |  |
|---------------------|----------|----------------------|--|
| Function:           |          | Remote ON/OFF        |  |
| Function:           |          | option ga            |  |
| Group of functions: |          | Control board inputs |  |
| c                   | Date     | 30.06.2025           | Circuit diagram<br>MOBILAIR M81.2<br>analogue input building group |
| b                   | Drawn    | Schubert             |  |
| a                   | Released | Schubert             |  |
| 38                  | Change   | Date                 | Name   |
|                     |          | SFA81.SK-03062.01    |  |
|                     |          | page 6               |  |
|                     |          | 8.Stl.               |  |





|                     |          |                 |                   |                     |  |
|---------------------|----------|-----------------|-------------------|---------------------|--|
| Function:           |          | GSM/GPS antenna |                   | GSM/GPS Modem       |  |
| Group of functions: |          | MOBILAIR M81.2  |                   | Control board EMR 4 |  |
| c                   | Date     | 30.06.2025      | -SK +             |                     |  |
| b                   | Drawn    | Schubert        | SFA81.SK-03062.01 |                     |  |
| a                   | Released | Schubert        | page 8            |                     |  |
| pl                  | Change   | Name            | 8.Stl.            |                     |  |

| 1                 | 2  |                  | 3   | 4                | 5  | 6   | 7                      | 8                              |                  |                    |                           |
|-------------------|--|------------------|---|------------------|--|---|------------------------|--------------------------------|------------------|--------------------|---------------------------|
| A                 | B  |                  | C   | D                | E  | F   | G                      | H                              |                  |                    |                           |
| Stückzahl<br>Qty. | Benennung und Verwendung<br>Description and function |                  | Fabrikatsbezeichnung<br>Identification data<br>Type base technical data (e.g. control voltage, frequency, adjustable range),<br>order No., manufacturer | Lfd. Nr.<br>Item | Betriebsmittel-Kennz.<br>Identifying symbol<br>of device | Stromlaufplan<br>Planabschnitt<br>Circuit diagram<br>sheet No.; section No. | Einbaulort<br>Location | Concerns only the manufacturer |                  |                    |                           |
|                   |  |                  |   |                  |  |   |                        | H<br>Schabl.<br>Nr.            | I<br>BZ-<br>Pos. | J<br>VA<br>(Kz. *) | K<br>Eingangs-<br>vermerk |
|                   |  | Control cabinet: |   |                  |  |   |                        |                                |                  |                    |                           |
| 1                 | Control cabinet                                      |                  | 226798.0  | Wagner           |  |   |                        |                                |                  |                    |                           |
| 1                 | Mounting plate                                       |                  | 226834.1  | Wagner           |  |   |                        |                                |                  |                    |                           |
| 1                 | Control board SCS                                    |                  | CR9052  | ifm              | -K20   |   |                        |                                |                  |                    |                           |
| 2                 | Relay  |                  | 12V, 1W, 30/40A   | FTM              | K32; K38; K48; K49                                       |   |                        |                                |                  |                    |                           |
| 2                 | Relay socket   |                  | 7.3411.00020  | FTM              | K32; K38; K48; K49                                       |   |                        |                                |                  |                    |                           |
| 1                 | Relay  |                  | 8.6544.00030  | FTM              | K30  |   |                        |                                |                  |                    |                           |
| 1                 | Relay socket   |                  | 7.3411.00010  | FTM              | K30  |   |                        |                                |                  |                    |                           |
| 4                 | Lead-through terminal                                |                  | HDFK-10 / 10mm <sup>2</sup>   | Phoenix          | -X2319;-X2330;   |   |                        |                                |                  |                    |                           |
|                   |  |                  |   |                  | -X2331;-X2350  |   |                        |                                |                  |                    |                           |
| 17                | Terminal   |                  | WKFN 2.5D22/35  | Wieland          | -X1  |   |                        |                                |                  |                    |                           |
| 2                 | Terminal   |                  | WKF 1635 P/WKFN   | Wieland          | -X1  |   |                        |                                |                  |                    |                           |
| 1                 | Terminal   |                  | WKFN 2.5E35/G2  | Wieland          | -X1  |   |                        |                                |                  |                    |                           |
| 2                 | Terminal   |                  | WKFN 4/35   | Wieland          | -X1  |   |                        |                                |                  |                    |                           |
| 10                | Fuse terminal  |                  | WKFN 4/F51  | Wieland          | -X1  |   |                        |                                |                  |                    |                           |
| 1                 | Fuse UNIVAL  |                  | 1 A   | FTM              | -F25   |   |                        |                                |                  |                    |                           |
| 1                 | Fuse UNIVAL  |                  | 2 A   | FTM              | -F27   |   |                        |                                |                  |                    |                           |
| 1                 | Fuse UNIVAL  |                  | 5 A   | FTM              | -F100  |   |                        |                                |                  |                    |                           |
| 1                 | Fuse UNIVAL  |                  | 7.5 A   | FTM              | -F15   |   |                        |                                |                  |                    |                           |
| 2                 | Fuse UNIVAL  |                  | 10 A  | FTM              | -F32;-F37  |   |                        |                                |                  |                    |                           |
| 2                 | Fuse UNIVAL  |                  | 15 A  | FTM              | -F13;-F39  |   |                        |                                |                  |                    |                           |
| 1                 | Fuse UNIVAL  |                  | 30 A  | FTM              | -F30   |   |                        |                                |                  |                    |                           |
| 1                 | Fuse UNIVAL  |                  | 40 A  | FTM              | F31;-F51   |   |                        |                                |                  |                    |                           |
| 2                 | Resistor   |                  | 120 Ω   | Bürklin          | R10;-R12   |   |                        |                                |                  |                    |                           |
| 1                 | Resistor   |                  | 68 Ω  | Bürklin          | R3   |   |                        |                                |                  |                    |                           |
| 1                 | Diode  |                  | BY550-600   | Bürklin          | R2   |   |                        |                                |                  |                    |                           |
| 1                 | Voltage transformer                                  |                  | 6-16VDC/12VDC   | TDK-Lambda       | -T20   |   |                        |                                |                  |                    |                           |
| 1                 | Diagnostic socket KAESER                             |                  | 14-pole   | Boersig          | -X100  |   |                        |                                |                  |                    |                           |
| 1                 | switch Control voltage ON/OFF                        |                  | RKWA  | Schlegel         | -S10   |   |                        |                                |                  |                    |                           |
| 1                 | Switching element                                    |                  | BTLS-24VDC-2A   | Schlegel         | -S10   |   |                        |                                |                  |                    |                           |

\*)Veränderschritte - Kennzeichen

When ordering the equipment, all data enclosed by the heavy lines of columns B and C should be added. In addition, the data in column D is G should be given together with the No. of this list of equipment, insofar as they are helpful in answering technical enquiries. When ordering spare parts, product if stated on the rating plate.

The German version applies in cases of doubt.

Spalten B und C angegebene Daten dieser Gerätebestellungsnummer für Ersatzteilbestellung ist zusätzlich Erzeugnisname genannt ist.

Bei Nachbestellung von Geräten und Maschinen sind alle in den stark umrandeten aufzuführen. Die Daten in den Spalten D bis G sind zusätzlich unter Nennung anzugeben, soweit sie die Beantwortung technischer Rückfragen erleichtern. die Angabe der Seriennummer erforderlich, falls diese auf dem Typenschild des Erzeugnisses genannt ist.

In Zweifelsfällen gilt die deutsche Fassung.

|                      |  |                |  |                 |  |
|----------------------|--|----------------|--|-----------------|--|
| Equipment parts list |  | MOBILAIR M81.2 |  | Control cabinet |  |
| KAESER KOMPRESSOREN  |  | M81.2          |  | GFA81-03062.01  |  |
| Date                 |  | 30.06.2025     |  | page 1          |  |
| Drawn                |  | Seubert        |  | 3. Sht.         |  |
| Released             |  | Schroder       |  |                 |  |
| Name                 |  |                |  |                 |  |
| Date                 |  |                |  |                 |  |
| F. Change            |  |                |  |                 |  |





















Component layout  
MOBILAIR M81.2  
rear panel switchboard




M81.2


= +  
AFA81-03062.01

page 2  
2 Str.


**13.5.2 tc Connecting the lighting and signalling system**

|   |          |            |                      |   |   |   |   |        |
|---|----------|------------|----------------------|---|---|---|---|--------|
| 1   | 2        | 3          | 4                    | 5   | 6 | 7 | 8 |        |
| <div style="border: 1px solid black; padding: 10px; margin: 0 auto; width: 80%;"> <p style="font-size: 1.2em; margin: 0;">Electrical diagrams</p> <p style="font-size: 1.2em; margin: 0;">MOBILAIR</p> <p style="font-size: 1.2em; margin: 0;">Lighting equipment</p> <p style="font-size: 1.2em; margin: 0;">for EU-Right-hand traffic/Left-hand traffic</p> </div>  |          |            |                      |   |   |   |   |        |
| <p style="margin: 0;">Manufacturer: <b>KAESER KOMPRESSOREN SE</b></p> <p style="margin: 0;">Postfach 2143</p> <p style="margin: 0;">96410 Coburg</p>  |          |            |                      |   |   |   |   |        |
| <p style="font-size: 0.8em; margin: 0;">The drawings remain our exclusive property. They are entrusted only for the agreed purpose. Copies or any other reproductions, including storage, treatment and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions must be forwarded or otherwise made accessible to third parties.</p> |          |            |                      |   |   |   |   |        |
| c   | Date     | 21.02.2020 | E                    | <div style="display: flex; align-items: center; justify-content: center;"> <div style="text-align: left; font-size: 0.7em;"> <p>Cover page<br/>MOBILAIR</p> </div> </div> |   |   |   | =      |
| b   | Drawn    | Stier      | +                    |   |   |   |   |        |
| a   | Released | Fischer C. | DFAEURL.BEL-03047.00 |   |   |   |   |        |
| A   | Change   | Date       | Name                 | page  | 1 |   |   | 1 Stl. |






## 13.6 Assembly drawings



Drawings remain our exclusive property. They are intended only for the stated purpose. Copies or any other reproduction, including storage, training and dissemination by use of electronic systems may not be made for any other than the stated purpose. Neither originals nor reproductions may be given or made available to third parties. Die Zeichnungen sind unser ausschließliches Eigentum. Sie sind nur zu dem angegebenen Zweck und zur angegebenen Zeit zu verwenden. Jedes Weitergeben, Kopieren, Speichern, Kopieren, Weitergeben oder elektronische Weitergabe ist ohne unsere schriftliche Genehmigung ausdrücklich untersagt. Originalen und Kopien von Zeichnungen dürfen nicht an Dritte weitergegeben werden. Diese Zeichnungen sind ausschließlich für den angegebenen Zweck und zu dem angegebenen Zeitpunkt zu verwenden. Originalen und Kopien von Zeichnungen dürfen nicht an Dritte weitergegeben werden.


|   |                  |
|---|------------------|
| <b>KAESER</b><br>KOMPRESSOREN                             |                  |
| Zzeichnung/Nr.  | Original         |
| Service spare part drawing / Service Ersatzteil Zeichnung | Datum            |
| REG-Nummer  | Doc. 13.01.2023  |
| REG-16679   | PUFFI            |
|   | PUFFI            |
|   | Blatt            |
|   | Status FREILEGEN |
|   | 1 von 1          |

Blattgruppe  
Filter / Operating materials / Filter / Betriebsstoffe  
Document Nr.  
**ServiceKit (Option) | Subassembly / Untereinheit**



Drawing remains our exclusive property. They are granted only for the stated purpose. Copies or any other reproduction, including images, training and dissemination by use of electronic systems may not be made for any other than the agreed purpose. Neither originals nor reproductions may be given or made available to third parties. Die Zeichnungen bleiben unser ausschließliches Eigentum. Sie sind nur zu dem vereinbarten Zweck und nur für den vorgesehenen Zweck zu verwenden. Jegliche Vervielfältigung, Verbreitung, auch auszugsweise, ist ohne schriftliche Genehmigung unserer Firma. Die Weitergabe oder die Herstellung von Kopien, auch auszugsweise, ist ohne schriftliche Genehmigung unserer Firma. Original nicht weitergeben! Original nicht weitergeben! Original nicht weitergeben!


|   |   |                     |                  |
|---|---|---------------------|------------------|
| <b>KAESER</b>   |   | <b>KOMPRESSOREN</b> |                  |
| Zzeichnung/Nr.  | Document No.  | Original            | Datum            |
| Service spare part drawing / Service Ersatzteil Zeichnung |   |                     | 03x 28.11.2024   |
| SECC-Nummer   | (Service-Kit) (Option) (Subassembly / Untereinheit) |                     | Blatt            |
| 850-19877   |   |                     | Stand: FREILEGEN |
|   |   |                     | 1 von 1          |



Drawings remain our exclusive property. They are granted only for the stated purpose. Copies or other reproduction, including storage, training and dissemination by use of electronic systems may not be made for any other than the agreed purpose. Neither originals nor reproductions may be given to or made available to third parties. Die Zeichnungen sind unser alleiniges Eigentum. Sie sind nur zu dem vereinbarten Zweck anzuwenden und dürfen nicht an Dritte weitergegeben werden. Kopieren, Speicherung, Verbreitung oder andere Reproduktionen sind ohne unsere schriftliche Genehmigung nicht zulässig. Originalen Zeichnungen dürfen nicht an Dritte weitergegeben werden. Weder Originalen noch Kopien dürfen an Dritte weitergegeben werden.


|   |              |
|---|--------------|
| <b>KAESER</b><br>KOMPRESSOREN                             |              |
| Zeichnungs-Nr.  | Document Nr. |
| Service spare part drawing / Service Ersatzteil-Zeichnung |              |
| Original  | Datum        |
| Original  | 2011.2024    |
| Doc. No. 2011.2024  | PUFFI        |
| Doc. No. 2011.2024  | PUFFI        |
| Stand: FREILEGEN  | Blatt        |
| Stand: FREILEGEN  | 1 von 1      |
| <b>Service-Kit (Option)   Subassembly / Untereinheit</b>  |              |
| SECO-Nummer   | SECO-16679   |

Blattgruppe  
Drive / Cooling / Antrieb / Kühlung



Drawing remains our exclusive property. They are granted only for the stated purpose. Copies or any other reproduction, including images, training and dissemination by use of electronic systems must not be made for any other than the agreed purpose. Neither originals nor reproductions may be given to or made available to third parties. Die Zeichnung ist als unser alleiniges Eigentum. Sie wird nur zu dem angegebenen Zweck zur Verfügung gestellt. Das Kopieren oder die Weitergabe von Zeichnungen, die Weitergabe von Zeichnungen durch elektronische Systeme, die Weitergabe von Zeichnungen für Schulungszwecke, die Weitergabe von Zeichnungen für die Weitergabe von Zeichnungen durch elektronische Systeme, die Weitergabe von Zeichnungen für die Weitergabe von Zeichnungen durch elektronische Systeme ist ausdrücklich untersagt. Original von: Weitergabe von Zeichnungen durch elektronische Systeme ist ausdrücklich untersagt. Weitergabe von Zeichnungen durch elektronische Systeme ist ausdrücklich untersagt.

|  |                   |
|--|-------------------|
| <b>KAESER</b><br>KOMPRESSOREN                              |                   |
| Zachowig's   | Document Nr.      |
| Service spare part drawing / Service Ersatzteil Zeichnung  | Original          |
| REG-Nummer   | Doc. 2811.2024    |
| REG-16679  | Preis 2811.2024   |
|  | Stück FREIGELEBEN |
|  | Blatt 1 von 1     |
| <b>(Service-Kit) (Option) (Subassembly / Untereinheit)</b> |                   |
| Baugruppe / Fahrgestelle                                   |                   |



Drawings remain our exclusive property. They are granted only for the stated purpose. Copies or any other reproduction, including storage, training and dissemination by use of electronic systems may not be made for any other than the agreed purpose. Neither originals nor reproductions may be given to third parties. Die Zeichnungen sind unser ausschließliches Eigentum. Sie sind nur zu dem vereinbarten Zweck und zur vereinbarten Nutzung zu verwenden. Jegliche Vervielfältigung, Verbreitung, auch auszugsweise, ist ohne schriftliche Genehmigung der Kaeser Kompressoren GmbH. Für die Weitergabe dieser Unterlagen an Dritte ist eine schriftliche Genehmigung erforderlich. Original von: Vervielfältigen dürfen Dritte nicht. Weitergabe ist nur mit schriftlicher Genehmigung möglich.

|                               |                      |
|-------------------------------|----------------------|
| <b>KAESER</b><br>KOMPRESSOREN |                      |
| Zeichnungs-Nr.                | Document Nr.         |
| Original                      | Datum                |
| Obz. 28.11.2024               | PU/F1                |
| PU/F1                         | Skiz. Edge           |
| PU/F1                         | Blatt                |
| PU/F1                         | Stand: FREIGELEGEBEN |
| 1 von 1                       |                      |

Options / Optionen  
 Zeichnungs-Nr. / Document Nr.  
 Original / Datum  
 Obz. 28.11.2024 / PU/F1  
 PU/F1 / Skiz. Edge  
 PU/F1 / Blatt  
 PU/F1 / Stand: FREIGELEGEBEN  
 1 von 1

Service-Kit (Option) / Subassembly / Untereinheit

## 14 Glossary

This chapter provides an alphabetical index of technical terms with explanations.

|   |  |
|---|--|
| <b>Airend discharge temperature – ADT</b>         | Gaseous fluids become heated during the compression process. The temperature achieved at the end of the compression process is referred to as the "airend discharge temperature".  |
| <b>Diesel oxidation catalytic converter – DOC</b> | The diesel oxidation catalytic converter reduces the hydrocarbon and carbon monoxide components in diesel engine exhaust gases.  |
| <b>Diesel particulate filter – DPF</b>            | The diesel particulate filter reduces the quantity of soot particles present in diesel engine exhaust gases.   |
| <b>Engine control unit – ECU</b>                  | An electronic system (control unit) developed for a specific engine type that assumes the control, regulation and monitoring of engine functions.  |
| <b>Flow rate</b>                                  | <p>Flow rate is the volume of a gaseous or liquid fluid moving through a cross-section within a certain unit of time under defined conditions.</p> <p>In the case of compressed air generators, the continuously conveyed volume is commonly referred to as "delivery volume". The specified value relates to the volume of a compressed fluid in its expanded state under atmospheric conditions.</p> |
| <b>SIGMA CONTROL SMART – SCS</b>                  | SIGMA CONTROL SMART is a KAESER machine controller.  |
| <b>Vehicle identification number – VIN</b>        | International standardised 17-digit serial number with which a vehicle can be clearly identified.  |
| <b>Working pressure</b>                           | Pressure value above atmospheric pressure within a pressure system during operation.   |

## 15 Annexe

### 15.1 Code

#### 15.1.1 Labelling on the machine




Fig. 89 Labelling on the machine

- ① Options label
- ② Machine nameplate
- ③ Vehicle identification number

#### 15.1.2 Drive engine identification

The engine serial number is displayed on the nameplate.




Fig. 90 Drive engine identification

- ① Engine nameplate
- ② Drive engine
- ③ Engine nameplate position

## 15.2 Coolant recommendation

Prepare the coolant for liquid-cooled engines and monitor it at regular intervals.  
If the coolant or its components are of poor quality, damage to the drive engine is possible.

### 15.2.1 Water quality

The correct water quality is essential for preparing the coolant.

In general, clear, clean, and preferably soft fresh water should be used, in line with the following analysis values:

| Characteristic                             |          |
|--|----------|
| pH value                                   | 6.5– 8.0 |
| Chloride [mg/l]                            | max. 80  |
| Chloride + Sulphate [mg/l]                 | max. 160 |
| Alkaline earth ions [mmol/l] <sup>1)</sup> | 2.7      |
| Hardness [°dH] <sup>2)</sup>               | 15       |

1) 7.147 mg/l Ca<sup>2+</sup> or 4.336 mg/l Mg<sup>2+</sup>

2) 1°dH = 0.1783 mmol/l

Tab. 84 Water quality

Contact the local water utilities for information regarding water quality. If the water does not meet the above parameters, it must be treated.

If no suitable water is available, distilled or fully demineralised water must be used to prepare the coolant.

Seawater, brackish water, brine and industrial wastewater are not suitable. Salts may promote corrosion or lead to build-up of problematic residues.

### 15.2.2 Coolant quality

During the course of ongoing technical development, a new anti-corrosion agent/antifreeze has been approved by the engine manufacturer.

Advantages of the new anti-corrosion agent/antifreeze:

- Less residue in the engine cooling system
- Improved heat flow
- Improved environmental compatibility

The coolant is treated by the mixing of antifreeze with ethylene glycol-based anti-corrosion additives and water.

The coolant used must be in accordance with the stipulations of the engine manufacturer HATZ.

- Do not use an anti-corrosion agent/antifreeze that has not been approved by the engine manufacturer.
- Avoid impermissible mixing ratios of anti-corrosion agent/antifreeze and water.

### 15.2.3 Initial fill of anti-corrosion agent/antifreeze

For the initial fill, the coolant cooler is filled with a mixture of the following liquid components:

| Components                      | Designation                                       | Proportion [%] |
|---------------------------------|---|----------------|
| Anti-corrosion agent/antifreeze | KAESER FLUID ENGINE ANTIFREEZE<br>Glysantin® G40® | 50             |
| Water                           |   | 50             |

Tab. 85 Initial fill of coolant cooler

### 15.2.4 Miscibility with other anti-corrosion agents/antifreezes

Mixing with other anti-corrosion agents/antifreezes is not recommended, even if from the same manufacturer.

This can result in significantly reduced corrosion/antifreeze protection, which may damage the engine cooling system.

Mixtures of different anti-corrosion agents/antifreezes provide lower performance than the specially balanced active components of a single coolant type.



The use of other anti-corrosion agents/antifreezes is only permitted following consultation with and approval from the engine manufacturer.

## 15.3 **dd** Operating manual for the compressed air filter



## Filters for Compressed Air P010 - P055 (WS, A0, AA, ACS)

User Guide


(EN) Original Language



aerospace  
climate control  
electromechanical  
**filtration**  
fluid & gas handling  
hydraulics  
pneumatics  
process control  
sealing & shielding



ENGINEERING YOUR SUCCESS.



**(EN) ONE YEAR AIR QUALITY GUARANTEE**

Your air quality has been guaranteed for 1 year and will be renewed at every annual filter element change.

Annual filter element changes ensure:

- Optimal performance is maintained
- Air quality continues to meet international standards
- Protection of downstream equipment, personnel and processes
- Low operational costs
- increased productivity and profitability
- peace of mind

**(NL) LUCHTKWALITEITSGARANTIE VAN ÉÉN JAAR**

De luchtkwaliteit wordt 1 jaar lang gegarandeerd. De garantie wordt elk jaar verlengd wanneer het filterelement wordt vervangen.

Een jaarlijkse vervanging van het filterelement heeft de volgende voordelen:

- Een onverminderde optimale prestatie
- Luchtkwaliteit die blijft voldoen aan de internationale normen
- Bescherming van apparatuur, personeel en processen achter de compressor
- Lage bedrijfskosten
- Hogere productiviteit en rentabiliteit
- Gemoedsrust

**(DE) EIN JAHR GARANTIE AUF DIE LUFTQUALITÄT**

Wir gewähren Ihnen eine 1-jährige Garantie auf die Luftqualität, die bei jedem jährlichen Austausch des Filterelements erneuert wird.

Ein jährlicher Austausch des Filterelements stellt Folgendes sicher:

- Optimale Leistung wird gewährleistet
- Die Luftqualität erfüllt weiterhin internationale Standards
- Schutz der nachgeschalteten Geräte, der Arbeitskräfte und Produktionsabläufe
- Geringe Betriebskosten
- Höhere Produktivität und Wirtschaftlichkeit
- Sorgenfreiheit

**(FR) QUALITÉ DE L'AIR GARANTIE PENDANT 1 AN**

La qualité de l'air est garantie pendant 1 an, garantie renouvelable à chaque remplacement annuel la de cartouche filtrante.

Le remplacement annuel des cartouches filtrantes garantit :

- La préservation de performances optimales
- Une qualité de l'air conforme aux normes internationales
- Une protection de l'équipement, des processus et du personnel en aval
- Des coûts d'utilisation réduits
- Un niveau de productivité et de rentabilité accru
- Votre tranquillité d'esprit

**(ES) GARANTÍA DE CALIDAD DEL AIRE PARA UN AÑO**

La calidad del aire tiene una garantía de 1 año y se renovará con cada cambio anual del filtro

El cambio anual del filtro le asegura:

- Se mantiene un rendimiento óptimo.
- La calidad del aire sigue cumpliendo las normas internacionales
- Protección del equipo, personal y procesos aguas abajo.
- Bajos costes de funcionamiento.
- mayor productividad y rentabilidad.
- tranquilidad.

**(IT) GARANZIA DI UN ANNO SULLA QUALITÀ DELL'ARIA**

La qualità dell'aria è garantita per un anno e la garanzia sarà rinnovata dopo ogni sostituzione annuale dell'elemento filtrante.

La sostituzione annuale dell'elemento filtrante assicura:

- Prestazioni ottimali nel tempo
- Aria di qualità sempre conforme alle norme internazionali
- Protezione del personale, delle apparecchiature e dei processi a valle
- Bassi costi di esercizio
- Maggiore produttività e redditività
- Tranquillità



⑤ Model Coding example:

| Model                 |                                  |                             |  |                     |                         |                                  |
|-----------------------|----------------------------------|-----------------------------|--|---------------------|-------------------------|----------------------------------|
| Element Grade         | Premium Energy Efficient Element | Model Size                  | Port Size  | Thread Type         | Drain Option            | DP Indicator                     |
| WS<br>AO<br>AA<br>ACS | P                                | 3 digit code as shown below | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Float<br>M = Manual | X = None<br>I = Incident Monitor |
| AA                    | P                                | 030                         | A  | G                   | F                       | I                                |

⑥ Voorbeeld van model codering:

| Model                 |                                   |  |  |                     |                              |                                 |
|-----------------------|-----------------------------------|--|--|---------------------|------------------------------|---------------------------------|
| Elementklasse         | Premium energie-efficiënt element | Afmetingen model                           | Poortafmeting  | Schroefdraadtype    | afvoer (optioneel)           | DP-indicator                    |
| WS<br>AO<br>AA<br>ACS | P                                 | 3-cijferige code zoals hieronder afgebeeld | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Flotter<br>M = Handmatig | X = Geen<br>I = Incidentmonitor |
| AA                    | P                                 | 030  | A  | G                   | F                            | I                               |

⑦ Beispiel für Modellschlüssel:

| Modell                |  |  |  |                     |                            |  |
|-----------------------|--|--|--|---------------------|----------------------------|--|
| Element-Klasse        | Energieeffizientes Element der Premiumklasse | Baugröße                                 | Anschlussgröße   | Gewindetyp          | Entleerung                 | DD-Anzeige                             |
| WS<br>AO<br>AA<br>ACS | P  | Dreistelliger Code wie unten dargestellt | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Schwimmer<br>M = Hand- | X = Keine<br>I = Verschmutzungsanzeige |
| AA                    | P  | 030                                      | A  | G                   | F                          | I                                      |

⑧ Exemple de code de modèle:

| Modèle                |  |                                    |  |                     |                                  |   |
|-----------------------|--|------------------------------------|--|---------------------|----------------------------------|---|
| Grade d'élément       | Élément de rendement énergétique de qualité supérieure | Dimensions du modèle               | Taille de l'orifice  | Type de filetage    | Option de purge                  | Indicateur PD                           |
| WS<br>AO<br>AA<br>ACS | P  | Code à 3 chiffres (ex. ci-dessous) | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Flotteur<br>M = Réactivation | X = Aucun<br>I = Contrôle des incidents |
| AA                    | P  | 030                                | A  | G                   | F                                | I                                       |

**㉔** Ejemplo de códigos de modelos:

| Modelo                |  |   |  |                     |                            |   |
|-----------------------|--|---|--|---------------------|----------------------------|---|
| Grado del elemento    | Elemento eficiente energéticamente premium | Tamaño del modelo   | Tamaño de puerto   | Tipo de rosca       | Opción de drenaje          | Indicador DP                              |
| WS<br>AO<br>AA<br>ACS | P  | Código de 3 dígitos, tal y como se muestra a continuación | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Flotador<br>M = Manual | X = Ninguno<br>I = Monitor de incidencias |
| AA                    | P  | 030   | A  | G                   | F                          | I   |

**㉕** Esempio di codifica dei

| Modello               |   |   |  |                     |                                    |                                      |
|-----------------------|---|---|--|---------------------|------------------------------------|--------------------------------------|
| Tipo elemento         | Elemento ad efficienza energetica Premium | Dimensioni modello                        | Dimensioni attacco   | Tipo di filettatura | Opzione di scarico                 | Indicatore DP                        |
| WS<br>AO<br>AA<br>ACS | P   | Codice a 3 cifre come indicato di seguito | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Galleggiante<br>M = Ripristino | X = Nessuno<br>I = Monitor criticità |
| AA                    | P   | 030                                       | A  | G                   | F                                  | I                                    |

**㉖** Product Selection

Stated flows are for operation at 7 bar g (100 psi g) with reference to 20°C, 1 bar a, 0% relative water vapour pressure. For flows at other pressures apply the correction factors shown.

**㉗** Productselectie

De weergegeven stroomsnelheden zijn voor een werking bij 7 bar (g) (100 psi g) met betrekking tot 20°C, 1 bar (a), 0% relatieve waterdampdruk. Voor stroomsnelheden bij andere drukverhoudingen dient u de vermelde correctiefactoren toe te passen.

**㉘** Produktauswahl

Die angegebenen Durchflussraten beziehen sich auf den Betrieb bei 7 bar ü (100 psi g), 20 °C, 1 bar ü und einem relativen Wasserdampfdruck von 0 %. Wenden Sie zur Bestimmung der Durchflussraten bei anderen Drücken die angegebenen Korrekturfaktoren an.

**㉙** Choix du produit

Les débits indiqués correspondent à un fonctionnement à une pression de 7 bar eff (100 psi eff) et aux conditions de référence suivantes : 20 °C, 1 bar (a) et 0 % de pression de vapeur d'eau relative. Pour les débits de pression différente, appliquez les facteurs de correction indiqués.

**㉚** Selección de productos

Los caudales se indican para el funcionamiento a 7 bar g (100 psi g), referidos a 20 °C (1 bar) y presión relativa del vapor de agua del 0%. Para caudales a otras presiones, aplique los factores de corrección que se muestran.

**㉛** Scelta del prodotto

Le portate indicate si riferiscono al funzionamento con una pressione di 7 bar g (100 psi g) a 20°C, 1 bar a, pressione relativa del vapore acqueo 0%. Per altri valori di pressione applicare i fattori di correzione indicati.

### Water Separator Flow Rates

Stroomsnelheden waterafscheider, Durchflusswerte des Wasserabscheiders, Débit du séparateur d'eau, Caudales del separador de agua, Portate del separatore d'acqua

| Model                | Port Size | L/s | m3/min | m3/hr | cfm  |
|----------------------|-----------|-----|--------|-------|------|
| WS P010A [ ] [ ] [ ] | ¼         | 10  | 0.6    | 36    | 21   |
| WS P010B [ ] [ ] [ ] | ¾         | 10  | 0.6    | 36    | 21   |
| WS P010C [ ] [ ] [ ] | ½         | 10  | 0.6    | 36    | 21   |
| WS P015C [ ] [ ] [ ] | ½         | 40  | 2.4    | 144   | 85   |
| WS P020D [ ] [ ] [ ] | ¾         | 40  | 2.4    | 144   | 85   |
| WS P025D [ ] [ ] [ ] | ¾         | 110 | 6.6    | 396   | 233  |
| WS P025E [ ] [ ] [ ] | 1         | 110 | 6.6    | 396   | 233  |
| WS P030G [ ] [ ] [ ] | 1 ½       | 110 | 6.6    | 396   | 233  |
| WS P035G [ ] [ ] [ ] | 1 ½       | 350 | 21.0   | 1260  | 742  |
| WS P040H [ ] [ ] [ ] | 2         | 350 | 21.0   | 1260  | 742  |
| WS P045I [ ] [ ] [ ] | 2 ½       | 350 | 21.0   | 1260  | 742  |
| WS P050I [ ] [ ] [ ] | 2 ½       | 800 | 48.0   | 2880  | 1695 |
| WS P055J [ ] [ ] [ ] | 3         | 800 | 48.0   | 2880  | 1695 |

### CFP - Correction Factor Minimum Inlet Pressure (Water Separators)

CFP - Correctiefactor minimale inlaatdruk (waterafschers), CFP – Korrekturfaktor minimaler Einlassdruck (Wasserabscheider), CFP – Facteur de correction de la pression d'admission minimale (Séparateurs d'eau), CFP: factor de corrección de presión mínima de entrada (separadores de agua), CFP - Fattore di correzione della pressione minima di ingresso (separatori d'acqua),

| Minimum Inlet Pressure | bar g | 1    | 2    | 3    | 4    | 5    | 6    | 7    | 8    | 9    | 10   | 11   | 12   | 13   | 14   | 15   | 16   |
|------------------------|-------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
|                        | psi g | 15   | 29   | 44   | 58   | 73   | 87   | 100  | 116  | 131  | 145  | 160  | 174  | 189  | 203  | 218  | 232  |
| Correction Factor      |       | 4.00 | 2.63 | 2.00 | 1.59 | 1.33 | 1.14 | 1.00 | 0.94 | 0.89 | 0.85 | 0.82 | 0.79 | 0.76 | 0.73 | 0.71 | 0.68 |

### Filter Flow Rates

Stroomsnelheid filter, Filter-Durchflussraten, Débits du filtre, Caudales del filtro, Portate del filtro

| Model                     | Port Size | L/s | m3/min | m3/hr | cfm  | Replacement Element kit | No. |
|---------------------------|-----------|-----|--------|-------|------|-------------------------|-----|
| [grade] P010A [ ] [ ] [ ] | ¼         | 10  | 0.6    | 36    | 21   | P010 [grade]            | 1   |
| [grade] P010B [ ] [ ] [ ] | ¾         | 10  | 0.6    | 36    | 21   | P010 [grade]            | 1   |
| [grade] P010C [ ] [ ] [ ] | ½         | 10  | 0.6    | 36    | 21   | P010 [grade]            | 1   |
| [grade] P015C [ ] [ ] [ ] | ½         | 20  | 1.2    | 72    | 42   | P015 [grade]            | 1   |
| [grade] P020C [ ] [ ] [ ] | ½         | 30  | 1.8    | 108   | 64   | P020 [grade]            | 1   |
| [grade] P020D [ ] [ ] [ ] | ¾         | 30  | 1.8    | 108   | 64   | P020 [grade]            | 1   |
| [grade] P025D [ ] [ ] [ ] | ¾         | 60  | 3.6    | 216   | 127  | P025 [grade]            | 1   |
| [grade] P025E [ ] [ ] [ ] | 1         | 60  | 3.6    | 216   | 127  | P025 [grade]            | 1   |
| [grade] P030G [ ] [ ] [ ] | 1 ½       | 110 | 6.6    | 396   | 233  | P030 [grade]            | 1   |
| [grade] P035G [ ] [ ] [ ] | 1 ½       | 160 | 9.6    | 576   | 339  | P035 [grade]            | 1   |
| [grade] P040H [ ] [ ] [ ] | 2         | 220 | 13.2   | 792   | 466  | P040 [grade]            | 1   |
| [grade] P045I [ ] [ ] [ ] | 2 ½       | 330 | 19.8   | 1188  | 699  | P045 [grade]            | 1   |
| [grade] P050I [ ] [ ] [ ] | 2 ½       | 430 | 25.8   | 1548  | 911  | P050 [grade]            | 1   |
| [grade] P055I [ ] [ ] [ ] | 2 ½       | 620 | 37.3   | 2232  | 1314 | P055 [grade]            | 1   |
| [grade] P055J [ ] [ ] [ ] | 3         | 620 | 37.3   | 2232  | 1314 | P055 [grade]            | 1   |

[grade] = grade  
 [Klasse] = Klasse  
 [Klasse] = Klasse  
 [grade] = grade  
 [grado] = grado  
 [grado] = grado

**CFP - Correction Factor Minimum Inlet Pressure (Coalescing and Dry Particulate Filters)**

CFP - Correctiefactor minimale inlaatdruk (coalescentiefilters en drogedeeltesfilters), CFP – Korrekturfaktor minimaler Einlassdruck (Koaleszenz- und Trockenpartikelfilter), CFP – Facteur de correction de la pression d'admission minimale (Filtres coalescents et à particules sèches), CFP: factor de corrección de presión mínima de entrada (filtros de partículas secas y coalescentes), CFP - Fattore di correzione della pressione minima di ingresso (filtri anti-particolato a coalescenza e per particolato asciutto)

| Minimum Inlet Pressure   | bar g | 1    | 2    | 3    | 4    | 5    | 6    | 7    | 8    | 9    | 10   | 11   | 12   | 13   | 14   | 15   | 16   | 17   | 18   | 19   | 20   |
|--------------------------|-------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
|                          | psi g | 15   | 29   | 44   | 58   | 73   | 87   | 100  | 116  | 131  | 145  | 160  | 174  | 189  | 203  | 218  | 232  | 248  | 263  | 277  | 290  |
| <b>Correction Factor</b> |       | 2.65 | 1.87 | 1.53 | 1.32 | 1.18 | 1.08 | 1.00 | 0.94 | 0.88 | 0.84 | 0.80 | 0.76 | 0.73 | 0.71 | 0.68 | 0.66 | 0.64 | 0.62 | 0.61 | 0.59 |

**Product Selection and Correction Factors**

To correctly select a Water Separator or Filter model, the flow rate of the filter must be adjusted for the minimum operating pressure of the system.

- 1 Obtain the minimum operating pressure and maximum compressed air flow rate at the inlet of the Water Separator or Filter.
- 2 Select the correction factor for minimum operating pressure from the CFP table (always round down e.g. for 5.3 bar, use 5 bar correction factor)
- 3 Calculate the minimum filtration capacity. Minimum Filtration Capacity = Compressed Air Flow Rate x CFP
- 4 Using the minimum filtration capacity, select a Water Separator or Filter model from the flow rate tables above (Water Separator or Filter selected must have a flow rate equal to or greater than the minimum filtration capacity).

**Productselectie en correctiefactoren**

Om het juiste waterafscheidings- of filtermodel te selecteren, dient u de stroomsnelheid van het filter aan te passen aan de minimale bedrijfsdruk van het systeem.

- 1 Bepaal de minimale bedrijfsdruk en de maximale stroomsnelheid van de perslucht bij de inlaat van de waterafscheider of het filter.
- 2 Kies de correctiefactor voor de minimale bedrijfsdruk uit de CFP-tabel (altijd naar beneden afronden, bijv. bij 5,3 bar gebruikt u 5 bar als correctiefactor).
- 3 Bereken de minimale filtratiecapaciteit. Minimale filtratiecapaciteit = persluchtstroming x CFP
- 4 Selecteer een filtermodel uit de bovenstaande tabel met stroomsnelheden aan de hand van de minimale filtercapaciteit (de stroomsnelheid van het geselecteerde filter moet gelijk zijn aan of hoger zijn dan de minimale filtercapaciteit).

**Produktauswahl und Korrekturfaktoren**

Zur richtigen Auswahl eines Wasserabscheiders oder Filtermodells muss die Durchflussrate des Filters entsprechend dem Mindestbetriebsdruck des Systems gewählt werden.

- 1 Bestimmen Sie den Mindestbetriebsdruck sowie die maximale Druckluftdurchflussrate am Einlass des Wasserabscheiders oder Filtereinlass.
- 2 Wählen Sie den Korrekturfaktor für den Mindestbetriebsdruck aus der CFP-Tabelle aus (immer abrunden, d. h. bei 5,3 bar einen Korrekturfaktor von 5 bar auswählen).
- 3 Berechnen Sie die Mindestfiltrationsleistung. Mindestfiltrationsleistung = Druckluftdurchflussrate x CFP (Korrekturfaktor)
- 4 Wählen Sie anhand der Mindestfiltrationsleistung einen Wasserabscheider oder Filter aus den obigen Tabellen mit der Durchflussrate (die Durchflussrate des ausgewählten Wasserabscheiders oder Filters muss gleich oder größer der Mindestfiltrationsleistung sein).

**Sélection du produit et facteurs de correction**

Pour sélectionner le bon modèle de filtre ou de séparateur d'eau, il convient de régler le débit du filtre en fonction de la pression de service minimale du système.

- 1 Déterminez la pression de service minimale et le débit d'air comprimé maximal au niveau de l'admission du séparateur d'eau ou du filtre.
- 2 Dans le tableau Facteurs de correction de pression (CFP), sélectionnez le facteur de correction correspondant à la pression de fonctionnement minimale (arrondissez toujours au chiffre inférieur. P. ex., pour 5,3 bar, utilisez un facteur de correction de 5 bar).
- 3 Calculez la capacité de filtration minimale. Capacité de filtration minimale = Débit d'air comprimé x CFP
- 4 À l'aide de la capacité de filtration minimale, sélectionnez un modèle de séparateur d'eau ou de filtre dans les tableaux de présentation des débits ci-dessus (le débit du séparateur d'eau ou du filtre sélectionné doit être égal ou supérieur à la capacité de filtration minimale).

**Selección de productos y factores de corrección**

Para seleccionar correctamente un modelo de filtro o separador de agua, el caudal del filtro se debe ajustar a la presión de trabajo mínima del sistema.

- 1 Determine la presión de trabajo mínima y el caudal máximo de aire comprimido en la entrada del filtro o del separador de agua.
- 2 Seleccione en la tabla de factores de corrección de presión (CFP) el factor de corrección para la presión de trabajo mínima (redondee siempre a la baja: por ejemplo, en el caso de 5,3 bar, utilice el factor de corrección correspondiente a 5 bar).
- 3 Calcule la capacidad mínima de filtración. Capacidad mínima de filtración = Caudal de aire comprimido x CFP
- 4 Use la capacidad mínima de filtración para seleccionar un modelo de separador de agua o filtro de las tablas de caudal anteriores (el separador de agua o el filtro seleccionados deben tener un caudal igual o superior a la capacidad mínima de filtración).

**Selezione dei prodotti e fattori di correzione**

Per selezionare il separatore d'acqua o modello di filtro corretto, regolare la portata del filtro per la pressione di esercizio minima dell'impianto.

- 1 Ricavare la pressione di esercizio minima e la portata massima dell'aria compressa all'ingresso del separatore d'acqua o del filtro.
- 2 Selezionare il fattore di correzione per la pressione di esercizio minima indicato nella tabella CFP (arrotondare sempre per difetto: ad esempio, per 5,3 bar scegliere il fattore di correzione 5 bar)
- 3 Calcolare la capacità di filtrazione minima. Capacità di filtrazione minima = Portata aria compressa x CFP
- 4 Considerando la capacità di filtrazione minima ottenuta, selezionare un separatore d'acqua o un modello del filtro dalla tabella in alto relativa alle portate (la portata del separatore d'acqua o del filtro selezionato deve essere pari o superiore alla capacità di filtrazione minima)

**Technical Data**


Technische gegevens, Technische Daten, Données techniques, Datos técnicos, Dati tecnici

| Model | Filter Models |     |     |   |     |   |     |     | Min Operating Pressure |       | Max Operating Pressure |       | Min Recommended Operating Temp |    | Max Recommended Operating Temp |    |    |     |     |
|-------|---------------|-----|-----|---|-----|---|-----|-----|------------------------|-------|------------------------|-------|--------------------------------|----|--------------------------------|----|----|-----|-----|
|       |               |     |     |   |     |   |     |     | bar g                  | psi g | bar g                  | psi g | °C                             | °F | °C                             | °F |    |     |     |
| WS    | P010          | [ ] | [ ] | F | [ ] | - | 055 | [ ] | [ ]                    | F     | [ ]                    | 1     | 15                             | 16 | 232                            | 2  | 35 | 80  | 176 |
| AO    | P010          | [ ] | [ ] | F | [ ] | - | 055 | [ ] | [ ]                    | F     | [ ]                    | 1     | 15                             | 16 | 232                            | 2  | 35 | 80  | 176 |
| AO    | P010          | [ ] | [ ] | M | [ ] | - | 055 | [ ] | [ ]                    | M     | [ ]                    | 1     | 15                             | 20 | 290                            | 2  | 35 | 100 | 212 |
| AA    | P010          | [ ] | [ ] | F | [ ] | - | 055 | [ ] | [ ]                    | F     | [ ]                    | 1     | 15                             | 16 | 232                            | 2  | 35 | 80  | 176 |
| AA    | P010          | [ ] | [ ] | M | [ ] | - | 055 | [ ] | [ ]                    | M     | [ ]                    | 1     | 15                             | 20 | 290                            | 2  | 35 | 100 | 212 |
| ACS   | P010          | [ ] | [ ] | M | [ ] | - | 055 | [ ] | [ ]                    | M     | [ ]                    | 1     | 15                             | 20 | 290                            | 2  | 35 | 50  | 122 |

Note: AO / AA / WS grade filters for use up to 16 bar g (232 psi g) are supplied with a float drain [F] as standard.  
For pressures between 16 and 20 bar g (232 and 290 psi g) a manual drain [M] must be used.  
ACS grade filters are supplied with a manual drain [M] as standard.

**Weights and Dimensions**

Gewichten en afmetingen, Gewichte und Abmessungen, Poids et dimensions, Pesos y dimensiones, Pesi e dimensioni



| Model      | Pipe Size | Height (H) |       | Width (W) |      | Depth (D) |      | (a) |      | (b) |      | (c) |      | (d) |     | Weight |       |
|------------|-----------|------------|-------|-----------|------|-----------|------|-----|------|-----|------|-----|------|-----|-----|--------|-------|
|            |           | mm         | ins   | mm        | ins  | mm        | ins  | mm  | ins  | mm  | ins  | mm  | ins  | mm  | ins | kg     | lbs   |
| WS / P010A | ¼"        | 180        | 7.09  | 76        | 2.99 | 66        | 2.60 | 154 | 6.1  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 0.61   | 1.34  |
| WS / P010B | ⅜"        | 180        | 7.09  | 76        | 2.99 | 66        | 2.60 | 154 | 6.1  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 0.61   | 1.34  |
| WS / P010C | ½"        | 180        | 7.09  | 76        | 2.99 | 66        | 2.60 | 154 | 6.1  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 0.61   | 1.34  |
| WS / P015C | ½"        | 238.5      | 9.36  | 89        | 3.5  | 83.5      | 3.29 | 202 | 8.0  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 1.16   | 2.55  |
| P020C      | ½"        | 238.5      | 9.36  | 89        | 3.5  | 83.5      | 3.29 | 202 | 8.0  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 1.12   | 2.58  |
| WS / P020D | ¾"        | 238.5      | 9.36  | 89        | 3.5  | 83.5      | 3.29 | 202 | 8.0  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 1.12   | 2.58  |
| WS / P025D | ¾"        | 227        | 10.9  | 120       | 4.72 | 114.5     | 4.5  | 232 | 9.1  | 70  | 2.76 | 32  | 1.3  | 38  | 1.5 | 2.21   | 4.86  |
| WS / P025E | 1"        | 227        | 10.9  | 120       | 4.72 | 114.5     | 4.5  | 232 | 9.1  | 70  | 2.76 | 32  | 1.3  | 38  | 1.5 | 2.21   | 4.86  |
| WS / P030G | 1 ½"      | 367        | 14.45 | 120       | 4.72 | 114.5     | 4.5  | 323 | 12.7 | 70  | 2.76 | 32  | 1.3  | 38  | 1.5 | 2.68   | 5.91  |
| WS / P035G | 1 ½"      | 531        | 20.9  | 164       | 6.46 | 156       | 6.10 | 384 | 15.1 | 100 | 3.94 | 68  | 2.68 | 38  | 1.5 | 6.90   | 15.20 |
| WS / P040H | 2"        | 623        | 24.5  | 164       | 6.46 | 156       | 6.10 | 476 | 18.7 | 100 | 3.94 | 68  | 2.68 | 38  | 1.5 | 7.30   | 16.10 |
| WS / P045I | 2 ½"      | 623        | 24.5  | 164       | 6.46 | 156       | 6.10 | 476 | 18.7 | 100 | 3.94 | 68  | 2.68 | 38  | 1.5 | 7.10   | 15.65 |
| WS / P050I | 2 ½"      | 745        | 29.3  | 192       | 7.56 | 183       | 7.20 | 587 | 23.1 | 120 | 4.72 | 68  | 2.68 | 38  | 1.5 | 10.30  | 22.71 |
| P055I      | 2 ½"      | 935        | 36.8  | 192       | 7.56 | 183       | 7.20 | 772 | 30.4 | 120 | 4.72 | 68  | 2.68 | 38  | 1.5 | 15.30  | 33.73 |
| WS / P055J | 3"        | 935        | 36.8  | 192       | 7.56 | 183       | 7.20 | 772 | 30.4 | 120 | 4.72 | 68  | 2.68 | 38  | 1.5 | 15.30  | 33.73 |

Note: Water Separators do not include a DP Indicator, use dimension H + d for the total height.

**EN Installation recommendations**

It is recommended that the compressed air is treated prior to entry into the distribution system and also at critical usage points / applications.

Installation of compressed air dryers to a previously wet system could result in additional dirt loading for point of use filters for a period whilst the distribution system dries out. Filter elements may need to be changed more frequently during this period.

For installations where oil-free compressors are used, water aerosol and particulate are still present, general purpose and high efficiency grades should still be used.

A general purpose filter must always be installed to protect the high efficiency filter from bulk liquid aerosols and solid particulate.

Install purification equipment at the lowest temperature above freezing point, preferably downstream of after coolers and air receivers.

Point of use purification equipment should be installed as close to the application as possible.

Purification equipment should not be installed downstream of quick opening valves and should be protected from possible reverse flow or other shock conditions.

Purge all piping leading to the purification equipment before installation and all piping after the purification equipment is installed and before connection to the final application.

If by-pass lines are fitted around purification equipment, ensure adequate filtration is fitted to the by-pass line to prevent contamination of the system downstream.

Fit drain lines from the coalescing filters directly to a condensate separator. If it is not possible to connect the drain lines directly to a separator, the lines should be vented in to a condensate manifold (vented at one end) and then in to a single inlet of a condensate separator.

Provide a facility to drain away collected liquids from the purification equipment. Collected liquids should be treated and disposed of in a responsible manner.

**NL Aanbevelingen voor de installatie**

Aanbevolen wordt de perslucht te zuiveren voordat de lucht in het distributiesysteem wordt toegelaten, en ook bij kritieke gebruikspunten of -toepassingen.

De aansluiting van persluchtdrogers op een systeem dat nat was, kan extra vuilophoping veroorzaken bij de gebruikspuntfilters terwijl het distributiesysteem uitdroogt. Het is mogelijk dat gedurende deze periode de filterelementen vaker vervangen moeten worden.

Voor installaties met olie-vrije compressoren, waarin water-aërosols en deeltjes nog steeds aanwezig zijn, moeten filters voor algemeen gebruik en filters met een hoge efficiëntiegraad worden gebruikt.

Een filter voor algemeen gebruik moet altijd geïnstalleerd worden om het filter met hoge efficiëntiegraad tegen bulkvloeistof-aërosols en vaste deeltjes te beschermen.

Installeer zuiveringsapparatuur op de laagste temperatuur boven het vriespunt, bij voorkeur op een punt in het systeem na de nakoelers en luchtontvangers.

De zuiveringsapparatuur bij gebruikspunten moet zo dicht mogelijk bij de applicatie geïnstalleerd worden.

Zuiveringsapparatuur dient niet op een punt in het systeem na snel-openende kleppen te worden geïnstalleerd en moet worden beschermd tegen mogelijke tegenstroom of andere schoksituaties.

Reinig alle leidingen naar de zuiveringsapparatuur voorafgaand aan de installatie en ook nadat de zuiveringsapparatuur is geïnstalleerd, voorafgaand aan de aansluiting op de definitieve applicatie.

Als er omloopleidingen rond de zuiveringsapparatuur zijn gemonteerd, zorg er dan voor dat er voldoende filtering bij deze leidingen bestaat om te voorkomen dat het systeem verderop vervuild raakt.

Bevestig de afvoerleidingen van de coalescentiefilters direct aan een condensaatafscheider. Als het niet mogelijk is om de afvoerleidingen direct op een afscheider aan te sluiten, moeten de leidingen worden ontlucht in een condensaatverdeelstuk (dat aan één zijde wordt ontlucht) en daarna in een enkele inlaat van een condensaatafscheider.

Zorg ervoor dat het mogelijk is om de verzamelde vloeistof uit het zuiveringssysteem af te voeren. Deze vloeistof moet eerst worden gezuiverd en dan op verantwoorde wijze van de hand worden gedaan..

**DE Installationsempfehlungen**

Es wird empfohlen, die Druckluft vor dem Eintritt in das Verteilungssystem bzw. in kritische Einsatzstellen/Anwendungspunkte aufzubereiten.

Der Anschluss von Drucklufttrocknern an Systeme, die zuvor nass waren, könnte während der Trocknung des Verteilungssystems bei eingebauten Filtern zu einer zusätzlichen Verschmutzung führen. Die Filterelemente sind in dieser Phase ggf. häufiger auszutauschen.

Bei Einrichtungen, in denen ölfreie Kompressoren eingesetzt werden und noch Wassertropfen und Schmutzpartikel vorhanden sind, müssen universelle und Hochleistungsfilter verwendet werden.

Zum Schutz des Hochleistungsfilters vor großen Mengen an Flüssigkeitstropfen und festen Schmutzpartikeln muss immer ein universeller Filter vorgeschaltet werden.

Installieren Sie den Filter bei der niedrigsten Temperatur über dem Gefrierpunkt vorzugsweise hinter den Nachkühlern und Luftbehältern.

Der Einsatzort des Filters muss sich in unmittelbarer Nähe zur Anwendung befinden.

Der Filter darf sich schnell öffnenden Ventilen nicht nachgeschaltet werden. Außerdem muss ein Schutz gegen Rückfluss und andere Schockzustände gewährleistet sein.

Spülen Sie alle zum Filter führenden Rohrleitungen vor der Installation sowie nach der Installation des Filters und auch vor dem Anschluss an die endgültige Anwendung.

Sofern Bypass-Leitungen den Filter umgehen, muss zum Schutz des nachgeschalteten Systems gegen Verschmutzung für eine ausreichende Filterung dieser Leitungen gesorgt werden.

Führen Sie Ablassleitungen von den Koaleszenzfiltern direkt zu einem Kondensatabscheider. Wenn es nicht möglich ist, die Ablassleitungen direkt an einen Abscheider anzuschließen, müssen die Leitungen an ein Kondensatsammelrohr (mit Entlüftung an einem Ende) und dann an einen einzelnen Einlass eines Kondensatabscheiders angeschlossen werden.

Sorgen Sie für eine Einrichtung, die angesammelte Flüssigkeit von dem Filter entfernt. Die angesammelte Flüssigkeit muss sicher aufbereitet und entsorgt werden.

**FR Consignes d'installation**

Il est recommandé de traiter l'air comprimé avant l'entrée dans le système de distribution, ainsi qu'au niveau des applications/points d'utilisation stratégiques.

L'installation d'un sécheur à air comprimé sur un ancien système humide peut entraîner une teneur en poussière supplémentaire pour les points d'utilisation des filtres pendant la période durant laquelle le système de distribution sèche. Il sera peut-être nécessaire de changer les cartouches filtrantes plus souvent au cours de cette période.

Pour les installations équipées de compresseurs sans huile et où des particules et un aérosol d'eau sont toujours présents, il faut continuer d'utiliser des filtres polyvalents et des filtres haute efficacité.

Un filtre polyvalent doit toujours être installé pour protéger le filtre haute efficacité des aérosols de liquide en masse et des particules solides.

Installez l'équipement de purification à la température la plus basse avant le point de gel, de préférence en aval des réfrigérants et des collecteurs d'air.

L'équipement de purification au point d'utilisation doit être installé aussi près que possible de l'application.

L'équipement de purification ne doit pas être installé en aval de soupapes à ouverture rapide et doit être protégé d'un éventuel flux en sens inverse ou des chocs.

Purgez tous les conduits menant à l'équipement de purification avant l'installation, et recommencez une fois l'équipement installé et avant la connexion à l'application finale.

Si des conduites de dérivation sont en place autour de l'équipement de purification, assurez-vous qu'un élément filtrant approprié est monté sur la conduite de dérivation pour éviter la contamination du système en aval.

Installez directement les conduites d'évacuation des filtres coalescents sur un séparateur de condensation. S'il n'est pas possible de raccorder directement les conduites à un séparateur, elles doivent disposer d'une évacuation vers un collecteur de condensation (avec une extrémité d'évacuation), puis vers un séparateur de condensation à entrée unique.

Installez un dispositif permettant d'évacuer les liquides collectés dans l'équipement de purification. Ces liquides doivent être traités et éliminés comme il convient.

**ES Recomendaciones de instalación**

Se recomienda tratar el aire comprimido antes de que entre en el sistema de distribución y también en aplicaciones o puntos de utilización críticos.

La instalación de secadores de aire comprimido en un sistema húmedo existente puede producir una carga de suciedad adicional en los puntos de uso de los filtros durante un tiempo, hasta que el sistema de distribución se seque. Filter elements may need to be changed more frequently during this period.

En instalaciones que utilicen compresores sin aceite, sigue habiendo aerosoles de agua y partículas, por lo que deben utilizarse filtros de grados de alta eficiencia y carácter general.

Siempre debe instalarse un filtro de carácter general para proteger el filtro de alta eficiencia frente a altas cantidades de aerosoles líquidos y partículas sólidas.

Instale equipos de purificación en el punto de mínima temperatura sobre el punto de congelación, preferentemente aguas abajo de postenfriadores y depósitos de aire.

Los equipos de purificación en punto de utilización se deben instalar lo más cerca posible de la aplicación.

Los equipos de purificación no deben instalarse aguas abajo de válvulas de apertura rápida y deben protegerse del posible flujo inverso o de otras condiciones de cambio brusco.

Antes de instalar los equipos de purificación, purgue todas las tuberías aguas arriba de los mismos, y todas las tuberías entre la citada instalación y la conexión a la aplicación final.

Si se instalan líneas para derivar los equipos de purificación, asegúrese de montar unos filtros adecuados en la línea de derivación para evitar la contaminación del sistema aguas abajo.

Instale conductos de drenaje desde los filtros coalescentes hasta el separador de condensado. Si no es posible conectar los conductos de drenaje directamente a un separador, los conductos deberían derivarse a un colector de condensado (a un extremo) y luego a una entrada individual de un separador de condensado.

Disponga los medios para drenar los líquidos recogidos en los equipos de purificación. Los líquidos recogidos se deben tratar y desechar de forma responsable.

**IT Istruzioni di installazione**

L'aria compressa deve essere trattata prima di entrare nel sistema di distribuzione e anche in corrispondenza dei punti di utilizzo / applicazione critici.

L'installazione di essiccatori per aria compressa su un impianto "umido" può provocare un ulteriore accumulo di impurità sui filtri del punto di utilizzo mentre il sistema di distribuzione si asciuga. In questo intervallo di tempo potrebbe essere necessario sostituire gli elementi filtranti con maggiore frequenza.

Gli impianti che utilizzano compressori senza olio richiedono comunque l'uso di filtri universali e ad alto grado di efficienza per la presenza di acqua sotto forma di aerosol e particelle.

Occorre sempre installare un filtro universale per proteggere il filtro ad alta efficienza dai liquidi misti in forma di aerosol e da particelle solide.

Installare depuratori a una temperatura immediatamente superiore al punto di congelamento, preferibilmente a valle di postrefrigeratori e serbatoi d'urto.

I depuratori destinati ai punti di utilizzo si devono installare il più vicino possibile alle applicazioni.



I depuratori non si devono installare a valle delle valvole ad apertura rapida e si devono proteggere dal riflusso o da altre condizioni d'urto.

Spurgare tutti i tubi che portano al depuratore prima dell'installazione, dopo aver installato il depuratore e prima di collegarli all'applicazione finale.

Se il depuratore è provvisto di linee di derivazione controllare che siano adeguatamente filtrate per evitare di contaminare il sistema a valle.

Montare le linee di scarico dai filtri a coalescenza direttamente su un separatore di condensa. Qualora non sia possibile collegare le linee di scarico direttamente a un separatore, le linee devono essere scaricate in un collettore di condensa (con sfuato su un'estremità) e quindi in un'unica entrata di un separatore di condensa.

Prevedere un sistema di deflusso dei liquidi raccolti dal depuratore. Trattare e smaltire i liquidi raccolti in modo responsabile.



Models 050 and 055 only

**(EN)** The lower closure plate may move when the filter is not pressurised



The lower closure plate is a non serviceable item and should never be removed.

**(NL)** De onderste sluitplaat kan verschuiven als het filter niet onder druk staat



De onderste sluitplaat behoeft geen onderhoud en mag nooit verwijderd worden.

**(DE)** Die untere Verschlussplatte kann sich bewegen, wenn der Filter nicht mit Druck beaufschlagt ist.



Die untere Verschlussplatte ist wartungsfrei und darf nicht entfernt werden.

**(FR)** La plaque de fermeture inférieure peut se déplacer si le filtre n'est pas pressurisé.



La plaque de fermeture inférieure ne peut pas être remplacée et ne doit jamais être retirée.

**(ES)** El plato de cierre inferior se puede mover cuando el filtro no está presurizado



El plato de cierre inferior no tiene piezas que requieran mantenimiento y no se debe desinstalar nunca.

**(IT)** Se il filtro non è pressurizzato la piastra di chiusura inferiore potrebbe spostarsi



La piastra di chiusura inferiore non è soggetta a manutenzione e non deve mai essere rimossa.

**EN Startup and Operation**



Before pressurising the filter ensure that the head and bowl are correctly fitted and that the locking detail is properly aligned as shown in the maintenance section (maintenance procedure 6) of this manual.

1. Open inlet valve slowly to gradually pressurise the unit.
2. Open outlet valve slowly to re-pressurise the downstream piping.

Do not open inlet or outlet valves rapidly or subject unit to excessive pressure differential or damage may occur.

**NL Starten en bediening**



Voordat het filter onder druk wordt gezet, moet u ervoor zorgen dat de kop en de kom juist zijn gemonteerd en dat de vergrendeling goed is uitgelijnd, zoals aangegeven in de onderhoudsinformatie (onderhoudsprocedure 6) van deze handleiding.

1. Doe de inlaatklep langzaam open om de druk in het toestel geleidelijk op te voeren.
2. Doe de uitlaatklep langzaam open om de druk in de leidingen verderop in het systeem opnieuw op te voeren.

Doe de inlaat- en uitlaatkleppen niet snel open en stel het toestel niet aan een te groot drukkendifferentieel bloot om schade te voorkomen.

**DE Starten und Betrieb**



Bevor Sie den Filter mit Druck beaufschlagen, stellen Sie sicher, dass der Filterkopf und die Filterschale ordnungsgemäß montiert sind und dass die Sperrklinke wie im Abschnitt „Wartung“ dieser Anleitung (Wartungsverfahren 6) dieser Anleitung beschrieben ordnungsgemäß ausgerichtet ist.

1. Einlassventil langsam öffnen, damit die Einheit allmählich mit Druck beaufschlagt wird.
2. Auslassventil langsam öffnen, damit nachgeschaltete Rohrleitungen erneut mit Druck beaufschlagt werden.

Einlass- und Auslassventil nicht schnell öffnen. Einheit nicht extremen Druckunterschieden aussetzen. Gefahr von Schäden.

**FR Démarrage et exploitation**



Avant de mettre le filtre sous pression, vérifiez que la tête et la cuve sont montées correctement et que l'indicateur de verrouillage est bien aligné, comme indiqué dans la section de maintenance (procédure de maintenance 6) du présent manuel.

1. Ouvrez lentement la soupape d'admission pour mettre progressivement l'unité sous pression.
2. Ouvrez lentement la soupape de refoulement pour faire remonter la pression des conduits en aval.

Ne pas ouvrir la soupape d'admission ou la soupape de refoulement trop rapidement, ne pas soumettre l'unité à une pression différentielle trop importante. Vous risqueriez d'endommager l'équipement.

**ES Puesta en marcha y funcionamiento**



Antes de presurizar el filtro, asegúrese de que la cabeza y el cilindro están correctamente ajustados y que el detalles de bloqueo está alineado de la forma apropiada, como se muestra en la sección de mantenimiento (procedimiento de mantenimiento 6) de este manual.

1. Abra lentamente la válvula de admisión para presurizar gradualmente la unidad.
2. Abra lentamente la válvula de descarga para volver a presurizar las tuberías aguas abajo.

Para evitar daños, no abra bruscamente las válvulas de admisión o de descarga ni someta la unidad a una diferencia de presiones excesiva.

**IT Avvio e funzionamento**






















Prima di pressurizzare il filtro assicurarsi che la testa e il bicchiere siano montati correttamente e che l'elemento di bloccaggio sia allineato in maniera adeguata, come indicato nella sezione relativa alla manutenzione (procedura di manutenzione 6) del presente manuale.

1. Aprire lentamente la valvola di mandata per aumentare gradualmente la pressione nell'unità.
2. Aprire lentamente la valvola di scarico per pressurizzare nuovamente i tubi a valle.

Non aprire rapidamente le valvole di mandata o scarico né sottoporre l'unità a una differenza di pressione eccessiva; rischio di danni.

Accessories / Spare Parts (Service Kits)  
Toebehooren / reserveonderdelen (onderhoudskits), Zubehör / Ersatzteile (Wartungssätze), Accessoires / Pièces de rechange (kits d'entretien),  
Accesorios / Piezas de repuesto (kits de mantenimiento), Accessori / Parti di ricambio (kit di manutenzione)

| Filter Models | Catalogue Number | Contents  |
|---------------|------------------|---|
| 010           | TRK1-2           |      |
| 015 - 020     | TRK2-2           |     |
| 025 - 030     | TRK3-2           |     |
| 035 - 045     | TRK4-2           |     |
| 050 - 055     | TRK5-2           |     |
| 010           | MBK1-1           |      |
| 015 - 020     | MBK2-1           |    |
| 025 - 030     | MBK3-1           |   |
| 035 - 045     | MBK4-1           |   |
| 050 - 055     | MBK5-1           |   |
| 010           | MBK1-2           |    |
| 015 - 020     | MBK2-2           |   |
| 025 - 030     | MBK3-2           |   |
| 035 - 045     | MBK4-2           |   |
| 050 - 055     | MBK5-2           |   |
| 010 - 055     | EM1              |  |
| 010 - 055     | PD15NO           |  |
| 010 - 030     | DPI-K            |  |
| 035 - 055     | ZD90GL           |  |

**Maintenance**

**Onderhoud, Wartung, Maintenance, Mantenimiento, Manutenzione**

**EN Maintenance Intervals**

To ensure optimal filter performance the AO, AA, grade elements require changing every 12 months along with the automatic drain.

The performance of the ACS element is based upon a maximum oil vapour inlet concentration of 0.018mg/m<sup>3</sup>. Replace the carbon filter element upon detection of vapour, odour or taste.

Unlike oil aerosol removal filters which are changed annually to guarantee compressed air quality, the lifetime of an oil vapour removal filter can be attributed to various factors and require more frequent changes (unless OVR is used which is sized for 6000hrs life):

**Factors affecting the lifetime of adsorption filters**

**Oil vapour concentration**

The higher the inlet concentration of oil vapour, the faster the activated carbon capacity will expire.

**Bulk oil**

Adsorption filters are designed to remove oil vapour and odours, not liquid oil or aerosols. Poorly maintained or non-existent pre-filtration will cause the OVR filter capacity to quickly expire.

**Temperature**

Oil vapour content increases exponentially to inlet temperature, reducing element life. Additionally, as temperature increases, the adsorption capacity decreases, again reducing element life.

**Relative Humidity or Dewpoint**

Wet air reduces the adsorptive capacity of the carbon.

**Compressor oil changes**

When compressor oil is changed, the new lubricant burns off "light ends" which increases the oil vapour content for hours or even weeks afterwards. This increase in oil vapour content is adsorbed by the OVR filter, significantly reducing its adsorptive life.

**NL Onderhoudsintervallen**

Voor een optimale filterprestatie moeten de elementen van graad AO, AA, om de 12 maanden worden vervangen, samen met de automatische afvoer.

The performance of the ACS element is based upon a maximum oil vapour inlet concentration of 0.018mg/m<sup>3</sup>. Replace the carbon filter element upon detection of vapour, odour or taste.

Unlike oil aerosol removal filters which are changed annually to guarantee compressed air quality, the lifetime of an oil vapour removal filter can be attributed to various factors and require more frequent changes (unless OVR is used which is sized for 6000hrs life):

**Factors affecting the lifetime of adsorption filters**

**Oil vapour concentration**

The higher the inlet concentration of oil vapour, the faster the activated carbon capacity will expire.

**Bulk oil**

Adsorption filters are designed to remove oil vapour and odours, not liquid oil or aerosols. Poorly maintained or non-existent pre-filtration will cause the OVR filter capacity to quickly expire.

**Temperature**

Oil vapour content increases exponentially to inlet temperature, reducing element life. Additionally, as temperature increases, the adsorption capacity decreases, again reducing element life.

**Relative Humidity or Dewpoint**

Wet air reduces the adsorptive capacity of the carbon.

**Compressor oil changes**

When compressor oil is changed, the new lubricant burns off "light ends" which increases the oil vapour content for hours or even weeks afterwards. This increase in oil vapour content is adsorbed by the OVR filter, significantly reducing its adsorptive life.

**DE Wartungsintervalle**

Um eine optimale Filterleistung zu gewährleisten, müssen die Elemente der Klassen AO, AA alle 12 Monate zusammen mit dem automatischen Ablass ausgetauscht werden.

Im Gegensatz zu Filtern für die Abscheidung von Ölaerosolen, die zur Gewährleistung der Druckluftqualität jährlich ausgetauscht werden, kann die Lebensdauer eines Ölnebel-Abscheidefilters für zahlreiche verschiedenen Faktoren abhängen, die einen häufigeren Austausch erfordern. Negative Faktoren für die Lebensdauer von Adsorptionsfiltern sind:

**Ölnebel-Konzentration:** Je höher die Ölnebel-Einlasskonzentration ist, desto schneller ist die Kapazität der Aktivkohle erschöpft.

**Öl:** Adsorptionsfilter sind entwickelt worden, um Ölnebel und Gerüche abzuscheiden, sie dienen nicht der Entfernung von flüssigem Öl oder Aerosolen. Schlecht gewartete oder nicht vorhandene Vorfiltration führt dazu, dass die OVR-Filterkapazität für die Ölnebelabscheidung schnell erschöpft ist.

**Temperatur:** Der Ölnebelgehalt steigt exponentiell zur Einlasstemperatur an und verringert so die Lebensdauer des Filterelements. Zudem verringert sich mit steigender Temperatur auch die Adsorptionskapazität, was ebenfalls die Lebensdauer des Filterelements verkürzt.

**Relative Feuchtigkeit oder Taupunkt:** Feuchte Luft verringert die Adsorptionsfähigkeit der Aktivkohle.

**Austausch des Kompressoröls:** Bei einem Austausch des Kompressoröls werden durch den neuen Schmierstoff „lose Enden“ abgebrannt, was zu einem Anstieg des Ölnebelgehalts für Stunden oder sogar Wochen führt. Dieser erhöhte Ölnebelgehalt wird vom OVR-Filter für die Ölabscheidung adsorbiert, wodurch sich die Lebensdauer des Filters erheblich reduziert.

Die Filterelementleistung nach ACS/AC basiert auf einer maximalen Ölnebel-Einlasskonzentration von 0,018 mg/m<sup>3</sup>, mit einer Drucklufttemperatur von 21 °C und einem Drucktaupunkt von -40 °C.

**Diese Elemente sollten ausgetauscht werden, wenn Ölnebel, Gerüche oder Geschmack festgestellt werden.**

**FR Intervalles de maintenance**

Pour assurer des performances de filtrage optimales, les cartouches de grade AO, AA, doivent être changées tous les 12 mois, en même temps que le purgeur automatique.

Contrairement aux filtres de suppression des aérosols d'huile remplacés chaque année pour garantir la qualité de l'air comprimé, la durée de vie d'un filtre d'élimination des vapeurs d'huile dépend de différents facteurs et nécessite des remplacements plus fréquents. Facteurs influant sur la durée de vie des filtres d'adsorption :

**concentration de vapeur d'huile** - Plus la concentration d'entrée des vapeurs d'huile est élevée, plus vite la capacité d'adsorption du charbon actif est épuisée.

**présence massive d'huile** - les filtres à adsorption sont conçus pour éliminer les vapeurs et les odeurs d'huile, et non pas l'huile ou les aérosols. Si la pré-filtration est mal entretenue, voire inexistante, le filtre OVR devient rapidement inefficace.

**Température** - la teneur en vapeurs d'huile augmente de façon exponentielle selon la température d'admission, réduisant ainsi la durée de vie de l'élément. En outre, plus la température augmente, plus la capacité d'adsorption diminue, ce qui réduit encore la durée de vie de l'élément.

**Humidité relative ou point de rosée** - l'air humide réduit la capacité d'adsorption du carbone.

**Vidanges d'huile de compresseur** - lorsque l'huile de compresseur est changée, le nouveau lubrifiant brûle « des extrémités légères » ce qui augmente la teneur en vapeur d'huile pendant des heures, voire des semaines après. Cette augmentation de la teneur en vapeur d'huile est adsorbée par le filtre OVR, réduisant de manière significative la durée de vie d'adsorption.

Les performances des filtres ACS/AC sont basées sur une concentration maximale des vapeurs d'huile d'entrée de 0,018 mg/m<sup>3</sup>, avec de l'air comprimé à 21°C et un point de rosée sous pression de -40°C PDP.

**Ces éléments doivent être remplacés en cas de détection de vapeur, d'odeur ou de goût.**

**ES Intervalos de mantenimiento**

Para asegurar un óptimo rendimiento del filtro, es necesario cambiar los elementos de grado AO, AA cada 12 meses junto con el drenaje automático.

A diferencia de los filtros de eliminación de aerosoles de aceite que se cambian anualmente con el fin de garantizar la calidad del aire comprimido, la vida útil de un filtro de eliminación de vapores de aceite puede atribuirse a diversos factores y requiere cambios más frecuentes. Los factores que afectan a la vida útil de los filtros de adsorción son:

**Concentración de vapores de aceite** - Cuanto mayor sea la concentración de vapores de aceite en la entrada, más rápidamente se agotará la capacidad del carbón activado.

**Acetite** - Los filtros de adsorción se han diseñado para eliminar los vapores y los olores de aceite, pero no los aerosoles ni el aceite líquidos. Si no existe prefiltrado o su mantenimiento es inadecuado, se agotará rápidamente la capacidad del filtro OVR.

**Temperatura** - El contenido de vapores de aceite aumenta de forma exponencial a la temperatura de admisión, lo que reduce la vida útil del elemento. Asimismo, a medida que aumenta la temperatura disminuye la capacidad de adsorción, lo que una vez más reduce la vida útil del elemento.

**Humedad relativa o punto de condensación** - El aire húmedo reduce la capacidad de adsorción del carbón.

**Cambios del aceite del compresor** - Cuando se cambia el aceite del compresor, se evaporan las fracciones más ligeras del aceite nuevo, lo cual aumenta el contenido de vapores de aceite durante las horas o incluso las semanas posteriores. El filtro OVR adsorbe este aumento del contenido de vapores de aceite, lo que reduce considerablemente la vida útil de adsorción.

El rendimiento de los elementos ACS/AC se calcula tomando como base una concentración de entrada de vapores de aceite máxima de 0,018 mg/m<sup>3</sup>, con aire comprimido a 21 °C y un punto de condensación de presión a -40 °C PDP.

**Estos elementos deberán sustituirse si se detecta vapor, olor y gusto.**

**IT Intervalli di manutenzione**

Per garantire prestazioni ottimali del filtro è necessario sostituire gli elementi filtranti di grado AO, AA ogni 12 mesi, insieme allo scarico automatico.

A differenza dei filtri per l'eliminazione di aerosol, che vengono cambiati una volta all'anno per garantire la qualità dell'aria compressa, i filtri per la rimozione dei vapori d'olio hanno una durata variabile e devono essere sostituiti più frequentemente. Fattori che influenzano la durata dei filtri ad adsorbimento:

**Concentrazione di vapori d'olio** - La capacità del carbone attivo si esaurisce tanto più rapidamente quanto maggiore è la concentrazione di vapori d'olio in ingresso.

**Oli misti** - I filtri ad adsorbimento sono studiati per eliminare vapori d'olio e odori, ma non oli liquidi e aerosol. La scarsa manutenzione o la mancanza di prefiltrazione causano il rapido esaurimento della capacità dei filtri OVR.

**Temperatura** - Il contenuto di vapori d'olio aumenta proporzionalmente con la temperatura di mandata, riducendo la durata del filtro. Inoltre, all'aumentare della temperatura, diminuisce la capacità di adsorbimento e ancora una volta si riduce la durata del filtro.

**Umidità relativa o punto di rugiada** - L'aria umida riduce la capacità di adsorbimento del carbone.

**Cambio olio del compressore** - Quando si cambia l'olio del compressore, il nuovo lubrificante brucia completamente gli idrocarburi leggeri provocando l'aumento del contenuto di vapori d'olio per alcune ore o addirittura per settimane. Il maggiore contenuto di vapori d'olio viene assorbito dal filtro OVR e provoca una riduzione significativa della durata di adsorbimento.

Le prestazioni degli elementi ACS / AC si basano su una concentrazione massima dei vapori d'olio in ingresso pari a 0,018 mg/m<sup>3</sup> con aria compressa a 21°C e un punto di rugiada in pressione di -40°C PDP.

**Questi elementi devono essere sostituiti non appena vengono percepiti vapori, odori o sapori.**

**EN Maintenance Procedure 1**

Slowly close the inlet (1) and outlet (2) valves and depressurise the filter (3) using the drain.

**NL Onderhoudsprocedure 1**

Sluit de inlaat- (1) en uitlaatkleppen (2) langzaam en haal de druk van het filter (3) af met de afvoer.

**DE Wartungsverfahren 1**

Einlass- (1) und Auslassventile (2) langsam schließen und den Druck vom Filter (3) mit dem Ablass ablassen.

**FR Procédure de maintenance 1**


Fermez lentement la soupape d'admission (1) et la soupape de refoulement (2), puis dépressurisez le filtre (3) à l'aide du purgeur.

**ES Procedimiento de mantenimiento 1**

Cierre lentamente las válvulas de admisión (1) y de descarga (2) y despresurice el filtro (3) utilizando el drenaje.

**IT Procedura di manutenzione 1**

Chiudere lentamente le valvole di mandata (1) e di scarico (2) e depressurizzare il filtro (3) tramite lo scarico.



**EN Maintenance Procedure 2**

Unscrew the filter bowl (1 & 2) and remove the used element (3)

**NL Onderhoudsprocedure 2**

Schroef de filterkom (1 & 2) los en verwijder het gebruikte element (3)

**DE Wartungsverfahren 2**

Filterschale lösen (1 & 2) und das verbrauchte Element entfernen (3)

**FR Procédure de maintenance 2**


Dévissez la cuve du filtre (1 et 2) et retirez la cartouche usagée (3)

**ES Procedimiento de mantenimiento 2**

Desenrosque el cilindro del filtro (1 y 2) y retire el elemento utilizado (3)

**IT Procedura di manutenzione 2**

Svitare il bicchiere del filtro (1 e 2) e rimuovere l'elemento filtrante usato (3)



**EN Maintenance Procedure 3**

Unscrew the automatic drain (1) and discard (2). Fit the new drain (3) and tighten (4).

**NL Onderhoudsprocedure 3**

Schroef de automatische afvoer (1) los en verwijder hem (2). Plaats de nieuwe afvoer (3) en draai hem vast (4).

**DE Wartungsverfahren 3**

Den automatischen Ablass abschrauben (1) und entsorgen (2). Den neuen Ablass anbringen (3) und festziehen (4).

**FR Procédure de maintenance 3**

Dévissez le purgeur automatique (1) puis mettez-le au rebut (2). Montez le nouveau purgeur (3) puis serrez (4).

**ES Procedimiento de mantenimiento 3**

Desenrosque el drenaje automático (1) y deséchelo (2). Instale el nuevo drenaje (3) y apriételo (4).

**IT Procedura di manutenzione 3**

Svitare lo scarico automatico (1) ed eliminarlo (2). Montare lo scarico nuovo (3) e serrare (4).



**EN Maintenance Procedure 4**

Insert the new element into the filter bowl ensuring that the lugs are seated correctly in the grooves.

**NL Onderhoudsprocedure 4**

Steek het nieuwe element in de filterkom, waarbij de lipjes goed in de groeven steken.

**DE Wartungsverfahren 4**

Das neue Filterelement in die Filterschale einsetzen und sicherstellen, dass die Führungen richtig in den Nuten sitzen.

**FR Procédure de maintenance 4**


Insérez la nouvelle cartouche dans la cuve en vérifiant que les languettes sont bien enfoncées dans les encoches.

**ES Procedimiento de mantenimiento 4**

Inserte el nuevo elemento en el cilindro del filtro, asegurándose de que los anillos están correctamente asentados en las ranuras.

**IT Procedura di manutenzione 4**

Inserire il nuovo elemento filtrante nel bicchiere del filtro assicurandosi che le alette siano inserite correttamente nelle scanalature.



**EN Maintenance Procedure 5**

Replace the O-ring located in the filter head with the new O-ring provided.



**Ensure to lubricate the O-ring and threads with a suitable acid free petroleum jelly.**

**NL Onderhoudsprocedure 5**

Vervang de O-ring in de filterkop door de nieuwe meegeleverde O-ring.



**Zorg ervoor dat de O-ring en de draden worden gesmeerd met een geschikt soort zuurloze vaseline.**

**DE Wartungsverfahren 5**

Den O-Ring im Filterkopf durch den mitgelieferten neuen O-Ring ersetzen.



**Sicherstellen, den O-Ring und das Gewinde mit geeigneter säurefreier Vaseline zu schmieren.**

**FR Procédure de maintenance 5**

Remplacez le joint torique qui se trouve dans la tête du filtre par le nouveau joint fourni.



**Lubrifiez le joint torique et le filetage à l'aide d'une gelée de pétrole sans acide.**

**ES Procedimiento de mantenimiento 5**

Sustituya la junta tórica localizada en la cabeza del filtro por la nueva junta tórica proporcionada.




**Asegúrese de lubricar la junta tórica y las roscas con un gel ácido sin petróleo apropiado.**

**IT Procedura di manutenzione 5**

Sostituire l'O-ring situato nella testa del filtro con il nuovo O-ring fornito in dotazione.



**Assicurarsi che l'O-ring e le filettature siano lubrificati con vaselina senza acido idonea.**



**EN Maintenance Procedure 6 (a)**

Refit the filter bowl and head ensuring that the threads are fully engaged and the locking details are aligned.

**Note: To ensure that the bowl is fully engaged into the head, the 010-030 bowl requires 360° of rotation until the thread stop and 720° for the 035-045 bowl**

**NL Onderhoudsprocedure 6 (a)**

Zet de filterkom en de kop terug op hun plaats en zorg ervoor dat de draden volledig gegrepen zijn en de vergrendeling uitgelijnd is.

**Opmerking: Zorg ervoor dat de kom volledig in de kop steekt. De 010-030 kom moet 360° gedraaid worden, tot aan de draadstop en 720° voor de 035-045 kom**

**DE Wartungsverfahren 6 (a)**

Die Filterschale und den Filterkopf wieder anbringen und dabei sicherstellen, dass die Gewinde vollständig fassen und die Sperrklinken richtig ausgerichtet sind.

**Hinweis: Um sicherzustellen, dass die Filterschale vollständig im Filterkopf sitzt, müssen die Schalen 005 bis 030 um 360° und die Schalen 035 bis 045 um 720° gedreht werden, bis das Gewinde stoppt.**

**FR Procédure de maintenance 6 (a)**

Remontez la cuve et la tête du filtre en vérifiant que le filetage est vissé à fond et que les indicateurs de verrouillage sont alignés.

**Remarque: pour vérifier que la cuve est bien enfoncée dans la tête, le modèle de cuve 005-030 doit opérer une rotation de 360° jusqu'à la fin du filetage et le modèle de cuve 035-045 doit opérer une rotation de 720°.**

**ES Procedimiento de mantenimiento 6 (a)**



Reinstale el cilindro y la cabeza del filtro, asegurándose de que las roscas están completamente acopladas y que los detalles de bloqueo están alineados.

**Nota: Para asegurarse de que el filtro está completamente acoplado a la cabeza, el cilindro de 010-030 necesita 360° de rotación, hasta que la rosca se detenga y 720° para el cilindro de 035-045.**

**IT Procedura di manutenzione 6 (a)**

Rimontare il bicchiere e la testa del filtro assicurandosi che le filettature siano completamente inserite e gli elementi di bloccaggio siano allineati.

**Nota: per assicurarsi che il bicchiere sia completamente inserito nella testa, è necessaria una rotazione di 360° fino al termine della filettatura per il bicchiere 010-030 e una rotazione di 720° per il bicchiere 035-045.**



**EN Maintenance Procedure 7**

Attach the element change date label to the filter bowl and write on the date the element is to be replaced. i.e. 12 months after element change.



**Do not use solvents or alcohol to clean the labels as this could cause damage.**

**NL Onderhoudsprocedure 7**

Plak het etiket met de vervangingsdatum aan de kom en schrijf de datum erop waarop het element weer vervangen moet worden, ofwel 12 maanden later..



**Gebruik geen oplosmiddelen of alcohol om de etiketten te reinigen, omdat dit schade kan veroorzaken.**

**DE Wartungsverfahren 7**

Den Austauschdatum-Aufkleber des Filterelements an der Filterschale anbringen und darauf das Datum notieren, zu dem das Filterelement ausgetauscht werden muss (d.h. 12 Monate nach dem Austausch des Elements).



**Zur Reinigung der Aufkleber keine Lösungsmittel oder Alkohol verwenden. Gefahr von Schäden.**

**FR Procédure de maintenance 7**

Attachez l'étiquette de date de remplacement de la cartouche à la cuve de filtre et notez la date du prochain remplacement, dans 12 mois.



**Ne pas utiliser de solvants ou d'alcool pour nettoyer les étiquettes car cela peut endommager l'équipement.**

**ES Procedimiento de mantenimiento 7**

Ponga la etiqueta de cambio de fecha en el cilindro del filtro y escriba en ella la fecha en la que hay que sustituir el elemento; i.e. 12 meses después del cambio de elemento.




**No utilice disolventes o alcohol para limpiar las etiquetas, puesto que podría dañarlas.**

**IT Procedura di manutenzione 7**

Attaccare l'etichetta della data di sostituzione dell'elemento filtrante al bicchiere del filtro riportando la data in cui l'elemento deve essere sostituito, ovvero 12 mesi dopo la sostituzione dell'elemento.



**Non usare solventi o alcol per pulire le etichette poiché potrebbero provocare danni.**



**EN -Maintenance Procedure 8**

Open the inlet valve (1) slowly to gradually pressurise the unit, slowly open outlet valve (2) to re-pressurise the downstream piping.



**Do not open inlet or outlet valves rapidly or subject unit to excessive pressure differential as damage may occur.**

**NL Onderhoudsprocedure 8**

Open de inlaatklep (1) langzaam om de druk in het toestel geleidelijk op te voeren. Zet de uitlaatklep (2) langzaam open om de druk in de uitgaande leidingen opnieuw op te voeren.



**Doe de inlaat- en uitlaatkleppen niet snel open en stel het toestel niet aan een te groot drukdifferential bloot om schade te voorkomen.**

**DE Wartungsverfahren 8**

Einlassventil langsam öffnen (1), damit die Einheit allmählich mit Druck beaufschlagt wird. Auslassventil langsam öffnen (2), damit nachgeschaltete Rohrleitungen erneut mit Druck beaufschlagt werden.



**Einlass- und Auslassventil nicht schnell öffnen. Einheit nicht extremen Druckunterschieden aussetzen. Gefahr von Schäden.**

**FR Procédure de maintenance 8**

Ouvrez la soupape d'admission (1) pour mettre progressivement l'unité sous pression, puis ouvrez lentement la soupape de refoulement (2) pour repressuriser les conduits en aval.



**Ne pas ouvrir la soupape d'admission ou la soupape de refoulement trop rapidement. Ne pas soumettre l'unité à une pression différentielle trop importante. Vous risqueriez d'endommager l'équipement.**

**ES Procedimiento de mantenimiento 8**

Abra lentamente la válvula de admisión (1) para presurizar gradualmente la unidad. Abra lentamente la válvula de descarga (2) para repressurizar las tuberías aguas abajo.




**No abra bruscamente las válvulas de admisión o de descarga ni someta la unidad a una diferencia de presiones excesiva, ya que podría ocasionar daños.**

**IT Procedura di manutenzione 8**

Aprire lentamente la valvola di mandata (1) per aumentare gradualmente la pressione nell'unità, aprire lentamente la valvola di scarico (2) per pressurizzare nuovamente i tubi a valle.



**Non aprire rapidamente le valvole di mandata o scarico né sottoporre l'unità a una differenza di pressione eccessiva; rischio di danni.**



**(FI) YHDEN VUODEN ILMANLAATUTAKUU**

Ilmanlaatuus taataan 1 vuodeksi ja takuu uusitaan aina vuosittaisen suodatinelementin vaihdon yhteydessä. Vuosittainen suodatinelementin vaihtaminen varmistaa

- ihanteellisen suorituskyvyn
- kansainvälisten standardien vaatimukset täyttävän ilmanlaadun
- tuotantovälineiden, henkilökunnan ja menetelmien suojaamisen
- alhaiset käyttökustannukset
- lisääntyneen tuottavuuden ja tuoton
- mielenrauhan

**(SV) ETT ÅRS LUFTKVALITETSGARANTI**

Din luftkvalitet garanteras under ett år och garantin förnyas vid varje årligt filterelementbyte.

Årliga filterelementbyten säkerställer att:

- Optimala prestanda upprätthålls
- Luftkvaliteten fortsätter uppfylla internationella standarder
- Skydd för nedströms utrustning, personal och processer
- Låga driftkostnader
- Ökad produktivitet och lönsamhet
- Du själv får sinnesfrid

**(NO) ETT ÅRS LUFTKVALITETSGARANTI**

Din luftkvalitet er garantert for 1 år og garantien vil bli fornyet ved hver årlige utskifting av filterelement.

Årlig utskifting av filterelement sikrer:

- Optimal ytelse opprettholdes
- Luftkvalitet som til enhver tid møter internasjonale standarder
- Beskyttelse av nedstrøms utstyr, personell og prosesser
- Lave driftskostnader
- Økt produktivitet og lønnsomhet
- Sinnsro

**(DA) ET ÅRS GARANTI PÅ LUFTKVALITET**

Der gives 1 års luftkvalitetsgaranti, og den bliver fornyet ved hver årlig udskiftning af filterelementet.

Årlig udskiftning af filterelementet sikrer:

- At optimal ydelse bevares
- At luftkvaliteten fortsat opfylder de internationale standarder
- Beskyttelse af udstyr, personer og processer længere fremme
- Lave driftsomkostninger
- Øget produktivitet og rentabilitet
- Ro i sinde

**(EL) ΕΓΓΥΗΣΗ ΠΟΙΟΤΗΤΑΣ ΑΕΡΑ ΕΝΟΣ ΕΤΟΥΣ**

Παρέχεται εγγύηση για την ποιότητα του αέρα σας για 1 έτος, η οποία ανανεώνεται με κάθε ετήσια αλλαγή στοιχείου φίλτρου.

Με τις ετήσιες αλλαγές στοιχείου φίλτρου διασφαλίζονται τα εξής:

- Ότι θα διατηρείται η βέλτιστη απόδοση
- Ότι η ποιότητα του αέρα συνεχίζει να ικανοποιεί τα διεθνή πρότυπα
- Προστασία του κατόντι εξοπλισμού, του προσωπικού και των διαδικασιών
- Χαμηλές δαπάνες λειτουργίας
- Αυξημένη παραγωγικότητα και κερδοφορία
- Ξενοιασιά

**(PT) GARANTIA DE QUALIDADE DO AR DE UM ANO**

A qualidade do seu ar tem garantia de um ano, a qual será renovada a cada substituição anual do elemento do filtro. As substituições anuais do elemento do filtro asseguram que:

- É mantido o desempenho ideal
- A qualidade do ar continua a respeitar as normas internacionais
- Protecção dos processos, do pessoal e do equipamento a jusante
- Baixos custos operacionais
- maior produtividade e rentabilidade
- paz de espírito



## ④ Mallikoodiesimerkki:

| Malli                 |                                   |                                 |  |                     |                               |                                       |
|-----------------------|-----------------------------------|---------------------------------|--|---------------------|-------------------------------|---------------------------------------|
| Elementin laatu       | Erittäin energiatehokas elementti | Mallin koko                     | Liitäntäaukon koko   | Kierretyyppi        | Vedenpoisto                   | Paine-eroilmaisin                     |
| WS<br>AO<br>AA<br>ACS | P                                 | 3-numeroinen koodi (kuten alla) | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Uimuri<br>M = Manuaalinen | X = Ei mitään<br>I = Ongelmanvalvonta |
| AA                    | P                                 | 030                             | A  | G                   | F                             | I                                     |

## ④ Exempel på modellkodning:

| Modell                |                            |                            |  |                     |                         |                                      |
|-----------------------|----------------------------|----------------------------|--|---------------------|-------------------------|--------------------------------------|
| Elementklass          | Energisnått premiumelement | Modellstorlek              | Portstorlek  | Gängtyp             | Dräneringsalternativ    | DP-indikator                         |
| WS<br>AO<br>AA<br>ACS | p                          | Tresifrig kod enligt nedan | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Flyt<br>M = Handbok | X = Ingen<br>I = Incidentövervakning |
| AA                    | P                          | 030                        | A  | G                   | F                       | I                                    |

## ④ Eksempel på modellkodning:

| Modell                |                                 |                                  |  |                     |                         |                                   |
|-----------------------|---------------------------------|----------------------------------|--|---------------------|-------------------------|-----------------------------------|
| Elementgradering      | Premium energieffektivt element | Modellstørrelse                  | Portstørrelse  | Gjengetype          | Dreneringsmulighet      | DP-indikator                      |
| WS<br>AO<br>AA<br>ACS | P                               | Tresifret kode som vist nedenfor | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Flyt<br>M = Manuell | X = Ingen<br>I = Hendelsesmonitor |
| AA                    | P                               | 030                              | A  | G                   | F                       | I                                 |

## ④ Eksempel på kodning af model:

| Model                 |   |                                 |  |                     |                         |                                      |
|-----------------------|---|---------------------------------|--|---------------------|-------------------------|--------------------------------------|
| Elementkvalitet       | Energieffektivt element i premiumkvalitet | Modelstørrelse                  | Portstørrelse  | Gevindtype          | Afløbsmulighed          | DP indikator                         |
| WS<br>AO<br>AA<br>ACS | P   | 3-cifret kode som vist nedenfor | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Flyde<br>M = Manuel | X = Ingen<br>I = Blokeringsindikator |
| AA                    | P   | 030                             | A  | G                   | F                       | I                                    |

**㉔ Παράδειγμα κωδικοποίησης μοντέλου:**

| Μοντέλο               |                                       |  |  |                     |                               |                                     |
|-----------------------|---------------------------------------|--|--|---------------------|-------------------------------|-------------------------------------|
| Βαθμίδα στοιχείου     | Premium ενεργειακά αποδοτικό στοιχείο | Μέγεθος μοντέλου                       | Μέγεθος θύρας  | Τύπος σπειρώματος   | Επιλογή αποστράγγισης         | Δείκτης DP                          |
| WS<br>AO<br>AA<br>ACS | P                                     | 3ψήφιος κωδικός όπως φαίνεται παρακάτω | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Φλοτέρ<br>M = Μη αυτόματα | X = Κανένα<br>I = Δείκτης συμβάντων |
| AA                    | P                                     | 030                                    | A  | G                   | F                             | I                                   |

**㉕ Exemplo da codificação do modelo:**

| Modelo                |   |  |  |                     |                        |   |
|-----------------------|---|--|--|---------------------|------------------------|---|
| Grau do elemento      | Elemento de eficiência energética de excelência | Dimensão do modelo                       | Dimensão da entrada  | Tipo de rosca       | Opção de drenagem      | Indicador de pressão diferencial        |
| WS<br>AO<br>AA<br>ACS | P   | Código de 3 dígitos como indicado abaixo | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Boia<br>M = Manual | X = Nenhum<br>I = Monitor de incidentes |
| AA                    | P   | 030                                      | A  | G                   | F                      | I                                       |

**㉖ Tuotevalinta**

Virtaamat on tarkoitettu käytettäväksi paineessa 7 bar g (100 psi g), olosuhteiden ollessa 20 °C, 1 bar/a, 0 % suhteellinen vesihöyryn paine. Muiden paineiden virtausarvoja varten noudata annettuja kertoimia.

**㉗ Val av produkt**

Uppgivna flöden är för drift vid 7 bar g (100 psi g) med referens till 20°C, 1 bar a, 0 % relativt vattenångstryck. Använd angivna korrektionsfaktorer till flöden vid andra tryck.

**㉘ Produktvalg**

Oppgitte strømningshastigheter er for drift ved 7 bar (g) (100 psi g) med referanse til 20 °C, 1 bar (a), 0 % relativt vanddamptrykk. Benytt korrigeringsfaktorene under for å finne strømningshastigheter ved andre trykk.

**㉙ Produktudvalg**

De anførte flow gælder for drift ved 7 bar g (100 psi g) med referenceværdierne 20°C, 1 bar a, 0 % relativt vanddamptryk. Ved flow med andre tryk skal de viste korrektionsfaktorer anvendes.

**㉚ Επιλογή προϊόντος**

Οι αναφερθείσες παροχές είναι για λειτουργία σε 7 bar g (100 psi g) με αναφορά στους 20°C, 1 bar a, σχετική πίεση υδρατμών 0%. Για ροές σε άλλες τιμές πίεσης, εφαρμόστε τους εμφανιζόμενους συντελεστές διόρθωσης.

**㉛ Seleção de Produtos**

Os débitos referidos são para um funcionamento a 7 bar g (100 psi g) com referência a 20°C, 1 bar a, 0% de pressão relativa do vapor de água. Para débitos a pressões diferentes, aplique os factores de correcção apresentados.

**Vedenerottimen virtausnopeudet**

Flödeshastigheter för vattenavskiljare, Flytrater for vannseparator, Vandudskillers gennemløbshastigheder, Παροχές διαχωριστή νερού, Taxas de fluxo do separador de água

| Model                | Port Size | L/s | m3/min | m3/hr | cfm  |
|----------------------|-----------|-----|--------|-------|------|
| WS P010A [ ] [ ] [ ] | ¼         | 10  | 0.6    | 36    | 21   |
| WS P010B [ ] [ ] [ ] | ¾         | 10  | 0.6    | 36    | 21   |
| WS P010C [ ] [ ] [ ] | ½         | 10  | 0.6    | 36    | 21   |
| WS P015C [ ] [ ] [ ] | ½         | 40  | 2.4    | 144   | 85   |
| WS P020D [ ] [ ] [ ] | ¾         | 40  | 2.4    | 144   | 85   |
| WS P025D [ ] [ ] [ ] | ¾         | 110 | 6.6    | 396   | 233  |
| WS P025E [ ] [ ] [ ] | 1         | 110 | 6.6    | 396   | 233  |
| WS P030G [ ] [ ] [ ] | 1 ½       | 110 | 6.6    | 396   | 233  |
| WS P035G [ ] [ ] [ ] | 1 ½       | 350 | 21.0   | 1260  | 742  |
| WS P040H [ ] [ ] [ ] | 2         | 350 | 21.0   | 1260  | 742  |
| WS P045I [ ] [ ] [ ] | 2 ½       | 350 | 21.0   | 1260  | 742  |
| WS P050I [ ] [ ] [ ] | 2 ½       | 800 | 48.0   | 2880  | 1695 |
| WS P055I [ ] [ ] [ ] | 2 ½       | 800 | 48.0   | 2880  | 1695 |
| WS P055J [ ] [ ] [ ] | 3         | 800 | 48.0   | 2880  | 1695 |

**Korjauserroinpaine (CFP) – korjauserroin, pienin tulopaine (vedenerottimet)**

CFP – korrigeringsfaktor för minsta inloppstryck (vattenavskiljare), CFP – korrektionsfaktor för minimums inntakstrykk (vannseparatorer), CFP – Korrektionsfaktor for minimalt indgangstryk (vandudskillere), CFP - Συντελεστής διόρθωσης ελάχιστης πίεσης εισαγωγής (διαχωριστές νερού), CFP – Pressão de admissão mínima do fator de correção (separadores de água) ,

| Minimum Inlet Pressure | bar g | 1    | 2    | 3    | 4    | 5    | 6    | 7    | 8    | 9    | 10   | 11   | 12   | 13   | 14   | 15   | 16   |
|------------------------|-------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
|                        | psi g | 15   | 29   | 44   | 58   | 73   | 87   | 100  | 116  | 131  | 145  | 160  | 174  | 189  | 203  | 218  | 232  |
| Correction Factor      |       | 4.00 | 2.63 | 2.00 | 1.59 | 1.33 | 1.14 | 1.00 | 0.94 | 0.89 | 0.85 | 0.82 | 0.79 | 0.76 | 0.73 | 0.71 | 0.68 |

**Suodattimen virtausnopeudet**

Flödeshastigheter för filter, Flytrater for filter, Filters gennemløbshastigheder, Παροχές φίλτρου, Taxas de fluxo do filtro

| Model                     | Port Size | L/s | m3/min | m3/hr | cfm  | Replacement Element kit | No.       |
|---------------------------|-----------|-----|--------|-------|------|-------------------------|-----------|
| [grade] P010A [ ] [ ] [ ] | ¼         | 10  | 0.6    | 36    | 21   | P010                    | [grade] 1 |
| [grade] P010B [ ] [ ] [ ] | ¾         | 10  | 0.6    | 36    | 21   | P010                    | [grade] 1 |
| [grade] P010C [ ] [ ] [ ] | ½         | 10  | 0.6    | 36    | 21   | P010                    | [grade] 1 |
| [grade] P015C [ ] [ ] [ ] | ½         | 20  | 1.2    | 72    | 42   | P015                    | [grade] 1 |
| [grade] P020C [ ] [ ] [ ] | ½         | 30  | 1.8    | 108   | 64   | P020                    | [grade] 1 |
| [grade] P020D [ ] [ ] [ ] | ¾         | 30  | 1.8    | 108   | 64   | P020                    | [grade] 1 |
| [grade] P025D [ ] [ ] [ ] | ¾         | 60  | 3.6    | 216   | 127  | P025                    | [grade] 1 |
| [grade] P025E [ ] [ ] [ ] | 1         | 60  | 3.6    | 216   | 127  | P025                    | [grade] 1 |
| [grade] P030G [ ] [ ] [ ] | 1 ½       | 110 | 6.6    | 396   | 233  | P030                    | [grade] 1 |
| [grade] P035G [ ] [ ] [ ] | 1 ½       | 160 | 9.6    | 576   | 339  | P035                    | [grade] 1 |
| [grade] P040H [ ] [ ] [ ] | 2         | 220 | 13.2   | 792   | 466  | P040                    | [grade] 1 |
| [grade] P045I [ ] [ ] [ ] | 2 ½       | 330 | 19.8   | 1188  | 699  | P045                    | [grade] 1 |
| [grade] P050I [ ] [ ] [ ] | 2 ½       | 430 | 25.8   | 1548  | 911  | P050                    | [grade] 1 |
| [grade] P055I [ ] [ ] [ ] | 2 ½       | 620 | 37.3   | 2232  | 1314 | P055                    | [grade] 1 |
| [grade] P055J [ ] [ ] [ ] | 3         | 620 | 37.3   | 2232  | 1314 | P055                    | [grade] 1 |

[luokka] = luokka  
 [klass] = klass  
 [type] = type  
 [kvalitet] = kvalitet  
 [βαθμίδα] = βαθμίδα  
 [grau] = grau

**Korjaukerroinpaine (CFP) – korjaukerroin, pienin tulopaine (saostus- ja kuivat hiukkassuodattimet)**

CFP – korrigeringsfaktor för minsta inloppstryck (avskiljnings- och partikelfilter), CFP – korreksjonsfaktor for minimums inntakstrykk (koagulerings- og tørrpartikelfiltre), CFP – Korrektionsfaktor for minimalt indgangstryk (koalescens- og tørrpartikelfiltre), CFP - Συντελεστής διόρθωσης ελάχιστης πίεσης εισαγωγής (φίλτρα σωματιδίων προσκόλλησης και ξηρών), CFP – Pressão de admissão mínima do fator de correção (filtros coalescentes e de partículas secas)

| Minimum Inlet Pressure | bar g | 1    | 2    | 3    | 4    | 5    | 6    | 7    | 8    | 9    | 10   | 11   | 12   | 13   | 14   | 15   | 16   | 17   | 18   | 19   | 20   |
|------------------------|-------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
|                        | psi g | 15   | 29   | 44   | 58   | 73   | 87   | 100  | 116  | 131  | 145  | 160  | 174  | 189  | 203  | 218  | 232  | 248  | 263  | 277  | 290  |
| Correction Factor      |       | 2.65 | 1.87 | 1.53 | 1.32 | 1.18 | 1.08 | 1.00 | 0.94 | 0.88 | 0.84 | 0.80 | 0.76 | 0.73 | 0.71 | 0.68 | 0.66 | 0.64 | 0.62 | 0.61 | 0.59 |

**① Tuotteen valinta ja korjaukertoimet**

Jotta osaat valita oikean vedenerottimen tai suodattimen mallin, suodattimen virtausnopeus pitää säätää järjestelmän pienimpään käyttöpaineseen.

- Selvitä pienin käyttöpaine ja suurin paineilman virtausnopeus vedenerottimen tai suodattimen tulossa.
- Valitse korjaukerroinpaineiden taulukosta pienimmän käyttöpaineen korjaukerroin (pyöristä aina alaspäin; esim. 5,3 baarin tapauksessa on käytettävä 5 baarin korjaukerrointa).
- Laske vähimmäissuodatuskapasiteetti. Vähimmäissuodatuskapasiteetti = paineilman virtausnopeus x CFP
- Valitse pienintä suodatuskapasiteettia käyttäen vedenerottimen tai suodattimen malli yllä olevasta virtausnopeustaulukosta (valitun vedenerottimen tai suodattimen virtausnopeus pitää olla vähintään yhtä suuri kuin vähimmäissuodatuskapasiteetti).

**② Produkturval och korrigeringsfaktorer**

För att du ska kunna välja rätt modell på vattenavskiljare eller filter måste flödes hastigheten för filtret justeras efter minsta driftstryck i systemet.

- Mät minsta driftstryck och maximal flödes hastighet för tryckluft vid inloppet för vattenavskiljaren eller filtret.
- Välj korrigeringsfaktor för minsta driftstryck från CFP-tabellen (runda alltid av nedåt – för 5,3 bar använder du till exempel korrigeringsfaktor 5 bar).
- Beräkna minsta filtreringskapacitet. Minsta filtreringskapacitet = flödes hastighet för tryckluft x CFP
- Använd den minsta filtreringskapaciteten för att välja en modell på vattenavskiljare eller filter från de ovanstående tabellerna med flödes hastighet (den vattenavskiljare eller det filter du väljer måste ha en flödes hastighet som motsvarar eller är högre än den minsta filtreringskapaciteten).

**③ Produktvalg og korreksjonsfaktorer**

Flytraten for filteret må være justert til minimum driftstrykk for systemet for å korrekt kunne velge vannseparator eller filtermodell.

- Oppnå minimum driftstrykk og maksimum flytrate for komprimert luft ved inntaket til vannseparatoren eller filteret.
- Velg korreksjonsfaktoren for minimum driftstrykk fra CFP-tabellen (rund alltid ned: f.eks. for 5,3 bar bør du bruke korreksjonsfaktoren for 5 bar)
- Beregn minimum filtreringskapasitet. Minimum filtreringskapasitet = flytrate for komprimert luft x CFP
- Bruk minimum filtreringskapasitet når du velger en vannseparator eller filtermodell fra flytratetabellene ovenfor (valgt vannseparator eller filter må ha en flytrate lik eller høyere enn minimum filtreringskapasitet).

**④ Produktvalg og korrektionsfaktorer**

For at vælge den rigtige vandudskiller og filtermodel skal filterets gennemløbshastighed justeres i forhold til systemets mindste driftstryk.

- Det mindste driftstryk og den maksimale luftgennemløbshastighed kan aflæses ved vandudskillerens eller filterets indløb.
- Vælg korrektionsfaktoren for det mindste driftstryk på CFP-tabellen (rund altid ned – ved f.eks. 5,3 bar, bruges korrektionsfaktor på 5 bar)
- Beregn den minimale filtreringskapacitet. Minimal filtreringskapacitet = trykløbstømning x CFP
- Brug den minimale filtreringskapacitet til at vælge en vandudskiller eller filtermodel på tabellen over gennemløbshastigheder ovenfor (valgt vandudskiller eller filter skal have en gennemløbshastighed, der er lig med eller større end den minimale filtreringskapacitet).

**⑤ Επιλογή προϊόντος και συντελεστής διόρθωσης**

Για να επιλέξετε σωστά ένα μοντέλο διαχωριστή νερού ή φίλτρου, η παροχή του φίλτρου πρέπει να ρυθμιστεί ανάλογα με την ελάχιστη πίεση λειτουργίας του συστήματος.

- Μάθετε ποιες είναι οι τιμές της ελάχιστης πίεσης λειτουργίας και της μέγιστης παροχής πεπιεσμένου αέρα του διαχωριστή νερού ή του φίλτρου.
- Επιλέξτε τον συντελεστή διόρθωσης για την ελάχιστη πίεση λειτουργίας από τον πίνακα CFP (στρογγυλοποιώντας πάντα προς τα κάτω, π.χ. για 5,3 bar, χρησιμοποιήστε συντελεστή διόρθωσης 5 bar)
- Υπολογίστε την ελάχιστη ικανότητα φιλτραρίσματος. Ελάχιστη ικανότητα φιλτραρίσματος = Παροχή πεπιεσμένου αέρα x CFP
- Χρησιμοποιήστε την ελάχιστη ικανότητα φιλτραρίσματος για να επιλέξετε ένα μοντέλο διαχωριστή νερού ή φίλτρου από τους παραπάνω πίνακες παροχών (ο διαχωριστής νερού ή το φίλτρο που θα επιλέξετε πρέπει να έχουν παροχή μεγαλύτερη από ή ίση με την ελάχιστη ικανότητα φιλτραρίσματος).

**⑥ Seleção de produto e fatores de correção**

Para seleccionar corretamente um separador de água ou modelo de filtro, a taxa de fluxo do filtro deve ser ajustado para a pressão mínima de funcionamento do sistema.

- Obtenha a pressão mínima de funcionamento e a taxa máxima de fluxo de ar comprimido na entrada do separador de água ou filtro.
- Selecione o fator de correção da pressão mínima de funcionamento a partir da tabela CFP (arredondar sempre por defeito, por ex. para 5,3 bar, utilize um fator de correção de 5 bar)
- Calcule a capacidade mínima de filtração. Capacidade mínima de filtração = taxa de fluxo de ar comprimido x CFP
- Ao usar a capacidade mínima de filtração, selecione um separador de água ou modelo de filtro a partir das tabelas de taxa de fluxo acima (separador de água ou filtro selecionado deve ter uma taxa de fluxo igual ou superior à capacidade mínima de filtração).

**Tekniset tiedot**


Tekniska data, Tekniske data, Tekniske specifikationer, Τεχνικά δεδομένα, Datos Técnicos

| Model | Filter Models |     |     |   |     |   |     |     |     |   | Min Operating Pressure |       | Max Operating Pressure |       | Min Recommended Operating Temp |    | Max Recommended Operating Temp |     |     |
|-------|---------------|-----|-----|---|-----|---|-----|-----|-----|---|------------------------|-------|------------------------|-------|--------------------------------|----|--------------------------------|-----|-----|
|       |               |     |     |   |     |   |     |     |     |   | bar g                  | psi g | bar g                  | psi g | °C                             | °F | °C                             | °F  |     |
| WS    | P010          | [ ] | [ ] | F | [ ] | - | 055 | [ ] | [ ] | F | [ ]                    | 1     | 15                     | 16    | 232                            | 2  | 35                             | 80  | 176 |
| AO    | P010          | [ ] | [ ] | F | [ ] | - | 055 | [ ] | [ ] | F | [ ]                    | 1     | 15                     | 16    | 232                            | 2  | 35                             | 80  | 176 |
| AO    | P010          | [ ] | [ ] | M | [ ] | - | 055 | [ ] | [ ] | M | [ ]                    | 1     | 15                     | 20    | 290                            | 2  | 35                             | 100 | 212 |
| AA    | P010          | [ ] | [ ] | F | [ ] | - | 055 | [ ] | [ ] | F | [ ]                    | 1     | 15                     | 16    | 232                            | 2  | 35                             | 80  | 176 |
| AA    | P010          | [ ] | [ ] | M | [ ] | - | 055 | [ ] | [ ] | M | [ ]                    | 1     | 15                     | 20    | 290                            | 2  | 35                             | 100 | 212 |
| ACS   | P010          | [ ] | [ ] | M | [ ] | - | 055 | [ ] | [ ] | M | [ ]                    | 1     | 15                     | 20    | 290                            | 2  | 35                             | 50  | 122 |

**Note:** AO / AA / WS grade filters for use up to 16 bar g (232 psi g) are supplied with a float drain [F] as standard.  
 For pressures between 16 and 20 bar g (232 and 290 psi g) a manual drain [M] must be used.  
 ACS grade filters are supplied with a manual drain [M] as standard.

**Painot ja mitat**

Vikter och dimensioner, Vekt og dimensioner, Vægt og mål, Βάρη και διαστάσεις, Pesos e Dimensões



| Model      | Pipe Size | Height (H) |       | Width (W) |      | Depth (D) |      | (a) |      | (b) |      | (c) |      | (d) |     | Weight |       |
|------------|-----------|------------|-------|-----------|------|-----------|------|-----|------|-----|------|-----|------|-----|-----|--------|-------|
|            |           | mm         | ins   | mm        | ins  | mm        | ins  | mm  | ins  | mm  | ins  | mm  | ins  | mm  | ins | kg     | lbs   |
| WS / P010A | 1/4"      | 180        | 7.09  | 76        | 2.99 | 66        | 2.60 | 154 | 6.1  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 0.61   | 1.34  |
| WS / P010B | 3/8"      | 180        | 7.09  | 76        | 2.99 | 66        | 2.60 | 154 | 6.1  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 0.61   | 1.34  |
| WS / P010C | 1/2"      | 180        | 7.09  | 76        | 2.99 | 66        | 2.60 | 154 | 6.1  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 0.61   | 1.34  |
| WS / P015C | 1/2"      | 238.5      | 9.36  | 89        | 3.5  | 83.5      | 3.29 | 202 | 8.0  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 1.16   | 2.55  |
| P020C      | 1/2"      | 238.5      | 9.36  | 89        | 3.5  | 83.5      | 3.29 | 202 | 8.0  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 1.12   | 2.58  |
| WS / P020D | 3/4"      | 238.5      | 9.36  | 89        | 3.5  | 83.5      | 3.29 | 202 | 8.0  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 1.12   | 2.58  |
| WS / P025D | 3/4"      | 227        | 10.9  | 120       | 4.72 | 114.5     | 4.5  | 232 | 9.1  | 70  | 2.76 | 32  | 1.3  | 38  | 1.5 | 2.21   | 4.86  |
| WS / P025E | 1"        | 227        | 10.9  | 120       | 4.72 | 114.5     | 4.5  | 232 | 9.1  | 70  | 2.76 | 32  | 1.3  | 38  | 1.5 | 2.21   | 4.86  |
| WS / P030G | 1 1/2"    | 367        | 14.45 | 120       | 4.72 | 114.5     | 4.5  | 323 | 12.7 | 70  | 2.76 | 32  | 1.3  | 38  | 1.5 | 2.68   | 5.91  |
| WS / P035G | 1 1/2"    | 531        | 20.9  | 164       | 6.46 | 156       | 6.10 | 384 | 15.1 | 100 | 3.94 | 68  | 2.68 | 38  | 1.5 | 6.90   | 15.20 |
| WS / P040H | 2         | 623        | 24.5  | 164       | 6.46 | 156       | 6.10 | 476 | 18.7 | 100 | 3.94 | 68  | 2.68 | 38  | 1.5 | 7.30   | 16.10 |
| WS / P045I | 2 1/2     | 623        | 24.5  | 164       | 6.46 | 156       | 6.10 | 476 | 18.7 | 100 | 3.94 | 68  | 2.68 | 38  | 1.5 | 7.10   | 15.65 |
| WS / P050I | 2 1/2     | 745        | 29.3  | 192       | 7.56 | 183       | 7.20 | 587 | 23.1 | 120 | 4.72 | 68  | 2.68 | 38  | 1.5 | 10.30  | 22.71 |
| P055I      | 2 1/2     | 935        | 36.8  | 192       | 7.56 | 183       | 7.20 | 772 | 30.4 | 120 | 4.72 | 68  | 2.68 | 38  | 1.5 | 15.30  | 33.73 |
| WS / P055J | 3         | 935        | 36.8  | 192       | 7.56 | 183       | 7.20 | 772 | 30.4 | 120 | 4.72 | 68  | 2.68 | 38  | 1.5 | 15.30  | 33.73 |

Note: Water Separators do not include a DP Indicator, use dimension H + d for the total height.

**FI Asenussuositukset**

On suositeltavaa, että paineilma käsitellään ennen jakelujärjestelmään syöttämistä ja kriittisissä käyttöasteissa/käyttökohteissa.

Paineilmakuvun asennus alemmin märkään järjestelmään saattaa kasvattaa käyttöasteen suodattimen liikkuvuudesta jakelujärjestelmän kuvunisen aikana. Suodatinelementit on ehkä vaihdettava tavallista useammin tänä ajanjaksona.

Asennuksessa, joissa käytetään jlyttömiä kompressoreja, on yhä vesiaerosoleja ja hiukkasia. Tällöin on käytettävä edelleen yleiskäyttö- ja suurtehotyyppejä.

Yleiskäyttöinen suodatin on aina asennettava suojaamaan suurtehosuodatinta nestemäisiltä aerosoleilta ja kiinteiltä hiukkasilta.

Puhdistuslaitteiston on asennettava kohtaan, jossa on alhaisin jäätympisteen yläpuolinen lämpötila, mieluiten jälkijäähdyttimistä ja ilmanvastaanottoilaitteista alavirtauksen suuntaan. Käyttöasteiden puhdistuslaitteisto on asennettava mahdollisimman lähelle käyttökohdetta. Puhdistuslaitteistoa ei saa asentaa pikaventtiileistä alavirtauksen suuntaan, ja se on suojattava mahdollisilta vastavirtauksilta ja muilta häätöolosuhteilta.

Kaikista puhdistuslaitteiston viivistä putkista on poistettava ilma ennen asennusta ja kaikista putkista on poistettava ilma puhdistuslaitteiston asennuksen jälkeen ja ennen liittämistä lopulliseen käyttökohteeseen.

Jos puhdistuslaitteiston ympärille asennetaan ohitusputket, ohitusputkeen on asennettava riittävät suodatimet, jotta alavirtauksen suunnassa oleva järjestelmä ei saastu.

Sovita poistoputket hiilisuodattimista suoraan kondenssierottimeen. Jos poistoputkien liittämisen suoraan erottimen ei ole mahdollista, putket on ilmattava jakoputkiston (ilmattava toiminta päästä) ja sen jälkeen yksittäissääntöön kondenssierottimeen.

Puhdistuslaitteiston keräytävälle nesteelle on oltava poistomenetelmä. Keräytyneet nesteet on hävitettävä ja käsiteltävä vastuuntuntoisesti.

**SV Rekommendationer för installation**

Vi rekommenderar att tryckluft behandlas innan den leds in i distributionssystemet och även vid viktiga luftförbrukningspunkter/applikationer.

Installation av tryckluftstorkar i system som tidigare varit våta kan orsaka ytterligare belastning p.g.a. smuts i filtern vid förbrukningspunkterna medan distributionssystemet torkar. Under denna period kan filterelementen behöva bytas ut oftare.

För installationer där oljefria kompressorer används och där vattenaerosol och partiklar fortfarande förekommer, ska universalvarianter och högeffektiva modeller fortfarande användas. Ett universalfilter måste alltid monteras för att skydda högeffektivitetsfiltern från vätskeerosoler i stora mängder samt fasta partiklar.

Installera reningstrutningen vid lägsta temperatur över fryspunkten, helst nedströms från efterkylare och tryckluftbehållare.

Reningstrutning vid förbrukningspunkterna ska installeras så nära applikationen som möjligt. Reningstrutningen bör inte installeras nedströms från snabböppnande ventiler, och den bör skyddas från eventuella backflöden och andra slagrörelser.

Töm alla rör som leder till reningstrutningen före installationen, och töm även alla rör efter att reningstrutningen har installerats samt före anslutning till den slutliga applikationen.

Om shuntledningar monteras runt reningstrutningen ska tillräcklig filtrering monteras på shuntledningarna för att förhindra att systemet förorenas nedströms.

Dräneringsledningningar direkt från koalescensfilter till kondensseparator. Om inte ledningarna kan dras direkt till en separator bör ledningarna dras till ett kondensgrenör (med utsläpp i ena änden) och sedan till en enda ingång på en kondensseparator.

Ombesörj en anordning för att tömma ut uppsamlade vätskor från reningstrutningen. Uppsamlade vätskor ska behandlas och bortskaffas på ett ansvarsfullt sätt.

**NO Anbefalinger for installering**

Det anbefales at den komprimerte luften behandles før den føres inn i distribusjonssystemet og også ved kritiske brukspunkter eller enheter.

Installering av luftfuktere for komprimert luft til et tidligere fuktig system kan føre til midlertidig smussbelastning for filtre ved brukspunkt i en periode mens distribusjonssystemet tørker ut. Filterelementene må kanskje skiftes oftere i denne perioden.

For installeringer der det brukes oljefrie kompressorer og det fortsatt finnes vannerosoler og partikler, bør det fortsatt brukes universal- og mikrofilterkvalitet.

Et universalfilter må alltid installeres for å beskytte mikrofilteret fra store volumer av væskeerosoler og faste partikler.

Installer rensustyr ved laveste temperatur over frysepunktet, fortrinnsvis nedstrøms for etterkylere og luftmottakere.

Rensustyr ved brukspunkt skal installeres så nær enheten som mulig.

Rensustyr skal ikke installeres nedstrøms for hurtigåpningsventiler og skal beskyttes mot mulig motstrøm eller andre stedsituasjoner.

Spyl alle rør som fører til rensustyret før installering, og alle rør etter installering av rensustyret og før tilkobling til sluttenheten.

Hvis det kobles til stikkør rundt rensustyret, skal man sørge for at det kobles tilstrekkelig filtrering til stikkørret for å hindre kontaminering av systemet nedstrøms.

Fest avløpsrør fra vannskillerfilterne direkte til en kondensatsutskiller. Dersom det ikke er mulig å koble avløpsrør direkte til en separator, skal linjene være ventiltert inn i en kondensatmanifold (luftet i den ene enden) og deretter inn i et enkelt inntak på en kondensatseparator.

Sørg for at det finnes mulighet for å drenere bort opsamlende væsker fra rensustyret. Opsamlende væsker bør behandles og avhendes på en ansvarlig måte.

**DA Installationsanbefalinger**

Det anbefales at behandle trykluft, for den sendes ind i fordelingsystemet, samt på kritiske brugssteder/apparater.

Installation af trykluftreanlæg i et tidligere vådanlæg kan i en periode medføre ekstra belastning p.g.a. smuds for filtre på brugsstedet, mens fordelingsystemet udtørres. Filterelementerne skal muligvis udskiftes oftere i denne periode.

I installationer med oljefrie kompressorer vil der stadig være vanddråber og -partikler, og der bør fortsat bruges universalfiltre samt filtre med høj effektivitetsklassificering.

Der skal altid installeres et universalfilter for at beskytte det højeffektive filter mod store mængder væske dråber og faste partikler.

Installer rensingsudstyr ved den lavest mulige temperatur over frysepunktet og helst efter efterkøler og luftudskillere.

Rensingsudstyr på brugsstedet bør installeres så tæt på apparaturet som muligt.

Rensingsudstyr bør ikke installeres efter lynåbneventiler og bør beskyttes mod eventuel modstrøm eller andre stødsitici.

Udluft alle rør, der fører til rensingsudstyret, før det installeres, og samtlige rør efter at rensingsudstyret er installeret, og før det tilsluttes det endelige apparatur.

Hvis der er monteret omløbsrør rundt om rensingsudstyret, skal der altid monteres passende filteringsudstyr på disse omløbsrør for at forhindre forurening af systemet længere fremme.

Montrér afløbsrør fra koalescensfilterne direkte på en kondensseparator. Hvis det ikke er muligt at tilslutte afløbsrørene direkte på en separator, skal rørene udluftes ind i et kondensatgrenør (udluftet i den ene ende) og derefter ind i et enkelt indløb på en kondensseparator.

Sørg for, at der er et anlæg til at fjerne den opsamlende væske fra rensingsudstyret. Opsamlet væske skal behandles og bortskaffes på ansvarlig vis.

**EL Συστάσεις εγκατάστασης**

Ο χειρισμός του πεπισμένου αέρα συνιστάται να πραγματοποιείται πριν την εισαγωγή στο σύστημα διανομής, καθώς επίσης και σε κρίσιμα σημεία/εφαρμογές χρήσης.

Η εγκατάσταση ξηραντήρων πεπισμένου αέρα σε προηγούμενος υγρό σύστημα μπορεί να έχει ως αποτέλεσμα πρόσθετη βροχή στο σημείο χρήσης των φίλτρων για ένα χρονικό διάστημα, έως ότου στεγνώσει το σύστημα διανομής. Τα φίλτρα ενδέχεται να πρέπει να αλλάζονται πιο συχνά κατά το χρονικό αυτό διάστημα.

Για τις εγκαταστάσεις όπου χρησιμοποιούνται συμπίεστες χωρίς λάδι, εξακολουθεί να υπάρχει νερό με μορφή αερολύματος και αιωρούμενων σωματιδίων, για αυτό και θα πρέπει να συνεχίσουν να χρησιμοποιούνται φίλτρα γενικής χρήσης υψηλής απόδοσης.

Το φίλτρο γενικής χρήσης πρέπει πάντα να τοποθετείται έτσι ώστε να προστατεύει το φίλτρο υψηλής απόδοσης από μεγάλους όγκους υγρών με μορφή αερολύματος και στερεών σωματιδίων.

Τοποθετήστε τον εξοπλισμό καθαρισμού στη χαμηλότερη θερμοκρασία πάνω από το σημείο πήξης, κατά προτίμηση κατόπι των μεταγωγικών και των καταναλωτικών αέρα.

Το σημείο χρήσης του εξοπλισμού καθαρισμού πρέπει να είναι τοποθετημένο όσο το δυνατό πιο κοντά στη εφαρμογή.

Ο εξοπλισμός καθαρισμού δεν πρέπει να τοποθετείται κατόπι των ταχυβαλβίδων και θα πρέπει να είναι προστατευμένος από πιθανή αντίστροφη ροή ή άλλες πιθανές αιτίες πρόκλησης κρούσματος.

Πριν την εγκατάσταση, κάντε εξέρωση όλων των σωληνώσεων που οδηγούν στον εξοπλισμό καθαρισμού. Επίσης, κάντε εξέρωση όλων των σωληνώσεων μετά την εγκατάσταση του εξοπλισμού καθαρισμού και πριν τη σύνδεση στην τελική εφαρμογή.

Εάν πριν και μετά τον εξοπλισμό καθαρισμού είναι τοποθετημένοι αγωγοί παράκαμψης, βεβαιωθείτε ότι εφαρμόζεται επαρκές φιλτράρισμα στον αγωγό παράκαμψης, για να αποφευχθεί η μόλυνση του συστήματος κατόπι.

Προσαρμάστε τους αγωγούς αποστράγγισης από τα φίλτρα προσκόλλησης απευθείας σε έναν διαχωριστή υδροπονημένων καταλοίπων. Αν δεν είναι δυνατό να συνδεθούν οι αγωγοί αποστράγγισης απευθείας σε έναν διαχωριστή, οι αγωγοί θα πρέπει να εκτονωθούν σε μια πλαστική υδροπονημένων καταλοίπων (με εξέρωση στο ένα άκρο) και στη συνέχεια σε μια ενιαία εισαγωγή ενός διαχωριστή υδροπονημένων καταλοίπων.

Παράχεται δυνατότητα αποστράγγισης των συσσωρευμένων υγρών από τον εξοπλισμό καθαρισμού. Ο χειρισμός και η απόρριψη των συσσωρευμένων υγρών πρέπει να πραγματοποιείται με υπεύθυνο τρόπο.

**PT Recomendações sobre a instalação**

Recomenda-se que o ar comprimido seja tratado antes da entrada no sistema de distribuição e também em aplicações/pontos de utilização críticos.

A instalação dos secadores de ar comprimido num sistema previamente húmido pode resultar numa acumulação adicional de sujidade nos pontos de utilização dos filtros durante o período em que o sistema de distribuição seca. Os elementos do filtro podem necessitar de ser substituídos com mais frequência durante este período.

Para instalações em que são utilizados compressores sem óleo, estão ainda presentes os aerossóis e partículas de água e ainda devem ser utilizados graus gerais e de elevado rendimento.

Um filtro geral deve ser sempre instalado para proteger o filtro de elevado rendimento dos aerossóis líquidos em bruto e das partículas sólidas.

Instale o equipamento de purificação na temperatura mais baixa acima do ponto de congelamento, preferencialmente a jusante dos refrigeradores posteriores e dos receptores de ar.

O ponto de utilização do equipamento de purificação deve ser instalado o mais próximo possível da aplicação.



O equipamento de purificação não deve ser instalado a jusante das válvulas de abertura rápida e deve ser protegido de um possível fluxo inverso ou de outras condições de choque.

Purgue todos os tubos que levam ao equipamento de purificação antes da instalação e todos os tubos após a instalação do equipamento de purificação e antes da ligação para a aplicação final.

Se as linhas de by-pass forem instaladas em volta do equipamento de purificação, certifique-se de que a filtragem adequada é instalada na linha de by-pass para evitar a contaminação do sistema a jusante.

Instale os tubos de drenagem a partir dos filtros coalescentes directamente para um separador de condensado. Se não for possível ligar directamente os tubos de drenagem a um separador, os tubos devem ser ventilados para um colectador de condensado (ventilado numa extremidade) e, em seguida, para uma entrada única de um separador de condensado.

Começa um instrumento para drenar os líquidos recolhidos do equipamento de purificação. Os líquidos recolhidos devem ser tratados e eliminados de uma forma responsável.



**(F)** Alempi sulkulevy voi liikkua, kun suodatinta ei ole paineistettu



Alempi sulkulevy ei vaadi huoltoa eikä sitä saa koskaan irrottaa.

**(SV)** Den nedre stängningsplattan kan röra sig om filtret inte trycksätts



Den nedre stängningsplattan går inte att utföra service på och ska aldrig tas bort.

**(NO)** Den nedre lukkeplaten vil kunne bevege seg når filteret ikke er trykksatt



Den nedre lukkeplaten skal ikke vedlikeholdes og bør aldri fjernes.

**(DA)** Den nederste lukkeplade kan flytte sig, når filteret ikke er under tryk



Den nederste lukkeplade kan ikke servicerer, og den må ikke afmonteres.

**(EL)** Η κάτω πλάκα κλεισίματος μπορεί να μετακινηθεί εάν το φίλτρο δεν βρίσκεται υπό πίεση



Η κάτω πλάκα κλεισίματος δεν επιδέχεται σέρβις και δεν πρέπει να αφαιρείται ποτέ.

**(PT)** A placa de isolamento inferior pode deslocar-se se o filtro não estiver pressurizado



A placa de isolamento inferior não necessita de manutenção e nunca deve ser retirada.

**FI Käynnistys ja käyttö**



Varmista ennen suodattimen paineistusta, että pää ja pesä on asetettu oikein ja että lukitusmekanismi on tässä oppaassa olevan kuvan osoittamalla tavalla huoltotilassa (huoltotoimenpide 5).

1. Paineista yksikkö asteittain avaamalla tuloventtiili.
2. Paineista laskuputkisto uudelleen avaamalla lähtöventtiili hitaasti.

Älä avaa tulo- tai lähtöventtiiliä nopeasti tai altista yksikköä liialliselle paine-erolle, sillä yksikkö voi vaurioitua.

**SV Start och drift**



Före trycksättning ska du kontrollera att huvudet och filterskålen är ordentligt monterade och att läsanordningen är korrekt inriktad så som visas i underhållsavsnittet (underhållsproceduren 6) i den här manualen.

1. Öppna inloppsventilen långsamt så att enheten trycksätts gradvis.
2. Öppna utloppsventilen långsamt för att trycksätta rörsystemet nedströms igen.

Öppna inte inlopps- eller utloppsventilerna snabbt och utsätt inte enheten för överdrivet differentiattryck, eftersom det kan orsaka skador.

**NO Oppstart og drift**



Før trykksætning av filteret, påse at filterhodet og filterskålen er korrekt montert og at låsemekanismen er riktig justert, som vist i vedlikeholdsavsnittet (vedlikeholdsprosedyre 6) i denne håndboken.

1. Åpne inntaksventilen langsomt for å sette enheten gradvis under trykk.
2. Åpne uttaksventilen langsomt for å sette nedstrømsrørene under trykk igjen.

Ikke åpne inntaks- eller uttaksventilene raskt, eller utsett enheten for høyt differensialtrykk, da dette kan føre til skade.

**DA Start og drift**



Inden filteret sættes under tryk, skal det sikres, at hovedet og beholderen er korrekt monteret, og at låsemærkerne står ud for hinanden som vist i afsnittet om vedligeholdelse (vedligeholdelsesproceduren 6) i denne manual.

1. Åbn indgangsventilen langsomt for gradvist at sætte enheden under tryk.
2. Åbn udløbsventilen langsomt for at sætte rørene længere fremme under tryk igen.

Åbn ikke indgangs- eller udgangsventiler hurtigt, og udsæt ikke enheden for store trykforskelle, da det kan medføre skader.

**EL Έναρξη λειτουργίας και χειρισμός**



Πριν θέσετε το φίλτρο υπό πίεση, βεβαιωθείτε ότι η κεφαλή και το ποτήρι του φίλτρου είναι σωστά προσαρμοσμένα και ότι τα σημεία ασφάλισης είναι σωστά ευθυγραμμισμένα, όπως απεικονίζεται στην ενότητα συντήρησης (διαδικασία συντήρησης 6) αυτού του εγχειριδίου.

1. Ανοίξτε αργά τη βαλβίδα εισαγωγής για να ανέβει σταδιακά η πίεση της μονάδας.
2. Ανοίξτε αργά τη βαλβίδα εξαγωγής για να ανέβει η πίεση της σωληνώσεως κατόπιν.

Μην ανοίγετε γρήγορα τις βαλβίδες εισαγωγής ή εξαγωγής και μην υποβάλλετε τη μονάδα σε υπερβολική διαφορετική πίεση, διότι μπορεί να προκύψει βλάβη.

**PT Arranque e Funcionamento**



Antes de pressurizar o filtro, certifique-se de que a cabeça e o copo estão instalados correctamente e de que o detalhe de bloqueio está correctamente alinhado, conforme ilustrado na secção de manutenção (procedimento de manutenção 6) deste manual.

1. Abra lentamente a válvula de entrada para pressurizar gradualmente a unidade.
2. Abra lentamente a válvula de saída para voltar a pressurizar a tubagem a jusante.

Não abra rapidamente as válvulas de entrada ou de saída nem sujeite a unidade a uma pressão diferencial excessiva, caso contrário poderão ocorrer danos.

Lisävarusteet / varaosat (Huoltopakkaukset)  
Tilbehør / Reservdelar (servicepaket), Tilbehør / Reservedeler (Service Kits), Tilbehør / Reserverdele (Servicesæt),  
Εξαρτήματα / Ανταλλακτικά (Κιτ σέρβις), Acessórios / Peças Sobressalentes (Kits de Manutenção)

| Filter Models | Catalogue Number | Contents |
|---------------|------------------|----------|
| 010           | TRK1-2           |          |
| 015 - 020     | TRK2-2           |          |
| 025 - 030     | TRK3-2           |          |
| 035 - 045     | TRK4-2           |          |
| 050 - 055     | TRK5-2           |          |
| 010           | MBK1-1           |          |
| 015 - 020     | MBK2-1           |          |
| 025 - 030     | MBK3-1           |          |
| 035 - 045     | MBK4-1           |          |
| 050 - 055     | MBK5-1           |          |
| 010           | MBK1-2           |          |
| 015 - 020     | MBK2-2           |          |
| 025 - 030     | MBK3-2           |          |
| 035 - 045     | MBK4-2           |          |
| 050 - 055     | MBK5-2           |          |
| 010 - 055     | EM1              |          |
| 010 - 055     | PD15NO           |          |
| 010 - 030     | DPI-K            |          |
| 035 - 055     | ZD90GL           |          |

**Huolto**

**Underhåll, Vedlikehold, Vedligeholdelse, Συντήρηση, Manutenção**

**Ⓜ Huoltovälit**

Jotta voitaisiin varmistaa suodattimen ihanteellinen suorituskyky, vaaditaan AO, AA, ja -luokituksen elementtien vaihto 12 kuukauden välein yhdessä automaattipoistoputken kanssa.

ACS-elementin suoritus perustuu tulevan öljyhöyryn enimmäispitoisuuteen, joka on 0,018 mg/m<sup>3</sup>. Korvaa hiilisuodattin-elementti, kun huomaat höyryä, hajua tai makua. Toisin kuin öljyaerosolien poistosuodattimet, jotka vaihdetaan vuosittain paineistetun ilman laadun takaamisen takia, öljyhöyryn poistosuodattimen käyttöikä riippuu monista asioista, ja se on ehkä vaihdettava useammin (paitsi jos käytetään poistosuodatinta, joka on mitoitettu 6 000:lle tunnille):

**Adsorbentisuodattimien käyttöikään vaikuttavat tekijät**

**Öljyhöyrypitoisuus**

Mitä korkeampi öljyhöyryn tulopitoisuus on, sitä nopeammin aktiivihiilikapasiteetti vanhenee.

**Irtoöljy**

Adsorbentisuodattimet on tarkoitettu poistamaan öljyhöyryä ja -hajuja, mutta ei nestemäistä öljyä tai aerosoleja. Huonosti hoidettu tai olematon esisuodatus vähentää öljyhöyryn poistosuodattimen kapasiteettia nopeasti.

**Lämpötila**

Öljyhöyrysisältö lisääntyy eksponentiaalisesti tulolämpötilassa ja vähentää näin ollen elementin käyttöikää. Lisäksi lämpötilan noustessa adsorptiokyky vähenee, mikä myös vähentää elementin käyttöikää.

**Suhteellinen kosteus tai kastepiste**

Märkä ilma vähentää hiilen adsorptiokykyä.

**Kompressoröljyn vaihdot**

Kun kompressoröljyt vaihdetaan, uusi voiteluaine polttaa "kevyet loppujakeet" pois, mikä lisää öljyhöyrypitoisuutta tunneiksi tai jopa viikoiksi sen jälkeen. Öljyhöyryn poistosuodattimen lisääntyneen öljyhöyryn ja näin ollen vähentää huomattavasti sen adsorptiokäyttöikää.

**Ⓜ Underhållsintervall**

För att säkerställa optimal funktion ska elementen klassade AO, AA, bytas ut var 12:e månad tillsammans med den automatiska tömningen.

Prestandan hos ACS -elementet baseras på en maximal inloppskoncentration av oljedimma på 0,018 mg/m<sup>3</sup>. Byt ut koffilterelementet vid detektering av dimma, odoör eller smak.

Till skillnad från filter för borttagning av oljaerosol om byts ut årligen för att säkerställa tryckluftskvaliteten, kan livslängden på ett oljedimdebortagningsfilter påverkas av olika faktorer och kräva mer frekvent byten (om inte OVR används som är utformat för en livslängd på 6 000 timmar):

**Faktorer som påverkar adsorptionsfilters livslängd**

**Oljedimmans koncentration**

Ju högre inloppskoncentration av oljedimma desto snabbare försämrans det aktiva kolets kapacitet.

**Bulkolja**

Adsorptionsfilter är utformade för att avlägsna oljedimma och odoörer, inte flytande olja eller aerosoler. Dåligt underhåll eller obehörig förfiltrering gör att OVR-filterets kapacitet snabbt försämrans.

**Temperatur**

Oljedimmenivån ökar exponentiellt mot inloppstemperaturen och minskar elementlivslängden. Dessutom försämrans adsorptionskapaciteten när temperaturen stiger, vilket även detta minskar elementlivslängden.

**Relativ fuktighet eller duggpunkt**

Fuktig luft minskar kolets adsorptionskapacitet.

**Byte av kompressorolja**

Vid byte av kompressorolja bränner det nya smörjmedlet av "lätta produkter" vilket ökar mängden oljedimma i timmar eller till och med veckor efteråt. Denna ökning av mängden oljedimma adsorberas av OVR-filteret, vilket minskar dess livslängd avsevärt.

**Ⓜ Vedlikeholdesintervaller**

För å sikre optimal filterytelse, krever klasse AO, AA, -elementene utskiftning hver 12. måned sammen med det automatiske avløpet.

Ytelsen til ACS-elementet er basert på maksimal oljedampinntakskonstrasjon på 0,018 mg/m<sup>3</sup>. Skift ut karbonfilterelementet hvis du oppdager damp, lukt eller smak.

Til forskjell fra filtre for fjerning av oljespray, som skiftes ut hvert år for å garantere kvaliteten på den komprimerte luften, kan levetiden til et filter for fjerning av oljespray tilskrives forskjellige faktorer og kreve hyppigere skift (bortsett fra hvis OVR brukes, da det har en levetid på 6000 timer):

**Faktorer som påvirker levetiden til adsorptionsfiltere**

**Oljedampkonsentrasjonen**

Jo høyere inntakskonstrasjon av oljedamp, jo raskere ekspirerer den aktive karbonkapasiteten.

**Bulkolje**

Adsorptionsfiltere er utformet for å fjerne oljedamp og lukt, ikke flytende olje eller aerosoler. Hvis det ikke finnes forfiltrering, eller den er dårlig vedlikeholdt, kan det føre til at OVR-filterkapasiteten utløper raskere.

**Temperatur**

Oljedampinnholdet øker eksponentielt i forhold til inntakstemperaturen, og reduserer elementets levetid. I tillegg reduseres adsorptionskapasiteten etter hvert som temperaturen øker, og reduserer elementets levetid.

**Relativ fuktighet eller duggpunkt**

Våt luft reduserer karbonets adsorberende kapasitet.

**Kompressoroljeskift**

Når kompressoroljen skiftes, brenner det nye smøremiddelet av lettkomponenter som øker oljedampinnholdet i mange timer eller til og med uker etterpå. Denne økningen i oljedampinnhold adsorberes av OVR-filteret, noe som reduserer levetiden betraktelig.

**Ⓜ Vedligeholdelsesintervaller**

For å sikre optimal filterytelse, skal elementer i kvalitet AO, AA, udskiftes hver 12. måned sammen med det automatiske afløb.

ACS-elementets ydelse er baseret på en maksimal indgangskoncentration i oliedamp på 0,018 mg/m<sup>3</sup>. Udskeft kulfiltrelementet ved registrering af damp, lugt eller smag.

Mosdat filtre til fjernelse af olieedraber, der udskiftes årligt for at sikre trykluftkvaliteten, kan levetiden for filteret til fjernelse af oliedamp tilskrives forskellige faktorer og kræve hyppigere udskiftninger (medmindre der bruges OVR, som er beregnet til en levetid på 6.000 timer):

**Faktorer, der påvirker adsorptionsfiltere**

**Oliedampkoncentration**

Jo højere oliedampindgangens koncentration er, jo hurtigere ophører det aktive kuls kapacitet.

**Olje**

Adsorptionsfiltere er udviklet til at fjerne olie damp og -lugt, ikke flydende olie eller dråber. Dårligt vedligeholdt eller ikke-eksisterende forfiltrering vil få OVR-filterkapaciteten til at ophøre hurtigt.

**Temperatur**

Oliedampindholdet øges eksponentielt ift. indgangstemperaturen, hvilket reducerer elementets levetid. Derudover mindskes adsorptionskapaciteten også i takt med, at temperaturen stiger, hvilket også medfører reduceret levetid.

**Relativ luftfugtighed eller duggpunkt**

Våd luft reducerer kulelets adsorptionskapacitet.

**Udskiftning af kompressorolie**

Når kompressorolien udskiftes, brænder det nye smøremiddel "lette ender" af, hvilket øger oliedampindholdet i flere timer eller endda uger efterfølgende. Forøgelsen af oliedampindholdet adsorberes af OVR-filteret, hvilket nedsætter dets adsorptionsmæssige levetid.

**Ⓜ Διαστήματα συντήρησης**

Για να εξασφαλίσετε τη βέλτιστη απόδοση του φίλτρου, τα στοιχεία βαθμίδας AO, AA, χρειάζεται να αλλάζονται κάθε 12 μήνες, μαζί με την αυτόματη αποστράγγιση.

Η απόδοση του στοιχείου ACS έχει υπολογιστεί για μέγιστη συγκέντρωση ατμών λαδιού στην εισαγωγή 0,018 mg/m<sup>3</sup>. Αντικαθιστάτε το στοιχείο φίλτρου άνθρακα όταν ανιχνεύετε ατμούς, οσμές ή γεύσεις.

Αντίθετα με τα φίλτρα αφαίρεσης αερολυμάτων λαδιού, τα οποία αντικαθίστανται μία φορά το χρόνο για να εξασφαλίζουν την ποιότητα του πεπεσμένου αέρα, η διάρκεια ζωής ενός φίλτρου αφαίρεσης ατμών λαδιού μπορεί να επηρεάζεται από διάφορους παράγοντες και να απαιτούνται πιο τακτικές αλλαγές (εκτός αν χρησιμοποιείται φίλτρο OVR, το οποίο είναι καταλληλό για διάρκεια ζωής 6000 ωρών):

**Παράγοντες που επηρεάζουν τη διάρκεια ζωής των φίλτρων προσρόφησης**

**Συγκέντρωση ατμών λαδιού**

Όσο μεγαλύτερη είναι η συγκέντρωση των ατμών λαδιού στην εισαγωγή, τόσο πιο νωρίς θα λήξει η ικανότητα φιλτραρίσματος του ενεργού άνθρακα.

**Μεγάλος όγκος λαδιού**

Τα φίλτρα προσρόφησης είναι σχεδιασμένα για να αφαιρούν ατμούς λαδιού και οσμές, όχι υγρό λάδι ή αερολύματα. Η κακή συντήρηση ή η αυταπάρα προφιλτραρίσματος προκαλεί τυχόν λάθη ή ικανότητα φιλτραρίσματος ενός φίλτρου OVR.

**Θερμοκρασία**

Η περιεκτικότητα σε ατμούς λαδιού αυξάνει εκθετικά σε σχέση με τη θερμοκρασία της εισαγωγής, μειώνοντας τη διάρκεια ζωής του φίλτρου. Επιπλέον, καθώς αυξάνεται η θερμοκρασία, η ικανότητα προσρόφησης ελαττώνεται, μειώνοντας και πάλι τη διάρκεια ζωής του φίλτρου.

**Σχετική υγρασία ή σημείο δρόσου**

Η μεγάλη υγρασία στον αέρα μειώνει την ικανότητα προσρόφησης του άνθρακα.

**Αλλαγές λαδιών του συμπιεστή**

Όταν αλλάζει το λάδι στον συμπιεστή, καίγονται τα "ελαφρά συστατικά" του λιπαντικού, αυξάνοντας έτσι την περιεκτικότητα σε ατμούς λαδιού για μερικές ώρες ή ακόμα και εβδομάδες μετά την αλλαγή. Η αυξημένη περιεκτικότητα σε ατμούς λαδιού προσροφάται από το φίλτρο OVR, μειώνοντας σημαντικά την προσροφητική διάρκεια ζωής του.

**Ⓜ Intervalos de Manutenção**

Para garantir um desempenho ideal do filtro, os elementos de grau AO, AA, necessitam de ser substituídos a cada 12 meses juntamente com o dreno automático.

O desempenho do elemento ACS é baseado numa concentração máxima da entrada de vapor do óleo de 0,018 mg/m<sup>3</sup>. Substitua o elemento do filtro de carvão mediante a detecção de vapor, odor ou sabor.

Ao contrário dos filtros de remoção dos aerossóis do óleo que são anualmente substituídos para garantir a qualidade do ar comprimido, a duração de um filtro de remoção do vapor do óleo pode ser atribuída a diversos factores e requer substituições mais frequentes (exceto se o OVR for utilizado, aumentando assim para uma duração de 6000 hrs):

**Factores que afectam a duração dos filtros de adsorção**

**Concentração do vapor do óleo**

Quanto maior for a concentração de entrada do vapor de óleo, mais rapidamente irá expirar a capacidade do carvão activado.

**Óleo em bruto**

Os filtros de adsorção foram concebidos para remover os vapores e odores do óleo e não o óleo líquido ou os aerossóis. A pré-filtragem não existente ou com uma fracca manutenção irá fazer com que a capacidade do filtro OVR se extinga rapidamente.

**Temperatura**

O conteúdo do vapor do óleo aumenta exponencialmente para a temperatura de entrada, reduzindo o tempo de vida útil do elemento. Para além disso, à medida que a temperatura aumenta, a capacidade de adsorção diminui, reduzindo novamente o tempo de vida útil do elemento.

**Humidade Relativa ou Ponto de Condensação**

O ar húmido reduz a capacidade de adsorção do carvão.

**Substituição do óleo do compressor**

Quando o óleo do compressor for substituído, o novo lubrificante queima as "extremidades leves" aumentando o conteúdo do vapor do óleo durante horas ou até mesmo durante algumas semanas. Este aumento do conteúdo do vapor do óleo é adsorvido pelo filtro OVR, reduzindo significativamente a respectiva duração da adsorção.

**FI** Huoltotoimenpiteet 1

Sulje sisäänmenoputki (1) ja poistoventtiilit (2) rauhallisesti ja poista paineistus venttiilistä (3) poistoputkea käyttäen.

**SV** Underhållsprocedur 1

Stäng långsamt inlopps- (1) och utloppsventilerna (2) och sänk trycket i filteret (3) med tömningen.

**NO** Vedlikeholdsprosedyre 1

Steng ventilene i innløp (1) og uttak (2) langsomt og reduser trykket i filteret (3) ved hjelp av avløpet.

**DA** Vedligeholdelsesprocedure 1


Luk indgangs- (1) og udgangsventilerne (2) langsomt, og tag trykket af filteret (3) ved hjælp af afløbet.

**EL** Διαδικασία συντήρησης 1

Κλείστε αργά τις βαλβίδες εισαγωγής (1) και εξαγωγής (2) και αποσυμπιέστε το φίλτρο (3) με τη βοήθεια της αποστράγγισης.

**PT** Procedimento de Manutenção 1

Feche lentamente as válvulas de entrada (1) e de saída (2) e despressurize o filtro (3) utilizando o dreno.



**FI** Huoltotoimenpiteet 2

Avaa suodatinastiat (1 ja 2) ja poista käytetty elementti (3).

**SV** Underhållsprocedur 2

Skruva loss filterskålen (1 och 2) och ta bort det förbrukade elementet (3).

**NO** Vedlikeholdsprosedyre 2

Skru løs filterskålene (1 & 2) og fjern de brukte elementene (3).

**DA** Vedligeholdelsesprocedure 2


Skru filterbeholderen af (1 og 2), og fjern det brugte element (3).

**EL** Διαδικασία συντήρησης 2

Ξεβιδώστε το ποτήρι του φίλτρου (1 & 2) και αφαιρέστε το μεταχειρισμένο στοιχείο (3).

**PT** Procedimento de Manutenção 2

Desaperte o copo (1 e 2) do filtro e retire o elemento utilizado (3).



**FI** Huoltotoimenpiteet 3

Ruuvaa auki automaattinen poistoputki (1) ja hävitä se (2). Sovita paikalleen uusi putki (3) ja kiristä (4).

**SV** Underhållsprocedur 3

Skruva loss den automatiska tömningen (1) och avyttra den (2). Sätt den nya tömningen på plats (3) och dra åt (4).

**NO** Vedlikeholdsprosedyre 3

Skru løs det automatiske avløpet (1) og kast det (2). Monter det nye avløpet (3) og stram til (4).

**DA** Vedligeholdelsesprocedure 3


Skru det automatiske afløb af (1), og bortskaf det (2). Monter det nye afløb (3), og spænd (4).

**EL** Διαδικασία συντήρησης 3

Ξεβιδώστε την αυτόματη αποστράγγιση (1) και πετάξτε την (2). Τοποθετήστε τη νέα αποστράγγιση (3) και σφίξτε την (4).

**PT** Procedimento de Manutenção 3

Desaperte o dreno automático (1) e elimine-o (2). Instale o novo dreno (3) e aperte (4).



**FI** Huoltotoimenpiteet 4

Sijoita uusi elementti suodatinastiaan varmistuen, että nokat ovat asianmukaisesti koloissaan.

**SV** Underhållsprocedure 4

Sätt i det nya elementet i filterskålen och se till att stiften passar i spåren.

**NO** Vedlikeholdsprosedyre 4

Sett det nye elementet inn i filterskålen og sikre at hakene sitter riktig i sporene.

**DA** Vedligeholdelsesprocedure 4


Sæt det nye element i filterbeholderen, og sørg for, at taperne sidder korrekt i rillerne.

**EL** Διαδικασία συντήρησης 4

Τοποθετήστε το νέο στοιχείο μέσα στο ποτήρι του φίλτρου, προσέχοντας οι προεξοχές να καθίσουν καλά μέσα στις εγκοπές.

**PT** Procedimento de Manutenção 4

Introduza o novo elemento no copo do filtro certificando-se de que as patilhas estão correctamente assentes nas ranhuras.



**FI** Huoltotoimenpiteet 5

Vaihda suodatinpään kummallakin puolella olevat O-renkaat uusiin..



**Varmista, että voitelet O-renkaan ja säikeet sopivalla hapottomalla vaseliinilla.**

**SV** Underhållsprocedure 5

Byt ut O-ringen som sitter i filterhuvudet mot den nya, medföljande O-ringen..



**Se till att smörja O-ringen och gängorna med någon passande syrefri oljegel.**

**NO** Vedlikeholdsprosedyre 5

Bytt ut O-ringen som ligger i filterskålen med den nye O-ringen som følger med.



**Sørg for å smøre O-ringen og gjengene med en passende syrefri vaselin.**

**DA** Vedligeholdelsesprocedure 5

Udskift O-ringen i filterhovedet med den nye medfølgende O-ring.



**Smør O-ringen og gevindet med en egnet syrefri vaseline.**

**EL** Διαδικασία συντήρησης 5

Αντικαταστήστε τον δακτύλιο O που βρίσκεται μέσα στην κεφαλή του φίλτρου με τον νέο παρεχόμενο δακτύλιο O.




**Μην παραλείψετε να λιπάνετε τον δακτύλιο O και τα σπειρώματα με κατάλληλη γέλη πετρελαίου χωρίς οξέα.**

**PT** Procedimento de Manutenção 5

Substitua o O-ring situado na cabeça do filtro pelo novo O-ring fornecido.



**Certifique-se de que lubrifica o O-ring e as roscas com vaselina adequada e sem ácido.**



**FI** Huoltotoimenpiteet 6 (a)

Sijoita suodatinastia ja -pää paikoilleen varmistuen siitä, että se sopii paikoilleen ja lukitusmekanismit ovat kohdakkain.

**Huomautus:** Jotta voidaan varmistaa astian kiinnittyminen päähän, 010-030-astia vaatii 360 °:n käännöksen ja 035-045-astia 720°:n käännöksen siihen asti, että kierre pysähtyy.

**SV** Underhållsprocedure 6 (a)

Sätt tillbaka filterskålen och huvudet och se till att de är ordentligt ådragna och att låsanordningarna är korrekt inriktade.

**OBS!** För att säkerställa att skålen är ordentligt festsatt i huvudet kräver skålen 010-030 360° vridning tills gängorna tar emot och skålen 035-045 kräver 720°.

**NO** Vedlikeholdsprosedyre 6 (a)

Monter filterskålen og hodet og sikre at gjengene griper riktig og låsmekanismene er justert.

**Obs!** For å sikre at skålen er satt helt inn i hodet, krever skål 005-030 360°rotasjon for gjengen stopper, og 720° for skål 035-045.

**DA** Vedligeholdelsesprocedure 6 (a)

Genmonter filterbeholderen og filterhovedet. Gevindet skal være skruet helt i bund, og læsemærkerne skal stå ud for hinanden.

**Bemærk:** For at sikre, at beholderen sidder korrekt i hovedet, skal 005-030-beholderen drejes 360° indtil gevindstoppet og 720° for 035-045-beholderen

**EL** Διαδικασία συντήρησης 6 (a)



Επανατοθετήστε το ποτήρι του φίλτρου και την κεφαλή, προσέχοντας τα σπειρώματα να βιδώσουν καλά μεταξύ τους και να ευθυγραμμιστούν τα σημεία ασφάλισης.

**Σημείωση:** Για να βεβαιωθείτε ότι το ποτήρι έχει τοποθετηθεί καλά μέσα στην κεφαλή, να έχετε υπόψη σας ότι το ποτήρι 010-030 απαιτεί περιστροφή 360° μέχρι να βιδώσει εντελώς και 720° για το ποτήρι 035-045.

**PT** Procedimento de Manutenção 6 (a)

Volte a instalar a cabeça e o corpo do filtro certificando-se de que as roscaes estão totalmente encaixadas e de que os detalhes de bloqueio estão alinhados.

**Nota:** Para se certificar de que o corpo está totalmente encaixado na cabeça, o corpo 010-030 necessita de uma rotação de 360° até atingir o batente da roscae o corpo 035-045 necessita de uma rotação de 720°.



**FI** Huoltotoimenpiteet 7

Kiinnitä suodatinastia vaihtopäivätarra ja kirjoita siihen päivämäärä, jolloin elementti on jälleen vaihdettava, esim. 12 kk kuluttua tämänkertaisesta vaihdosta.



Älä käytä liuottimia tai alkoholia tarrojen puhdistukseen, sillä ne voivat aiheuttaa vaurioita.

**SV** Underhållsprocedure 7

Fäst elementets etikett för bytesdatum på filterskålen och skriv dit datumet som elementet ska bytas ut, d.v.s. 12 månader efter bytet av elementet.



Använd inga lösningsmedel eller alkohol för att rengöra etiketterna eftersom det kan orsaka skador.

**NO** Vedlikeholdsprosedyre 7

Fest element endre dato etiketten til filteret bolle og skriv på datoen elementet skal erstattes. I.e 12 måneder etter element endring.



Ikke bruk løsemidler eller alkohol for å rengjøre etikettene, da dette kan forårsake skade.

**DA** Vedligeholdelsesprocedure 7

Fastgør mærkaten med dato for elementudskiftning på filterbeholderen, og skriv datoen for, hvornår elementet skal udskiftes - d.v.s. 12 måneder efter elementudskiftningen.



Brug ikke opløsningsmidler eller alkohol til rengøring af mærkaterne, da det kan medføre beskadigelse.

**EL** Διαδικασία συντήρησης 7

Κολλήστε την ετικέτα ημερομηνίας αλλαγής του στοιχείου στο ποτήρι του φίλτρου και σημειώστε την ημερομηνία που πρέπει να αλλάξει το στοιχείο, δηλ. 12 μήνες μετά την αλλαγή του στοιχείου..




Μην χρησιμοποιείτε διαλύτες ή αλκοόλες για να καθαρίσετε τις ετικέτες, γιατί έτσι μπορεί να προκληθεί ζημιά.

**PT** Procedimento de Manutenção 7

Prenda a etiqueta com a data de substituição do elemento no corpo do filtro e anote a data em que o elemento deve ser substituído. Por ex.: 12 meses após a substituição do elemento.



Não utilize solventes nem álcool para limpar as etiquetas, pois tal poderá provocar danos.



**FI** Huoltotoimenpiteet 8

Avaa sisääntuloventtiili (1) hitaasti paineistaaksesi yksikön, avaa hitaasti ulostuloventtiili (2) paineistaaksesi laskuputkiston



Älä avaa tulo- tai lähtöventtiiliä nopeasti tai altista yksikköä liialliselle paine-erolle, sillä yksikkö voi vaurioitua.

**SV** Underhållsprocedur 8

Öppna långsamt inloppsventilen (1) för att gradvis släppa ut trycket och öppna långsamt utloppsventilen (2) för att släppa ut trycket ur rörledningarna nedströms.



Öppna inte inlopps- eller utloppsventilerna snabbt och utsätt inte enheten för överdrivet differentiattryck, eftersom det kan orsaka skador.

**NO** Vedlikeholdsprosedyre 8

Åpne inntaksventilen (1) sakte for gradvis å trykksette enheten, og åpne utløpsventilen (2) sakte for å trykksette nedstrømsrørene igjen



Du må ikke åpne inntaks- eller utløpsventilene raskt, eller utsette enheten for høyt differensialtrykk, da dette kan føre til skade.

**DA** Vedligeholdelsesprocedure 8

Åbn indgangsventilen (1) langsomt for gradvist at sætte enheden under tryk, og åbn udgangsventilen (2) langsomt for at sætte rørene længere fremme under tryk igen.



Åbn ikke indgangs- eller udgangsventiler hurtigt, og udsæt ikke enheden for store trykforskelle, da det kan medføre skader.

**EL** Διαδικασία συντήρησης 8

Ανοίξτε τη βαλβίδα εισαγωγής (1) αργά, για να ανέβει σταδιακά η πίεση της μονάδας, ανοίξτε αργά τη βαλβίδα εξαγωγής (2) για να ανέβει η πίεση της σωλήνωσης κατόπι.




Μην ανοίγετε γρήγορα τις βαλβίδες εισαγωγής ή εξαγωγής και μην υποβάλλετε τη μονάδα σε υπερβολική διαφορική πίεση, διότι μπορεί να προκύψει βλάβη.

**PT** Procedimento de Manutenção 8

Abra lentamente a válvula de entrada (1) para pressurizar gradualmente a unidade, abra lentamente a válvula de saída (2) para voltar a pressurizar a tubagem a jusante.



Não abra rapidamente as válvulas de entrada ou de saída nem sujeite a unidade a uma pressão diferencial excessiva, caso contrário poderão ocorrer danos.



**PL ROCZNA GWARANCJA JAKOŚCI POWIETRZA**

Jakość powietrza jest gwarantowana przez okres 1 roku, a gwarancja jest odnawiana po każdej corocznej wymianie wkładu.

Coroczna wymiana wkładu filtra zapewnia:

- Utrzymanie optymalnej wydajności
- Jakość powietrza spełniająca normy międzynarodowe
- Ochronę urządzeń podłączonych za filtrem, osób oraz procesów
- Niski koszt obsługi
- Większą produktywność i zyski
- Brak problemów

**SK JEDNOROČNÁ ZÁRUKA KVALITY VZDUCHU**

Kvalita vzduchu je zaručená na jeden rok a bude obnovená po každoročnej výmene filtračnej vložky.

Každoročné výmeny filtračných vložiek zabezpečujú:

- zachovanie optimálnej výkonnosti,
- plnenie medzinárodných noriem kvality vzduchu,
- ochranu zariadení v smere prúdenia, personálu a procesov,
- nízke prevádzkové náklady,
- zvýšenú produktivitu a ziskovosť,
- pokoj v duši.

**CS ROČNÍ ZÁRUKA KVALITY VZDUCHU**

Na kvalitu vzduchu je poskytována záruka 1 rok, která se obnovuje při každoroční výměně filtračního prvku.

Každoroční výměny filtračního prvku zajišťují:

- Zachování optimálního výkonu
- Trvalé dodržování mezinárodních norem týkajících se kvality vzduchu
- Ochranu zařízení, pracovníků a procesů za filtrem
- Nízké provozní náklady
- vyšší produktivitu a ziskovost
- klid na duši

**ET AASTANE GARANTII ÕHU KVALITEEDILE**

Teie õhu kvaliteet on garanteeritud aastaks ja prast iga-aastast filtrielemendi vahetamist algab garantiiperiood uuesti.

Iga-aastane filtrielemendi vahetamine tagab:

- optimaalse judluse silimise;
- õhukvaliteedi jtkuva vastavuse rahvusvahelistele nõuetele;
- allavoolu paiknevate seadmete, totajate ja protsesside kaitses;
- madalad kituskulud;
- suurema tootlikkuse ja kasumlikkuse;
- meelerahu.

**HU EGY ÉV LEVEGMINSÉG GARANCIA**

A levegminsget 1 vre garantljuk, azt a szrbett ves cserjekor egy vvel meghosszabljuk.

Az ves szrbett-csere a kvetkez elnyket biztosítja:

- Optimlis teljesitmny fenntartsa
- Nemzetkzi szabvnyoknak megfelel levegminsg
- A folyamat ksbbi pontjn elhelyezett eszkzk, a dolgozk s a folyamatok vdelme
- Alacsony zemelttesi kltsgek
- Jobb termelkenysg s magasabb profit
- Leiki nyugalom

**LV GAISA KVALITTES VIENA GADA GARANTIJA**

Gaisa kvalittes garantija ir spk 1 gadu, turklt tiks atjaunota pc katras ikgadjs filtra elementa maiņas.

Mainot filtra elementu reizi gad, tiek nodrošinta:

- optimlas veiktspjas uzturšana,
- gaisa kvalittes pastvīga atbilstība starptautiskajiem standartiem,
- aiz filtra pievienot aprikojuma, personla un procesu aizsardzība,
- nelielas ekspluatcijas izmaksas,
- palielints raigums un ienesīgums,
- nav iemesla satraukumam



## ④ Przykład kodowania modeli:

| Model                 |   |                           |  |                     |                              |  |
|-----------------------|---|---------------------------|--|---------------------|------------------------------|--|
| Klasa wkładu filtra   | Wkład o wysokiej efektywności energetycznej | Rozmiar modelu            | Rozmiar przyłącza  | Typ gwintu          | Opcja drenażu                | Wskaźnik różnicy ciśnienia                 |
| WS<br>AO<br>AA<br>ACS | P   | 3-cyfrowy kod jak poniżej | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Plywak<br>M = Instrukcja | X = Brak<br>I = Wskaźnik kontrolny zdarzeń |
| AA                    | P   | 030                       | A  | G                   | F                            | I  |

## ④ Příklad kódování modelu:

| Model                 |                                     |                                |  |                     |                               |  |
|-----------------------|-------------------------------------|--------------------------------|--|---------------------|-------------------------------|--|
| Třída vložky          | Prémiová energeticky výkonná vložka | Velikost modelu                | Velikost otvoru  | Typ závitů          | Možnost odtoku                | Indikátor DP                           |
| WS<br>AO<br>AA<br>ACS | P                                   | 3-číselný kód (zobrazený níže) | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Plávající<br>M = Manuální | X = Žádný<br>I = Monitorování udalostí |
| AA                    | P                                   | 030                            | A  | G                   | F                             | I                                      |

## ④ Příklad kódu modelu:

| Model                 |                                      |                              |  |                     |                         |                                 |
|-----------------------|--------------------------------------|------------------------------|--|---------------------|-------------------------|---------------------------------|
| Stupeň prvku          | Prvotřídní energeticky úsporný prvek | Velikost modelu              | Velikost hrdla   | Typ závitů          | Možnost vypouštění      | Indikátor diferenčního tlaku    |
| WS<br>AO<br>AA<br>ACS | P                                    | 3číselný kód znázorněný níže | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Plovák<br>M = Ruční | X = Žádný<br>I = Monitor nehody |
| AA                    | P                                    | 030                          | A  | G                   | F                       | I                               |

## ④ Mudeli koodi näide:

| Mudel                 |                                    |   |  |                     |                           |                                    |
|-----------------------|------------------------------------|---|--|---------------------|---------------------------|------------------------------------|
| Elemendi klass        | Premium-tüüpi energiatõhus element | Mudeli suurus                               | Pordi suurus   | Keerme tüüp         | Äravoolu variant          | DP-indikaator                      |
| WS<br>AO<br>AA<br>ACS | P                                  | 3-numbriline kood, nagu allpool on näidatud | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Ujuk<br>M = Manuaalne | X = Puudub<br>I = Sündmuse monitor |
| AA                    | P                                  | 030   | A  | G                   | F                         | I                                  |

**④ Példa az egyes modellek kódjelölésére:**

| Típus                   |                                  |                              |  |                     |                      |                                  |
|-------------------------|----------------------------------|------------------------------|--|---------------------|----------------------|----------------------------------|
| Betét minőségi osztálya | Prémium energiahatékonyságú elem | Típus mérete                 | Csatlakozófurat mérete   | Menet típusa        | Leeresztés módja     | Nyomáskülönbség-jelző            |
| WS<br>AO<br>AA<br>ACS   | P                                | Az alább látható 3-jegyű kód | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Úszó<br>M = Kézi | X = Nincs<br>I = Problémafigyelő |
| AA                      | P                                | 030                          | A  | G                   | F                    | I                                |

**④ Modelja kodu piešķiršanas piemērs**

| Modelis               |  |                                   |  |                     |                            |  |
|-----------------------|--|-----------------------------------|--|---------------------|----------------------------|--|
| Elementa kategorija   | Augstākās klases enerģiju taupošs elements | Modelja izmērs                    | Pieslēgvietas izmērs   | Vitnes veids        | Notecināšanas iespēja      | DP indikators                                    |
| WS<br>AO<br>AA<br>ACS | P  | Trīsciparu kods, kā redzams tālāk | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Pludīņš<br>M = Manuāls | X = Nevienas<br>I = Incidentu uzraudzības ierīce |
| AA                    | P  | 030                               | A  | G                   | F                          | I  |

**④ Dobór produktów**

Wymienione przepływy dotyczą pracy przy ciśnieniu 7 bar g (100 psi g) w odniesieniu do temp. 20°C, ciśnienia 1 bar (a) i ciśnienia względnego pary wodnej 0%.

W przypadku przepływów w innych ciśnieniach należy zastosować przedstawione współczynniki korekcji.

**④ Výber produktu**

Uvedené prietoky sú pre prevádzku pri tlaku 7 bar g (100 psi g) s referenciou 20°C, 1 bar (a), 0 % relatívny tlak vodnej pary.

V prípade prietokov pri iných tlakoch sa musia uplatňovať uvedené korekčné koeficienty.

**④ Výběr produktu**

Uvedené průtoky platí při provozu na 7 bar g (100 psi g) při teplotě 20 °C, 1 bar a, 0 % relativního tlaku vodní páry.

Pro průtoky při jiném tlaku použijte uvedené korekční faktory.

**④ Toote valimine**

Toodud voolukiirused on mõeldud töötamiseks võimsusel 7 baari g (100 psi g), kusjuures referentsväärtuseks on 20°C, 1 baari a, 0% suhteline veeauru surve.

Muude survete puhul rakendage näidatud korrigeerimisfaktoreid.

**④ Termékválasztás**

A megadott átfolyási értékek 7 bar g (100 psi g) nyomáson való üzemeltetés esetén, 20°C hőmérsékletnél, 1 bar a és 0% relatív vízpáramomás referenciaértékeken érvényesek.

Más nyomásértékek mellett az átfolyásra alkalmazza a bemutatott korrekciós tényezőket.

**④ Produktu atlase**

Noteiktās plūsmas darbībai ar 7 stieniem g (100 psi g) ar norādi 20 °C, 1 stienis (a), 0% relatīvais ūdens tvaika spiediens.

Plūsmām pie citām spiediena vērtībām lietojiet norādītos labošanas faktoros.

### Natężenia przepływu przez separator wody

Prietokové rýchlosti odľučovača vody, Průtokové rychlosti odľučovače vody, Veeseparatori vooluhulgad, Vízleválasztó átfolyási sebességei, Üdens separatora plüsmas átruma vërtëbas

| Model                | Port Size | L/s | m <sup>3</sup> /min | m <sup>3</sup> /hr | cfm  |
|----------------------|-----------|-----|---------------------|--------------------|------|
| WS P010A [ ] [ ] [ ] | ¼         | 10  | 0.6                 | 36                 | 21   |
| WS P010B [ ] [ ] [ ] | ¾         | 10  | 0.6                 | 36                 | 21   |
| WS P010C [ ] [ ] [ ] | ½         | 10  | 0.6                 | 36                 | 21   |
| WS P015C [ ] [ ] [ ] | ½         | 40  | 2.4                 | 144                | 85   |
| WS P020D [ ] [ ] [ ] | ¾         | 40  | 2.4                 | 144                | 85   |
| WS P025D [ ] [ ] [ ] | ¾         | 110 | 6.6                 | 396                | 233  |
| WS P025E [ ] [ ] [ ] | 1         | 110 | 6.6                 | 396                | 233  |
| WS P030G [ ] [ ] [ ] | 1 ½       | 110 | 6.6                 | 396                | 233  |
| WS P035G [ ] [ ] [ ] | 1 ½       | 350 | 21.0                | 1260               | 742  |
| WS P040H [ ] [ ] [ ] | 2         | 350 | 21.0                | 1260               | 742  |
| WS P045I [ ] [ ] [ ] | 2 ½       | 350 | 21.0                | 1260               | 742  |
| WS P050I [ ] [ ] [ ] | 2 ½       | 800 | 48.0                | 2880               | 1695 |
| WS P055J [ ] [ ] [ ] | 3         | 800 | 48.0                | 2880               | 1695 |

CFP — współczynnik korekcji dla minimalnego ciśnienia wlotowego (separator wody)

CFP – korekčný faktor minimálneho tlaku na prívode (odľučovače vody), CFP – korekční faktor, minimální vstupní tlak (odľučovače vody),

CFP – minimaalse sisselaskerõhu parandustegur (veeseperatorid), CFP - Minimális bemeneti nyomás korrekciós tényezője (vízleválasztók),

CFP — korekcijas faktora minimālais ieplūdes spiediens (ūdens separatoris) ,

| Minimum Inlet Pressure | bar g | 1    | 2    | 3    | 4    | 5    | 6    | 7    | 8    | 9    | 10   | 11   | 12   | 13   | 14   | 15   | 16   |
|------------------------|-------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
|                        | psi g | 15   | 29   | 44   | 58   | 73   | 87   | 100  | 116  | 131  | 145  | 160  | 174  | 189  | 203  | 218  | 232  |
| Correction Factor      |       | 4.00 | 2.63 | 2.00 | 1.59 | 1.33 | 1.14 | 1.00 | 0.94 | 0.89 | 0.85 | 0.82 | 0.79 | 0.76 | 0.73 | 0.71 | 0.68 |

### Natężenia przepływu przez filtr

Prietokové rýchlosti filtra, Průtokové rychlosti filtru, Filtri vooluhulgad, Szűrő átfolyási sebességei, Filtra plüsmas átruma vërtëbas

| Model                     | Port Size | L/s | m <sup>3</sup> /min | m <sup>3</sup> /hr | cfm  | Replacement Element kit | No.       |
|---------------------------|-----------|-----|---------------------|--------------------|------|-------------------------|-----------|
| [grade] P010A [ ] [ ] [ ] | ¼         | 10  | 0.6                 | 36                 | 21   | P010                    | [grade] 1 |
| [grade] P010B [ ] [ ] [ ] | ¾         | 10  | 0.6                 | 36                 | 21   | P010                    | [grade] 1 |
| [grade] P010C [ ] [ ] [ ] | ½         | 10  | 0.6                 | 36                 | 21   | P010                    | [grade] 1 |
| [grade] P015C [ ] [ ] [ ] | ½         | 20  | 1.2                 | 72                 | 42   | P015                    | [grade] 1 |
| [grade] P020C [ ] [ ] [ ] | ½         | 30  | 1.8                 | 108                | 64   | P020                    | [grade] 1 |
| [grade] P020D [ ] [ ] [ ] | ¾         | 30  | 1.8                 | 108                | 64   | P020                    | [grade] 1 |
| [grade] P025D [ ] [ ] [ ] | ¾         | 60  | 3.6                 | 216                | 127  | P025                    | [grade] 1 |
| [grade] P025E [ ] [ ] [ ] | 1         | 60  | 3.6                 | 216                | 127  | P025                    | [grade] 1 |
| [grade] P030G [ ] [ ] [ ] | 1 ½       | 110 | 6.6                 | 396                | 233  | P030                    | [grade] 1 |
| [grade] P035G [ ] [ ] [ ] | 1 ½       | 160 | 9.6                 | 576                | 339  | P035                    | [grade] 1 |
| [grade] P040H [ ] [ ] [ ] | 2         | 220 | 13.2                | 792                | 466  | P040                    | [grade] 1 |
| [grade] P045I [ ] [ ] [ ] | 2 ½       | 330 | 19.8                | 1188               | 699  | P045                    | [grade] 1 |
| [grade] P050I [ ] [ ] [ ] | 2 ½       | 430 | 25.8                | 1548               | 911  | P050                    | [grade] 1 |
| [grade] P055I [ ] [ ] [ ] | 2 ½       | 620 | 37.3                | 2232               | 1314 | P055                    | [grade] 1 |
| [grade] P055J [ ] [ ] [ ] | 3         | 620 | 37.3                | 2232               | 1314 | P055                    | [grade] 1 |

[klasa] = klasa

[stupeň] = stupeň

[Třída] = třída

[puhastusaste] = puhastusaste

[osztály] = osztály

[Kategorija] = Kategorija

**CFP — współczynnik korekcji dla minimalnego ciśnienia wlotowego (filtry koalescencyjne i suchych cząstek stałych)**

CFP – korekčný faktor minimálneho tlaku na prívode (zlučovače a suché časticové filtre), CFP – korekční faktor, minimální vstupní tlak (slučovací filtry a filtry suchých částic), CFP – minimaalse sisselaskerõhu parandustegur (koalestsents- ja kuivade osakeste filtrid), CFP - Minimális bemeneti nyomás korrekciós tényezője (Koaleszcens és száraz részecskeszűrők), CFP — korekcijas faktora minimālais ieplūdes spiediens (koalescences filtrs un sauso daļiņu filtrs)

| Minimum Inlet Pressure | bar g | 1    | 2    | 3    | 4    | 5    | 6    | 7    | 8    | 9    | 10   | 11   | 12   | 13   | 14   | 15   | 16   | 17   | 18   | 19   | 20   |
|------------------------|-------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
|                        | psi g | 15   | 29   | 44   | 58   | 73   | 87   | 100  | 116  | 131  | 145  | 160  | 174  | 189  | 203  | 218  | 232  | 248  | 263  | 277  | 290  |
| Correction Factor      |       | 2.65 | 1.87 | 1.53 | 1.32 | 1.18 | 1.08 | 1.00 | 0.94 | 0.88 | 0.84 | 0.80 | 0.76 | 0.73 | 0.71 | 0.68 | 0.66 | 0.64 | 0.62 | 0.61 | 0.59 |

**☞ Dobór produktów i współczynniki korekcji**

W celu doboru właściwego modelu filtra lub separatora wody należy skorygować natężenie przepływu przez filtr ze względu na minimalne ciśnienie robocze systemu.

- 1 Uzyskaj informacje na temat minimalnego ciśnienia roboczego i maksymalnego natężenia przepływu sprężonego powietrza na wlocie filtra lub separatora wody.
- 2 Z tabeli CFP wybierz współczynnik korekcji dla minimalnego ciśnienia roboczego (zawsze zaokrąglając w dół — np. dla ciśnienia 5,3 bara użyj współczynnika korekcji dla 5 barów).
- 3 Oblicz minimalną wydajność filtracji. Minimalna wydajność filtracji = natężenie przepływu powietrza sprężonego x CFP
- 4 Na podstawie minimalnej wydajności filtracji wybierz model filtra lub separatora wody z tabeli natężenia przepływu powyżej (wybrany filtr lub separator wody musi charakteryzować się natężeniem przepływu większym lub równym minimalnej wydajności filtracji).

**☞ Výber produktov a korekčné faktory**

Pre výber správneho modelu odlučovača vody alebo filtra je potrebné prietokovú rýchlosť filtra prispôsobiť minimálnemu prevádzkovému tlaku systému.

- 1 Na prívode odlučovača vody alebo filtra dosiahnite minimálny prevádzkový tlak a maximálnu prietokovú rýchlosť stlačeného vzduchu.
- 2 Z tabuľky CFP vyberte korekčný faktor pre minimálny prevádzkový tlak (vždy zaokrúhľte nadol, napr. v prípade 5,3 bar použite korekčný faktor 5 bar).
- 3 Vypočítajte minimálnu filtračnú kapacitu. Minimálna filtračná kapacita = prietoková rýchlosť stlačeného vzduchu x CFP
- 4 Na základe minimálnej filtračnej kapacity vyberte z hore uvedených tabuliek prietokových rýchlostí vhodný model odlučovača vody alebo filtra (vybratý odlučovač vody alebo filter musí mať prietokovú rýchlosť rovnakú alebo vyššiu ako je minimálna filtračná kapacita).

**☞ Vyběr produktu a korekční faktory**

Ke správnému výběru modelu odlučovače vody nebo filtru je třeba přizpůsobit průtokovou rychlost filtru minimálnímu provoznímu tlaku systému.

- 1 Na vstupu odlučovače vody nebo filtru dosáhněte minimálního provozního tlaku a maximálního průtoku stlačeného vzduchu.
- 2 Podle tabulky faktorů CFP zvolte korekční faktor odpovídající minimálnímu provoznímu tlaku (zaokrouhľte vždy dolů, např. při tlaku 5,3 bar použijte korekční faktor pro tlak 5 bar).
- 3 Vypočítejte minimální filtrační kapacitu. Minimální filtrační kapacita = průtoková rychlost stlačeného vzduchu x CFP
- 4 Na základě minimální filtrační kapacity zvolte model odlučovače vody nebo filtru podle výše uvedených tabulek průtokové rychlosti (vybraný odlučovač vody nebo filtr musí mít průtokovou rychlost stejnou nebo vyšší než minimální filtrační kapacita).

**☞ Tootte valimine ja parandustegurid**

Veeseparaatori või filtri mudeli õigesti valimiseks tuleb filtri vooluhulka reguleerida vastavalt süsteemi minimaalsele tööõhule.

- 1 Minimaalse tööõhu ja maksimaalse suruõhu vooluhulga saate veeseparaatori või filtri sisselaskevall.
- 2 Valige minimaalse tööõhu parandustegur CFP-tabelist (alati ümardage allapoole, nt tööõhu 5,3 bar puhul kasutage tööõhu 5 bar parandustegurit)
- 3 Arvutage minimaalne filtreerimisvõimsus. Minimaalne filtreerimisvõimsus = suruõhu vooluhulk x CFP
- 4 Kasutades minimaalset filtreerimisvõimsust, valige veeseparaatori või filtri mudel eespool olevatest vooluhulga tabelitest (valitud veeseparaatori või filtri peab olema vooluhulk, mis on võrdne minimaalse filtreerimisvõimsusega või mis on sellest suurem).

**☞ Termékválasztás és korrekciós tényezők**

A vízelválasztó- vagy szűrőtípus megfelelő kiválasztásához a szűrő átfolyási sebességét a rendszer minimális üzemi nyomásához kell állítani.

- 1 Határozza meg a vízelválasztó vagy a szűrő bemeneténél érvényes minimális üzemi nyomást és maximális sűrített levegő-átfolyási sebességet.
- 2 A CFP táblázatból válassza ki a minimális üzemi nyomáshoz tartozó korrekciós tényezőt (mindig lefelé kerekítsen, pl.: 5,3 bar esetén 5 bar korrekciós tényezőt használjon)
- 3 Számítsa ki a minimális szűrőképességet. Minimális szűrőképesség = Sűrített levegő átfolyási sebessége x CFP
- 4 A minimális szűrőképesség alapján válasszon egy vízelválasztó- vagy szűrőtípust az átfolyási sebességekkel kapcsolatos fenti táblázatokból (a kiválasztott vízelválasztó vagy szűrő átfolyási sebességének legalább akkorának kell lennie, mint a minimális szűrőképesség).

**☞ Izstrādājumu atlase un korekcijas faktori**

Lai pareizi atlasītu ūdens separatoru vai filtra modeli, filtra plūsmas ātrums ir jāpielāgo sistēmas minimālajam darba spiedienam.

- 1 Iegūstiet minimālo darba spiedienu un maksimālo saspīsta gaisa plūsmas ātrumu pie ūdens separatora vai filtra ieplūdes.
- 2 Atlasiet korekcijas faktoru minimālajam darba spiedienam no CFP tabulas (vienmēr noapaļojiet uz leju, piemēram, 5,3 bāriem izmantojiet 5 bāru korekcijas faktoru)
- 3 Aprēķiniet minimālo filtrācijas kapacitāti. Minimālā filtrācijas kapacitāte = saspīsta gaisa plūsmas ātrums x CFP
- 4 Izmantojot minimālo filtrācijas kapacitāti, atlasiet ūdens separatora vai filtra modeli no iepriekš dotajām plūsmas ātruma tabulām (atlasītajam ūdens separatoram vai filtram ir jābūt tādām plūsmas ātrumam, kas vienāds ar minimālo filtrācijas ātrumu vai lielāks par to).

**Parametry techniczne**


Technické údaje, Technické údaje, Tehniline teave, Műszaki adatok, Tehniskie dati

| Model | Filter Models |                     |               |       |    |    |     |    |    |     | Min Operating Pressure |  | Max Operating Pressure |  | Min Recommended Operating Temp |  | Max Recommended Operating Temp |  |
|-------|---------------|---------------------|---------------|-------|----|----|-----|----|----|-----|------------------------|--|------------------------|--|--------------------------------|--|--------------------------------|--|
|       | bar g         | psi g               | bar g         | psi g | °C | °F | °C  | °F |    |     |                        |  |                        |  |                                |  |                                |  |
| WS    | P010          | [ ] [ ] F [ ] - 035 | [ ] [ ] F [ ] | 1     | 15 | 16 | 232 | 2  | 35 | 80  | 176                    |  |                        |  |                                |  |                                |  |
| AO    | P010          | [ ] [ ] F [ ] - 035 | [ ] [ ] F [ ] | 1     | 15 | 16 | 232 | 2  | 35 | 80  | 176                    |  |                        |  |                                |  |                                |  |
| AO    | P010          | [ ] [ ] M [ ] - 035 | [ ] [ ] M [ ] | 1     | 15 | 20 | 290 | 2  | 35 | 100 | 212                    |  |                        |  |                                |  |                                |  |
| AA    | P010          | [ ] [ ] F [ ] - 035 | [ ] [ ] F [ ] | 1     | 15 | 16 | 232 | 2  | 35 | 80  | 176                    |  |                        |  |                                |  |                                |  |
| AA    | P010          | [ ] [ ] M [ ] - 035 | [ ] [ ] M [ ] | 1     | 15 | 20 | 290 | 2  | 35 | 100 | 212                    |  |                        |  |                                |  |                                |  |
| ACS   | P010          | [ ] [ ] M [ ] - 035 | [ ] [ ] M [ ] | 1     | 15 | 20 | 290 | 2  | 35 | 50  | 122                    |  |                        |  |                                |  |                                |  |

Note: AO / AA / WS grade filters for use up to 16 bar g (232 psi g) are supplied with a float drain [F] as standard. For pressures between 16 and 20 bar g (232 and 290 psi g) a manual drain [M] must be used. ACS grade filters are supplied with a manual drain [M] as standard.

**Masy i wymiary**

Hmotnosti a rozmery, Hmotnosti a rozmery, Massid ja mõõtmed, Tömeg- és méretadatok, Svarts un izmēri



| Model      | Pipe Size | Height (H) |       | Width (W) |      | Depth (D) |      | (a) |      | (b) |      | (c) |      | (d) |     | Weight |       |
|------------|-----------|------------|-------|-----------|------|-----------|------|-----|------|-----|------|-----|------|-----|-----|--------|-------|
|            |           | mm         | ins   | mm        | ins  | mm        | ins  | mm  | ins  | mm  | ins  | mm  | ins  | mm  | ins | kg     | lbs   |
| WS / P010A | ¼"        | 180        | 7.09  | 76        | 2.99 | 66        | 2.60 | 154 | 6.1  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 0.61   | 1.34  |
| WS / P010B | ⅜"        | 180        | 7.09  | 76        | 2.99 | 66        | 2.60 | 154 | 6.1  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 0.61   | 1.34  |
| WS / P010C | ½"        | 180        | 7.09  | 76        | 2.99 | 66        | 2.60 | 154 | 6.1  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 0.61   | 1.34  |
| WS / P015C | ½"        | 238.5      | 9.36  | 89        | 3.5  | 83.5      | 3.29 | 202 | 8.0  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 1.16   | 2.55  |
| P020C      | ½"        | 238.5      | 9.36  | 89        | 3.5  | 83.5      | 3.29 | 202 | 8.0  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 1.12   | 2.58  |
| WS / P020D | ¾"        | 238.5      | 9.36  | 89        | 3.5  | 83.5      | 3.29 | 202 | 8.0  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 1.12   | 2.58  |
| WS / P025D | ¾"        | 227        | 10.9  | 120       | 4.72 | 114.5     | 4.5  | 232 | 9.1  | 70  | 2.76 | 32  | 1.3  | 38  | 1.5 | 2.21   | 4.86  |
| WS / P025E | 1"        | 227        | 10.9  | 120       | 4.72 | 114.5     | 4.5  | 232 | 9.1  | 70  | 2.76 | 32  | 1.3  | 38  | 1.5 | 2.21   | 4.86  |
| WS / P030G | 1 ½"      | 367        | 14.45 | 120       | 4.72 | 114.5     | 4.5  | 323 | 12.7 | 70  | 2.76 | 32  | 1.3  | 38  | 1.5 | 2.68   | 5.91  |
| WS / P035G | 1 ½"      | 531        | 20.9  | 164       | 6.46 | 156       | 6.10 | 384 | 15.1 | 100 | 3.94 | 68  | 2.68 | 38  | 1.5 | 6.90   | 15.20 |
| WS / P040H | 2         | 623        | 24.5  | 164       | 6.46 | 156       | 6.10 | 476 | 18.7 | 100 | 3.94 | 68  | 2.68 | 38  | 1.5 | 7.30   | 16.10 |
| WS / P045I | 2 ½"      | 623        | 24.5  | 164       | 6.46 | 156       | 6.10 | 476 | 18.7 | 100 | 3.94 | 68  | 2.68 | 38  | 1.5 | 7.10   | 15.65 |
| WS / P050I | 2 ½"      | 745        | 29.3  | 192       | 7.56 | 183       | 7.20 | 587 | 23.1 | 120 | 4.72 | 68  | 2.68 | 38  | 1.5 | 10.30  | 22.71 |
| P055I      | 2 ½"      | 935        | 36.8  | 192       | 7.56 | 183       | 7.20 | 772 | 30.4 | 120 | 4.72 | 68  | 2.68 | 38  | 1.5 | 15.30  | 33.73 |
| WS / P055J | 3         | 935        | 36.8  | 192       | 7.56 | 183       | 7.20 | 772 | 30.4 | 120 | 4.72 | 68  | 2.68 | 38  | 1.5 | 15.30  | 33.73 |

Note: Water Separators do not include a DP Indicator, use dimension H + d for the total height.

**PL Zalecenia dotyczące instalacji**

Zalecane jest oczyszczenie sprężonego powietrza przed punktami wlotowymi systemu rozpraszania, jak też w głównych punktach stosowania.

Instalowanie osuszaczy sprężonego powietrza w wilgotnym układzie może prowadzić do gromadzenia się dodatkowych zanieczyszczeń w punktach stosowania filtrów do czasu osuszenia układu rozpraszającego. W tym czasie może być konieczna częstsza wymiana wkładów filtrów.

W instalacjach, w których stosuje się sprężarki bezolejowe, aerozol wodny i cząsteczki zanieczyszczeń nadal będą występować; należy wtedy nadal używać filtrów uniwersalnych i wysokowydajnych.

Filtr uniwersalny powinien być zawsze instalowany w celu ochrony filtra wysokowydajnego przed większymi ilościami aerozoli cieczy i cząstkami stałymi.

Sprzęt oczyszczający należy zainstalować w najniższej temperaturze powyżej temperatury krzepnięcia, najlepiej za chłodnicą końcową i odbiornikami powietrza.

Punkt stosowania sprzętu oczyszczającego powinien znajdować się jak najbliżej miejsca stosowania powietrza.

Sprzęt oczyszczający nie może być instalowany za zaworami szybko otwierającymi i powinien być zabezpieczony przed ewentualnym przepływem wstecznym i innymi warunkami uderzeniowymi.

Przed instalacją należy oczyścić wszystkie przewody rurowe prowadzące do sprzętu oczyszczającego; należy również oczyścić wszystkie przewody rurowe po instalacji sprzętu oczyszczającego i przed podłączeniem do odbiorników końcowych.

Jeżeli do sprzętu oczyszczającego są zamontowane boczniki, należy sprawdzić, czy są do nich zamontowane odpowiednie filtry chroniące przed zanieczyszczeniem systemu w dół kierunku przepływu.

Przewody drenażowe z filtrów koalescencyjnych należy przymocować do separatora skroplin. Jeśli dalsze układanie nieistoty przy użyciu filtrów podczas obrotów, kym distribuční systém vycišťuje. Filtračné vložky bude potrebné počas tohto obdobia vymieňať častejšie.

Należy zapewnić system drenażu cieczy ze sprzętu oczyszczającego. Zebrana ciecz powinna zostać oczyszczona i usunięta w odpowiedni sposób.

**SK Odporúčania týkajúce sa inštalácie**

Stlačený vzduch sa odporúča spracúvať pred vstupom do distribučního systému a tiež v kritických používateľských bodoch alebo aplikáciách.

Instalácia tlakových vzduchových suchičov do predtým mokrého systému by mohla zapríčiniť ďalšie ukladanie nečistoty pri používaní filtrov počas obdobia, kým distribuční systém vycišťuje. Filtračné vložky bude potrebné počas tohto obdobia vymieňať častejšie.

Pri inštaláciách, kde sa používajú bezolejnaté kompresory, je stále prítomný vodný aerosól a častice, a preto by sa stále mali používať univerzálne a vysokoúčinné stupne. Vždy musí byť nainštalovaný univerzálny filter, ktorý má chrániť vysokoúčinný filter pred voľne ložnými aerosólmi a pevnými časticami.

Čistiace zariadenie inštalujte pri čo najnižšej teplote nad bodom mrazu, najlepšie v smere prúdenia chladivého vzduchu a príjmačov vzduchu.

Bod použitia čistiaceho zariadenia by mal byť nainštalovaný čo najbližšie k aplikácii.

Čistiace zariadenie by sa nemalo inštalovať v smere prúdenia rýchlootváracích ventilov a malo by byť chránené pred možným opačným prúdením alebo pred inými nepriaznivými podmienkami.

Pred inštaláciou vyčistite všetky potrubia vedúce k čistiaciemu zariadeniu a po nainštalovaní čistiaceho zariadenia a pred pripojením ku konečnej aplikácii vyčistite všetky potrubia.

Ak sú okolo čistiaceho zariadenia nainštalované obtokové trubicе, zabezpečte, aby bola do obtokových trubíc nainštalovaná primeraná filtračná, aby sa zabránilo znečisteniu systému v smere prúdenia.

Odtokové trubicе z koalescencných filtrov nasaďte priamo na separátor kondenzátu. Ak nie je možné pripojiť odtokové trubicе priamo na separátor, mali by sa odventilovať do zberného potrubia kondenzátu (na jednom konci) a potom do jedného ventilu separátora kondenzátu.

Zabezpečte príslušnosť na odvádzanie nahromadenej kvapaliny z čistiaceho zariadenia. Pri zaobchádzaní s nahromadenou kvapalinou a jej likvidácii je potrebné postupovať zodpovedným spôsobom.

**CS Doporučení k instalaci**

Před připojením do rozvodného systému a v kritických místech použít / v přívodech doporučujeme stlačený vzduch upravit.

Instalace vysoušičů stlačeného vzduchu do vlhkého systému může vést k nanesení dalších nečistot do filtrů po dobu vysoušení rozvodného systému. Během této doby může být potřeba častější výměna filtračních prvků.

V instalacích, kde se využívají bezolejové kompresory, je vodní aerosol a jeho částice stále přítomné. Přesto je stále třeba použít všeobecné využitelné filtry s vysokým stupněm účinnosti.

Všeobecné využitelné filtry musí být vždy instalovány tak, aby chránily vysoce účinný filtr před velkým objemem kapalinových aerosolů a pevnými částicemi.

Čistící zařízení inštalujte pri čo najnižšej teplote nad bodom mrazu, najlepšie v smere dochlazonave a zásobníku vzduchu.

Čistící zařízení v místě použití by mělo být instalováno co nejlíže k přívodu.

Čistící zařízení by nemělo být instalováno ve směru rychlootváracích ventilů a mělo by být chráněno před případným zpětným průtokem či jinými podobnými situacemi.

Před instalací vyčistěte veškeré potrubí vedoucí k čistícím zařízením. Čištění veškerého potrubí opakujte po instalaci a před připojením zařízení k poslednímu přívodu.

Pokud jsou kolem čistícího zařízení umístěna obtoková potrubí, zkontrolujte, zda je filtrace upevněna k obtokovému potrubí, aby nedošlo ke kontaminaci ve směru systému.

Odtoková potrubí upevněte od koalescencných filtrů přímo k oddělovači kondenzátu. Pokud není možné připojit odtoková potrubí přímo k oddělovači, měli byste potrubí odvést do potrubí kondenzátu (odvětrávaného na jednom konci) a pak do jediného vstupu oddělovače kondenzátu.

Opäťete si vybavení pro odvod nahromaděné kapaliny z čistícího zařízení. S nahromadenou kvapalinou je nutné zacházet odpovědným způsobem a stejným způsobem ji také likvidovat.

**ET Paigaldussoovitused**

Suruühku on soovitatav töödelda enne jaotussüsteemi sisenemist, samuti enne kriitilisi kasutuspunkte/rakendusid.

Suruühkuivalite paigaldamine eelnevalt märga süsteemi võib põhjustada saasta täiendava kogunemise kasutuspunktide filtrites ajavahemikul, mil jaotussüsteem kuivab. Sel ajal võib osutada vajaliku filterelementide sagedasem vahetamine.

Seadmele, kus kasutatakse õlivabu kompressoreid, on vesiaerosool ja mikroosakesed siiski olemas, mis nõuavad ikkagi üldtöösteliste ja kõrgtootlike klasside kasutamist.

Üldtööstelise filter peab olema alati paigaldatud, et kaitsta kõrgtootlikku filtrit vedelaie aerosoolide ja tahkete osakeste eest.

Puhastusseadme paigaldage kõige madalama temperatuuriga kohtadesse, enne hangumispunkti, eelistatavalt väljavoolule järeljahutit ja õhuressiveritist.

Puhastusseadme kasutuspunkt peaks asuma rakenduskohtale võimalikult lähedal.

Puhastusseadet ei tohiks paigaldada kiiresti avanevatest ventiliidest allavoolu ning seade peaks olema kaitstud võimaliku tagasivoolu või muude löökkoormuste eest.

Kogu puhastusseadmeni viiv torustik tuleb enne puhastusseadme paigaldamist läbi puhuda, samuti pärast seadme paigaldamist ning enne selle ühendamist lõpliku rakenduskohtaga.

Kui puhastusseade varustatakse moodavooluliiniga, tuleb tagada selle vastav filtreerimine, hoidmaks ära väljavoolusüsteemi saastumist.

Ühendage kogumisfiltrite äravooluliinid otse kondensaadi separaatoriga. Kui äravooluline ei ole võimalik otse separaatoriga ühendada, tuleks liinid ventileerida kondensaadikolektorisse (ühest otstast ventileeritud) ja seejärel kondensaadi separaatori ühisesse sisselaskeavasse.

Puhastusseadmet sinna kogunenud vedeliku välja laskmiseks varustage see kraaniga. Kogunenud vedelike tuleb käidelda ja utiliseerida ettenähtud viisil.

**HU Üzembe helyezési javaslatok**

Javasoljuk, hogy az elosztórendszerbe, valamint a kritikus felhasználási pontokhoz/alkalmazásokhoz is kezelje sűrítettelevégőt biztosítson.

A sűrítettelevégős szűrők korábban nedves rendszerbe telepítése járulékos szennyezési terhelést jelenthet a szűrő használatának kezdetétől számítva a szállítórendszer kiszáradásáig terjedő időtartamig. Ezen időszak alatt esetleg gyakrabban kell cserélni a szűrőbetéteket.

Olajmentes kompresszorokat tartalmazó összeállítások esetén vízpermet és (szilárd) részecskék jelenléte mellett általános rendeltetésű és nagy hatékonyságú fokozatokat is kell használni.

Az általános rendeltetésű szűrőt a nagy hatékonyságú szűrő nagy mennyiségű folyadék-aeroszoltól és szilárd részecskéktől való védelme érdekében mindig használni kell.

A tisztítóberendezést telepítse a fagyponot feletti legalacsonyabb hőmérsékletű helyre, lehetőleg az utóhűtők és levegő beomlók utáni vezetékcsakaszra.

A használat helyéhez tervezett tisztítóberendezést helyezze el a lehető legközelebb az alkalmazáshoz.

A tisztítóberendezések nem telepíthetők a gyorsnyitású szelepek elmenő oldalára, azokat meg kell védeni az esetleges ellenáramlástól és más hirtelen behatásoktól.

A telepítés előtt fúvasson át minden, a tisztítóberendezéshez vezető csövezeteket, a telepítés után és az alkalmazás végső bekötése előtt pedig még egyszer fúvassa át az összes csövezeteket.

Ha a tisztítóberendezés körül megkerülő csövezeteket találhatók, a rendszer elmenő oldal elszennyeződésének megelőzése érdekében gondoskodjon a kerülővezetéseken megfelelő szűrésről.

Illesse a koaleszcenciás szűrő leeresztő vezetékeit közvetlenül a kondenzát-leválasztóra. Ha a leeresztő vezetékeket nem lehet közvetlenül a leválasztóra csatlakoztatni, akkor a vezetékeket a kondenzát elosztócsőnél kell levegővel szellőztetni (az egyik végéről), majd azt a kondenzát-leválasztó önálló bemenetéhez kell csatlakoztatni.

A tisztítóberendezés leürítésénél gondoskodjon az összegyűlt folyadék megfelelő elszállításáról. Az összegyűjtött folyadékot kezelje és selejtezze le környezetbarát módon.

**LV Ieteikumi uzstādīšanas**

Ieteicams saspiešto gaisu apstrādāt pirms ievadīšanas sadales sistēmā un arī izšķirošajos lietošanas punktos / lietojumos.

Uzstādot saspieštā gaisa zāvētājus uz sistēmas, kas pirms tam bijusi mitra, filtros, kas uzstādīti lietošanas vietā, laikā, kamēr sadalīšanas sistēma izžūst, attiecīgi var sakrāties neturimi. Filtra elementi, iespējams, šajā laikā jāmaina daudz biežāk.

Ja uzstādījums, kur izmantoti saspiegti bez eļļas, joprojām atrodas ūdens aerosols un daļiņas, joprojām jāpiemēro vispārējā nolūka un augstas produktivitātes kritēriji.

Vienmēr jābūt uzstādītam vispārējā nolūka filtram, lai augstas produktivitātes filtrs būtu pasargāts no šķidruma balonu aerosolēm un cietām daļiņām.

Uzstādiēt attīrīšanas iekārtu viszemākajā temperatūrā vīrs sasalšanas punkta, vislabāk aiz pēdzesētājiem un gaisa uztvērējiem.

Attīrīšanas iekārtas lietošanas punktam jābūt uzstādītam pēc iespējas tuvu lietojumam.



Attīrīšanas iekārtu nedrīkst uzstādīt aiz ātrās atveres vārstiem, un tā ir jāsigarā no iespējamās pretplūsmas vai cietiem trieciena apstākļiem.

Pirms uzstādīšanas izīriet visas caurules, kas virzītas uz attīrīšanas iekārtu: izīriet tās vēlreiz pēc attīrīšanas iekārtas uzstādīšanas, kā arī pirms pievienošanas pēdējām lietojumam.

Ja ap attīrīšanas iekārtu ir uzstādītas apvadlīnijas, nodrošiniet, ka apvadlīnijas ir aprīkotas ar piemērotu filtru, lai nepiesārotu tālāk esošo sistēmu.

Uzstādiēt novadcaurules, kas ved no koalescējošajiem filtriem tieši līdz kondensāta atdāļlīnijām. Ja novadcaurules nav iespējams savienot tieši ar separatoru, tās jāizvada kondensāta kolektorā (ar izēju vienā galā) un pēc tam vienā kondensāta separatora ielūdes vietā.

Apģādājiēt attīrīšanas iekārtu ar ierīci, ar ko no tās iztecina uzkrātu šķidrumu. Savāktais šķidrums jāapstrādā un no tā jāatbrīvojas atbilstoši veidā.



**PL** Dolna płyta zamykająca może poruszać się, gdy filtr nie jest pod ciśnieniem.



Dolna płyta zamykająca nie jest elementem przeznaczonym do serwisowania, dlatego nigdy nie należy jej demontować.

**SK** Spodný doskový uzáver sa môže hýbať, keď filter nie je pod tlakom.



Spodný doskový uzáver nie je opraviteľnou časťou a nikdy sa nesmie odmontovať.

**CS** Dolní uzavírací deska se může dát do pohybu, pokud filtr není natlakován



Dolní uzavírací deska je neopravitelná položka a nikdy by se neměla demontovat.

**ET** Alumine sulgurplaat võib liikuda, kui filter on survestamata.



Alumist sulgurplaati ei saa hooldada ja seda ei tohi kunagi eemaldada.

**HU** Az alsó zárólemez elmozdulhat, ha a szűrőt nem helyezi nyomás alá.



Az első zárólemez nem javítható, azt tilos elmozdítani.

**LV** Ja filtrā nav paaugstināta spiediena, apakšējā noslēgplāksne var kustēties



Apakšējā noslēgplāksne ir detaļa, kam nav nepieciešama apkope, un to nedrīkst noņemt.

**PL** **Uruchomienie i eksploatacja**


Przed zwiększeniem ciśnienia w filtrze należy się upewnić, że głowica oraz obudowa są prawidłowo zamontowane, a elementy blokujące są prawidłowo ustawione, jak pokazano w sekcji dotyczącej konserwacji (procedura konserwacji 6) w niniejszym podręczniku.

1. Powoli otwórz zawór wlotowy, aby stopniowo zwiększyć ciśnienie w urządzeniu.
2. Powoli otwórz zawór wylotowy, aby zwiększyć ciśnienie w dalszej części instalacji.

Nie wolno szybko otwierać zaworów wlotowych ani wylotowych, ponieważ może to doprowadzić do zbyt dużej różnicy ciśnień w urządzeniu i do jego uszkodzenia.

**SK** **Spustenie a prevádzka**


Préd natlakovaním filtra sa uistite, že hlavica a teleso sú nasadené správne a zaisťovacia súčiastka je správne zarovnaná, ako je zobrazené v časti o údržbe (postup údržby 6) tejto príručky.

1. Pomalým otvorením prírodného ventilu postupne natlakujte jednotku.
2. Pomalým otvorením vývodného ventilu opätovne natlakujte potrubie v smere prúdenia.

Prívodný ani vývodný ventil neotvárajte rýchlo ani nevystavujte jednotku nadmernému rozdielu tlaku, inak môže dôjsť k poškodeniu.

**CS** **Spuštění a provoz**


Než natlakujete filtr, zkontrolujte, zda je hlavice a baňka řádně nasazena a že pojistný detail je správně zarovnan v souladu s ustanoveními oddílu údržby (postup údržby č. 6) v tomto návodu.

1. Pomalým otevřením přírodního ventilu jednotku povolna natlakujte.
2. Pomalým otevřením výstupního ventilu znovu natlakujte potrubí ve směru rozvodu.

Přívodní ani výstupní ventily neotvírejte rychle, ani jednotku nevystavujte nadměrným rozdílu tlaku, v opačném případě může dojít k poškození.

**ET** **Käikulaskmine ja käitamine**


Enne filtri survestamist veenduge, et kate ja nõu on õigesti paigaldatud ning lukustusdetail õigesti joondatud, nagu on näidatud käesoleva juhendi hooldusjaotises (hooldustoiming nr 6).

1. Üksuse järkjärguliseks survestamiseks avage sisselaskeventiil aeglaselt.
2. Avage väljalaskeventiil aeglaselt surve taastamiseks väljavoolutorustikus.

Sisselaske- ja väljalaskeventiile ei tohi avada kiiresti ega põhjustada üksuses liiga suurt surveelangu, mis võib seda kahjustada.

**HU** **Beindítás és üzemeltetés**


A szűrő nyomás alá helyezése előtt győződjön meg arról, hogy a szűrőedény és a szűrőfej megfelelően van felszerelve, és a zárószerszemet megfelelően igazodik - a kézikönyv karbantartási fejezetében látható módon (6-os karbantartási eljárás).

1. Az egység fokozatosan történő nyomás alá helyezéséhez a bemenő szelepet lassan nyissa meg.
2. Az elvezető csővezeték nyomásának visszaállításához lassan nyissa meg az elvezető szelepet.

A berendezés károsodásának elkerülése érdekében ne nyissa meg túl gyorsan a bemenő vagy az elvezető szelepet, és ne tegye ki az egységet nagy nyomáskülönbségnek.




















**LV** **Darbības uzsākšana un darbība**


Pirms spiediena paaugstināšanas filtrā pārliecinieties, vai filtra galva un korpusa ir uzstādīts pareizi un vai fiksēšanas atzīmes atrodas viena pret otru, kā parādīts šīs rokasgrāmatas apkopes sadaļā (6. apkopes procedūra).

1. Lēni atveriet ieplūdes vārstu, lai iekārtā pakāpeniski paaugstinātu spiedienu.
2. Lēni atveriet izplūdes vārstu, lai atkal paaugstinātu spiedienu aiz iekārtas esošajās caurulēs.

Neatveriet ieplūdes vai izplūdes vārstus strauji un nepakļaujiet iekārtu pārmērīgai spiedienam starpībai, citādi var radīt bojājumus.

Akcesoria / części zamienne (zestawy serwisowe)  
Prislušenstvo / náhradní díly (servisní sady), Příslušenství / Náhradní díly (Servisní sady), Tarvikud / varuosad (teeninduskomplektid),  
Tartozékok / cserealkatrész lista (szervizkészletek), Piederumi / rezerves dajas (apkopes komplekti)

| Filter Models | Catalogue Number | Contents  |
|---------------|------------------|---|
| 010           | TRK1-2           |      |
| 015 - 020     | TRK2-2           |     |
| 025 - 030     | TRK3-2           |     |
| 035 - 045     | TRK4-2           |     |
| 050 - 055     | TRK5-2           |     |
| 010           | MBK1-1           |      |
| 015 - 020     | MBK2-1           |     |
| 025 - 030     | MBK3-1           |    |
| 035 - 045     | MBK4-1           |   |
| 050 - 055     | MBK5-1           |   |
| 010           | MBK1-2           |    |
| 015 - 020     | MBK2-2           |   |
| 025 - 030     | MBK3-2           |   |
| 035 - 045     | MBK4-2           |   |
| 050 - 055     | MBK5-2           |   |
| 010 - 055     | EM1              |  |
| 010 - 055     | PD15NO           |  |
| 010 - 030     | DPI-K            |   |
| 035 - 055     | ZD90GL           |   |

**Konserwacja**  
**Údržba, Údržba, Hooldamine, Karbantartás, Tehniská apkpe**

**PL** **Częstotliwość konserwacji**

W celu zapewnienia optymalnego działania filtra należy co 12 miesięcy wymieniać wkłady filtra klasy AO, AA, oraz dren automatyczny. Skuteczność działania wkładu ACS jest oparta na maksymalnym stężeniu oparów oleju wynoszącym 0,018mg/m<sup>3</sup>. W przypadku wykrycia oparów, zapachu lub smaku wymienić wkład węglowy filtra.

W przeciwieństwie do filtrów usuwających aerozol olejowy, które są wymieniane co roku w celu zagwarantowania odpowiedniej jakości sprężonego powietrza, trwałość filtra usuwającego opary oleju zależy od różnych czynników: filtr wymaga częstszej wymiany (chyba że stosowany jest filtr OVR o trwałości 6000 godzin).

**Czynniki wpływające na trwałość filtrów adsorpcyjnych**

**Stężenie oparów oleju**

Im większe stężenie oparów oleju na wlocie, tym mniejsza trwałość węgla aktywowanego.

**Ciekły olej**

Filtry adsorpcyjne są przeznaczone do usuwania oparów oleju i zapachów, a nie ciekłego oleju i aerozoli. Nieprawidłowo konserwowany układ filtracji wstępnej lub jego brak powoduje znaczne zmniejszenie trwałości filtra OVR.

**Temperatura**

Zawartość oparów oleju rośnie wykładniczo ze wzrostem temperatury na wlocie, co powoduje spadek trwałości wkładu. Ponadto ze wzrostem temperatury spada skuteczność adsorpcji, co powoduje dodatkowe zmniejszenie trwałości wkładu.

**Wilgotność względna lub punkt rosy**

Wilgotne powietrze zmniejsza zdolność adsorpcyjną węgla.

**Wymiany oleju w sprężarce**

Po wymianie oleju w sprężarce nowy środek smarny wypala związki organiczne o niskiej masie cząsteczkowej, co powoduje wzrost zawartości oparów oleju na wiele godzin, a nawet tygodni. Ta zwiększona ilość oparów oleju jest pochłaniana przez filtr OVR, co powoduje znaczne zmniejszenie jego trwałości adsorpcyjnej.

**SK** **Intervaly údržby**

Na zabezpečenie optimálnej výkonnosti filtra sa výmena vložiek stupňa AO, AA spolu s automatickým vypustom vyžaduje každých 12 mesiacov.

Výkon prvku ACS je založený na maximálnej vstupnej koncentrácii olejových výparov 0,018 mg/m<sup>3</sup>. Vymeňte vložku uhlíkového filtra po zaznamenaní výparov, zápachu alebo chuti.

Na rozdiel od filtrov odstraňujúcich olejový aerosól, ktoré sa vymieňajú každý rok z dôvodu zaručenia kvality stlačeného vzduchu, môže byť životnosť filtra odstraňujúceho olejové výpary ovplyvnená rôznymi faktormi, a preto si tento filter vyžaduje častejšiu výmenu (ak sa nepoužíva OVR, ktoré je dimenzované na životnosť 6000 hodín):

**Faktory ovplyvňujúce životnosť adsorpcných filtrov**

**Koncentrácia olejových výparov**

Čím vyššia je vstupná koncentrácia olejových výparov, tým rýchlejšie sa kapacita aktivovaného uhlíka spotrebuje.

**Objemový olej**

Adsorpcné filtre sú navrhnuté na odstraňovanie olejových výparov a zápachov, nie kvapalného oleja alebo aerosólov. Slatá údržba alebo neexistencia predfiltrácie spôsobí, že sa kapacita OVR filtra rýchlo spotrebuje.

**Teplota**

Obsah olejových výparov sa exponenciálne zvyšuje so vstupnou teplotou, čo znižuje životnosť vložky. Okrem toho pri zvyšovaní teploty sa adsorpcná kapacita znižuje, čo ešte viac znižuje životnosť vložky.

**Relatívna vlhkosť alebo rosný bod**

Vlhký vzduch znižuje adsorpcnú kapacitu uhlíka.

**Výmeny kompresorového oleja**

Po výmene kompresorového oleja nové mazivo spáli „ľahké častice“, čo zvyšuje obsah olejových výparov na celé nasledujúce hodiny, alebo dokonca týždne. Takýto zvýšený obsah olejových výparov adsorbujú OVR filter, čo však výrazne zníži jeho adsorpcnú životnosť.

**CS** **Intervaly údržby**

Chcete-li zaručit optimální výkonnost filtru, je nutné vyměňovat vložky třídy AO, AA společně s automatickým vypouštěním každých 12 měsíců.

Funkčnost vložky ACS je založena na maximální koncentraci vstupujících olejových par 0,018 mg/m<sup>3</sup>. Při zjištění výparů, zápachu nebo pachuti vyměňte uhlíkovou filtrační vložku.

Na rozdíl od filtrů určených pro odstranění aerosolu, které se pro zajištění kvality stlačeného vzduchu mění každý rok, je životnost filtru pro odstranění olejových par závislá na různých faktorech a vyžaduje častější výměny (pokud se nepoužije OVR s životností 6000 provozních hodin):

**Faktory ovlivňující životnost adsorpcních filtrů**

**Koncentrace olejových par**

Čím vyšší je koncentrace olejových par na vstupu, tím rychleji bude vyčerpána kapacita aktivního uhlí.

**Olej**

Absorpcní filtry jsou navrženy tak, aby odstraňovaly olejové páry a zápach, nikoli kapalný olej nebo aerosoly. Špatně udržovaná nebo neexistující předfiltrace způsobí rychlé vyčerpání kapacity filtru OVR.

**Teplota**

Obsah olejových par se zvyšuje exponenciálně podle teploty vstupu a snižuje životnost vložky. Kromě toho se se zvyšující teplotou snižuje adsorpcní kapacita, což rovněž snižuje životnost vložky.

**Relativní vlhkosť nebo rosný bod**

Mokry vzduch snižuje adsorpcní kapacitu uhlí.

**Výměna oleje kompresoru**

Když vyměníte olej kompresoru, nové mazivo spaluje „lehké kousky“, což zvyšuje obsah olejových par po dobu následujících hodin nebo týdnů. Toto zvýšení obsahu olejových par je absorbováno filtrem OVR, což významně snižuje adsorpcní životnost.

**ET** **Hooldusintervallid**

Filtri optimaalse jõudluse tagamiseks tuleb AO, AA klassi elemente vahetada iga 12 kuu tagant koos automaatselt väljalaskeseadmega.

ACS elemendi jõudlus põhineb maksimaalsel õliaurude kontsentratsioonil 0,018mg/m<sup>3</sup>. Auru, lõhna või maitse tuvastamise korral vahetage välja söefiltri element.

Erinevalt õliaerosooli eemaldusfiltritest, mida tuleb suringu kvaliteedi tagamiseks vahetada kord aastas, sõltub õliauru eemaldusfiltri tööiga erinevatel teguritel ja seda tuleb vahetada sagedamini (kui ei kasutata OVR-i, mille tööiga on 6000 tundi).

**Adsorptsioonifiltri tööiga mõjutavad tegurid**

**Õliaurude kontsentratsioon**

Mida suurem on sisselasuva õliauru kontsentratsioon, seda kiiremini saab täis aktiivsõe maht.

**Jääkõli**

Adsorptsioonifiltrid on mõeldud õliaurude ja lõhnade eemaldamiseks, mitte vedela õli või aerosooli eemaldamiseks. Halvasti hooldatud või puudut eelfiltratsioon põhjustab OVR-filtri mahu kiiret vähenemist.

**Temperatuur**

Õliaurude maht suureneb eksponentsiaalselt sisend-temperatuuri suhtes, vähendades elemendi tööiga. Lisaks väheneb temperatuuri suurenedes adsorptsioonivõime, vähendades omakorda elemendi tööiga.

**Suhteline niiskus või kastepunkt**

Niiske õhk vähendab sõe adsorptsioonivõimet.

**Kompressorõli vahetus**

Kompressorõli vahetamisel põleb ära uue määrdeaine ülejääk, mis suurendab õliaurude mahtu veel tunde või koguni nädalaid hiljem. See õliaurude suurenenud adsorbieritakse OVR-filtri poolt, mis vähendab oluliselt selle adsorbierimisvõimet.

**HU** **Karbantartási gyakoriság**

Az optimális szűrési teljesítményhez az AO, AA, osztályú szűrőbetéteket 12 havonta kell cserélni az automatikus leeresztéssel együtt.

Az ACS szűrőbetét megfelelő működésének feltétele a maximum 0,018mg/m<sup>3</sup> bemeneti olajgőz-koncentráció. Gőz, szag vagy íz észlelése esetén cserélje ki a szén szűrőbetétet.

A sűrített levegő minőségének garantálására évente cserélt olajpermet-eltávolító szűrőkkel ellentétben az olajgőz-eltávolító szűrők élettartamát különböző tényezők befolyásolhatják és gyakoribb cserére lehet szükség (kivéve a 6000 üzemóra élettartama méretezett olajgőz-eltávolító szűrőket).

**Az elnyelő szűrők élettartamát befolyásoló tényezők**

**Az olajgőz koncentrációja**

Minél magasabb az olajgőz bemeneti koncentrációja, annál gyorsabban merül ki az aktív szén kapacitása.

**Nagy sűrűségű olaj**

Az elnyelő szűrők olajgőzök és szagok, nem pedig folyadék halmazállapotú olaj vagy permet eltávolítására szolgálnak. A nem megfelelően karbantartott vagy hiányzó előszűrés az olajgőz-eltávolító szűrők kapacitásának túl gyors kimerüléséhez vezet.

**Hőmérséklet**

Az olajgőztartalom a bemeneti hőmérséklet növekedésével exponenciálisan nő, csökkentve a szűrőbetétek élettartamát. Ezen kívül a hőmérséklet növekedésével csökken az elnyelőképeség, ami ugyancsak csökkenti a szűrőbetétek élettartamát.

**Relatív nedvesség-tartalom vagy harmatpont**

A nedves levegő csökkenti a szén elnyelőképeséget.

**Olajcserék a kompresszorban**

A kompresszor olajának cseréjekor az új kenőanyag mint „előpárlat” kiég, ami órákra, esetleg hetekre is megnöveli az olajgőz-tartalmat. Az olajgőz-tartalom ezen növekményét az olajgőz-eltávolító szűrő nyeli el, amelynek elnyelési élettartama így jelentősen csökken.

**LV** **Apkopes intervälli**

Lai nodrošinātu optimālu filtra veiktspēju, ik pēc 12 mēnešiem jānomaina AO, AA, klases elementi un automātiskā novācuurūlīte.

ACS klases elementa veiktspēja ir atkarīga no maksimālās eļļas tvaiku ietilpības koncentrācijas 0,018 mg/m<sup>3</sup>. Ja tiek konstatēti tvaiki, aromāts vai garša, nomainiet oglekļa filtra elementu.

Pretrēji eļļas aerosolu atdališanas filtriem, kas tiek mainīti katru gadu, lai nodrošinātu spiesti gaisa kvalitāti, eļļas tvaiku atdališanas filtra kalpošanas laiku var saīsināt ar dažādiem faktoriem, un tas ir jānomaina daudz biežāk (ja vien netiek izmantots OVR, kura kalpošanas laiks ir noteikts 6000 stundām).

**Faktori, kas ietekmē adsorbcijas filtru kalpošanas laiku**

**Eļļas tvaiku koncentrācija**

Jo augstāka ietilpības koncentrācija, jo ātrāk beidzas aktīvā oglekļa kapacitāte.

**Eļļa lielā apjomā**

Adsorbcijas filtri ir paredzēti eļļas tvaiku un aromātu likvidēšanai, nevis šķidrās eļļas vai aerosolu likvidēšanai. Ja priekšfiltrācija ir vāji uzturēta vai tās nav vispār, OVR filtra kapacitāte ātri beidzas.

**Temperatūra**

Eļļas tvaiku saturs palielinās atbilstoši ietilpības temperatūrai, samazinot elementa kalpošanas laiku. Turklāt, palielinoties temperatūrai, samazinās adsorbcijas kapacitāte, kas arī samazina elementa kalpošanas laiku.

**Relatīvais mitrums vai kondensācijas temperatūra**

Mitrš gaisa samazina oglekļa adsorbcijas kapacitāti.

**Kompresora eļļas maiņa**

Kad tiek mainīta kompresora eļļa, jaunais eļļas materiāls sadedzina vieglās frakcijas, kas palielina eļļas tvaiku saturu uz vairākām stundām vai pat nedēļām. Ar to tiek palielināts eļļas tvaiku saturs, ko adsorbē OVR filtri, ievērojami samazinot tā adsorbēšanas kapacitāti.

**PL Procedura konserwacji 1**

Powoli zamknąć zawór wlotowy (1) i wylotowy (2) i obniżyć ciśnienie w filtrze (3) przy użyciu drenu.

**SK Postup údržby 1**

Pomalú zatvorte prívodný (1) a vývodný (2) ventil a vypustite tlak z filtra (3) použitím výpustu.

**CS Postup údržby č. 1**

Pomalú uzavřete vstupní (1) a výstupní (2) ventily a odtlačíte filtr (3) pomocí vypouštění.

**ET Hooldustoiming nr 1**


Sulgege aeglaselt sisselaske- (1) ja väljalaskeventiilid (2) ning rõhutustage filter (3) äravoolu abil.

**HU 1-es karbantartási eljárás**

Lassan zárja el a bemenő (1) és a kimenő (2) szelepeket és nyomásmentesítse a szűrőt (3) a leeresztő segítségével.

**LV 1. apkopes procedūra**

Lēni aizveriet ieplūdes (1) un izplūdes (2) vārstu un samaziniet spiedienu filtrā (3), izmantojot novadcauruli.



**PL Procedura konserwacji 2**

Odkręcić obudowę filtra (1 i 2) i wyjąć zużyty wkład (3).

**SK Postup údržby 2**

Odskrutkujte teleso filtra (1 a 2) a vyberte použitú vložku (3).

**CS Postup údržby č. 2**

Odsróbujte baňku filtra (1 a 2) a sejměte použitý prvek (3)

**ET Hooldustoiming nr 2**


Keerake filtrinõu (1 ja 2) lahti ja eemaldage kasutatud element (3)

**HU 2-es karbantartási eljárás**

Csavarja le a szűrőedényt (1 és 2) és vegye ki belőle a használt szűrőbetétet (3).

**LV 2. apkopes procedūra**

Atskrūvējiet filtra korpusu (1 un 2) un izņemiet izlietoto elementu (3).



**PL Procedura konserwacji 3**

Odkręcić dren automatyczny (1) i wyrzucić go (2). Zamontować nowy dren (3) i dokręcić go (4).

**SK Postup údržby 3**

Odskrutkuje automatický výpust (1) a zlikvidujte ho (2). Nasadte nový výpust (3) a utiahnite (4).

**CS Postup údržby č. 3**

Odsróbujte automatické vypouštění (1) a zlikvidujte je (2). Nasadte nové vypouštění (3) a utáhněte (4).

**ET Hooldustoiming nr 3**


Keerake automaatne väljalaskeade (1) lahti ja visake ära (2). Paigaldage uus väljalaskeade (3) ja kinnitage (4).

**HU 3-as karbantartási eljárás**

Csavarja le azt automatikus leeresztést (1) és selejtezze azt le (2). Helyezze el az új leeresztést (3) és húzza azt meg (4).

**LV 3. apkopes procedūra**

Noskrūvējiet automātisko novadcauruli (1) un izmetiet to (2). Uzstādiat jauno novadcauruli (3) un pievelciat to (4).



**PL Procedura konserwacji 4**

Włożyć nowy wkład do obudowy filtra i upewnić się, że występy są prawidłowo ustawione w rowkach.

**SK Postup údržby 4**

Do telesa filtra vložte novú vložku a uistite sa, že výstupky sú správne nasadené do drážok.

**CS Postup údržby č. 4**

Zasuňte nový prvek do baňky filtru a zkontrolujte, zda jsou čepy řádně usazeny v drážkách.

**ET Hooldustoiming nr 4**


Sisestage uus element filtrinõusse, veendudes, et tugiõpad on õigesti soontes.

**HU 4-es karbantartási eljárás**

Helyezze az új szűrőbetétet a szűrőedénybe úgy, hogy a fűlek jól illeszkedjen a kiképzett hornyokba.

**LV 4. apkopes procedūra**

Ievietojiet jauno elementu filtra korpusā, nodrošinot, lai izciļņi pareizi iegultu rievās.



**PL Procedura konserwacji 5**

Wymienić pierścieni typu o-ring na głowicy filtra na dostarczony nowy pierścieni.



**Nasmarować pierścieni typu o-ring oraz gwinty odpowiednią wazeliną nie zawierającą kwasów.**

**SK Postup údržby 5**

Tesniaci krúžok umiestnený v hlavici filtra nahradte novým dodaným tesniacim krúžkom.



**Tesniaci krúžok a závitý namažte vhodnou vazelinou neobsahujúcou kyselínu.**

**CS Postup údržby č. 5**

Vyměňte těsnicí kroužek umístěný v hlavici filtru za nový dodaný těsnicí kroužek.



**Nezapomeňte těsnicí kroužek a závitý namazat vhodnou vazelinou bez kyseliny.**

**ET Hooldustoiming nr 5**

Asendage filtri kattes olev rõngastihend uue kaasasoleva rõngastihendiga.



**Määrige kindlasti rõngastihendit ja keermeid sobiva happevaba vaseliiniga.**

**HU 5-ös karbantartási eljárás**

Cserélje le a szűrőfejben található O-gyűrűt a mellékelt O-gyűrűre.



**Ne feledje megkenni az O-gyűrűt és a meneteket arra alkalmas savmentes ásványi olaj zselével.**

**LV 5. apkopes procedūra**

Nomainiet filtra galvā esošo blīvgredzenu ar komplektā iekļauto jauno blīvgredzenu.



**Noteiktī ieeļļojiet blīvgredzenu un vītnes ar piemērotu vazelinu, kas nesatur skābi.**



**PL Procedura konserwacji 6 (a)**

Zamontować obudowę filtra oraz głowicę i upewnić się, że gwinty są całkowicie dokręcone, a elementy blokujące są prawidłowo ustawione.

**Uwaga:** Upewnić się, że obudowa jest pewnie przymocowana do głowicy — obudowa 0010-030 wymaga obrócenia o 360° do ogranicznika gwintu, a obudowa 035-045 wymaga obrócenia o 720°

**SK Postup údržby 6 (a)**

Znovu nasadte teleso a hlavicu filtra a uistite sa, že závitý úplne zapadli a zaisťovacie súčiastky sú zarovnané.

**Poznámka:** S cieľom uistiť sa, či teleso úplne zapadlo do hlavice, sa pri telese 010-030 vyžaduje 360° rotácia, kým sa závit nezastaví, a 720° sa vyžaduje pri telese 035-045.

**CS Postup údržby č. 6 (a)**

Nasadte zpět baňku a hlavici filtru a zkontrolujte, zda jsou závitý řádně zapojeny a pojistné detaily jsou v rovině.

**Poznámka:** Abyste měli jistotu, že baňka je plně zapojena do hlavice, baňka 010-030 vyžaduje otáčení o 360°, dokud se závit nedotočí, a 720° u baňky 035-045.

**ET Hooldustoiming nr 6 (a)**

Paigaldage tagasi filtrinõu ja kate ning korralikult lõpuni keerates, nii et lukustusdetailid on kohakuti.

**Märkus:** Nõu lõpuni katte külge kinnitamiseks on vaja nõu 010-030 pöörata 360° kuni keermete lõpuni ja 720° nõu 035-045 korral.

**HU 6-os karbantartási eljárás (a)**



Szerelje vissza a szűrőedényt és a fejet. Győződjön meg a menetek és a záróelemek megfelelő illeszkedéséről.

**Megjegyzés:** Annak biztosításához, hogy az edény teljesen a fejbe illeszkedjen a 010-030 edényt 360°-ban el kell forgatni, míg a menet el nem fogy, ill. a 035-045 edényt 720°-ban.

**LV 6. apkopes procedūra (a)**

Atkal samontējiet filtra korpusu un galvu, nodrošinot, lai vītnes būtu pilnībā savienotas un fiksēšanas atzīmes atrastos viena pret otru.

**Piezīme:** Lai nodrošinātu, ka korpusi ir pilnībā ieskrūvēts galvā, korpus 010-030 jāpagriež par 360°, līdz vītne ir pilnībā izmantota (korpus 035-045 jāpagriež par 720°).



**PL Procedura konserwacji 7**

Przymocować etykietę z datą wymiany wkładu do obudowy filtra i zapisać na niej datę kolejnej wymiany wkładu przypadającą 12 miesięcy po ostatniej wymianie



**Do czyszczenia etykiet nie należy używać rozpuszczalników ani alkoholu, ponieważ może to spowodować ich uszkodzenie.**

**SK Postup údržby 7**

Na teleso filtra pripojte štítok s dátumom výmeny vložky a napíšte dátum, kedy sa má vložka vymeniť, t. j. 12 mesiacov po výmene vložky.



**Na čistenie štítkov nepoužívajte rozpúšťadlá ani alkohol, pretože môže dôjsť k poškodeniu.**

**CS Postup údržby č. 7**

Přípevněte štítek s datem výměny prvku k baňce filtru a запиšte datum příští výměny prvku, tj. 12 měsíců po výměně prvku



**Nečistěte štítky rozpouštědly ani alkoholem, mohlo by dojít k poškození.**

**ET Hooldustoiming nr 7**

Kinnitage elemendi vahetamise kuupäeva viit filtrinõu külge ja kirjutage sellele elemendi asendamise kuupäev (12 kuud pärast elemendi vahetamist).



**Ärge puhastage silte piirituse või lahustitega, kuna need võivad silte rikkuda.**

**HU 7-es karbantartási eljárás**

Helyezze el a szűrőbetét-csere dátumát megadó címét a szűrőedényre, és jegyezze fel a következő csere időpontját; értsd: 12 hónappal a mostani szűrőbetét-csere utáni időpontot.




**Ne használjon oldószert vagy alkoholt a címék tisztításához, mert az sérüléseket okozhat.**

**LV 7. apkopes procedūra**

Pie filtra piestipriniet elementa maiņas datuma etiķeti un norādiet tajā nākamās elementa maiņas datumu, t. i., pēc 12 mēnešiem pēc elementa maiņas.



**Etiķešu tīrīšanā neizmantojiet šķīdinātājus vai spirtu, jo tā var radīt bojājumus.**



**PL Procedura konserwacji 8**

Powoli otworzyć zawór wlotowy (1), aby stopniowo zwiększyć ciśnienie w urządzeniu, a następnie powoli otworzyć zawór wylotowy (2), aby zwiększyć ciśnienie w dalszej części instalacji



**Nie wolno szybko otwierać zaworów wlotowych ani wylotowych, ponieważ może to doprowadzić do zbyt dużej różnicy ciśnień w urządzeniu i do jego uszkodzenia.**

**SK Postup údržby 8**

Pomalým otvorením prírodného ventilu (1) postupne natlakujte jednotku, pomalým otvorením vývodného ventilu (2) opätovne natlakujte potrubie v smere prúdenia.



**Prívodný ani vývodný ventil neotvárajte rýchlo ani nevystavujte jednotku nadmernému rozdielu tlaku, pretože môže dôjsť k poškodeniu.**

**CS Postup údržby č. 8**

Pomalým otvíráním vstupního ventilu (1) jednotku postupně natlakujte, pomalým otvíráním výstupního ventilu (2) znovu natlakujte potrubí ve směru rozvodu.



**Prívodní ani výstupní ventily neotvírejte rychle, ani jednotku nevystavujte nadměrným rozdílům tlaku, v opačném případě může dojít k poškození.**

**ET Hooldustoiming nr 8**

Avage aeglaselt sisselaskeventiil (1), et üksus järk-järgult survestada, ning avage aeglaselt väljalaskeventiil (2) surve taastamiseks väljavoolutorustikus..



**Sisselaske- ja väljalaskeventiile ei tohi avada kiiresti ega põhjustada üksuses liiga suurt survelangu, mis võib tekitada sellele kahjustusi.**

**HU 8-as karbantartási eljárás**

Az egység fokozatos nyomás alá helyezéséhez a bemenő szelepet (1) nyissa meg lassan; az elvezető csővezeték nyomásának visszaállításához lassan nyissa meg az elvezető szelepet (2).




**A berendezés károsodásának elkerülése érdekében ne nyissa meg túl gyorsan a bemenő vagy az elmenő szelepet, és ne tegye ki az egységet nagy nyomáskülönbségnek.**

**LV 8. apkopes procedūra**

Lēni atveriet ieplūdes vārstu (1), lai pakāpeniski palielinātu spiedienu iekārtā, lēni atveriet izplūdes vārstu (2), lai atkal paaugstinātu spiedienu aiz iekārtas esošajās caurulēs.



**Neatveriet ieplūdes vai izplūdes vārstus strauji un nepakļaujiet iekārtu pārmērīgai spiedienam starpībai, citādi var radīt bojājumus.**



**LT VIENERIŲ METŲ KOKYBĖS GARANTIJA**

Jūsų oro kokybę garantuojama 1 metų laikotarpiu ir bus atnaujinta kasmet pakeitus filtro elementą. Kasmetiniai filtro elemento keitimai užtikrina, kad:

- bus išlaikomos optimalios charakteristikos
- oro kokybė ir toliau atitiks tarptautinius standartus
- bus apsaugoti filtruotoje aplinkoje esantys įrenginiai, darbuotojai ir procesai
- išliks mažos eksploataavimo išlaidos
- padidės produktyvumas ir pelningumas
- sumažės rūpesčių

**RU ГОДОВАЯ ГАРАНТИЯ КАЧЕСТВА ВОЗДУХА**

Качество воздуха гарантируется в течение одного года. Эту гарантию можно продлевать ежегодно за счет замены фильтрующего элемента. Ежегодная замена фильтрующего элемента обеспечивает следующие преимущества.

- Поддержание оптимальных рабочих характеристик.
- Соответствие качества воздуха международным стандартам.
- Защита оборудования, расположенного ниже по потоку, персонала и процессов.
- Снижение эксплуатационных расходов.
- Повышение продуктивности и доходности.
- Уверенность в исправной работе.

**SL ENOLETNA GARANCIJA ZA KAKOVOST ZRAKA**

Garancija za kakovost zraka velja eno leto in se obnovi pri vsakoletni zamenjavi filtrirnega elementa. Vsakoletna zamenjava filtrirnega elementa zagotavlja:

- vzdrževanje optimalne učinkovitosti,
- nadaljnjo skladnost kakovosti zraka z mednarodnimi standardi,
- zaščito priključene opreme, osebja in procesov,
- nizke obratovalne stroške,
- zvišano produktivnost in donosnost ter brezskrbnost.

**TR BİR YIL HAVA KALİTESİ GARANTİSİ**

Havanızın kalitesi 1 yıllığına garanti edilmiştir ve garanti, her yıllık filtre öğesi değişikliğinde yenilenecektir. Yıllık filtre öğesi değişikliği sunları sağlar:

- En iyi performansın devam etmesi sağlanır
- Hava kalitesi uluslararası standartları karşılamaya devam eder
- Aşağı akım ekipmanının, personelin ve süreçlerinin korunması
- Düşük işletim masrafları
- artan verimlilik ve kârlılık
- gönül rahatlığı

**MT GARANZIJA TA' SENA FUQ IL-KWALITÀ TAL-ARJA**

Il-kwalità tal-arja tieghek giet iggarantita għal sena u sejra tiġġedded ma' kull tibdil tal-element tal-filtru kull sena. Tibdiliet tal-element tal-filtru kull sena jiġguraw:

- Zamma tal-aqwa prestazzjoni
- Il-kwalità tal-arja li b'q' tissodisfa l-istandards internazzjonali
- Il-protezzjoni ta' apparat, personal u processi 'l isfel
- Spejjeż operattivi baxxi
- Zieda fil-produktività u fil-profitabilità
- serhan il-mohh

**RO UN AN GARANȚIE A CALITĂȚII AERULUI**

Calitatea aerului a fost garantată pentru 1 an și va fi reinnoită la fiecare înlocuire anuală a elementului filtrului. Înlocuirile anuale ale elementului filtrului asigură:

- menținerea unor performanțe optime
- respectarea continuă a standardelor internaționale referitoare la calitatea aerului
- protecția echipamentului din aval, a personalului și a proceselor
- costuri operaționale scăzute
- productivitate și profitabilitate crescută
- liniște sufletească

**BG ЕДНА ГОДИНА ГАРАНЦИЯ ЗА КАЧЕСТВО НА ВЪЗДУХА**

Качеството на Вашия въздух е гарантирано за 1 година и ще бъде подновявано с всяка годишна смяна на филтърен елемент. Годишните смени на филтърен елемент осигуряват:

- Поддържане на оптимална ефективност
- Качеството на въздуха продължава да отговаря на международните стандарти
- Защита на изходните елементи на оборудването, персонала и процесите
- Ниски оперативни разходи
- Увеличена продуктивност и рентабилност
- Душевно спокойствие



## ④ Modelio kodavimo pavyzdys:

| Modelis               |  |   |  |                     |                           |                                   |
|-----------------------|--|---|--|---------------------|---------------------------|-----------------------------------|
| Elemento klasė        | Aukštesniosios klasės energiją taupantis elementas | Modelio dydis                           | Prievado dydis   | Gijų tipas          | Išleidimo parinktis       | DP indikatorius                   |
| WS<br>AO<br>AA<br>ACS | P  | 3 skaitmenų kodas, kaip parodyta toliau | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Plūdė<br>M = Rankinis | X = Nėra<br>I = Įvykių monitorius |
| AA                    | P  | 030                                     | A  | G                   | F                         | I                                 |

## ④ Пример кодировки модели:

| Модель                      |  |                                   |  |                     |                                 |  |
|-----------------------------|--|-----------------------------------|--|---------------------|---------------------------------|--|
| Марка фильтрующего элемента | Высококачественный энергоэффективный фильтрующий элемент | Размер модели                     | Размер отверстия   | Тип резьбы          | Вариант сливного устройства     | Индикатор перепада давления                |
| WS<br>AO<br>AA<br>ACS       | P  | Трёхзначный код, как указано ниже | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Поплавок<br>M = Руководство | X = Нет<br>I = Монитор аварийных сообщений |
| AA                          | P  | 030                               | A  | G                   | F                               | I  |

## ④ Primer kodiranja modela:

| Model                 |  |  |  |                     |                            |                                   |
|-----------------------|--|--|--|---------------------|----------------------------|-----------------------------------|
| Razred elementa       | Element energetske učinkovitosti »Premium« | Velikost modela                            | Velikost odprtine  | Tip navoja          | Možnost praznjenja         | Indikator diferencialnega tlaka   |
| WS<br>AO<br>AA<br>ACS | P  | Koda s 3 števками, kot je prikazano spodaj | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Plavajoče<br>M = Ročno | X = Brez<br>I = Monitor pojavitve |
| AA                    | P  | 030  | A  | G                   | F                          | I                                 |

**88 Model Kodlama örneği:**

| Model                 |                               |                                    |  |                     |                             |                              |
|-----------------------|-------------------------------|------------------------------------|--|---------------------|-----------------------------|------------------------------|
| Eleman Sınıfı         | Premium Enerji Verimli Eleman | Model Boyutu                       | Port Boyutu  | Dış Tipi            | Taliye Seçeneği             | DP Göstergesi                |
| WS<br>AO<br>AA<br>ACS | P                             | Aşağıdaki gibi 3 basamaklı bir kod | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Şamandıra<br>M = Manuel | X = Yok<br>I = Olay Monitörü |
| AA                    | P                             | 030                                | A  | G                   | F                           | I                            |

**89 Ežempju ta' Kodifikazzjoni tal-Mudell:**

| Mudell                |   |                                 |  |                     |                          |                                       |
|-----------------------|---|---------------------------------|--|---------------------|--------------------------|---------------------------------------|
| Grad ta' Element      | Element ta' Effiċjenza ta' Enerġija Primjum | Daqs tal-Mudell                 | Daqs tal-Port  | Tip ta' Kamin       | Opzjoni ta' Drejn        | Indikator DP                          |
| WS<br>AO<br>AA<br>ACS | P   | kodiċi bi 3 cifri kif muri taht | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Flowt<br>M = Manwali | X = Xejn<br>I = Moniter tal-Inċidenti |
| AA                    | P   | 030                             | A  | G                   | F                        | I                                     |

**90 Exempu codificare model:**

| Model                 |   |  |  |                     |                           |                                      |
|-----------------------|---|--|--|---------------------|---------------------------|--------------------------------------|
| Calitate element      | Element cu eficiență energetică premium | Dimensiunea modelului                      | Dimensiunea orificiului  | Tip de filet        | Opțiune de golire         | Indicator de presiune diferențială   |
| WS<br>AO<br>AA<br>ACS | P                                       | Cod din 3 cifre, după cum se arată mai jos | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = Flotant<br>M = Manual | X = Niciunul<br>I = Monitor incident |
| AA                    | P                                       | 030  | A  | G                   | F                         | I                                    |

**91 Пример за кодиране на модел:**

| Модел                 |                                   |  |  |                     |                             |                                      |
|-----------------------|-----------------------------------|--|--|---------------------|-----------------------------|--------------------------------------|
| Клас на елемента      | Надежден енергоэффективен елемент | Размер на модела                       | Размер на порта  | Тип с резба         | Опция за дрениране          | Индикатор за диференциално налягане  |
| WS<br>AO<br>AA<br>ACS | P                                 | 3-цифрен код, както е показано по-долу | A = 1/4"<br>B = 3/8"<br>C = 1/2"<br>D = 3/4"<br>E = 1"<br>G = 1 1/2"<br>H = 2"<br>I = 2 1/2"<br>J = 3" | G = BSPP<br>N = NPT | F = С поплавок<br>M = Ръчно | X = Няма<br>I = Монитор за инциденти |
| AA                    | P                                 | 030                                    | A  | G                   | F                           | I                                    |

**㉑ Gaminio pasirinkimas**

Nurodyti srautai skirti veikimui esant 7 barams (100 psi g), kai atskaita 20°C, 1 baras ir 0 % santykinis vandens garų slėgis.

Kito slėgio srautams taikykite nurodytus korekcijos veiksnius.

**㉒ Выбор продуктов**

Значения расхода определены для работы под давлением 7 бар (100 фунтов на кв. дюйм) при температуре 20 °С, атмосферном давлении 1 бар и относительном давлении водяного пара 0 %.

Для определения расхода при других значениях давления используйте указанные поправочные коэффициенты.

**㉓ Izbira izdelka**

Navedeni pretoki so za delovanje pri 7 barg (100 psig) pri 20° C, 1 bar (a), 0% relativni tlak vodne pare.

Za pretoke z drugačnimi tlaki uporabite prikazane korekcijske faktorje.

**㉔ Ürün Seçimi**

Belirtilen akışlar, 20°C, 1 bar a, %0 nispi su buharı basıncına referansla 7 bar g'de (100 psi g) işletme içindir.

Diğer basınçlarda akış miktarı için aşağıda verilen düzeltme faktörleri kullanılır.

**㉕ Għażla tal-Prodott**

Il-flussi indikati huma għal tħaddim ta' 7 bar g (100 psi g) b'referenza ta' 20°C, 1 bar a, 0% pressjoni relattiva tal-fwar ta' ilma.

Għal flussi f'kundizzjonijiet oħrajn, applika l-fatturi ta' korrezzjoni murija.

**㉖ Selecie produs**

Valorile indicate ale debitelor sunt destinate operației la 7 bar g (100 psi g) cu referință la 20°C, 1 bar a, 0% presiune relativă a vaporilor de apă.

Pentru debitele aflate la alte presiuni, se aplică factorii de corecție prezentați anterior.

**㉗ Избор на продукт**

Посочените потоци са за работа при налягане 7 бара (изм.) (100 фунта на кв. инч (изм.)) при референтна температура от 20°C, 1 бар (атм.), 0% относително налягане на водни пари.

За потоци при други налягания прилагайте показаните коефициенти на корекция.

**Vandens separatoriaus debitai**

Расход на водяном сепараторе, Hitrosti pretoka izločevalnikov vode, Su Ayrıştırıcısı Akış Hızları, Rati tal-Fluss tas-Separatur tal-Ilma, Debite separator de apă, Дебити на водните сепаратори

| Model                | Port Size | L/s | m3/min | m3/hr | cfm  |
|----------------------|-----------|-----|--------|-------|------|
| WS P010A [ ] [ ] [ ] | ¼         | 10  | 0.6    | 36    | 21   |
| WS P010B [ ] [ ] [ ] | ¾         | 10  | 0.6    | 36    | 21   |
| WS P010C [ ] [ ] [ ] | ½         | 10  | 0.6    | 36    | 21   |
| WS P015C [ ] [ ] [ ] | ½         | 40  | 2.4    | 144   | 85   |
| WS P020D [ ] [ ] [ ] | ¾         | 40  | 2.4    | 144   | 85   |
| WS P025D [ ] [ ] [ ] | ¾         | 110 | 6.6    | 396   | 233  |
| WS P025E [ ] [ ] [ ] | 1         | 110 | 6.6    | 396   | 233  |
| WS P030G [ ] [ ] [ ] | 1 ½       | 110 | 6.6    | 396   | 233  |
| WS P035G [ ] [ ] [ ] | 1 ½       | 350 | 21.0   | 1260  | 742  |
| WS P040H [ ] [ ] [ ] | 2         | 350 | 21.0   | 1260  | 742  |
| WS P045I [ ] [ ] [ ] | 2 ½       | 350 | 21.0   | 1260  | 742  |
| WS P050I [ ] [ ] [ ] | 2 ½       | 800 | 48.0   | 2880  | 1695 |
| WS P055J [ ] [ ] [ ] | 3         | 800 | 48.0   | 2880  | 1695 |

**CFP – mažiausias pataisos koeficientas (angl. Correction Factor Minimum) įleidimo angos slėgiui (vandens separatoriai)**

CFP — поправочный коэффициент при минимальном входном давлении (водяные сепараторы), CFP – korekcijski faktor pri minimalnem dovodnem tlaku (izločevalniki vode), CFP – Düzeltme Faktörü Minimum Giriş Basıncı (Su Ayrıştırıcıları), CFP – Pressjoni Minima tal-Ħbökk tad-Dhul tal-Fattur ta' Korrezzjoni (Separaturi tal-Ilma), CFP - Factor de corec ie presiune de intrare minimă (Separatoare de apă), CFP - коригирац коефициент, минимално входно налягане (водни сепаратори) ,

| Minimum Inlet Pressure | bar g | 1    | 2    | 3    | 4    | 5    | 6    | 7    | 8    | 9    | 10   | 11   | 12   | 13   | 14   | 15   | 16   |
|------------------------|-------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
|                        | psi g | 15   | 29   | 44   | 58   | 73   | 87   | 100  | 116  | 131  | 145  | 160  | 174  | 189  | 203  | 218  | 232  |
| Correction Factor      |       | 4.00 | 2.63 | 2.00 | 1.59 | 1.33 | 1.14 | 1.00 | 0.94 | 0.89 | 0.85 | 0.82 | 0.79 | 0.76 | 0.73 | 0.71 | 0.68 |

**Filtro debitai**

Расход на фильтре, Hitrosti pretoka filtrov, Filtre Akış Hızları, Rati tal-Fluss tal-Filtru, Debite filtru, Дебити на филтрите

| Model                     | Port Size | L/s | m3/min | m3/hr | cfm | Replacement Element kit | No. |
|---------------------------|-----------|-----|--------|-------|-----|-------------------------|-----|
| [grade] P010A [ ] [ ] [ ] | ¼         | 10  | 0.6    | 36    | 21  | P010 [grade]            | 1   |
| [grade] P010B [ ] [ ] [ ] | ¾         | 10  | 0.6    | 36    | 21  | P010 [grade]            | 1   |
| [grade] P010C [ ] [ ] [ ] | ½         | 10  | 0.6    | 36    | 21  | P010 [grade]            | 1   |

|         |       |     |     |     |     |     |      |      |      |      |         |   |
|---------|-------|-----|-----|-----|-----|-----|------|------|------|------|---------|---|
| [grade] | P015C | [ ] | [ ] | [ ] | ½   | 20  | 1.2  | 72   | 42   | P015 | [grade] | 1 |
| [grade] | P020C | [ ] | [ ] | [ ] | ½   | 30  | 1.8  | 108  | 64   | P020 | [grade] | 1 |
| [grade] | P020D | [ ] | [ ] | [ ] | ¾   | 30  | 1.8  | 108  | 64   | P020 | [grade] | 1 |
| [grade] | P025D | [ ] | [ ] | [ ] | ¾   | 60  | 3.6  | 216  | 127  | P025 | [grade] | 1 |
| [grade] | P025E | [ ] | [ ] | [ ] | 1   | 60  | 3.6  | 216  | 127  | P025 | [grade] | 1 |
| [grade] | P030G | [ ] | [ ] | [ ] | 1 ½ | 110 | 6.6  | 396  | 233  | P030 | [grade] | 1 |
| [grade] | P035G | [ ] | [ ] | [ ] | 1 ½ | 160 | 9.6  | 576  | 339  | P035 | [grade] | 1 |
| [grade] | P040H | [ ] | [ ] | [ ] | 2   | 220 | 13.2 | 792  | 466  | P040 | [grade] | 1 |
| [grade] | P045I | [ ] | [ ] | [ ] | 2 ½ | 330 | 19.8 | 1188 | 699  | P045 | [grade] | 1 |
| [grade] | P050I | [ ] | [ ] | [ ] | 2 ½ | 430 | 25.8 | 1548 | 911  | P050 | [grade] | 1 |
| [grade] | P055I | [ ] | [ ] | [ ] | 2 ½ | 620 | 37.3 | 2232 | 1314 | P055 | [grade] | 1 |
| [grade] | P055J | [ ] | [ ] | [ ] | 3   | 620 | 37.3 | 2232 | 1314 | P055 | [grade] | 1 |

[klase] = klasé  
 [klacc] = klacc  
 [razred] = razred  
 [derece] = derece  
 [grad] = grad  
 [grad] = grad  
 [razredka] = razredka

**CFP – mažiausias pataisos koeficientas (angl. Correction Factor Minimum) įleidimo angos slėgiui (koalescenciniai ir sausų kietųjų dalelių filtrai)**

CFP — поправочный коэффициент при минимальном входном давлении (коалесцирующий фильтр и сухой фильтр для улавливания твердых частиц), CFP – korekcijski faktor pri minimalnem dovodnem tlaku (koalescentni filtri in filtri suhih delcev), CFP - Düzeltme Faktörü Minimum Giriş Basıncı (Birleştirme ve Kuru Partikül Filtreleri), CFP – Pressjoni Minima taž-Zbokk tad-Dhul ta' Fattur ta' Korrezjoni (Filtri Koalexenti u ta' Frak Xott), CFP - Factor de corec ie presiune de intrare minimă (Filtru de coalescen ă i de particule uscate), CFP - коригирац коэффициент, минимално входно налягане (коалесциращи филтри и сухи филтри за улавяне на частици)

| Minimum Inlet Pressure   | bar g | 1    | 2    | 3    | 4    | 5    | 6    | 7    | 8    | 9    | 10   | 11   | 12   | 13   | 14   | 15   | 16   | 17   | 18   | 19   | 20   |
|--------------------------|-------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|------|
|                          | psi g | 15   | 29   | 44   | 58   | 73   | 87   | 100  | 116  | 131  | 145  | 160  | 174  | 189  | 203  | 218  | 232  | 248  | 263  | 277  | 290  |
| <b>Correction Factor</b> |       | 2.65 | 1.87 | 1.53 | 1.32 | 1.18 | 1.08 | 1.00 | 0.94 | 0.88 | 0.84 | 0.80 | 0.76 | 0.73 | 0.71 | 0.68 | 0.66 | 0.64 | 0.62 | 0.61 | 0.59 |

**㉑ Gaminio atrankos ir korekcijos koeficientai**

Norint teisingai pasirinkti vandens separatoriaus arba filtro modelį, filtro debitas turi būti suderintas pagal mažiausią darbinį sistemos slėgį.

- 1 Gaukite mažiausią darbinį slėgį ir didžiausią suspausto oro debitą ties vandens separatoriaus arba filtro įleidimo anga.
- 2 Iš CFP lentelės pasirinkite pataisos koeficientą mažiausiam darbiniam slėgiui (jį visada suapvalinkite, pvz., esant 5,3 barų naudokite 5 barų pataisos koeficientą).
- 3 Apskaičiuokite mažiausią filtravimo talpą. Mažiausia filtravimo talpa = suspausto oro debitas x CFP
- 4 Naudodami mažiausią filtravimo talpą, pasirinkite vandens separatoriaus arba filtro modelį iš anksčiau pateiktų debito lentelių (pasirinkto vandens separatoriaus arba filtro debitas turi būti lygus arba didesnis nei mažiausia filtravimo talpa).

**㉒ Выбор изделия и поправочные коэффициенты**

Для правильного выбора модели водяного сепаратора или фильтра необходимо отрегулировать расход на фильтре при минимальном рабочем давлении в системе.

- 1 Определите минимальное рабочее давление и максимальный расход сжатого воздуха на входе водяного сепаратора или фильтра.
- 2 Выберите поправочный коэффициент для минимального входного давления из таблицы коэффициентов CFP (всегда округляйте значения, например для 5,3 бар используйте поправочный коэффициент для 5 бар).
- 3 Рассчитайте минимальную фильтрующую способность. Минимальная фильтрующая способность = расход сжатого воздуха x CFP
- 4 Используйте минимальную фильтрующую способность, выберите модель водяного сепаратора или фильтра из представленных выше таблиц расхода (выбранный водяной сепаратор или фильтр должен иметь расход, равный или больший минимальной фильтрующей способности).

**㉓ Dejavniki za izbiri izdelka in korekcijo**

Da bi pravilno izbrali model izločevalnika vode ali filtra, morate hitrost pretoka filtra nastaviti na minimalni delovni tlak sistema.

- 1 Ugotovite minimalni delovni tlak in maksimalno hitrost pretoka stisnjenega zraka pri vstopu izločevalnika vode ali filtra.
- 2 Izberite korekcijski faktor za minimalni delovni tlak iz tabele CFP (vedno zaokrožite navzdol, npr. pri 5,3 bara uporabite korekcijski faktor 5 barov)
- 3 Izračunajte minimalno kapaciteto filtriranja. Minimalna kapaciteta filtriranja = hitrost pretoka stisnjenega zraka x CFP
- 4 S pomočjo minimalne kapacitete filtriranja v zgornjih tabelah hitrosti pretokov izberite model izločevalnika vode ali filtra (izbrani izločevalnik vode ali filter mora imeti hitrost pretoka enako ali večjo kot minimalno kapaciteto filtriranja).

**㉔ Ürün Seçimi ve Düzeltme Faktörleri**

Su Ayrıştırıcısı ve Filtre modelinin doğru seçilebilmesi için filtrenin akış hızının, sistemin minimum çalışma basıncına göre ayarlanması gerekir.

- 1 Su Ayrıştırıcısı veya Filtre'nin girişindeki minimum çalışma basıncı ve maksimum sıkıştırılmış hava akış hız değerlerini öğrenin.
- 2 CFP tablosundan minimum çalışma basıncı için düzeltme faktörünü seçin (her zaman aşağıya yuvarlayın, 5,3 bar için 5 bar düzeltme faktörü gibi)
- 3 Minimum filtrasyon kapasitesini hesaplayın. Minimum Filtrasyon Kapasitesi = Sıkıştırılmış Hava Akış Hızı x CFP
- 4 Minimum filtrasyon kapasitesini kullanarak yukarıdaki akış hızı tablolarından bir Su Ayrıştırıcısı ve Filtre modeli seçin (Seçilen Su Ayrıştırıcısı veya Filtre'nin akış hızı, minimum filtrasyon kapasitesine eşit veya ondan daha fazla olmalıdır).

**㉕ Għażla tal-Prodott u Fatturi ta' Korrezjoni**

Bieħ tagħzel b' mod korrett Separatur tal-Ilma jew mudell ta' Filtru, ir-rata tal-fluss għandha tiġi aġġustata għall-pressjoni ta' thaddim minima tas-sistema.

- 1 Iksebi il-pressjoni ta' thaddim minima u r-rata tal-fluss tal-arja kkompessata massima fl-iżbokk tad-dhul tas-Separatur tal-Ilma jew Filtru.
- 2 Aghzel il-fattur ta' korrezjoni għal pressjoni tat-thaddim minima mit-tabella CFP (dejjem qarreb għal numru shiħ iżghar eż. għal 5.3 bar, uża fattur ta' korrezjoni ta' 5 bar)
- 3 Ikkalkula l-kapaċità tal-filtrazzjoni minima. Kapaċità tal-Filtrazzjoni Minima = Rata tal-Fluss tal-Arja Kkompessata x CFP
- 4 Billi tuża l-kapaċità tal-filtrazzjoni minima, aghzel Separatur tal-Ilma jew mudell ta' Filtru mit-tabelli tar-rata tal-fluss ta' hawn fuq (Separatur tal-Ilma jew Filtru magħżul għandu jkollu rata ta' fluss ugwali jew ikbar mill-kapaċità ta' filtrazzjoni minima).

**☞ Selectarea produsului i factori de corec ie**

Pentru a selecta corect un model de separator sau filtru de apă, debitul filtrului trebuie reglat la presiunea minimă de func ionare a sistemului.

- 1 Ob ine i presiunea minimă de func ionare i debitul maxim de aer comprimat la intrarea separatorului sau filtrului de apă.
- 2 Selecta i factorul de corec ie pentru presiunea minimă de func ionare din tabelul CFP (rotunjii i întotdeauna, de ex., pentru 5,3 bari, utiliza i factorul de corec ie 5 bari)
- 3 Calcula i capacitatea minimă de filtrare. Capacitatea minimă de filtrare = Debitul de aer comprimat x CFP
- 4 Utilizând capacitatea minimă de filtrare, selecta i un model de separator sau filtru de apă din tabelele pentru debit de mai sus (Separatorul sau filtrul de apă selectat trebuie să aibă un debit egal cu sau mai mare decât capacitatea minimă de filtrare).

**☞ Избор на продукт и коригиращи коефициенти**

За да се направи правилен избор на модел на воден сепаратор или филтър, дебитът на филтъра трябва да бъде съгласуван с минималното работно налягане на системата.

- 1 Проверете минималното работно налягане и максималния дебит на компресиран въздух на входа на водния сепаратор или филтъра.
- 2 Изберете коригиращ коефициент за минималното работно налягане от таблицата с CFP (винаги закръгляйте надолу, напр. за 5,3 bar използвайте коригиращ коефициент за 5 bar)
- 3 Изчислете минималния капацитет на филтрация. Минимален капацитет на филтрация = Дебит на компресиран въздух x CFP
- 4 Като използвате минималния капацитет на филтрация, изберете модел на воден сепаратор или филтър от таблиците за дебити по-горе (избраният воден сепаратор или филтър трябва да има дебит, равен на или по-голям от минималния капацитет на филтрация).


**Techniniai duomenys**

Технически данни, Tehnični podatki, Teknik Veriler, Dejta Teknika, Date tehnice, Технически данни

| Model | Filter Models |     |     |   |     |   |     |     | Min Operating Pressure |       | Max Operating Pressure |       | Min Recommended Operating Temp |    | Max Recommended Operating Temp |    |    |     |     |
|-------|---------------|-----|-----|---|-----|---|-----|-----|------------------------|-------|------------------------|-------|--------------------------------|----|--------------------------------|----|----|-----|-----|
|       |               |     |     |   |     |   |     |     | bar g                  | psi g | bar g                  | psi g | °C                             | °F | °C                             | °F |    |     |     |
| WS    | P010          | [ ] | [ ] | F | [ ] | - | 035 | [ ] | [ ]                    | F     | [ ]                    | 1     | 15                             | 16 | 232                            | 2  | 35 | 80  | 176 |
| AO    | P010          | [ ] | [ ] | F | [ ] | - | 035 | [ ] | [ ]                    | F     | [ ]                    | 1     | 15                             | 16 | 232                            | 2  | 35 | 80  | 176 |
| AO    | P010          | [ ] | [ ] | M | [ ] | - | 035 | [ ] | [ ]                    | M     | [ ]                    | 1     | 15                             | 20 | 290                            | 2  | 35 | 100 | 212 |
| AA    | P010          | [ ] | [ ] | F | [ ] | - | 035 | [ ] | [ ]                    | F     | [ ]                    | 1     | 15                             | 16 | 232                            | 2  | 35 | 80  | 176 |
| AA    | P010          | [ ] | [ ] | M | [ ] | - | 035 | [ ] | [ ]                    | M     | [ ]                    | 1     | 15                             | 20 | 290                            | 2  | 35 | 100 | 212 |
| ACS   | P010          | [ ] | [ ] | M | [ ] | - | 035 | [ ] | [ ]                    | M     | [ ]                    | 1     | 15                             | 20 | 290                            | 2  | 35 | 50  | 122 |

**Svoris ir matmenys**

Вес и габаритные размеры, Teža in mere, Ağırlıklar ve Boyutlar, Pizijiet u Dimensjonijiet, Greutăți și dimensiuni, Тегло и размери



| Model      | Pipe Size | Height (H) |       | Width (W) |      | Depth (D) |      | (a) |      | (b) |      | (c) |      | (d) |     | Weight |       |
|------------|-----------|------------|-------|-----------|------|-----------|------|-----|------|-----|------|-----|------|-----|-----|--------|-------|
|            |           | mm         | ins   | mm        | ins  | mm        | ins  | mm  | ins  | mm  | ins  | mm  | ins  | mm  | ins | kg     | lbs   |
| WS / P010A | ¼"        | 180        | 7.09  | 76        | 2.99 | 66        | 2.60 | 154 | 6.1  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 0.61   | 1.34  |
| WS / P010B | ⅜"        | 180        | 7.09  | 76        | 2.99 | 66        | 2.60 | 154 | 6.1  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 0.61   | 1.34  |
| WS / P010C | ½"        | 180        | 7.09  | 76        | 2.99 | 66        | 2.60 | 154 | 6.1  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 0.61   | 1.34  |
| WS / P015C | ½"        | 238.5      | 9.36  | 89        | 3.5  | 83.5      | 3.29 | 202 | 8.0  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 1.16   | 2.55  |
| P020C      | ½"        | 238.5      | 9.36  | 89        | 3.5  | 83.5      | 3.29 | 202 | 8.0  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 1.12   | 2.58  |
| WS / P020D | ¾"        | 238.5      | 9.36  | 89        | 3.5  | 83.5      | 3.29 | 202 | 8.0  | 50  | 1.97 | 32  | 1.3  | 38  | 1.5 | 1.12   | 2.58  |
| WS / P025D | ¾"        | 227        | 10.9  | 120       | 4.72 | 114.5     | 4.5  | 232 | 9.1  | 70  | 2.76 | 32  | 1.3  | 38  | 1.5 | 2.21   | 4.86  |
| WS / P025E | 1"        | 227        | 10.9  | 120       | 4.72 | 114.5     | 4.5  | 232 | 9.1  | 70  | 2.76 | 32  | 1.3  | 38  | 1.5 | 2.21   | 4.86  |
| WS / P030G | 1 ½"      | 367        | 14.45 | 120       | 4.72 | 114.5     | 4.5  | 323 | 12.7 | 70  | 2.76 | 32  | 1.3  | 38  | 1.5 | 2.68   | 5.91  |
| WS / P035G | 1 ½"      | 531        | 20.9  | 164       | 6.46 | 156       | 6.10 | 384 | 15.1 | 100 | 3.94 | 68  | 2.68 | 38  | 1.5 | 6.90   | 15.20 |
| WS / P040H | 2         | 623        | 24.5  | 164       | 6.46 | 156       | 6.10 | 476 | 18.7 | 100 | 3.94 | 68  | 2.68 | 38  | 1.5 | 7.30   | 16.10 |
| WS / P045I | 2 ½"      | 623        | 24.5  | 164       | 6.46 | 156       | 6.10 | 476 | 18.7 | 100 | 3.94 | 68  | 2.68 | 38  | 1.5 | 7.10   | 15.65 |
| WS / P050I | 2 ½"      | 745        | 29.3  | 192       | 7.56 | 183       | 7.20 | 587 | 23.1 | 120 | 4.72 | 68  | 2.68 | 38  | 1.5 | 10.30  | 22.71 |
| P055I      | 2 ½"      | 935        | 36.8  | 192       | 7.56 | 183       | 7.20 | 772 | 30.4 | 120 | 4.72 | 68  | 2.68 | 38  | 1.5 | 15.30  | 33.73 |
| WS / P055J | 3         | 935        | 36.8  | 192       | 7.56 | 183       | 7.20 | 772 | 30.4 | 120 | 4.72 | 68  | 2.68 | 38  | 1.5 | 15.30  | 33.73 |

Note: Water Separators do not include a DP Indicator, use dimension H + d for the total height.

**17 Montavimo rekomendacijos**

Rekomenduojama suspausta ora apdoroti prieš jam patekiant į skirstymo sistemą ir kritiniuose naudojimo taškuose / įrenginiuose.

Suspausto oro džiovinimus sumontavus drėgnose sistemose, džiūstant paskirstymo sistemai daugiau nesvarumų kaupiasi taškuose, kuriuose naudojami filtri. Šiuo laikotarpiu gali reikėti dažniau keisti filtravimo elementus.

Įrangoje, kurioje naudojami kompresoriai be alyvos, vis tiek yra vandens aerosolių ir dalelių, todėl joje reikia naudoti bendrosios paskirties didelio efektyvumo klasikų filtrus.

Bendrosios paskirties filtri visada turi būti įrengti siekiant apsaugoti didelio efektyvumo filtrus nuo skystų aerosolių ir kietųjų dalelių pagardinio kiekio poveikio.

Gryninimo įrangą sumontuokite ten, kur yra žemiausia teigiama temperatūra, geriausia – už galinių aušintuvų ir oro surinkimo rezervuarų.

Naudojimo gryninimo įrangos tašką reikia sumontuoti kuo arčiau įrenginio.

Gryninimo įrangos nereikėtų montuoti už greito atidarymo vožtuvų, ją reikia apsaugoti, kad nesusidarytų galima atbulinė srovė ar kiti hidrauliniai smūgiai.

Prieš montuodami išvalykite visus į gryninimo įrangą einančius vamzdžius, taip pat išvalykite visus vamzdžius, kai sumontuosite valymo įrangą, prieš prijungdami ją prie galutinio įrenginio.

Jei aplink gryninimo liniją įtaisytos apėjimo linijos, išitinkinkite, jog atitinkami filtri įtaisyti apėjimo linijoje tam, kad neužstotų už jų esanti sistemos dalis.

Prijunkite išleidimo linijas nuo sujungiamųjų filtrų tiesiai prie kondensato skyrklio. Jeigu nepažinote prijungti išleidimo linijų tiesiai prie skyrklio, linijos turi būti nukreiptos į kondensato kolektorius (atviro viename gale), tada į vieną kondensato skyrklio įvadą.

Pasirūpinkite įrangą, kuri išleidži surinktus skysčius iš gryninimo įrangos. Surinktus skysčius reikia tinkamai apdoroti ir išmesti.

**18 Рекомендации по установке**

Перед вводом в распределительную систему, а также в критических точках использования / подаче рекомендуется использовать скатый воздух.

Установка осушителей скатого воздуха во влажную систему может привести к дополнительному загрязнению фильтрующего элемента, которое накапливается в период высыхания системы. В этот период может потребоваться чаще менять фильтрующие элементы.

В установках, в которых используются безмасляные компрессоры, присутствуют водные аэрозоли и твердые частицы, следует использовать универсальные и высокоэффективные фильтры.

Для защиты высокоэффективного фильтра от масляных аэрозолей и твердых частиц следует обязательно установить универсальный фильтр.

Устанавливайте очистительное оборудование при низкой температуре, максимально приближенной, но не достигающей температуры замерзания, предпочтительно после добавочных охлаждающей и воздухогрейщиков.

Место установки очистительного оборудования должно находиться как можно ближе к подаводу.

Очистительное оборудование не должно устанавливаться после быстро открывающихся клапанов, а также должно быть защищено от возможного обратного потока или других условий, создающих ударную нагрузку.

Перед установкой очистите все трубопроводы, ведущие к очистительному оборудованию, а также все трубопроводы, отходящие от очистительного оборудования, до подключения последнего подавода.

Если вокруг очистительного оборудования проложен обводной трубопровод, убедитесь, что к обводному трубопроводу подключена соответствующая фильтрующая система, чтобы предотвратить загрязнение основного потока системы.

Подсоединяйте дренажные трубопроводы из коалесцентных фильтров непосредственно к сепаратору конденсата. Если невозможно подсоединить дренажные трубопроводы непосредственно к сепаратору, необходимо вывести эти трубопроводы в коллектор конденсата (вентилируемый с одной стороны), а затем в один вход сепаратора конденсата.

Установите средства для дренажа жидкостей из очистительного оборудования. Собранные жидкости должны быть утилизированы в соответствии с указанными требованиями.

**19 Priporočila za namestitve**

Stisnjeni zrak je priporočljivo obdelati še pred vstopom v distribucijski sistem in ob odločilnih točkah uporabe.

Namestitev sušilnikov stisnjeneга zraka na moker sistem lahko povzroči dodatno nalaganje umazanije v filtrir med obdobjem sušenja distribucijskega sistema. Med tem obdobjem bo morda potrebna pogostejša menjava filtrirnih elementov.

Pri namestitvah, kjer so v uporabi kompresorji brez olja in kjer so še vedno prisotni vodni in trdni delci, je treba uporabljati običajne in visokoeffektivne enote.

Za zaščito visokoeffektivnega filtra pred veliko količino vodnih in trdnih delcev mora biti vedno nameščen običajni filter.

Namestite čistilno opremo pri najnižji temperaturi nad zmrziščem, po možnosti za hladilniki polnilnega zraka in sprejemniki zraka.

Čistilna oprema naj bo nameščena kolikor je mogoče blizu mesta uporabe.

Čistilna oprema naj ne bo nameščena za zapornimi ventili in naj bo zaščiten pred morebitnim nasprotnim tokom ali ostalimi neobičajnimi situacijami.

Pred namestitvijo očistite vse cevi, ki vodijo do čistilne opreme, po namestitvi čistilne opreme in pred priključitvijo na zaključeni sistem pa očistite vse cevi.

Če so blizu čistilne opreme predvideni odvodi, zagotovite ustrezno filtriranje teh cevi, da ne pride do kontaminacije priključnega sistema.

Odtocne vode iz različnih filtrov priključite neposredno na ločevalnik kondenzata. Če odtocnih vodov ni možno napeljati neposredno v ločevalnik, je treba te vode napeljati v razdelilnik kondenzata (izliv na enem koncu voda) in zatem na posamezni dotok na ločevalniku kondenzata. Zagotovite način za odvajanje zbrane tekočine iz čistilne opreme. Zbrano tekočino je treba ravhati in jo odstraniti predamo in odgovorno.

**20 Kurulum tavsiyeleri**

Sıkıştırılmış havanın dağıtım sistemine girmeden önce ve kritik kullanim noktalarında / uygulamalarda işlemden geçirilmesi tavsiye edilir.

Onceden yag olan bir sisteme sıkıştırılmış hava kurutulularının kurulması, dağıtım sistemi kurulum noktası işlemlerine fazladan kir yüklenmesine yol açabilir. Bu süre içinde filtre öğelerinin daha sık değiştirilmesi gerekebilir.

Yağsız kompresörlerin kullandığı kurulumlarda, su spreyi ve zerrecikler yine mevcuttur, bu durumlarda da genel amaçlı ve yüksek etkinlik düzeylerini kullanılmaldır.

Yüksek etkinlikli filtreyi hacimli sıvı spreylelerden ve katı zerreciklerden korumak için her zaman genel amaçlı bir filtre takılmaldır.

Arıdırma ekipmanının donma noktasının üstündeki en düşük ısıda ve tercihen son soğutuluların ve hava depolama aşağı akım tarafına kurun.

Kullanma noktası arıdırma ekipmanı, uygulamanın mümkün olduğu kadar yakınına kurulmalıdır.

Arıdırma ekipmanı, çabuk açma valflerinin aşağı akım tarafına kurulmamalı ve ters akım olasılığına ve başka çok koşullarına karşı korunmalıdır.

Arıdırma ekipmanına giden tüm boruları kurulumdan önce, bütün boruları da arıdırma ekipmanı kurulduktan sonra ve son uygulamaya bağlamadan önce arıdırın.

Arıdırma ekipmanının çevresine by-pass hatları takılmırsa, sistemin aşağı akımında kirlenmeyi önlemek için by-pass hattına yeterli filtre donanımının takılması sağlayın.

Birleşime filtrelerinden gelen süzürme hatlarını doğrudan yoğunlaşma separatörüne tekni. Süzürme hatlarını doğrudan separatöre bağlamak mümkün değilse, hatları yoğunlaşma manifolduna salınmalı (bir uçtan salınır), ardından da yoğunlaşma separatörünün tek bir girişine salınmalıdır.

Biriken sıvıları arıdırma ekipmanından süzürcecek bir tertibat olmasını sağlayın. Biriken sıvıları sorumlu bir şekilde işlemler ve atılmaldır.

**21 Rakkomandazzjonijiet għall-Installazzjoni**

Nirakkomandaw li l-arja kompressata tiġi trattata qabel ma tidhol fis-sistema ta' distribuzzjoni kif ukoll fi-punt / l-applikazzjonijiet kritiċi ta' l-użu.

L-installazzjoni ta' tagħmir li jnixxi l-arja kompressata fuq sistema li kienet imxarba jista' jirriżulta f'aktar tagħbija ta' hmiġ għall-filtri li jintużaw f'punt wieħed, għall-perjodu sakemm is-sistema ta' distribuzzjoni tinfez. L-elementi tal-filtri jista' jkollhom bżonn li jribdlu aktar spiss matul dan il-perjodu.

Għall-installazzjonijiet fejn jintużaw kumpressuri mingħajr żejg, xorta jkun hemm preżenti ajrosols u partikli ta' l-ilma, għalhekk xorta għandhom jintużaw građi bi skop ġenerali u b'effiċjenza kbira. Filtru għal skopijiet ġenerali għandu dejjem iġi installat biex jiproteġi l-filtru ta' effiċjenza kbira mill-volum kbir ta' ajrosols likwidi u partikli solidi.

Installa tagħmir ta' purifikazzjoni fl-aktar temperatura baxxa possibbli imma b'mod li ma jkunx hemm iffirzar, preferibbilment aktar i s'isel milli-aftercoolers u mir-ricivitur ta' l-arja.

Tagħmir tal-purifikazzjoni fil-punt ta' l-użu għandu jiġi installat kemm jista' jkun qrib tal-post fejn għandu jappjika.

It-tagħmir ta' purifikazzjoni m'għandux iġi installat aktar i s'isel milli-valve li jiġth malajr u għandu jkun proteti minn possibbiltà ta' fluss bl'ura jew kundizzjonijiet oħra stressanti.

Naddaf il-pajps kollha li jwasslu għal-tagħmir ta' purifikazzjoni qabel tinstalla u l-pajps kollha wara li tinstalla l-tagħmir ta' purifikazzjoni u qabel ma tqabbad ma l-applikazzjoni finali.

Jekk tiffittja linji ta' by-pass madwar it-tagħmir ta' purifikazzjoni, kun żgur li hemm biżżejjed filtrazzjoni fittjata mal-linja tal-by-pass b'iek ma thallix li jkun hemm kontaminazzjoni tas-sistema aktar i s'isel.

Waħhal il-linji tad-drejn mill-filtri koalescenti direttament mas-separatur tal-kondensat. Mhuxwix possibbli li tqabbad il-linji tad-drejn direttament mal-separatur, il-linji għandu jkollhom vent għall-manifold tal-kondensat (b'vent minn naha waħda) u mbagħad għal gewwa zbokk wahdieni ta' separatur tal-kondensat.

Iprovdi faċilità biex tiddejnja l-likwidi li jingabru mit-tagħmir tal-purifikazzjoni. Il-likwidi li jingabru għandhom jiġu trattati u mormija b'mod responsabbli.

**22 Recomandări de instalare**

Se recomandă ca aerul comprimat să fie tratat anterior pătrunderii în sistemul de distribuție și, de asemenea, în punctele de utilizare/aplicație critice.

Instalarea uscătoarelor cu aer comprimat pe un sistem de tip umed anterior poate avea ca rezultat acumularea suplimentară, pentru o perioadă, de impurități în filtrele de la punctele de utilizare. În timpul uscării sistemului de distribuție. Este posibil ca, pe durata acestei perioade, să fie necesară înlocuirea mai frecventă a elementelor filtrului.

La instalații unde se utilizează compresoare fără ulei, aerosolii de apă și macroparticulele sunt în continuare prezente, deci este necesară utilizarea în continuare a filtrelor de uz general și a celor cu grade de eficiență ridicată.

Un filtru de uz general trebuie instalat întotdeauna, pentru a proteja filtrul de eficiență ridicată de aerosolii lichizi în cantități mari și de macroparticulele solide.

Instalați echipamentul de purificare la cea mai redusă temperatură deasupra punctului de îngheț, preferabil în aval de răcitoarele secundare și de recipientele de aer.

Echipamentul de purificare de la punctul de utilizare trebuie instalat cât mai aproape de aplicația propriei-zisă.

Echipamentul de purificare nu trebuie instalat în aval de supapele cu deschidere rapidă și trebuie protejat de posibili contracurenți sau de alți factori de soc.

Purjați toate conductele care duc spre echipamentul de purificare înainte de instalare și toate conductele după instalarea echipamentului de purificare și înainte de conectarea la aplicația finală.

Dacă sunt montate conducte de trecere în jurul echipamentului de purificare, verificați să fie montate sisteme adecvate de filtrare la conducta de trecere, pentru a preveni contaminarea sistemului în aval.

Montați conducte de recuperare de la filtrele de coalescență direct la un separator de condens. Dacă nu este posibilă cuplarea directă a conductelor de recuperare la un separator, conductele trebuie ventilate la un colector de condens (ventilat la un capăt), apoi la o singură intrare a unui separator de condens.

Furtați o instalație care să elimine, prin drenare, lichidele colectate din echipamentul de purificare. Lichidele colectate trebuie tratate și evacuate într-o manieră responsabilă.

**23 Препоръки за инсталацията**

Препоръчително е компресиранят въздух да се обработва преди влизането в системата за разпределение, а също така в точки/приложения с изключително значение.

Инсталирането на сушители за компресиран въздух към намокрена система може да доведе до натрупване на допълнително замърсяване при използването на филтрите за определен период, докато системата за разпределение изсъхва. Елементите на филтъра може да се нуждаят от смяна по-често по време на този период.

За инсталации, където се използват безмаслени компресори, а водни аерозоли и частици все още са налични, все още трябва да се използват високоэффективни разредки, както и разредки с общо предназначение.

Филтърът с общо предназначение трябва винаги да е се инсталира, за да предпази високоэффективния филтър от обемни аерозоли и твърди частици.

Инсталирайте пречистващо оборудване при най-ниската температура над точката на замръзване, за предпочитане крайните допълнителни охладители и въздухприемници.

Точката на използване на пречистващо оборудване трябва да се инсталира възможно най-близо до уреда.



Пречистващото оборудване не трябва да се инсталира в края на бързо отварящи се клапани и трябва да се предпази от възможен обратен поток или други ударни условия.

Продухайте всички тръби, водещи към пречистващото оборудване, преди инсталацията, както и всички тръби след инсталацията на пречистващото оборудване и преди свързването на крайния уред.

Ако байпасната тръба е поставена около пречистващото оборудване, се уверете, че към байпасната тръба е нагласено подходящо филтриране, което да предотврати замърсяване нататък по системата.

Поставете отточни тръби от съединителните филтри директно към сепаратор на кондензат. Ако не е възможно директно свързване на отточни тръби към сепаратор, тръбите трябва да се оттичат към един колектор на кондензат (отворен от единия край) и след това в един вход на сепаратор на кондензат.

Осигурете условия за отичане на натрупаните флуиди от пречистващото оборудване. Натрупаните флуиди трябва да се обработват и изхвърлят по подходящия начин.



(LT) Apatinė uždarymo plokštė gali judėti, kai filtrė nėra slėgio



Apatinei uždarymo plokštei nereikia techninės priežiūros ir jos niekada nereikia nuimti.

(RU)

Если в фильтре отсутствует давление, нижняя пластина корпуса может перемещаться.



Нижняя пластина корпуса не подлежит обслуживанию и ее демонтаж не предусмотрен.

(SL)

Če filter ni pod tlakom, se lahko spodnja zapiralna plošča premika.



Spodnje zapiralne plošče ni možno popravljati in je nikoli ne odstranjujte.

(TR)

Alttaki kapatma plakası, filtreye basınç uygulanmadığında hareket edebilir



Altteki kapatma plakası servis hizmeti verilen öğelerden değildir ve asla çıkarılmamalıdır.

(MT)

Il-plakka tal-għeluq t'isfel tista' timxi meta l-filtru ma jkunx taħt pressjoni



Il-plakka tal-għeluq t'isfel hija oġġett li ma jistax isirliu servis u qatt ma għandu jitneħħa.

(RO)

Placa inferioară de acoperire se poate deplasa atunci când filtrul nu este presurizat



Placa inferioară de acoperire este un element care nu poate fi remediat în service și care nu trebuie demontat.

(BG)

Долната затваряща пластина може да помръдне, когато филтърът не е под налягане.



Долната затваряща пластина не може да се обслужва и не трябва никога да се сваля.

**LT** Paleidimas ir naudojimas



Prieš nukreipdami slėgį į filtrą įsitinkite, kad galvutė ir indas yra gerai pritvirtinti, o fiksavimo detalės tinkamai sulygiuotos, kaip parodyta techninės priežiūros skyriuje (6 techninės priežiūros procedūra) šiame vadove.

1. Lėtai atidarydami įleidimo vožtuvą palaipsniui didinkite slėgį įrenginyje.
2. Lėtai atidarydami išleidimo vožtuvą, iš naujo sudarykite slėgį už jo esančiame vamzdyje.

Negalima staigiai atidaryti įleidimo ar išleidimo vožtuvų, paveikti įrenginio pernelyg dideliu diferencialiniu slėgiu, nes galima sugadinti įrangą.

**RU** Запуск и эксплуатация



Перед созданием давления в фильтре убедитесь, что стакан и головка фильтра правильно установлены и фиксатор правильно выровнен, как показано в разделе технического обслуживания данного руководства (процедура технического обслуживания 6).

1. Впускной клапан следует открывать плавно, чтобы постепенно создать давление в устройстве.
2. Плавно откройте выпускной клапан, чтобы создать давление в системе трубопровода.

Запрещено резко открывать впускной или выпускной клапаны, а также используемое устройство, так как это может привести к перепаду давления и повреждениям.

**SL** Zagon in uporaba



Pred obremenitvijo filtra s tlakom zagotovite, da sta glava in posoda filtra pravilno nameščeni in da sta označbi na glavi in posodi filtra ustrezno poravnani druga z drugo, kot je prikazano v poglavju o vzdrževanju v tem priročniku (postopek vzdrževanja – korak 6).

1. Počasi odprite dovodni ventil, da enoto postopoma obremenite s tlakom.
2. Počasi odprite odvodni ventil za ponovno tlačno obremenitev cevodova za tem ventilom.

Dovodnih ali odvodnih ventilov nikoli ne odpirajte naglo in enote ne izpostavljajte prekomernim nihanjem tlaka, saj lahko to povzroči škodo.

**TR** Çalıştırma ve İşletme



Filtreye basınç uygulamadan önce, başın ve haznenin düzgün bir şekilde takıldığından ve kilitleme tertibatının, bu kılavuzun bakım bölümünde (bakım prosedürü 6) gösterildiği gibi, düzgün bir şekilde hizalandığından emin olun.

1. Giriş valfini yavaşça açıp üniteye yavaş yavaş basınç uygulayın.
2. Aşağı akım borularına yeniden basınç uygulamak için çıkış valfini yavaşça açın.

Giriş ve çıkış valflerini hızla açmayın veya üniteyi aşırı basınç farklarına maruz bırakmayın; aksi halde hasar oluşabilir.

**MT** Kif Tixghel u Kif Thaddem



Gabel tiffa' pressjoni fuq il-filtru, aghmel żgur li r-ras u l-bowl huma mwahhlin b'mod korrett u li d-dettall tas-sokor huwa allinjat kif jixraq kif muri fis-sezzjoni tal-manutenzjoni (proċedura ta' manutenzjoni 6) ta' dan il-manwal.

1. Iftah il-valv tad-dhul bil-mod, biex iżjed gradwalment il-pressjoni fil-unità.
2. Iftah il-valv tal-hruġ bil-mod biex terġa' tibni l-pressjoni fil-pajps li jwasslu 'l isfel. Ara li ma tifтах il-valvs tad-dhul jew tal-hruġ f'daqqa jew b'xi mod tikkawża differenza eċċessiva fil-pressjoni tat-tagħmir għax tista' tagħmel il-hsara.

**RO** Pornire și operare



Înainte de presurizarea filtrului, asigurați-vă că paharul și capul filtrului sunt corect montate și că detaliul de fixare este corect aliniat, așa cum se arată în secțiunea de întreținere (procedura de întreținere 6) a acestui manual.

1. Deschideți încet supapa de admisie, pentru a presuriza gradat aparatul.
2. Deschideți încet supapa de evacuare pentru a represariza sistemul de conducte din aval.

Nu deschideți rapid supapele de admisie sau de evacuare și nu supuneți aparatul la o diferență excesivă de presiune; în caz contrar, aparatul poate suferi deteriorări.

**BG** Начало и работа



Преди херметизиране на филтъра се уверете, че главата и чашката са монтирани правилно и заключващият детайл е подходящо подравнен, както е показано в раздела за поддръжка (процедура по поддръжка 6) на това ръководство.

1. Отворете бавно входния вентил, за да пуснете постепенно налягане на уреда.
2. Отворете бавно изходния вентил, за да премахнете налягането по протежението на тръбите.

Не отваряйте входния или изходния вентил бързо и не подлагайте уреда на голяма разлика в налягането, тъй като това може да доведе до повреда.

Priedai / atsarginės dalys (techninės priežiūros komplektai)  
Принадлежности / запасные части (ремонтные комплекты), Dodatna oprema / nadomestni deli (servisni kompleti), Aksesuarlar / Yedek Parçalar (Servis Kitleri),  
Accesorii / Lista tal-Parts (Settjiet tas-Servis), Accesorii / Pieze de schimb (Truse de service), Принадлежности / резервные части (сервисные комплекты)

| Filter Models | Catalogue Number | Contents |
|---------------|------------------|----------|
| 010           | TRK1-2           |          |
| 015 - 020     | TRK2-2           |          |
| 025 - 030     | TRK3-2           |          |
| 035 - 045     | TRK4-2           |          |
| 050 - 055     | TRK5-2           |          |
| 010           | MBK1-1           |          |
| 015 - 020     | MBK2-1           |          |
| 025 - 030     | MBK3-1           |          |
| 035 - 045     | MBK4-1           |          |
| 050 - 055     | MBK5-1           |          |
| 010           | MBK1-2           |          |
| 015 - 020     | MBK2-2           |          |
| 025 - 030     | MBK3-2           |          |
| 035 - 045     | MBK4-2           |          |
| 050 - 055     | MBK5-2           |          |
| 010 - 055     | EM1              |          |
| 010 - 055     | PD15NO           |          |
| 010 - 030     | DPI-K            |          |
| 035 - 055     | ZD90GL           |          |

**Techninė priežiūra**

**Техническое обслуживание, Vzdrževanje, Bakım, Manutenzjoni, İntreținere, Поддръжка**

**(IT) Techninės priežiūros intervalai**

Norint užtikrinti optimalias filtro charakteristikas AO, AA tipo elementus reikia keisti kas 12 mėnesių kartu su automatinio išleidimo čiupu.

Elemento ACS veikimas paremtas didžiausia alyvos garų leidimo koncentracija 0,018 mg/m<sup>3</sup>. Pakeiskite anglies filtro elementą aptikę garų, keistą kvapą arba skonį.

Kitaip nei alyvos aerosolių šalinimo filtrai, kurie keičiami kasmet siekiant užtikrinti suspausto oro kokybę, alyvos garų šalinimo filtro tarnavimo laikas priklauso nuo įvairių veiksnių ir jį reikia daug dažniau keisti (nebent naudojamas OVR, kurio tarnavimo laikas apskaičiuotas 6000 valandų).

**Veiksniai, darantys poveikį adsorbicijos filtrų tarnavimo laikui**

**Alyvos garų koncentracija**

Kuo didesnė alyvos garų leidimo koncentracija, tuo greičiau baigsis aktyvuotosios anglies talpa.

**Karterio alyva**

Adsorbicijos filtrai skirti pašalinti alyvos garus ir kvapus, o ne suskystintą alyvą ar aerosolius. Dėl blogai prižiūrinčių filtrų arba apskritai neuzdėtų išankstinių filtrų OVR filtrai taip greitai pasibaigia.

**Temperatūra**

Alyvos garų kiekis didėja eksponentiškai pagal leidimo temperatūrą, taip sutrumpindamas elemento tarnavimo laiką. Be to, didėjant temperatūrai, mažėja adsorbicijos galia, ir elemento tarnavimo laikas taip pat trumpėja.

**Santykinis drėgnumas arba rasos taškas**

Drėgnas oras sumažina adsorbicines anglies savybes.

**Kompresoriaus alyvos pokyčiai**

Pakeitus kompresoriaus alyvą, naujas tepalas išdegina „lengvąją frakciją“, todėl po to alyvos garų kiekis padidėja valandoms ar net savaitėms. Šį padidėjusį alyvos garų kiekį adsorbuoja OVR filtrai, žymiai sumažinant adsorbicinį tarnavimo laiką.

**(RU) Интервалы технического обслуживания**

Для обеспечения оптимальной эффективности фильтра требуется менять элементы классов AO, AA каждые 12 месяцев вместе с автоматическим дренажным устройством.

Эффективность элемента ACS рассчитана на максимальную концентрацию входящих паров масла, не превышающую 0,018 мг/м<sup>3</sup>. При обнаружении испарений или запаха заменить угольный элемент фильтра.

В отличие от масляных аэрозольных фильтров, которые подлежат ежегодной замене в целях обеспечения чистоты воздухом надлежащего качества, срок службы фильтров масляных паров зависит от различных факторов, и требует более частой замены (если только не используется OVR, срок службы которого 6 000 часов).

**Факторы, влияющие на продолжительность срока службы адсорбционных фильтров:**

**Концентрация паров масла**

Чем выше концентрация паров масла на входе, тем быстрее произойдет насыщение парами активированного угля.

**Масло в емкостях.**

Адсорбционные фильтры предназначены для поглощения паров масла и запахов, а не жидкой нефти или аэрозолей. Плохо выполняющаяся предварительная фильтрация или ее отсутствие приводит к быстрому ухудшению свойств фильтра OVR.

**Температура**

Содержание паров масла увеличивается в экспоненциальной зависимости от температуры на входе, что сокращает срок службы элемента. Кроме того, при увеличении температуры способность элемента к адсорбции уменьшается, что также сокращает срок службы элемента.

**Относительная влажность или точка росы**

Влажный воздух ухудшает способность углерода к адсорбции.

**Замена масла в компрессоре**

При замене компрессорного масла, в новом масле происходит сжигание легких углеводородов, что приводит к увеличению содержания паров масла на несколько часов или даже недель. Эти пары поглощаются фильтром OVR, что значительно сокращает его срок службы.

**(SL) Intervali vzdrževanja**

Da bi zagotovili optimalno delovanje filtra, je treba elemente razredov AO, AA zamenjati vsajih 12 mesecev, skupaj z avtomatskim izpuščem.

Zmogljivost elementa ACS temelji na največji koncentraciji naftnih hlapov na dovodu 0,018mg/m<sup>3</sup>. Ko zaznate hlap, vonj ali okus, zamenjajte filtrirni element z ogljem.

Za razliko od filtrov za odstranjevanje naftnih aerosolov, ki se jih za zagotavljanje kakovost stisnjeneга zamenjuje enkrat letno, je življenjska doba filtra za odstranjevanje hlapov odvisna od različnih dejavnikov in zahtevajo bolj pogoste zamenjave (razen, če se uporablja OVR, z zasnovano trajnostjo 6000 ur).

**Dejavniki, ki vplivajo na življenjsko dobo adsorbcijskih filtrov**

**Koncentracija oljnih hlapov**

Večja kot je koncentracija oljnih hlapov na vstopu, hitreje bo sposobnost aktivnega oglja zasenena.

**Tekoče olje**

Adsorbcijski filtri so namenjeni odstranjevanju oljnih hlapov in vonjav, ne tekočega olja ali aerosolov. Slabo vzdrževano predhodno filtriranje ali brez le-tega bo povzročilo hitro iztrošenje zmogljivosti OVR filtra.

**Temperatura**

Vsebnost oljnih hlapov narašča eksponentno glede na vstopno temperaturo, s tem se življenjska doba elementa skrajša. Poleg tega se z naraščanjem temperature zmanjšuje sposobnost adsorbpcije, ravno tako tudi življenjska doba elementa.

**Relativna vlažnost ali rosišče**

Vlažnost zraka zmanjšuje adsorbcijsko sposobnost oglja.

**Menjave kompresorskega olja**

Ko se kompresorsko olje zamenja, novo mazivo izloči "lahke frakcije", kar za več ur ali celo tednov poveča vsebnost oljnih hlapov. To vedno količino oljnih hlapov adsorbira OVR filter, s tem pa se bistveno skrajša njegova življenjska doba.

**(TR) Bakım Araklıkları**

En iyi performansı sağlamak için AO, AA, düzey öğelerin otomatik süzdürme tertibatı ile birlikte her 12 ayda bir değiştirilmesi gerekir.

ACS öğesinin performansı, 0.018mg/m<sup>3</sup> maksimum yağ buharı girişi konsantrasyonuna dayanır. Buhar, koku veya tat saptandığında karbon filtre öğesini değiştirin.

Yağ buharı giderme filtresinin kullanım süresi, basınçlı hava kalitesini garanti etmek için her yıl değiştirilen yağ aerosolü giderme filtrelerinden farklı olarak, çeşitli faktörlere bağlanabilir ve daha sık değiştirilmeleri gerekebilir (6000 saatlik ömür için boyutlandırılmış OVR kullanılmadığı sürece).

**Emiş filtrelerinin kullanım süresini etkileyen faktörler**

**Yağ buharı konsantrasyonu**

Yağ buharının girişi konsantrasyonu arttıkça, aktif karbon kapasitesi daha hızlı biçimde tükenir.

**Yağ kütlesi**

Emiş filtreleri, sıvı yağ veya aerosoller değil, yağ buharını ve kokuları gidermek için tasarlanmıştır. Yeterli bakım yapılmayan veya mevcut olmayan ön filtrasyon, OVR filtre kapasitesinin hızlı biçimde tükenmesine neden olur.

**Sıcaklık**

Yağ buharı içeriği, giriş sıcaklığına göre kattanarak artar ve öğenin ömrünü kısaltır. Ayrıca, sıcaklık arttıkça emilim kapasitesi düşer ve yine öğenin ömrünü kısaltır.

**Nispi Nem veya Çiylenme Noktası**

Yağ hava, karbonun emilim kapasitesini düşürür.

**Kompresör yağ değişimleri**

Kompresör yağ değiştirildiğinde, yeni yağ/ajantı "hafif uçları" yakar; bu da sonraki saatler, hatta haftalar boyunca yağ buharı içeriğini artırır. Yağ buharı içeriğindeki bu artış, OVR filtresi tarafından emilecek, emiş ömrünü önemli ölçüde kısaltır.

**(IT) Intervalli tal-Manutenzjoni**

Bixx tizgura l-aqwa prestazzjoni tal-filtru, l-elementi ta' grad AO, AA jehtieju tibdil kull 12-il xahar filimkien mad-drejn awtomatiku.

Il-prestazzjoni tal-element ACS hija bbażata fuq koncentrazzjoni massima tal-izbokk tal-fwar taż-żejt ta' 0.018mg/m<sup>3</sup>. Ibdel l-element tal-filtru tal-faham wara l-kxf ta' fwar, rħa jew toghma.

B'differenza mill-filtri ta' tnehħija tal-aerosol taż-żejt li jinbidlu kull sena bixx tiġi ggarantita l-kwalità tal-arja kkompressata, il-hajja ta' filtru ta' tnehħija taż-żejt tista' tiġi attribwita għal diversi fatturi u jista' jkun hemm b'żonn li l-filtri jinbidlu aktar ta' spiss (sakemm ma jintuzax OVR li huwa maħsub għal hajja ta' 6000 siegħa).

**Fatturi li jaffettwaw l-ghomr tal-filtri ta' assorbiment**

**Koncentrazzjoni ta' fwar taż-żejt**

Aktar ma l-koncentrazzjoni tal-izbokk tal-fwar taż-żejt tkun ogħla, aktar il-kapaċità ta' karbonju attiv tiskadi malajr.

**Żejt tal-bulk**

Filtri ta' assorbiment huma maħsubin bixx inehħu fwar taż-żejt u l-irwejjah, żejt mhux likwidu jew aerosols. Filtrazzjoni minn qabel miżmuma ħażin jew meżżenit tkkawza l-kapaċità tal-filtru tal-OVR bixx tiskadi malajr.

**Temperatura**

Il-kontenut tal-fwar taż-żejt ijjedid b'mod esponenzjali skont temperatura tal-izbokk tad-dħu, u jnaqqas il-hajja tal-element. Barra minn hekk, hekk kif tiżdied it-temperatura, il-kapaċità ta' assorbiment tonqos, u għal darb'ohra tnaqqas il-hajja tal-element.

**Umdità jew Punt tan-nida**

L-arja niedja tnaqqas il-kapaċità adsorbivta tal-faham.

**Tibdil taż-żejt tal-kompressur**

Meta jinbidel iż-żejt tal-kompressur, il-lubrikant il-ġdid jħraġq it-truf irraq li jżidu l-kontenut tal-fwar taż-żejt għal sığħat jew saħansitra għal ġimghat wara. Din iż-żieda fil-kontenut tal-fwar taż-żejt hija adsorbivta mill-filtru OVR, u tnaqqas b'mod sinifikanti l-hajja adsorbivta tiegħu.

**(RO) Intervale de întreținere**

Pentru a asigura performanțe optime ale filtrului, elementele de grad AO, AA necesită înlocuire la fiecare 12 luni, alături de evacuarea automată.

Performanța elementului ACS se bazează pe o concentrație maximă a vaporilor de ulei care intră de 0,018mg/m<sup>3</sup>. Înlocuiriți elementul filtrului de carbon la detectarea de vapori, miros sau gust.

Spre deosebire de filtrele de îndepărtare a vaporilor de ulei, care sunt modificate anual pentru a garanta calitatea aerului comprimat, durata de viață a unui filtru de îndepărtare a vaporilor de ulei poate fi atribuită mai multor factori? Necesită schimbări mai frecvente (cu excepția cazului în care OVR este folosit, acesta fiind dimensionat pentru 6000 ore de funcționare).

**Factori care influențează durata de viață a filtrelor de adsorbție**

**Concentrația vaporilor de ulei**

Cu cât concentrația de intrare a vaporilor de ulei este mai mare, cu atât mai repede va expira capacitatea carbonului activ.

**Ulei la vrac**

Filtrele de adsorbție sunt concepute pentru a îndepărta vaporii de ulei și mirosurile, nu uleiul lichid sau vaporii. Un filtru rău întreținut sau absent?ia unei prefiltrări va determina expirarea rapidă a capacității filtrului OVR.

**Temperatură**

Conținutul de vapori de ulei crește exponențial la temperatura de intrare, reducând durata de viață a elementului. În plus, odată cu creșterea temperaturii, capacitate de adsorbție scade, reducând din nou durata de viață a elementului.

**Umiditatea relativă sau punctul de rouă**

Aerul umed reduce capacitatea de adsorbție a carbonului.

**Schimbări ale uleiului de compresor**

La schimbarea uleiului de compresor, noul lubrifant arde "capetele uoare", care măresc conținutul de vapori de ulei timp de câteva ore sau chiar săptămâni după aceea. Această creștere a conținutului de vapori de ulei este adsorbivta prin filtrul OVR, reducând în mod semnificativ durata adsorbției.

**LT 1 techninės priežiūros procedūra**

Lėtai uždarykite įleidimo (1) ir išleidimo (2) vožtuvus ir išleiskite slėgį iš filtro (3) per išleidimo angą.

**RU Процедура технического обслуживания 1**

Медленно закройте впускной (1) и выпускной (2) клапаны и сбросьте давление в фильтре (3) с помощью дренажа.

**SL Postopek vzdrževanja – korak 1**

Počasi zaprite dotočni (1) in odtočni (2) ventili in iz filtra (3) prek odtoka izpustite ves tlak.

**TR Bakım Prosedürü 1**

Giriş (1) ve çıkış (2) valflerini yavaşça kapatın ve süzdürme tertibatını kullanarak filtredeki (3) basıncı boşaltın.

**MT Procedura ta' Manutenzjoni 1**


Aghlaq bil-mod il-valvi tal-iżbakk tad-dfuol (1) u tal-hruġ (2) u neħhi l-pressjoni tal-filtru (3) billi tuża d-drejn.

**RO Procedură de întreținere 1**

Închideți încet supapa de admisie (1) și de evacuare (2) și depresurizați filtrul (3) utilizând evacuarea.

**BS Процедура по поддръжка 1**

Бавно затворете входния (1) и изходния (2) вентил и изпуснете налягането от филтъра (3) с помощта на дренажа.



**LT 2 techninės priežiūros procedūra**

Atsukite filtro indą (1 ir 2) ir išimkite panaudotą elementą (3)

**RU Процедура технического обслуживания 2**

Открутите стакан фильтра (1 и 2) и снимите использованный элемент (3)

**SL Postopek vzdrževanja – korak 2**

Odvijte posodo filtra (1 in 2) in odstranite uporabljeni element (3).

**TR Bakım Prosedürü 2**

Filtre haznesini (1 ve 2) gevşetin ve kullanılan öğeyi (3) çıkarın

**MT Procedura ta' Manutenzjoni 2**


Halli il-bowl tal-filtru (1 u 2) u neħhi l-element uzat (3)

**RO Procedură de întreținere 2**

Deșurubați paharul filtrului (1 și 2) și demontați elementul uzat (3)

**BS Процедура по поддръжка 2**

Развийте филтърната чашка (1 и 2) и сваляте използвания елемент (3)



**LT 3 techninės priežiūros procedūra**

Atsukite automatinio išleidimo čiurpą (1) ir išmeskite (2). Įstatykite naują išleidimo čiurpą (3) ir priveržkite (4).

**RU Процедура технического обслуживания 3**

Открутите автоматический дренаж (1) и утилизируйте его (2). Установите новый дренаж (3) и затяните его (4).

**SL Postopek vzdrževanja – korak 3**

Odvijte samodejni odtok (1) in ga zavržite (2). Namestite nov samodejni odtok (3) in ga privijte (4).

**TR Bakım Prosedürü 3**

Otomatik süzme tertibatını gevşetin (1) ve atın (2). Yeni süzdürme tertibatını takın (3) ve sıkın (4).

**MT Procedura ta' Manutenzjoni 3**


Halli id-drejn awtomatiku (1) u armi (2). Wahħal id-drejn il-ġdid (3) u ssikka (4).

**RO Procedură de întreținere 3**

Deșurubați evacuarea automată (1) și aruncați (2). Montați noua evacuare (3) și strângeți (4).

**BS Процедура по поддръжка 3**

Отвийте автоматичния дренаж (1) и го изхвърлете (2). Поставете новия дренаж (3) и затегнете (4).



**LT** 4 techninės priežiūros procedūra

Išstatykite naują elementą į filtro indą, įsitikindami, kad ašelis tinkamai įstatytos į išpjovą.

**RU** Процедура технического обслуживания 4

Вставьте новый элемент в стакан фильтра, проверив, что ушки правильно сели в пазы.

**SL** Postopek vzdrževanja – korak 4

V posodo filtra vstavite nov filtrirni element in zagotovite, da so nastavki elementa pravilno nameščeni v utorih.

**TR** Bakım Prosedürü 4

Yeni öğeyi filtre haznesine yerleştirerek trnakların oluklara düzgün bir şekilde oturmasını sağlayın.

**MT** Procedura ta' Manutenzjoni 4


Dahhal l-element il-ġdid fil-bowl tal-filtru u aghmel żgur li l-hugs ikunu mpoġġja tajjeb fil-gruvs.

**RO** Procedură de întreținere 4

Introduceți noul element în paharul filtrului, asigurându-vă că inelele sunt corect amplasate în canale.

**BS** Процедура по поддержке 4

Поставьте новый элемент в чашката на филтъра, като се уверите, че издадените части влизат правилно в каналите.



**LT** 5 techninės priežiūros procedūra

Pakeiskite sandarinimo žiedą filtro galvutėje pateikiamais naujais sandarinimo žiedais.



Būtina patepkite sandarinimo žiedą ir sriegius tinkamu techniniu vazelinu be rūgščių.

**RU** Процедура технического обслуживания 5

Замените кольцевое уплотнение в головке фильтра новым кольцевым уплотнением.



Смажьте кольцевое уплотнение и резьбу вазелином, не содержащим кислоты.

**SL** Postopek vzdrževanja – korak 5

Stari tesnilni O-obroč v glavi filtra zamenajte z novim.



O-obroč in navoje namažite z ustreznim brezisliskim petrolejevim gelom.

**TR** Bakım Prosedürü 5

Filtrenin başında yer alan O-halkasını, verilen yeni O-halkasıyla değiştirin.



O-halkasının ve yivlerin uygun bir asitsiz vazelin ile yağlanması sağlansın.

**MT** Procedura ta' Manutenzjoni 5

Ibdel l-O-ring li jinsab fir-ras tal-filtru bl-O-ring il-ġdid ipprovdut.



Aghmel żgur li til-lubrifiċa l-O-rings u l-kamini b'jelly tal-petroleum hieles minn aċidi xieraq.

**RO** Procedură de întreținere 5

Înlocuiți garnitura inelară situată în capul filtrului cu noua garnitură inelară furnizată.




Asigurați-vă că lubrifiați garnitura inelară și filetele cu vaselină rectificată adecvată, fără acid.

**BS** Процедура по поддержке 5

Заменете O-пръстена, разположен във филтърната глава с предоставения нов O-пръстен.



Осигурете смазване на O-пръстена и резбите с подходящ безкиселинен вазелин.



**LT** 6 techninės priežiūros procedūra (a)

Vėl uždėkite filtro indą ir galvutę, įsitikindami, kad sriegiai iki galo priveržti, o fiksavimo detalės suligiuotos.

**Pastaba.** Kad įsitikintumėte, jog indas yra gerai pritvirtintas prie galvutės, 010-030 indą sukite 360°, kol sriegis nebesisuks, o 035-045 indą 720°.

**RU** Процедура технического обслуживания 6 (a)

Установите на место стакан и головку фильтра, проверив, что резьбы полностью закручены и фиксаторы выровнены.

**Примечание.** Для полной установки стакана в головку необходимо повернуть стакан на 360° до полной остановки хода резьбы (стакан 005-030) или на 720° (стакан 035-045).

**SL** Postopek vzdrževanja – korak 6 (a)

Novovno namestite posodo filtra in filtersko glavo ter pazite, da so navoji priviti do konca in da sta označbi na glavi in posodi filtra ustrezno poravnani druga z drugo.

**Opomba:** posoda filtra je popolnoma privita na glavo, če posodo 010-030 zavrtite za 360° do konca navoja. Posodo 035-045 je treba zavrteti za 720°.

**TR** Bakım Prosedürü 6 (a)

Filtre haznesini ve başını, yivler tamamen yerine oturacak ve kilitleme tertibatı aynı hizaya gelecek şekilde yeniden takın.

**Not:** Haznenin başa tamamen yerleşmesini sağlamak için, 010-030 hazne için yiv durana kadar 360° döndürüş, 035-045 hazne için ise 720° döndürüş için gerekir.

**MT** Procedura ta' Manutenzjoni 6 (a)

Erga' wahhda il-bowl tal-filtru u r-ras filwaqt li tizgura li l-kamini jkunni mqgabbdin sew u d-dettalji tas-sokor ikunu allinjati.

**Nota:** Biex ikun żgurat li l-bowl tkun imqabdda ghal kollox fir-ras, il-bowl 010-030 tehtieg rotazzjoni ta' 360° sakemm jieqaf il-kamin u 720° għall-bowl 035-045.

**RO** Procedură de întreținere 6 (a)



Montați la loc paharul și capul filtrului, asigurându-vă că filetele sunt complet cuplate și că detaliile de blocare sunt aliniate.

**Notă:** Pentru a vă asigura că paharul este complet cuplat în capul filetelui, paharul 010-030 necesită o rotație de 360° până la oprirea filetelui, respectiv de 720° pentru paharul 035-045.

**BG** Процедура по поддръжка 6 (a)

Поставете обратно филтърниите чашка и глава, като се уверите, че резбите са напълно навити и заключващите детайли са подравнени.

**Забележка:** За да е сигурно, че чашката е добре закрепена в главата, 010-030 чашката изисква завъртане на 360° до застопоряване на резбата и на 720° за 035-045 чашката.



**LT** 7 techninės priežiūros procedūra

Priklijuokite elemento keitimo datos etiketę prie filtro indo ir užrašykite datą, kada elementas turės būti pakeistas, t. y. 12 mėnesių po elemento keitimo.



Nevalykite etiketę tirpikliais arba spiritu, nes galite jas sugadinti.

**RU** Процедура технического обслуживания 7

Приклейте к стакану фильтра табличку с датой замены элемента и впишите в нее дату следующей замены (то есть через 12 месяцев после текущей замены).



Не используйте растворители или спиртосодержащие растворы для очистки табличек, так как это может привести к повреждению.

**SL** Postopek vzdrževanja – korak 7

Na posodo filtra prilepite novo nalepko z datumom, ko je treba ponovno zamenjati filtrirni element (čez 12 mesecev).



Za odstranjevanje nalepk ne uporabljajte alkohola ali čistil, ker lahko poškodujejo posodo filtra.

**TR** Bakım Prosedürü 7

Öge değiştirme tarihi etiketini filtre haznesine yapıştırın ve ögenin yenisiyle değiştirileceği tarihi yazın, örneğin öge değişikliğinden 12 ay sonra.



Zarar verebileceği için, etiketleri temizlemek için çözücü veya alkol kullanmayın.

**MT** Procedura ta' Manutenzjoni 7

Wahhal it-tikketta tad-data tat-ibdil tal-element mal-bowl tal-filtru u ikteb id-data li fiha għandu jnibdel l-element, jiġifieri 12-il xahar wara li jnibdel l-element.



Tużax solvanti jew alkohol biex tnaqqaf it-tikketti għallex dan jista' jikkawża hsara.

**RO** Procedură de întreținere 7

Atașați eticheta cu data de înlocuire a elementului la paharul filtrului și notați pe aceasta data la care elementul trebuie înlocuit, adică după 12 luni de la înlocuirea elementului.




Nu utilizați solvenți sau alcool pentru curățarea etichetelor, deoarece puteți provoca deteriorări.

**BG** Процедура по поддръжка 7

Залепете етикет с датата на смяна на елемента върху филтърната чашка и запишете на него датата, на която трябва да се смени елемента, т.е. 12 месеца след смяната на елемента.



Не използвайте разтворители или алкохол за почистване на етикетите, тъй като това може да доведе до повреда.



**LT** 8 techninės priežiūros procedūra

Lėtai atidarykite įleidimo vožtuvą (1) palaipsniui didindami slėgį įrenginyje, lėtai atidarykite išleidimo vožtuvą (2) paleisdami slėgį iš jo esančius vamzdžius.



**Negalima staigiai atidaryti įleidimo ar išleidimo vožtuvų, paveikti įrenginio pernelgų didelių diferencialinių slėgiu, nes gali būti sugadinta įranga.**

**RU** Процедура технического обслуживания 8

Медленно откройте впускной клапан (1), чтобы постепенно создать давление в приборе, медленно откройте выпускной клапан (2) для сброса давления в трубопроводе ниже по потоку.



**Запрещено резко открывать впускной или выпускной клапаны, а также используемое устройство, так как это может привести к перепаду давления и повреждениям.**

**SL** Postopek vzdrževanja – korak 8

Počasi odprite dovodni ventil (1), da enoto postopoma obremenite s tlakom, zatem pa počasi odprite še odvodni ventil (2) za ponovno tlačno obremenitev cevododa za tem ventilom..



**Dovodnih ali odvodnih ventilov nikoli ne odpirajte naglo in enote ne izpostavljajte prekomernim nihanjem tlaka, saj lahko to povzroči škodo.**

**TR** Bakım Prosedürü 8

Üniteye aşamalı olarak basınç uygulamak için giriş valfini (1) yavaşça açın ve aşağı akım borularına yeniden basınç uygulamak için çıkış valfini (2) yavaşça açın..



**Giriş ve çıkış valflerini hızla açmayın veya üniteyi aşırı basınç farklarına maruz bırakmayın; aksi halde hasar oluşabilir.**

**MT** Procedura ta' Manutenzjoni 8

Iftaħ il-valv tad-dhul (1) bil-mod biex terġa' tibni l-pressjoni fil-unità, iftaħ il-valv tal-hruġ (2) biex terġa' tibni l-pressjoni fil-pajpijiet li jwasslu 'l isfel.



**Ara li ma tiftaħx il-valvs tad-dhul jew tal-hruġ f'daqqa jew b'xi mod tikkawża differenza eċċessiva fil-pressjoni tat-tagħmir għax tista' tagħmel il-hsara.**

**RO** Procedură de întreținere 8

Deschideți încet supapa de admisie (1) pentru a presuriza gradat aparatul, deschideți încet supapa de evacuare (2) pentru a represiuriza sistemul de conducte din aval.




**Nu deschideți rapid supapele de admisie sau de evacuare și nu supuneți aparatul la o diferență excesivă de presiune; în caz contrar, aparatul poate suferi deteriorări.**

**BG** Процедура по поддръжка 8

Отворете бавно входния вентил (1), за да пуснете постепенно налягане на уреда, отворете бавно изходния вентил (2), за да премахнете налягането по протежението на тръбите.



**Не отваряйте входния или изходния вентил бързо и не подлагайте уреда на голяма разлика в налягането, тъй като това може да доведе до повреда.**



---

**Declaration of Conformity****EN**

**Parker Hannifin Manufacturing Limited**  
Dukesway, TVTE, Gateshead, Tyne & Wear, NE11 0PZ. UK



**Compressed Air Filters**  
**Oil-X AO/AA/ACS/WS (Size 1-5)**


|  |  |
|--|--|
| <b>Directives</b>  | 2014/68/EU   |
| <b>Standards used</b>  | Generally in accordance with ASMEVIII Div 1 : 2015 & AS1210  |
| <b>PED Assessment Route :</b>  | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>Size 5 Category II according to module B & D |
| <b>EU Certificate of Conformity</b><br><b>Notified body for PED:</b> | COV0912556/1<br>Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS  |
| <b>Authorised Representative</b>                                     | Damian Cook<br><br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE                                     |




**Declaration**



I declare that as the authorised representative, the above information in relation to the supply / manufacture of this product, is in conformity with the standards and other related documents following the provisions of the above Directives.


**Signature:****Date:** 21/10/2016**Declaration Number:** 00298/211016


| Verklaring van Conformiteit   |  | Konformitätserklärung   |  |
|---|--|---|--|
| NL  |  | DE  |  |
| <p><b>Parker Hannifin Manufacturing Limited</b><br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p><b>Compressed Air Filters</b><br/>Oil-X AO/AA/ACS/WS (Size 1-5)</p>   |  | <p><b>Parker Hannifin Manufacturing Limited</b><br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p><b>Compressed Air Filters</b><br/>Oil-X AO/AA/ACS/WS (Size 1-5)</p>   |  |
| <b>Richtlijnen</b>  | 2014/68/EU   | <b>Richtlinien</b>  | 2014/68/EU   |
| <b>Gehanteerde normen</b>   | Gewoonlijk volgens ASMEVIII Div 1 : 2015 & AS1210.   | <b>Angewandte Normen</b>  | Allgemein in Übereinstimmung mit ASMEVIII Div 1 : 2015 & AS1210.   |
| <b>PED-beoordelingstraject:</b>   | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>Size 5 Category II according to module B & D<br>COV0912556/1 | <b>Beurteilungsrouten der Druckgeräterichtlinien:</b>   | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>COV0912556/1   |
| <b>EC Type onderzoekscertificaat:</b>   | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS  | <b>Benannte Stelle für die Druckgeräterichtlinie:</b>   | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS  |
| <b>Aangemelde instantie voor PED:</b>   | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS  | <b>Bevollmächtigter Vertreter</b>   | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE   |
| <b>Bevoegde vertegenwoordiger</b>   | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE   | <b>Erklärung</b>  | Hiermit erkläre ich als bevollmächtigter Vertreter die Konformität der oben aufgeführten Informationen in Bezug auf die Lieferung/Herstellung dieses Produkts mit den Normen und anderen zugehörigen Dokumenten gemäß den Bestimmungen der oben genannten Richtlinien. |
| <p><b>Verklaring</b></p> <p>Als bevoegde vertegenwoordiger verklaar ik dat bovenstaande informatie met betrekking tot de levering / vervaardiging van dit product overeenstemt met de normen en andere bijbehorende documentatie volgens de bepalingen van bovengenoemde richtlijnen.</p> |  | <p><b>Unterschrift:</b>  <b>Datum:</b> 21/10/2016</p>   |  |
| <b>Handtekening:</b>   | <b>Datum:</b> 21/10/2016   | <b>Unterschrift:</b>    | <b>Datum:</b> 21/10/2016   |
| <b>Verklaringnummer:</b> 00298/211016   |  | <b>Nummer der Erklärung:</b> 00298/211016   |  |
| Déclaration de conformité   |  | Vaatumustenmukaisuusvakuutus  |  |
| FR  |  | FI  |  |
| <p><b>Parker Hannifin Manufacturing Limited</b><br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p><b>Compressed Air Filters</b><br/>Oil-X AO/AA/ACS/WS (Size 1-5)</p>   |  | <p><b>Parker Hannifin Manufacturing Limited</b><br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p><b>Compressed Air Filters</b><br/>Oil-X AO/AA/ACS/WS (Size 1-5)</p>   |  |
| <b>Directives</b>   | 2014/68/EU   | <b>Direktiivit</b>  | 2014/68/EU   |
| <b>Normes utilisées</b>   | Généralement conforme à ASMEVIII div. 1 : 2015 & AS1210.   | <b>Käytetyt standardit</b>  | Yleensä seuraavan standardin mukaisesti: ASMEVIII Div 1: 2015 & AS1210.  |
| <b>Méthode d'évaluation de la directive d'équipements de pression :</b>   | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>COV0912556/1   | <b>PED-arviointimenettely:</b>  | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>COV0912556/1   |
| <b>Certificat d'examen de type CE :</b>   | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS  | <b>EY-tyyppihyväksynnän sertifikaatti:</b>  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS  |
| <b>Organisme de notification pour la directive d'équipement sous pression :</b>   | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS  | <b>PED-säännösten ilmoitettu laitos:</b>  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS  |
| <b>Représentant agréé</b>   | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE   | <b>Valtuutettu edustaja</b>   | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE   |
| <p><b>Déclaration</b></p> <p>Je déclare à titre de représentant agréé que les informations ci-dessus liées à la fourniture/fabrication de ce produit sont en conformité avec les normes et autres documents liés déclarés selon les dispositions des directives susmentionnées.</p>       |  | <p><b>Vakuutus</b></p> <p>Valtuutettuna edustajana vakuutan, että yllä olevat tiedot, jotka liittyvät tämän tuotteen toimittamiseen tai valmistamiseen, ovat standardien ja muiden asiaan liittyvien asiakirjojen mukaisia ja noudattavat yllä mainittuja direktiivejä.</p> |  |
| <b>Signature :</b>   | <b>Date :</b> 21/10/2016   | <b>Allekirjoitus:</b>   | <b>Päiväys:</b> 21/10/2016   |
| <b>N° de déclaration :</b> 00298/211016   |  | <b>Vakuutuksen numero:</b> 00298/211016   |  |


| Försäkran om överensstämmelse   |  | SV                | Konformitetserklæring   |  | NO                     |
|---|--|-------------------|---|--|------------------------|
| <p>Parker Hannifin Manufacturing Limited<br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p>Compressed Air Filters<br/>Oil-X AO/AA/ACS/WS (Size 1-5)</p>   |  |                   | <p>Parker Hannifin Manufacturing Limited<br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p>Compressed Air Filters<br/>Oil-X AO/AA/ACS/WS (Size 1-5)</p>   |  |                        |
| Direktiv  | 2014/68/EU   |                   | Direktiver  | 2014/68/EU   |                        |
| Använda standarder  | Generellt i enlighet med ASMEVIII Div 1: 2015 & AS1210.  |                   | Benyttede standarder  | Hovedsakelig i samsvar med ASMEVIII div 1 : 2015 & AS1210.   |                        |
| Fastställningsväg för PED:  | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 - Category I according to module B & D<br>COV0912556/1 |                   | Rute for vurdering av PED<br>(direktivet for trykpålagt utstyr):<br>EC-typegodkjenningssertifikat:  | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 - Category I according to module B & D<br>COV0912556/1 |                        |
| EG-intyg om typprovning:  |  |                   | Underrettet organ for PED:  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                    |                        |
| Anmält organ för PED:   | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                    |                   | Autoriseret representant  | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE           |                        |
| Auktoriserad representant   | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE           |                   |   |  |                        |
| <p>Försäkran</p> <p>Jag försäkrar, i egenskap av auktoriserad representant, att ovannämnda information avseende leverans/tillverkning av denna produkt överensstämmer med standarder och övriga relaterade dokument enligt villkoren i ovanstående direktiv.</p>                            |  |                   | <p>Erklæring</p> <p>Jeg erklærer som autorisert representant at informasjonen ovenfor med hensyn til levering/produksjon av dette produktet, er i overensstemmelse med standardene og andre relaterte dokumenter ifølge bestemmelsene i direktivene ovenfor.</p>            |  |                        |
| Underskrift:  |                       | Datum: 21/10/2016 | Signatur:   |                      | Dato: 21/10/2016       |
| Försäkran nummer: 00298/211016  |  |                   | Erklæring nr: 00298/211016  |  |                        |
| Overensstemmelseerklæring   |  | DA                | Δήλωση συμμόρφωσης  |  | EL                     |
| <p>Parker Hannifin Manufacturing Limited<br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p>Compressed Air Filters<br/>Oil-X AO/AA/ACS/WS (Size 1-5)</p>   |  |                   | <p>Parker Hannifin Manufacturing Limited<br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p>Compressed Air Filters<br/>Oil-X AO/AA/ACS/WS (Size 1-5)</p>   |  |                        |
| Direktiver  | 2014/68/EU   |                   | Οδηγίες   | 2014/68/EU   |                        |
| Anvendte standarder   | Generelt i overensstemmelse med ASMEVIII div. 1: 2015 & AS1210.  |                   | Πρότυπα που χρησιμοποιήθηκαν  | Γενικά σε συμφωνία με το ASMEVIII Div 1: 2015 & AS1210.  |                        |
| Forløb for PED-bedømmelse:  | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 - Category I according to module B & D<br>COV0912556/1 |                   | Διαδρομή αξιολόγησης για κανονισμούς PED:   | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 - Category I according to module B & D<br>COV0912556/1 |                        |
| EF-typeafprøvningsattest:   |  |                   | Πιστοποιητικό εξέτασης τύπου EK:  |  |                        |
| Notificeret organ for PED:  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                    |                   | Ενήμερος οργανισμός για κανονισμούς PED:  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                    |                        |
| Autoriseret repræsentant  | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE           |                   | Εξουσιοδοτημένος αντιπρόσωπος   | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE           |                        |
| <p>Erklæring</p> <p>Jeg erklærer hermed som autoriseret repræsentant, at ovennævnte oplysninger vedrørende levering/produktion af dette produkt er i overensstemmelse med de anførte standarder og øvrige tilknyttede dokumenter i henhold til bestemmelserne i ovenstående direktiver.</p> |  |                   | <p>Δήλωση</p> <p>Δηλώνω ως ο εξουσιοδοτημένος αντιπρόσωπος ότι οι παραπάνω πληροφορίες σε σχέση με τη διάθεση / κατασκευή αυτού του προϊόντος, συμμορφώνονται ως προς τα πρότυπα και ως προς τα άλλα σχετικά έγγραφα που συνοδεύουν τις διατάξεις των πιο πάνω οδηγιών.</p> |  |                        |
| Underskrift:  |                     | Dato: 21/10/2016  | Υπογραφή:   |                    | Ημερομηνία: 21/10/2016 |
| Erklæringnummer: 00298/211016   |  |                   | Αριθμός δήλωσης: 00298/211016   |  |                        |

| Declaración de conformidad  |  | ES                | Declaração de Conformidade  |  | PT               |
|---|--|-------------------|---|--|------------------|
| <p>Parker Hannifin Manufacturing Limited<br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p>Compressed Air Filters</p> <p>Oil-X AO/AA/ACS/WS (Size 1-5)</p>  |  |                   | <p>Parker Hannifin Manufacturing Limited<br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p>Compressed Air Filters</p> <p>Oil-X AO/AA/ACS/WS (Size 1-5)</p>  |  |                  |
| Directivas  | 2014/68/EU   |                   | Directivas  | 2014/68/EU   |                  |
| Normas utilizadas   | Generalmente de conformidad con ASMEVIII Div 1: 2015 & AS1210.                                       |                   | Padrões utilizados  | De forma geral em concordância com ASMEVIII Div 1: 2015 & AS1210.                                    |                  |
| Ruta de evaluación de la normativa PED:   | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>COV0912556/1 |                   | Percurso de Avaliação do PED:   | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>COV0912556/1 |                  |
| Certificado de examen CE de tipo:   | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  |                   | Certificado de Inspeção Tipo CE:  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  |                  |
| Organismo notificado para la normativa PED:   | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  |                   | Notificado para o PED:  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  |                  |
| Representante autorizado  | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE         |                   | Revendedor Autorizado   | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE         |                  |
| <p><b>Declaración</b></p> <p>Como representante autorizado, declaro que la información anteriormente expuesta en relación con el suministro y/o fabricación de este producto cumple las normativas indicadas y otros documentos afines según las disposiciones de las Directivas citadas anteriormente.</p>                             |  |                   | <p><b>Declaração</b></p> <p>Declaro, na qualidade de representante autorizado, que as informações acima contidas referentes ao fornecimento / fabrico deste produto estão em conformidade com as normas e outros documentos relacionados, de acordo com as disposições das Directivas anteriores.</p> |  |                  |
| Firma:  |                     | Fecha: 21/10/2016 | Assinatura:   |                    | Data: 21/10/2016 |
| Número de declaración: 00298/211016   |  |                   | Número da Declaração: 00298/211016  |  |                  |
| Dichiarazione di conformità   |  | IT                | Deklaracja zgodności  |  | PL               |
| <p>Parker Hannifin Manufacturing Limited<br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p>Compressed Air Filters</p> <p>Oil-X AO/AA/ACS/WS (Size 1-5)</p>  |  |                   | <p>Parker Hannifin Manufacturing Limited<br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p>Compressed Air Filters</p> <p>Oil-X AO/AA/ACS/WS (Size 1-5)</p>  |  |                  |
| Directive   | 2014/68/EU   |                   | Dyrektywy   | 2014/68/EU   |                  |
| Norme utilizzate  | Generalmente conforme a ASMEVIII Div 1: 2015 & AS1210.   |                   | Stosowane standardy   | Ogólnie zgodny z ASMEVIII dział 1: 2015 & AS1210.  |                  |
| Procedura di valutazione PED:   | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>COV0912556/1 |                   | Ścieżka potwierdzenia zgodności z PED:  | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>COV0912556/1 |                  |
| Attestato di certificazione tipo CE:  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  |                   | Certyfikat badania typu WE:   | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  |                  |
| Organismo accreditato per PED:  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  |                   | Organ/institucja powiadamiana na mocy PED:  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  |                  |
| Rappresentante autorizzato  | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE         |                   | Autoryzowany przedstawiciel   | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE         |                  |
| <p><b>Dichiarazione</b></p> <p>In qualità di rappresentante autorizzato dichiaro che le informazioni di cui sopra, in merito alla fornitura/fabbricazione del prodotto in oggetto, sono conformi alle norme indicate e a qualsiasi altro documento correlati alla fornitura basato su quanto prescritto dalle direttive menzionate.</p> |  |                   | <p><b>Deklaracja</b></p> <p>Oświadczam, jako autoryzowany przedstawiciel, że powyższe informacje dotyczące dostawy / wytworzenia niniejszego produktu są zgodne ze standardami i innymi dokumentami powiązanyymi zgodnie z postanowieniami powyższych dyrektyw.</p>                                   |  |                  |
| Firma:  |                   | Data: 21/10/2016  | Podpis:   |                  | Data: 21/10/2016 |
| Dichiarazione numero: 00298/211016  |  |                   | Numer deklaracji: 00298/211016  |  |                  |

| Vyhlásenie o zhode  |   | SK                         | Prohlášení o shodě  |   | CS                       |
|---|---|----------------------------|---|---|--------------------------|
| <b>Parker Hannifin Manufacturing Limited</b><br>Dukesway, TVTE, Gateshead, Tyne & Wear, NE11 0PZ. UK<br><br><b>Compressed Air Filters</b><br>Oil-X AO/AAACS/WS (Size 1-5)                                   |   |                            | <b>Parker Hannifin Manufacturing Limited</b><br>Dukesway, TVTE, Gateshead, Tyne & Wear, NE11 0PZ. UK<br><br><b>Compressed Air Filters</b><br>Oil-X AO/AAACS/WS (Size 1-5)   |   |                          |
| <b>Smernice</b>   | 2014/68/EU  |                            | <b>Směrnice</b>   | 2014/68/EU  |                          |
| <b>Použitě normy</b>  | Vo všeobecnosti v zhode s ASMEVIII oddiel 1 : 2015 & AS1210   |                            | <b>Použitě normy</b>  | Obecně v souladu ASMEVIII Div 1 : 2015 & AS1210.  |                          |
| <b>Spôsob posudzovania podľa smernice PED</b>   | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>COV/0912556/1 |                            | <b>Metoda stanoveni shody pro tlaková zařízení (PED):</b>   | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>COV/0912556/1 |                          |
| <b>Osvědčenie typovej skúšky ES</b>   |   |                            | <b>Osvědčeni o zkoušce typu ES:</b>   |   |                          |
| <b>Oboznámený orgán podľa smernice PED:</b>   | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                   |                            | <b>Notifikovaný orgán pro PED:</b>  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                   |                          |
| <b>Spinomocnený zástupca</b>  | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE          |                            | <b>Oprávněný zástupce</b>   | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE          |                          |
| <b>Vyhlasenie</b>   |   |                            | <b>Prohlášení</b>   |   |                          |
| Ako splnomocnený zástupca vyhlasujem, že informácie uvedené vyššie, sú v súvislosti s dodávkou / výrobou tohto výrobku v zhode s normami a inými súvisiacimi dokumentmi podľa ustanovení uvedených smerníc. |   |                            | Jako oprávněný zástupce prohlašuji, že výše uvedené informace týkající se dodávky / výroby tohoto produktu jsou v souladu s normami a jinými souvisejícími dokumenty vyplývajícími z ustanovení výše uvedených směrnic.   |   |                          |
| <b>Podpis:</b>  |                      | <b>Dátum:</b> 21/10/2016   | <b>Podpis:</b>  |                     | <b>Datum:</b> 21/10/2016 |
| <b>Číslo vyhlásenia:</b> 00298/211016   |   |                            | <b>Číslo prohlášení:</b> 00298/211016   |   |                          |
| Vastavusdeklaratsioon   |   | ET                         | Megfelelőségi nyilatkozat   |   | HU                       |
| <b>Parker Hannifin Manufacturing Limited</b><br>Dukesway, TVTE, Gateshead, Tyne & Wear, NE11 0PZ. UK<br><br><b>Compressed Air Filters</b><br>Oil-X AO/AAACS/WS (Size 1-5)                                   |   |                            | <b>Parker Hannifin Manufacturing Limited</b><br>Dukesway, TVTE, Gateshead, Tyne & Wear, NE11 0PZ. UK<br><br><b>Compressed Air Filters</b><br>Oil-X AO/AAACS/WS (Size 1-5)   |   |                          |
| <b>Direktívíd</b>   | 2014/68/EU  |                            | <b>Direktívák</b>   | 2014/68/EU  |                          |
| <b>Kasutatud standardid</b>   | Üldiselt vastavuses standardiga ASMEVIII Div 1: 2015 & AS1210.  |                            | <b>Alkalmazott szabványok:</b>  | Általánosan a következők alapján: ASMEVIII Div 1 : 2015 & AS1210.                                     |                          |
| <b>PED-vastavushinnangu jaotus:</b>   | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>COV/0912556/1 |                            | <b>PED értékelési irányvonal</b>  | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>COV/0912556/1 |                          |
| <b>EÜ tüübihindamistõend:</b>   |   |                            | <b>EC típusvizsgálati bizonyítvány:</b>   |   |                          |
| <b>PEDist (survaseadmets direktivist) teavitatud asutus:</b>  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                   |                            | <b>PED-del kapcsolatban értesített testület:</b>  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                   |                          |
| <b>Volitatud esindaja</b>   | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE          |                            | <b>Hivatalos képviselő</b>  | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE          |                          |
| <b>Deklaratsioon</b>  |   |                            | <b>Nyilatkozat</b>  |   |                          |
| Volitatud esindajana kinnitan, et ülalloodud teave seoses antud toote tarnimisega on vastavuses standardite ja muude seotud dokumentidega vastavalt ülalloodud direktiivide sätetele.                       |   |                            | Hivatalos képviselőként kijelentem, hogy a termék szállításával / gyártásával kapcsolatos fent olvasható információk megfelelnek a fenti Direktívák előírásai szerinti szabványoknak és egyéb kapcsolódó dokumentumoknak. |   |                          |
| <b>Allkirj:</b>   |                    | <b>Kuupäev:</b> 21/10/2016 | <b>Aláírás:</b>   |                   | <b>Dátum:</b> 21/10/2016 |
| <b>Deklaratsioon number:</b> 00298/211016   |   |                            | <b>Nyilatkozat száma:</b> 00298/211016  |   |                          |

| Atbilstības deklarācija  |  | LV                                      |  | Atbilstības deklarācija   |  | LT            |            |
|--|--|---|--|---|--|---------------|------------|
| <b>Parker Hannifin Manufacturing Limited</b><br>Dukesway, TVTE, Gateshead, Tyne & Wear, NE11 0PZ. UK<br><br><b>Compressed Air Filters</b><br><br>Oil-X AO/AA/ACS/WSS (Size 1-5)  |  |   |  | <b>Parker Hannifin Manufacturing Limited</b><br>Dukesway, TVTE, Gateshead, Tyne & Wear, NE11 0PZ. UK<br><br><b>Compressed Air Filters</b><br><br>Oil-X AO/AA/ACS/WSS (Size 1-5)                               |  |               |            |
| <b>Direktīvas</b>  | 2014/68/EU   | <b>Direktīvos</b>                       | 2014/68/EU   |   |  |               |            |
| <b>Izmantotie standarti</b>  | Parasti saskaņā ar ASMEVIII Div 1 : 2015 & AS1210.   | <b>Naudoti standarti</b>                | Atitinka bendrās prasmes ASMEVIII Div 1 : 2015 & AS1210 nuostatas                                    |   |  |               |            |
| <b>PED novērtējums :</b>   | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>COV0912556/1 | <b>PED įvertinimo pakopa:</b>           | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>COV0912556/1 |   |  |               |            |
| <b>EK sastādīts Eksaminācijas sertifikāts:</b>   | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  | <b>EB tipo testavimo sertifikatas:</b>  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  |   |  |               |            |
| <b>Par PED informētā organizācija</b>  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  | <b>PED notifikuojoji institūcija:</b>   | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  |   |  |               |            |
| <b>Pilnvarotais pārstāvis</b>  | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE         | <b>Igaliotasis atstovas</b>             | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE         |   |  |               |            |
| <b>Deklarācija</b>   |  |   |  | <b>Deklarācija</b>  |  |               |            |
| Es kā pilnvarots pārstāvis ar šo paziņoju, ka iepriekšminētā informācija, kas attiecas uz šī produkta piegādi / ražošanu, atbilst standartiem un citiem atbilstošiem dokumentiem saskaņā ar iepriekšminētajām Direktīvām.      |  |   |  | Aš, īgaliotasis atstovas, patvirtinu, kad aukščiau pateikta gaminio tiekimo/pagaminoimo informacija atitinka aukščiau nurodytus standartus ir kitą su nurodytų direktyvų nuostatomis susijusią dokumentaciją. |  |               |            |
| <b>Paraksts:</b>   |                     | <b>Datums:</b>                          | 21/10/2016   | <b>Parašas:</b>   |    | <b>Data:</b>  | 21/10/2016 |
| <b>Deklarācijas numurs:</b> 00298/211016   |  |   |  | <b>Deklaracijos numeris:</b> 00298/211016   |  |               |            |
| Декларация соответствия  |  | RU                                      |  | Izjava o skladnosti   |  | SL            |            |
| <b>Parker Hannifin Manufacturing Limited</b><br>Dukesway, TVTE, Gateshead, Tyne & Wear, NE11 0PZ. UK<br><br><b>Compressed Air Filters</b><br><br>Oil-X AO/AA/ACS/WSS (Size 1-5)  |  |   |  | <b>Parker Hannifin Manufacturing Limited</b><br>Dukesway, TVTE, Gateshead, Tyne & Wear, NE11 0PZ. UK<br><br><b>Compressed Air Filters</b><br><br>Oil-X AO/AA/ACS/WSS (Size 1-5)                               |  |               |            |
| <b>Требования</b>  | 2014/68/EU   | <b>Direktive</b>                        | 2014/68/EU   |   |  |               |            |
| <b>Применяемые стандарты</b>   | В большинстве случаев обеспечивается соответствие стандарту ASMEVIII, Раздел 1: 2015 & AS1210.       | <b>Uporabljeni standardi</b>            | Spolšno skladno z ASMEVIII Div 1: 2015 & AS1210.   |   |  |               |            |
| <b>Система обеспечения качества PED:</b>   | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>COV0912556/1 | <b>Ocenjevalna pot PED:</b>             | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 Category I according to module B & D<br>COV0912556/1 |   |  |               |            |
| <b>Сертификат ЕС на проведение типовых испытаний:</b>  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  | <b>Certifikat o tipskem pregledu ES</b> | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  |   |  |               |            |
| <b>Уполномоченный орган для PED:</b>   | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  | <b>Priglašeni organ za PED:</b>         | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                  |   |  |               |            |
| <b>Уполномоченный представитель</b>  | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE         | <b>Pooblaščenči zastopnik</b>           | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE         |   |  |               |            |
| <b>Декларация</b>  |  |   |  | <b>Izjava</b>   |  |               |            |
| Как уполномоченный представитель, я заявляю, что приведенная выше информация относительно поставки/производства данного продукта соответствует стандартам, другим связанным документам и положениям указанных выше требований. |  |   |  | Kot pooblaščenči zastopnik izjavljam, da so zgornji podatki glede dobave/proizvodnje tega izdelka skladni s standardi in ostalimi sorodnimi dokumenti, ki sledijo določbam zgornjih direktiv.                 |  |               |            |
| <b>Подпись:</b>  |                   | <b>Дата:</b>                            | 21/10/2016   | <b>Podpis:</b>  |  | <b>Datum:</b> | 21/10/2016 |
| <b>Номер декларации:</b> 00298/211016  |  |   |  | <b>Številka izjave:</b> 00298/211016  |  |               |            |

| Uyum Beyanı   |  | TR | Dikjarazzjoni tal-Konformità  |  | MT |
|---|--|----|---|--|----|
| <p>Parker Hannifin Manufacturing Limited<br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p>Compressed Air Filters<br/>Oil-X AO/AA/ACS/WS (Size 1-3)</p>   |  |    | <p>Parker Hannifin Manufacturing Limited<br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p>Compressed Air Filters<br/>Oil-X AO/AA/ACS/WS (Size 1-5)</p>   |  |    |
| Direktifler   | 2014/68/EU   |    | Direttivi   | 2014/68/EU   |    |
| Kullanılan standartlar  | Genelde ASMEVIII Div 1 : 2015 & AS1210'e uygun.  |    | Standards uzati   | Generalment f'konformità ma' ASMEVIII Div 1 : 2015 & AS1210.   |    |
| PED (Basınçlı Ekipman Direktifi)<br>Değerlendirilmesi Yolu:<br>AT Tipi İncelemesi Sertifikası:  | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 - Category I according to module B & D<br>COV0912556/1 |    | Rotta ta' l-Assessjar tal-PED:<br>Çertifikat tal-KE ta' l-eżaminazzjoni tat-Tip:  | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 - Category I according to module B & D<br>COV0912556/1 |    |
| PED için bildirimde bulunulan kuruluş:  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                    |    | Korp notifikat għall-PED:   | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                    |    |
| Yetkili Temsilci  | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE           |    | Rappreżentant Awtorizzat  | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE           |    |
| <p><b>Beyan</b></p> <p>Yetkili temsilci olarak beyan ederim ki bu ürünün teminine / üretimine ilişkin olarak yukarıda verilen bilgiler yukarıda anılan Direktiflerin hükümlerine uyan standartlara ve ilgili başka belgelere uygundur.</p>                          |  |    | <p><b>Dikjarazzjoni</b></p> <p>Niddikjara li bhala r-rappreżentant awtorizzat, l-informazzjoni ta' hawn fuq, f'dak li għandu x'jaqşam mal-formiment/manifattura ta' dan il-prodott, hija f'konformità ma' l-istandards u d-dokumenti l-oħra relatati li jsegwu d-dispożizzjonijiet tad-Direttivi msemmija hawn fuq.</p> |  |    |
| İmza:    | Tarih: 21/10/2016  |    | Firma:    | Data: 21/10/2016   |    |
| Beyan No: 00298/211016  |  |    | Numru tad-Dikjarazzjoni: 00298/211016   |  |    |
| Декларация за съответствие  |  |    | Declarația de conformitate  |  |    |
| <p>Parker Hannifin Manufacturing Limited<br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p>Compressed Air Filters<br/>Oil-X AO/AA/ACS/WS (Size 1-5)</p>   |  |    | <p>Parker Hannifin Manufacturing Limited<br/>Dukesway, TVTE, Gateshead, Tyne &amp; Wear, NE11 0PZ. UK</p> <p>Compressed Air Filters<br/>Oil-X AO/AA/ACS/WS (Size 1-5)</p>   |  |    |
| Директиви   | 2014/68/EU   |    | Directive   | 2014/68/EU   |    |
| Исползвани стандарти  | Generalment f'konformità ma' ASMEVIII Div 1 : 2015 & AS1210.   |    | Standardele folosite  | Generalment f'konformità ma' ASMEVIII Div 1 : 2015 & AS1210.   |    |
| Начин на оценка от PED :  | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 - Category I according to module B & D<br>COV0912556/1 |    | Cale de evaluare PED:   | Size 1-3 Article 4, Paragraph 3 (SEP)<br>Size 4 - Category I according to module B & D<br>COV0912556/1 |    |
| Сертификат за ЕС типово изпитване:  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                    |    | Agentia notificata pentru PED:  | Lloyds Register Verification<br>71 Fenchurch St. London<br>EC3M 4BS                                    |    |
| Упълномощен представител  | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE           |    | Reprezentant autorizat  | Damian Cook<br>Divisional Engineering Manager<br>Parker Hannifin Manufacturing Limited, GSFE           |    |
| <p><b>Декларация</b></p> <p>Декларирам като изпълномощен представител, че горната информация относно доставката / производството на този продукт е в съответствие със стандартите и други свързани документи следващи разпоредбите на горепосочените директиви.</p> |  |    | <p><b>Declarație</b></p> <p>Declar, în calitate de reprezentant autorizat, faptul că informația de mai sus referitoare la livrarea / fabricarea acestui produs este în conformitate cu standardele și alte documente asociate care urmăresc prevederile directivelor de mai sus.</p>                                    |  |    |
| Подпис:    | Дата: 21/10/2016   |    | Semnătura:    | Data: 21/10/2016   |    |
| Номер на декларацията: 00298/211016   |  |    | Numărul declarației: 00298/211016   |  |    |



## Parker Worldwide

**AE – UAE, Dubai**  
Tel: +971 4 8127100  
parker.me@parker.com

**AR – Argentina, Buenos Aires**  
Tel: +54 3327 44 4129

**AT – Austria, Wiener Neustadt**  
Tel: +43 (0)2622 23501-0  
parker.austria@parker.com

**AT – Eastern Europe, Wiener Neustadt**  
Tel: +43 (0)2622 23501 900  
parker.easteurope@parker.com

**AU – Australia, Castle Hill**  
Tel: +61 (0)2-9634 7777

**AZ – Azerbaijan, Baku**  
Tel: +994 50 2233 458  
parker.azerbaijan@parker.com

**BE/LU – Belgium, Nivelles**  
Tel: +32 (0)67 280 900  
parker.belgium@parker.com

**BR – Brazil, Cachoeirinha RS**  
Tel: +55 51 3470 9144

**BY – Belarus, Minsk**  
Tel: +375 17 209 9399  
parker.belarus@parker.com

**CA – Canada, Milton, Ontario**  
Tel: +1 905 693 3000

**CH – Switzerland, Etoy**  
Tel: +41 (0)21 821 87 00  
parker.switzerland@parker.com

**CL – Chile, Santiago**  
Tel: +56 2 623 1216

**CN – China, Shanghai**  
Tel: +86 21 2899 5000

**CZ – Czech Republic, Klecany**  
Tel: +420 284 083 111  
parker.czechrepublic@parker.com

**DE – Germany, Kaarst**  
Tel: +49 (0)2131 4016 0  
parker.germany@parker.com

**DK – Denmark, Ballerup**  
Tel: +45 43 56 04 00  
parker.denmark@parker.com

**ES – Spain, Madrid**  
Tel: +34 902 330 001  
parker.spain@parker.com

**FI – Finland, Vantaa**  
Tel: +358 (0)20 753 2500  
parker.finland@parker.com

**FR – France, Contamine s/Arve**  
Tel: +33 (0)4 50 25 80 25  
parker.france@parker.com

**GR – Greece, Athens**  
Tel: +30 210 933 6450  
parker.greece@parker.com

**HK – Hong Kong**  
Tel: +852 2428 8008

**HU – Hungary, Budapest**  
Tel: +36 1 220 4155  
parker.hungary@parker.com

**IE – Ireland, Dublin**  
Tel: +353 (0)1 466 6370  
parker.ireland@parker.com

**IN – India, Mumbai**  
Tel: +91 22 6513 7081-85

**IT – Italy, Corsico (MI)**  
Tel: +39 02 45 19 21  
parker.italy@parker.com

**JP – Japan, Tokyo**  
Tel: +81 (0)3 6408 3901

**KR – South Korea, Seoul**  
Tel: +82 2 559 0400

**KZ – Kazakhstan, Almaty**  
Tel: +7 7272 505 800  
parker.easteurope@parker.com

**LV – Latvia, Riga**  
Tel: +371 6 745 2601  
parker.latvia@parker.com

**MX – Mexico, Apodaca**  
Tel: +52 81 8156 6000

**MY – Malaysia, Shah Alam**  
Tel: +60 3 7849 0800

**NL – The Netherlands, Oldenzaal**  
Tel: +31 (0)541 585 000  
parker.nl@parker.com

**NO – Norway, Asker**  
Tel: +47 66 75 34 00  
parker.norway@parker.com

**NZ – New Zealand, Mt Wellington**  
Tel: +64 9 574 1744

**PL – Poland, Warsaw**  
Tel: +48 (0)22 573 24 00  
parker.poland@parker.com

**PT – Portugal, Leca da Palmeira**  
Tel: +351 22 999 7360  
parker.portugal@parker.com

**RO – Romania, Bucharest**  
Tel: +40 21 252 1382  
parker.romania@parker.com

**RU – Russia, Moscow**  
Tel: +7 495 645-2156  
parker.russia@parker.com

**SE – Sweden, Spånga**  
Tel: +46 (0)8 59 79 50 00  
parker.sweden@parker.com

**SG – Singapore**  
Tel: +65 6887 6300

**SK – Slovakia, Banská Bystrica**  
Tel: +421 484 162 252  
parker.slovakia@parker.com

**SL – Slovenia, Novo Mesto**  
Tel: +386 7 337 6650  
parker.slovenia@parker.com

**TH – Thailand, Bangkok**  
Tel: +662 717 8140

**TR – Turkey, Istanbul**  
Tel: +90 216 4997081  
parker.turkey@parker.com

**TW – Taiwan, Taipei**  
Tel: +886 2 2298 8987

**UA – Ukraine, Kiev**  
Tel: +380 44 494 2731  
parker.ukraine@parker.com

**UK – United Kingdom, Warwick**  
Tel: +44 (0)1926 317 878  
parker.uk@parker.com

**US – USA, Cleveland**  
Tel: +1 216 896 3000

**VE – Venezuela, Caracas**  
Tel: +58 212 238 5422

**ZA – South Africa, Kempton Park**  
Tel: +27 (0)11 961 0700  
parker.southafrica@parker.com

European Product Information Centre  
Free phone: 00 800 27 27 5374  
(from AT, BE, CH, CZ, DE, EE, ES, FI, FR, IE, IL, IS, IT, LU, MT, NL, NO, PT, SE, SK, UK)

© Parker Hannifin Corporation. All rights reserved.

Catalogue: 171186000  
01/17 Rev: -



**Parker Hannifin Manufacturing Limited**  
Gas Separation and Filtration Division EMEA  
Dukesway, Team Valley Trading Est  
Gateshead, Tyne and Wear  
England NE11 0PZ  
Tel: +44 (0) 191 402 9000  
Fax: +44 (0) 191 482 6296  
www.parker.com/dhi

**A**

Actuating pressure [149](#)  
Adjustment range [14](#)  
Air inlet [54](#)  
Airend discharge temperature (ADT) [17](#)  
Alternative shutdown procedures [79](#)  
Ambient temperature [50](#)  
Anti-vibration element [68](#)  
Assembly drawing [212](#)  
Assembly work on the chassis [69](#)  
AUTO OFF [79](#)

**B**

Battery [21](#), [38](#), [127](#)  
Battery charger [27](#)  
Biodiesel [20](#)  
Bodywork [41](#)

**C**

Capacity [21](#)  
Carbon dioxide emissions [21](#)  
Charge air cooler [143](#)  
Charge air cooling [49](#)  
Charge level [127](#)  
Checking the coolant level [104](#)  
Checking the coolant quality [105](#)  
Code [11](#)  
Cold discharge test current [21](#)  
Combustible gas mixture [54](#)  
Compressed air aftercooler [22](#), [51](#), [83](#), [150](#), [151](#)  
Compressed air aftercooler bypass [83](#)  
Compressed air aftercooler with bypass [51](#)  
Compressed air connection [16](#)  
Compressed air outlet [16](#), [50](#)  
Compressed air outlet pressure gauge [77](#)  
Compressed air quality [50](#)  
Compressed air treatment [50](#)  
Compressor cooler [143](#)  
Compressor oil  
    Changing [133](#)  
    First aid [38](#)  
Compressor oil circuit  
    Airend [43](#)  
    Oil cooler [43](#)  
    Oil filter [43](#)  
    Oil separator cartridge [43](#)  
    Oil separator tank [43](#)  
    Thermostatic valve [43](#)  
Compressor oil fill volume [18](#)  
Compressor oil recommendation [17](#)  
Condensate drain line [51](#)  
Connection diagram  
    IT power network [54](#)  
Connection size [16](#)  
Control panel [77](#)

Control range [14](#)  
Controller On/Off [77](#)  
Coolant cooler [143](#)  
Coolant preheating [22](#), [82](#)  
Cooled exhaust gas recirculation [49](#)  
Cooling air flow  
    Cooling air inlet [43](#)  
    Cooling air outlet [43](#)  
Cooling air inlet [41](#)  
Cooling air outlet [41](#)  
Copyright [9](#)  
Correctly mixing the coolant [105](#)  
Crane lifting eye cover [41](#)  
Crankcase venting valve [120](#)

**D**

Danger area [32](#)  
Directional control valve [83](#), [84](#)  
Directive [36](#)  
Dirt trap [51](#), [151](#)  
Display elements [47](#)  
Document [7](#)  
Drive engine cooler [143](#)

**E**

Emergency [37](#)  
EMERGENCY STOP button [77](#)  
Engine [19](#)  
Engine air shut-off valve [54](#), [159](#)  
Engine coolant temperature (ECT) [17](#)  
Engine nameplate [219](#)  
Engine speed [49](#)  
Environmental protection [38](#)  
Exhaust gas after-treatment [19](#)  
    Diesel oxidation catalytic converter [43](#)  
    Diesel particulate filter [43](#)  
Exhaust gas turbocharger [49](#)

**F**

Filter cap  
    Dismantling [109](#), [140](#)  
Filter combination [51](#)  
Fire hazard area [54](#)  
Floor pan [58](#)  
Flow diagram [172](#)  
Flow rate  
    Definition [15](#)  
    pV diagram [15](#)  
Fluid distribution module, oil filter [134](#)  
Fluid distribution module, oil separator [137](#)  
Fuel consumption [19](#)  
Fuel filter [111](#), [114](#)  
Fuel line [113](#)  
Fuel prefilter [111](#), [113](#)  
Fuel recommendation [20](#)

Fuel system [111](#), [113](#)  
Fuel type [19](#)  
Fuel-water separator [112](#)

## G

Generator operation  
    Flow rate [23](#)  
    Nominal power [23](#)  
Generator specification [22](#)  
Guaranteed sound power level [13](#)  
Guideline [36](#)

## H

Heat exchanger [84](#)  
Heat exchanger bypass [84](#)  
Heating for compressed air condensate separator [22](#)

## I

Initial fill of coolant cooler [220](#)  
Inlet valve control [49](#)  
Inspection interval [37](#)  
Installation condition [66](#)  
Insulation monitoring device [87](#)  
Insulation monitoring test key [87](#)

## L

Load securing [61](#)  
Lubricant supply vessel [156](#)  
Luftfilter  
    Compressor [140](#)  
    Drive motor [109](#)  
    Filter cap [109](#), [140](#)  
    Retaining clip [109](#), [140](#)

## M

Machine feet [68](#)  
Machine foot [68](#)  
Machine nameplate [10](#), [219](#)  
Material damage [8](#)  
Maximum working pressure [14](#)  
Measure  
    Organisational [37](#)

## N

Noise emission [13](#)

## O

Oil cooler [143](#)  
Oil separator cartridge [137](#)  
Oil separator tank [132](#), [133](#)  
Operating console [77](#)  
Operating elements [46](#)

Operating fluids [58](#)  
Operating fluids/materials [98](#)  
Operating instruments [77](#)  
Operator [36](#), [37](#)  
Options label [11](#), [219](#)

## P

Paraffinic diesel fuel [20](#)  
Part number [98](#)  
Personnel [37](#)  
Pictogram [8](#)  
Pressure adjustment range [14](#)  
Pressure rating [15](#)  
    Adjustment range [14](#)  
    Control range [14](#)  
Proper fuel type [81](#)  
pV Control [14](#)

## Q

Quick reference guide [77](#)

## R

Rated engine power [19](#)  
Regulation [36](#)  
Responsibility [36](#)  
Rubber buffer [68](#)  
Rubber buffers [68](#)

## S

Safety [28](#)  
Safety device [45](#)  
Safety shutdown [17](#), [149](#)  
Safety signs on the machine exterior [33](#)  
Safety signs on the machine interior [33](#)  
Safety valve [16](#), [149](#)  
Screw connections [13](#)  
Screws [13](#)  
Servicing the generator drive belt [157](#)  
Servicing the spark arrester [158](#)  
Shutting down [79](#)  
Spare part number [98](#), [212](#)  
Spare parts [98](#)  
Spark arrester [54](#)  
Speed [19](#)  
Standby temperature [17](#)  
Start the machine [78](#)  
Starting instruments [77](#)  
Stopping [79](#)  
Stopping the machine [79](#)  
Symbol [8](#)

## T

Telematics [56](#)  
Thread size [13](#)  
Tightening torque [13](#)

Toggle latch [41](#)  
Tool lubricator [22](#), [52](#), [86](#), [156](#)  
Torque [13](#)  
Transport damage [60](#)  
Treated compressed air [84](#)

## U

Untreated compressed air [83](#)  
Use  
    Improper [28](#)  
    Intended [28](#)

## V

Variable pressure-flow rate control [14](#), [49](#)  
    Control range [15](#)  
    Engine speed [15](#)  
    Nominal system pressure [15](#)  
    Pressure rating [15](#)  
    pV diagram [15](#)  
Vehicle identification number [219](#)

## W

Warning notice [7](#)  
Warranty [9](#)  
Water quality [220](#)  
Water separator [51](#), [151](#)  
Weight [12](#)  
Wiring diagram [180](#)  
Working pressure [49](#)  
    Maximum working pressure [15](#)  
    Pressure rating [15](#)