

Service Manual

Reciprocating compressor

Premium car D

No.: 9_6964 01E

RAMIRENT

Manufacturer:

KAESER KOMPRESSOREN GmbH

96410 Coburg • PO Box 2143 • GERMANY • Tel. +49-(0)9561-6400 • Fax +49-(0)9561-640130

<http://www.kaeser.com>

RAMIRENT

1	Regarding this document	
1.1	Using the Document	1
1.2	Further Documents	1
1.3	Copyright	1
1.4	Symbols and Identification	1
1.4.1	Warnings	1
1.4.2	Other instructions and symbols	2
2	Technical Specification	
2.1	Nameplate	3
2.2	Weight	3
2.3	Compressor block	3
2.4	Ambient Conditions	4
2.5	Pressure switch setting	4
2.6	Pressure	4
2.7	Sound emission	5
2.8	Motor power and speed	5
2.9	Compressor oil recommendations	5
2.9.1	Compressor oil charge	6
2.10	Power Supply	6
2.10.1	Three-phase power supply	6
2.11	Network Conditions	7
2.11.1	Network conditions at 400V/3/50Hz	7
2.12	Machine duty cycle	7
3	Safety and Responsibility	
3.1	Basic Information	9
3.2	Specified Use	9
3.3	Improper Use	9
3.4	User's Responsibilities	9
3.4.1	Observe statutory and universally accepted regulations.	9
3.4.2	Qualified personnel	10
3.4.3	Adherence to inspection schedules and accident prevention regulations	10
3.5	Dangers	11
3.5.1	Safely dealing with sources of danger	12
3.5.2	Safe machine operation	13
3.5.3	Organisational Measures	14
3.6	Safety Devices	14
3.7	Safety Signs	15
3.8	Information signs	15
3.9	In Emergency	16
3.9.1	Fire fighting	16
3.9.2	Remove any compressor oil from your person.	16
3.10	Warranty	16
3.11	Environmental Protection	17
4	Design and Function	
4.1	Outline of the machine	18
4.1.1	Function	18
4.2	Operating modes and control modes	19
4.2.1	Operating modes	19
4.2.2	Control modes	19
4.3	Safety Devices	19
5	Installation and Operating Conditions	
5.1	Safety	20

5.2	Installation conditions	20
6	Installation	
6.1	Safety	21
6.2	Reporting Transport Damage	21
6.3	Fitting the Antivibration Mounts	21
6.4	Compressed Air Connection	22
6.5	Connecting the Power Supply	22
7	Initial Start-up	
7.1	Safety	24
7.2	Instructions to be observed before commissioning or recommissioning	24
7.3	Checking positioning and operating conditions	25
7.4	Motor overload protection	25
7.4.1	Motor protection setting with direct online starting	25
7.5	Checking direction of rotation	26
7.6	Starting the machine for the first time	26
7.7	Measuring the Air Receiver Filling Time	26
7.8	Setting network pressure	27
7.9	Setting the filter regulator	28
8	Operation	
8.1	Switching on and off	29
9	Fault Recognition and Rectification	
9.1	Basic Information	30
9.2	Alarms	30
10	Maintenance	
10.1	Safety	32
10.2	Maintenance Schedule	32
10.2.1	Logging maintenance work	32
10.2.2	Regular maintenance tasks	33
10.2.3	Oil change interval	33
10.2.4	Regular service tasks	33
10.3	Air cooler maintenance	34
10.3.1	Cleaning the air cooler	34
10.4	Air filter maintenance	35
10.5	Drive Motor Maintenance	36
10.6	Checking the Oil Level	36
10.7	Topping up the compressor oil	36
10.8	Changing the Compressor Oil	37
10.9	Checking the pressure relief valve	38
10.9.1	Pressure relief valve in the collecting pipe	38
10.9.2	Air receiver pressure relief valve	39
10.10	Air Receiver	39
10.11	Venting the machine (de-pressurising)	40
10.12	Maintaining the check valve	41
10.13	Maintenance of the pressure switch unloading valve	41
10.14	Cleaning the filter regulator	42
10.15	Cylinder Head and Valves	43
10.15.1	Checking the cylinder head and valves	43
10.16	Document maintenance and service work.	44
11	Spares, Operating Materials, Service	
11.1	Note the Nameplate	45
11.2	Ordering consumable parts and operating fluids/materials	45

11.3	KAESER AIR SERVICE	45
11.4	Service Addresses	46
11.5	Spare Parts for Service and Repair	46
12	Decommissioning, Storage and Transport	
12.1	De-commissioning	47
12.2	Packing	47
12.3	Storage	48
12.4	Transporting	48
	12.4.1 Safety	48
12.5	Disposal	48
13	Annex	
13.1	Dimensional Drawing	49
13.2	Electrical Diagram	51

RAMIRENT

RAMIRENT

Fig. 1	Location of safety signs	15
Fig. 2	Machine layout	18
Fig. 3	Fitting the antivibration mounts	22
Fig. 4	Compressed air connection	22
Fig. 5	Setting network pressure	27
Fig. 6	Setting the filter regulator	28
Fig. 7	Switching on and off	29
Fig. 8	Cleaning the air cooler	34
Fig. 9	Air filter maintenance	35
Fig. 10	Checking the Oil Level	36
Fig. 11	Changing the compressor oil	37
Fig. 12	Checking the collecting pipe relief valve	38
Fig. 13	Checking pressure relief valve on the air receiver	39
Fig. 14	Venting the machine	40
Fig. 15	Cleaning the check valve	41
Fig. 16	Maintenance of the pressure switch unloading valve	42
Fig. 17	Cleaning the Filter Regulator	43
Fig. 18	Consumable parts	45

RAMIRENT

Tab. 1	The levels of danger and their meaning	2
Tab. 2	Nameplate	3
Tab. 3	Weight	3
Tab. 4	Compressor block	3
Tab. 5	Ambient Conditions	4
Tab. 6	Pressure switch setting	4
Tab. 7	Air receiver pressure relief valve setting	4
Tab. 8	Collecting pipe relief valve setting	4
Tab. 9	Sound Pressure Level	5
Tab. 10	Power and speeds	5
Tab. 11	Permissible starting frequency	5
Tab. 12	Compressor oil recommendations	5
Tab. 13	Compressor oil charge	6
Tab. 14	Connection details 230V/3/50Hz	7
Tab. 15	Connection details 400V/3/50Hz	7
Tab. 16	Network impedance	7
Tab. 17	Machine duty cycle	8
Tab. 18	Inspection intervals according to Ordinance on Industrial Safety and Health	11
Tab. 19	Safety Signs	15
Tab. 20	Information signs	16
Tab. 21	Re-commissioning after storage	25
Tab. 22	Checklist of installation conditions	25
Tab. 23	Air receiver filling time	27
Tab. 24	Changing the pressure switch setting	28
Tab. 25	Faults and remedies	30
Tab. 26	Regular maintenance tasks	33
Tab. 27	Oil change intervals	33
Tab. 28	Regular service tasks	33
Tab. 29	Logged maintenance tasks	44
Tab. 30	Consumable parts	45

RAMIRENT

1 Regarding this document

1.1 Using the Document

The service manual is part of the machine. It describes the machine as it was at the time of first delivery after manufacture.

- Keep the service manual in a safe place throughout the life of the machine.
- Pass the manual on to the next owner/user of the machine.
- Ensure that all amendments received are entered in the manual.
- Enter details from the machine nameplate and individual items of equipment in the table in chapter 2.

1.2 Further Documents

Included with this service manual are additional documents intended to assist in the safe operation of the machine:

- Certificate of acceptance / operating instructions for the pressure vessel.
- Manufacturer's declaration / declaration of conformity in accordance with applicable directives.

Missing documents can be requested from KAESER.

- Make sure all documents are complete and observe the instructions contained in them.
- Make sure you give the data from the nameplate when ordering documents.

1.3 Copyright

This service manual is protected by copyright. Any queries regarding the use or duplication of this documentation should be referred to KAESER. We would be pleased to help you in using the information to meet your unique requirements.

1.4 Symbols and Identification

1.4.1 Warnings

Warning notices indicate three levels of danger signified by the signal word.

- DANGER
- WARNING
- CAUTION



DANGER

These show the kind of danger and its source!

The possible consequences of ignoring a warning are shown here.

The word "Danger" indicates that death or severe injury can result from ignoring the instruction.

- The measures required to protect yourself from danger are shown here.

1 Regarding this document

1.4 Symbols and Identification

- Always read and comply with warning instructions.

Signal word	Meaning	Consequences of non-observance
DANGER	Warns of an imminent threat of danger	Death or serious injury may result
WARNING	Warns of possible danger	Death or serious injury are possible
CAUTION	Warns of a possibly dangerous situation	Light injuries or material damage are possible

Tab. 1 The levels of danger and their meaning

1.4.2 Other instructions and symbols



This symbol refers to particularly important information.

Material Here you will find details on special tools, operating materials or spare parts.

Precondition Here you will find conditional requirements necessary to carry out the task.
Here conditions relevant to safety are named that will help you to avoid dangerous situations.

- This symbol is placed by lists of actions comprising one stage of a task.
In lists of actions with several stages the sequence of actions is numbered.



Information referring to potential problems are identified by a question mark.

The cause is named in the help text

- ... and a remedy given.



This symbol refers to important information or measures concerning environmental protection.

2 Technical Specification

2.1 Nameplate

The machine's nameplate provides the model designation and important technical information.

➤ Enter here the nameplate data as a reference:

Features	Value
Reciprocating Compressor	
Material number	
Serial number	
Year of manufacture	
Maximum working pressure	
inlet volume	
Rated voltage	
Synchronous speed	
Rated power	(*) **
Ambient temperature	
* Power requirement at the compressor drive shaft (EN 1012-1)	
** Motor shaft output power (EN 60034-1 VDE 0530)	

Tab. 2 Nameplate

2.2 Weight

The weight indicated is the maximum weight. The actual weight depends on equipment fitted.

Model	Weight [kg]
Premium 660/70	118

Tab. 3 Weight

2.3 Compressor block

Model	Theoretical displacement [l/min]	FAD at 6 bar [l/min]	Number of cylinders
KC 630	660	440	2

Tab. 4 Compressor block

2.4 Ambient Conditions

Installation	
Maximum altitude AMSL* [m]	1000
Permissible ambient temperature [°C]	5–35

* Higher altitudes are permissible only after consultation with the manufacturer.

Tab. 5 Ambient Conditions

2.5 Pressure switch setting

Specified pressures are factory set.
Customer-specific settings may differ.

Characteristic	Value
Cut-in pressure [bar]	7
Cut-out pressure [bar]	9
Pressure differential Δp [bar]	2
Minimum setting range [bar]*	3/4

*Minimum adjustment range: Cut-in pressure/cut-out pressure

Tab. 6 Pressure switch setting

2.6 Pressure

Air receiver pressure relief valve	
Characteristic	Value
Maximum working over-pressure [bar]	10
Pressure relief valve activating pressure [bar]	11

Tab. 7 Air receiver pressure relief valve setting

Pressure relief valve in the collecting pipe	
Characteristic	Value
Maximum working over-pressure [bar]	10
Pressure relief valve activating pressure [bar]	12.5

Tab. 8 Collecting pipe relief valve setting

2.7 Sound emission

Sound power level

- in accordance with 2000/14/EG and ISO 3744

Emission sound pressure level

- calculated from the measured average sound power level (directive 2000/14/EG, Sound Measuring Standard ISO 3744) according to EN ISO 11203:1995 6.2.3d at distance $d = 1$ m, $Q_2 =$ Logarithmic surface ratio: dB.

EC type approval:

- Certificate No.: OR/2551/SZ03

Model	Sound pressure level [dB(A)]		Emission sound pressure level [dB(A)]	Logarithmic surface ratio [dB]
	Measured	Guaranteed		
Premium 660/70	91	97	77	14.6

Tab. 9 Sound Pressure Level

2.8 Motor power and speed

- Read off the enclosure protection rating from the motor nameplate and enter in the table:

Compressor block	Rated power [kW]	Synchronous speed [min ⁻¹] (50 Hz)	Degree of protection
KC 630	3.0	1500	

Tab. 10 Power and speeds

Permissible starting frequency

- Read-off the permissible starting frequency of the motor from the table below.

Rated power [kW]	Permissible starting frequency [1/h]
3.0	15

Tab. 11 Permissible starting frequency

2.9 Compressor oil recommendations

The standard compressor oil is VDL 150.

For special applications FGP oil is used and the machine carries a sticker indicating this.

Information on ordering compressor oil is found in chapter 11.

- Mark the oil that your compressor contains in the table below.

	Standard oil	Special oil
Oil type	VDL 150	FGP

* Cool to moderate ambient temperatures, low humidity, low to average duty cycle.

	Standard oil	Special oil
Application:	Standard oil for all applications except in connection with food-stuffs.	Specially for use in compressors where the air comes in direct contact with foodstuff.
maximal permissible fluid change interval in operating hours/years	1000/1*	1000/2*
Oil contained in my compressor		

* Cool to moderate ambient temperatures, low humidity, low to average duty cycle.

Tab. 12 Compressor oil recommendations

2.9.1 Compressor oil charge

Model	Total charge [l]	Topping up volume [l] (max. - min.)
KC 630	1.2	0.22

Tab. 13 Compressor oil charge

2.10 Power Supply

Basic requirements

The machine is designed for a power supply conforming to EN 60204–1 (IEC 60204–1), section 4.3. In the absence of other user-specified conditions, the limits laid down in this standard must be adhered to.

It is recommended that the supplier and user confer and agree on the basis of the EN 60204–1, Annex B.

2.10.1 Three-phase power supply

The machine requires a symmetrical three-phase power supply.

In a symmetrical three-phase supply the phase angles and voltages are all the same.

This machine may only be supplied from an earthed TN or TT three-phase supply in which the **neutral point** is earthed.

Connection to an IT supply is not permitted without taking further measures (earth leak detection, etc.).

Further information When connecting to a European 400 V/3/50 Hz power supply the requirements in chapter 2.11 are also to be observed.

See electrical diagram in 13.2.

2.10.1.1 Power supply specifications

The following conductor cross-sections (copper multicore) and fusing (industrial fuses, slow blow) are given according to VDE 0100, parts 430 and 523 (IEC 60364–4–43) for ambient temperatures from 30 °C and laying method C.



➤ The conductor cross-sections should be changed accordingly if other conditions prevail.

Other conditions would include:

- higher temperature
- other cable laying method
- cable lengths >50 m

Rated power supply: 230V±10%/3/50Hz

Model	Mains fusing [A]	Supply cable [mm ²]	Current drawn [A]
Premium 660/70	20	4 x 2.5	11.8

Tab. 14 Connection details 230V/3/50Hz

Rated power supply: 400V±10%/3/50Hz

Model	Mains fusing [A]	Supply cable [mm ²]	Current drawn [A]
Premium 660/70	16	4 x 2.5	6.8

Tab. 15 Connection details 400V/3/50Hz

2.11 Network Conditions

The machines listed in the table below are intended for use in changing locations.

No interference with other devices is to be expected with network impedance less than Z_{max} [Ohm].

In general, the maximum permissible network impedance will not be exceeded if the machine is supplied at the transfer point with a rated current of $I_{\text{äqv}}$.

2.11.1 Network conditions at 400V/3/50Hz

Model	Starts [1/h]	Z_{max} [Ω]	$I_{\text{äqv}}$ [A]
Premium 660	6	0.153	35
	12	0.110	50
	18	0.091	50

Tab. 16 Network impedance

2.12 Machine duty cycle

Calculating the cycling period:

$$\text{Cycling time} = \text{time under load} + \text{time at standstill}$$

Calculating the duty cycle:

$$\text{Duty cycle [\%]} = \frac{\text{time under load}}{\text{time under load} + \text{standstill time}} \times 100$$

Example

$$\frac{12 \text{ minutes}}{20 \text{ minutes}} \times 100 \% = 60 \%$$

The following values are valid for:

- 20 °C ambient temperature
- 30 % relative humidity
- 1013 mbar air pressure

	Permissible duty cycle ² [%]	Cycling period ¹ [min]
Premium 660/70	≤ 70	4–40

Tab. 17 Machine duty cycle

RAMIRENT

3 Safety and Responsibility

3.1 Basic Information

The machine is manufactured to the latest engineering standards and acknowledged safety regulations. Nevertheless, dangers can arise through its operation:

- danger to life and limb of the operator or third parties,
- impairments to the machine and other material assets.



DANGER

Disregard of these instructions can result in serious injury.

- Read the service manual carefully and take notice of the contents for safe machine operation.
- Use this machine only if it is in a technically perfect condition and only for the purpose for which it is intended; observe all safety measures and the instructions in the service manual.
- Immediately rectify (have rectified) any faults that could be detrimental to safety.

3.2 Specified Use

The machine is intended solely for generating compressed air for industrial use. Any other use is considered incorrect. The manufacturer is not liable for any damages that may result therefrom. The user alone is liable for any risks incurred.

- Keep to the specifications listed in this service manual.
- Operate the machine only within its performance limits and under the permitted ambient conditions.
- Do not use compressed air for breathing purposes unless it is specifically treated.
- Do not use compressed for any application that will bring it into direct contact with foodstuffs unless it is specifically treated.

3.3 Improper Use

- Never direct compressed air at persons or animals.
- Use hot cooling air for heating purposes only if there is no risk to the health of humans or animals. If necessary, hot cooling air should be treated by suitable means.
- Do not allow the machine to breath in toxic, acidic, flammable or explosive gases or vapours.
- Do not operate the machine in areas in which specific requirements with regard to explosion protection are in force.

3.4 User's Responsibilities

3.4.1 Observe statutory and universally accepted regulations.

This is, for example, nationally applied European directives and/or valid national legislation, safety and accident prevention regulations.

- Observe relevant statutory and accepted regulations during installation, operation and maintenance of the machine.

3.4.2 Qualified personnel

These are people who, by virtue of their training, knowledge and experience as well as their knowledge of relevant regulations can assess the work to be done and recognise the possible dangers involved.

Authorised operators possess the following qualifications:

- are of legal age,
- are conversant with and adhere to the safety instructions and sections of the service manual relevant to operation,
- have received adequate training and authorisation to operate electrical and compressed air devices.

Authorised installation and maintenance personnel have the following qualifications:

- are of legal age,
 - have read, are conversant with and adhere to the safety instructions and sections of the service manual applicable to installation and maintenance,
 - are fully conversant with the safety concepts and regulations of electrical and compressed air engineering,
 - are able to recognise the possible dangers of electrical and compressed air devices and take appropriate measures to safeguard persons and property,
 - have received adequate training and authorisation for the safe installation and maintenance on this equipment.
- Ensure that operating, installation and maintenance personnel are qualified and authorised to carry out their tasks.

3.4.3 Adherence to inspection schedules and accident prevention regulations

The machine is subject to local inspection schedules.

Examples of German operation

- Recurring inspections according to BGR 500, chapter 2.11.
The user must ensure that, for machines with motor power above 0.5 kW, safety devices are checked for function as required or at least annually.

- Keep to inspection intervals in accordance with the Ordinance on Industrial Safety and Health with maximum intervals as laid down in §15.



The inspection intervals are laid down in the technical specification for the air receiver. Inspection intervals are dependent on the pressure/volume product of the air receiver, i.e. max permissible pressure (PS) in bar, times the receiver volume (V) in litres.

Example: volume $V = 90$ litres, max. permissible pressure $PS = 11$ bar; pressure/volume product = 990.

Inspection	Inspection interval	Inspecting authority
Installation and equipment inspection	Before commissioning if pressure $PS \times \text{volume } V \leq 200$	Competent person (e. g. KAESER Service Technician)
	Compressors with type approval inspection (Ordinance on Industrial Safety and Health, annex 5 no. 25) $PS \times V \leq 1000$	Competent person (e. g. KAESER Service Technician)
	Before commissioning if $PS \times V > 200$	Approved supervisory body
Internal inspection	Every 5 years after installation or the last inspection if $PS \times V \leq 1000$	Competent person (e. g. KAESER Service Technician)
	Every 5 years after installation or the last inspection if $PS \times V > 1000$	Approved supervisory body
Strength test	Every 10 years after installation or the last inspection if $PS \times V \leq 1000$	Competent person (e. g. KAESER Service Technician)
	Every 10 years after installation or the last inspection if $PS \times V > 1000$	Approved supervisory body

* The inspection interval is determined by the user in consultation with the approved supervisory body. The responsible body is to be notified not later than 6 months after the inspection carried out before commissioning (if pressure x volume $V > 1000$). Intervals given are the maximum in each case.

Tab. 18 Inspection intervals according to Ordinance on Industrial Safety and Health

3.5 Dangers

Basic Information

Information concerning the various forms of danger that can arise during machine operation are found here.

Basic safety instructions are found in this service manual at the beginning of each chapter in the section entitled 'Safety'.

Warning instructions are found before a potentially dangerous task.

3.5.1 Safely dealing with sources of danger

Information concerning the various forms of danger that can arise during machine operation are found here.

Electricity

- Allow only qualified and authorised electricians or trained personnel under the supervision of a qualified and authorised electrician to carry out work on electrical equipment according to electrical engineering regulations .
- Before every start-up, the user must make sure there is adequate protection against electric shock from direct or indirect contact.
- Before starting any work on electrical equipment:
Switch off and lock out the power supply disconnecting device and check that no voltage is present.
- Switch off any external power sources.
These could be connections to floating relay contacts or electrical machine heating, for example.
- Use fuses corresponding to machine power.
- Check regularly that all electrical connections are tight and in order.

Forces of compression

Compressed air is contained energy. Uncontrolled release of this energy can cause serious injury or death. The following information concerns work on components that could be under pressure.

- Close shut-off valves or otherwise isolate the machine from the air main to ensure that no compressed air can flow back into the machine.
- Vent all pressurized components and chambers completely.
- Do not carry out welding, heat treatment or mechanical modifications to pressurized components (e.g. pipes and vessels) as this influences the component's resistance to pressure.
The safety of the machine is then no longer ensured.

Compressed air quality

- Never directly inhale compressed air.
- Use appropriate systems for air treatment before using the compressed air from this machine as breathing air and/or for the processing of foodstuffs.
- Use compressor oil compatible with foodstuffs if compressed air can come into contact with them.

Spring force

Springs under tension or compression represent contained energy. Uncontrolled release of this energy can cause serious injury or death.

The non-return valve is spring loaded.

- Do not open or dismantle the valve.

Rotating components

Touching the fan while the machine is running can result in serious injury.

- Do not open the enclosure while the machine is switched on.
- Switch off and lock out the power supply disconnecting device and check that no voltage is present.

- Wear close-fitting clothes and a hair net if necessary.
- Make sure all covers and safety guards are in place and secured before starting.

Heat

- Avoid contact with hot components.
These include, for example, compressor blocks, compressed air pipes, coolers, motors and machine heaters.
- Wear protective clothing.
- If welding is carried out on or near the machine, take adequate measures to prevent sparks or heat from igniting oil vapours or parts of the machine.

Noise

- Operate the machine only with full soundproofing.
- Wear hearing protection if necessary.
The pressure relief valve blowing off can be particularly loud.

Operating materials

- Strictly forbid fire, open flame and smoking.
- Follow safety regulations when dealing with lubricants and chemical substances.
- Avoid contact with skin and eyes.
- Do not inhale oil mist and vapours.
- Do not eat or drink while handling cooling and lubricating fluids.
- Keep suitable fire extinguishing agents ready for use.
- Use only KAESER approved operating materials.

Unsuitable spare parts

- Use only spare parts approved by the manufacturer for use in this machine.
Unsuitable spare parts compromise the safety of the device.
- Use only genuine KAESER pressure components.

Conversion or modification of the machine

- Do not permit conversion or modification of the machine as this can compromise function and safe working.

Extension or modification of the compressed air system

- Extension or modification of the compressor station:
Check the blow-off capacity of pressure relief valves on air receivers and compressed air lines before installing any new machines.
- If the blow-off capacity is insufficient:
Install pressure relief valves with larger blow-off capacity.

3.5.2 Safe machine operation

Information on safe conduct when handling the machine is found here.

Transport

- Use suitable lifting gear that conforms to local safety regulations.
- Allow transport only by personnel trained in the safe movement of goods.
- Attach lifting gear only to suitable lifting points.
- Note the centre of gravity to avoid danger of the machine tipping over.
- Make sure the danger zone is clear of personnel.

Installation

- Install the machine in a suitable compressor room.
- If installed outdoors, the machine must be protected from frost, direct sunlight, dust, rain and splashing water.
- Do not operate in areas in which specific requirements with regard to explosion protection are in force.
For instance, the requirements of ATEX directive 94/9/EC "Equipment and Protective Systems intended for use in Potentially Explosive Atmospheres".
- Ensure adequate ventilation.
- Ensure that required ambient conditions are maintained with regard to:
 - Ambient temperature and humidity
 - Clean inlet air with no damaging contaminants.
 - Inlet air free of explosive or chemically unstable gases or vapours.
 - inlet air free of acid/alkaline forming substances, particularly ammonia, chlorine or hydrogen sulphide.
- Do not position the machine in warm exhaust air from other machines.
- Ensure accessibility so that all work on the machine can be carried out without danger or hindrance.

Decommissioning, storage, disposal

- Drain out fluids and dispose of according to environmental regulations. These include, for example, lubricating oil and compressor oil.
- Dispose of the machine in accordance with local environmental regulations.

3.5.3 Organisational Measures

- Designate personnel and their responsibilities.
- Give clear instructions on reporting faults and damage to the machine.
- Give instructions on fire reporting and fire-fighting measures.

3.6 Safety Devices

Various safety devices ensure safe working with the machine.

- Do not change, bypass or disable safety devices.
- Check safety devices for correct function regularly.

- Do not remove or obliterate labels and notices.
- Ensure that labels and notices are clearly legible.

Further information More information on safety devices is contained in chapter 4, section 4.3.

3.7 Safety Signs

The diagram shows the positions of safety signs on the machine. The table lists the various safety signs used and their meanings.








Fig. 1 Location of safety signs

Item	Sign	Meaning
1		<p>Danger of fatal injury from electric shock!</p> <ul style="list-style-type: none"> ➤ Before starting any work on electrical equipment: Switch off and lock out the power supply disconnecting device and check that no voltage is present.
2		<p>Hot surface!</p> <p>Risk of burns caused by contact with hot components</p> <ul style="list-style-type: none"> ➤ Do not touch the surface. ➤ Wear long-sleeved garments (not synthetics such as polyester) and protective gloves.
3		<p>Risk of injury caused by an automatic machine start!</p> <ul style="list-style-type: none"> ➤ Switch off and lock out the power supply disconnecting device and check that no voltage is present before opening any machine enclosure or guard.

Tab. 19 Safety Signs

3.8 Information signs

The table lists the various information signs used and their meanings.

Sign	Meaning
	Take heed of safety instructions and the service manual.
	Maintain the air filter regularly.
	Drain the condensate daily. If automatic condensate drainage is fitted, check the function at regular intervals.
	Check the oil level regularly and change the oil at the correct intervals.

Tab. 20 Information signs

3.9 In Emergency

3.9.1 Fire fighting

Suitable extinguishing agents

- Foam
- Carbon dioxide
- Sand or earth

Unsuitable or unsafe extinguishing agents

- Strong jet of water

1. Keep calm.
2. Give the alarm.
3. Switch off the power supply disconnecting device, if possible.
4. Move to safety
 - Warn persons in danger
 - Help incapacitated persons
 - Close the doors
5. Try to extinguish the fire if you have the skill to do so.

3.9.2 Remove any compressor oil from your person.

- Eye contact
Rinse thoroughly with lukewarm water and seek medical assistance.
- Skin contact
Wash off immediately.

3.10 Warranty

This service manual contains no independent warranty commitment. Our general terms and conditions of business apply with regard to warranty.

A condition of our warranty is that the machine is used for the purpose for which it is intended under the conditions specified.

Due to the multitude applications for which the machine is suitable the obligation lies with the user to determine its suitability for his specific application.

In addition, we accept no warranty obligation for:

- the use of unsuitable parts or operating materials,
- unauthorised modifications,
- incorrect maintenance,
- incorrect repair.

Correct maintenance and repair includes the use of original spare parts and operating materials.

- Obtain confirmation from KAESER that your specific operating conditions are suitable.

3.11 Environmental Protection

- Store and dispose of operating materials and replaced parts in accordance with local environmental protection regulations.
- Observe relevant national regulations.
This applies particularly to parts contaminated with compressor oil.
- Drain condensate into a receptacle.
Obtain advice from KAESER on suitable drains and receptacles.



- Do not allow operating materials to escape to the environment or into the sewage system.

4 Design and Function

4.1 Outline of the machine

4.1.1 Function




Fig. 2 Machine layout

- | | |
|--------------------------------------|---------------------------------------|
| ① Air filter | ⑩ Oil filler port |
| ② Compressor block | ⑪ Oil drain plug |
| ③ Check valve | ⑫ Compressed air connection |
| ④ Air receiver | ⑬ Condensate drain |
| ⑤ Air receiver pressure relief valve | ⑭ Arrow showing direction of rotation |
| ⑥ Pressure switch | ⑮ Collecting pipe relief valve |
| ⑦ Electric motor | ⑯ Pressure regulator |
| ⑧ Air receiver pressure gauge | ⑰ Working pressure gauge |
| ⑨ Oil level sight glass | ⑱ Compressed air cooler |

Machine

Atmospheric air is drawn through a filter into the compression chamber of the block. The air is drawn in during the downward stroke of the piston. It is compressed during the upward stroke.

The compressed air flows through the cooler, giving up most of its heat, then via the check valve into the air receiver. The check valve prevents reverse flow of compressed air from the air receiver to the compressor block.

4.2 Operating modes and control modes

4.2.1 Operating modes

There are two operating modes:

- **LOAD:**
The compressor block delivers compressed air.
The compressor motor runs under full load.
- **STANDSTILL**
No air is compressed. A check valve prevents compressed air flowing back into the compressor chamber. The compressor block is vented.
The drive motor is stopped.

4.2.2 Control modes

- **Pressure switch:**
According to the set switching points, the pressure switch toggles the machine between the LOAD and STANDSTILL operating modes.

4.3 Safety Devices

The following safety devices are provided and may not be modified in any way.

Pressure relief valve

The pressure relief valve protects the machine from excessive pressure. It is preset at the factory.

Check valve

The check valve prevents the flow of compressed air from the air receiver back to the compressor block when the machine is stopped.

Enclosures and covers

Enclosures and covers over moving parts and electrical connections protect against accidental contact.

5 Installation and Operating Conditions

5.1 Safety

- Strictly forbid fire, open flame and smoking.
- If welding is carried out on or near the machine, take adequate measures to prevent sparks or heat from igniting oil vapours or parts of the machine.
- The machine is not explosion-proof:
Do not operate in areas in which specific requirements with regard to explosion protection are in force.
For instance, the requirements of ATEX directive 94/9/EC "Equipment and Protective Systems intended for use in Potentially Explosive Atmospheres".
- Ensure that required ambient conditions are maintained with regard to:
 - ambient temperature and humidity,
 - clean inlet air with no damaging contaminants,
 - inlet air free of explosive or chemically unstable gases or vapours,
 - inlet air free of acid/alkaline forming substances, particularly ammonia, chlorine or hydrogen sulphide.
- Keep suitable fire extinguishing agents ready for use.

5.2 Installation conditions

Precondition The floor must be level, firm and capable of bearing the weight of the machine.

- If installed outdoors, the machine must be protected from frost, direct sunlight, dust and rain.
- Ensure adequate lighting so that all work on the machine can be carried out without danger or hindrance.

6 Installation

6.1 Safety

Here you will find instructions for safe initial start-up of the machine.
Warning instructions are located before a potentially dangerous task.

Basic safety instructions

1. Follow the instructions in chapter "Safety and Responsibility".
2. Have installation work carried out by authorized installation personnel only.
3. Before switching on, make sure that:
 - no personnel are working on the machine,
 - all panels are in place and secured.

Working on live components

1. Work on electrical equipment may only be carried out by authorized electricians.
2. Switch off and lock out the power supply disconnecting device and check that no voltage is present.

Working on pressure systems

1. Close shut-off valves or otherwise isolate the machine from the compressed air system to ensure that no compressed air can flow back into the machine.
2. Vent all pressurized components and chambers completely.
3. The pressure gauge on the machine must read 0 bar.

Working on the drive system

1. Switch off and lock out the power supply disconnecting device and check that no voltage is present.
2. Replace and secure all enclosure panels before starting the machine.

Further information See chapter 3.4.2 regarding authorized personnel.
See chapter 3.5 regarding hazards and their avoidance.

6.2 Reporting Transport Damage

1. Check the machine for visible and hidden transport damage.
2. Inform the carrier and the manufacturer in writing of any damage without delay.

6.3 Fitting the Antivibration Mounts


Antivibration mounts appropriate to the machine are delivered with the machine but not fitted.



CAUTION

There is a danger of tipping because of the centre of gravity and weight of the machine.

- Use slings to lift the machine.



06-P0028


Fig. 3 Fitting the antivibration mounts

- ① Antivibration mount
- ② Hexagonal nut

- Remove the wooden frame from the air receiver feet.
- Secure the antivibration mounts to the feet with hexagon nuts.

6.4 Compressed Air Connection

Precondition The compressed air system is vented completely to atmospheric pressure.



06-P0072

Fig. 4 Compressed air connection

- ① Compressed air connection

- Make the connection to the air main by a flexible hose.



In addition, on versions with a hose reel the air connection can be made to the compressed air hose.

6.5 Connecting the Power Supply

Machines with a total power rating up to 3 kW and rated current up to 16 amps may be plugged into the mains supply.

Precondition The machine is disconnected from all power supply phases.
The disconnecting device is locked in the off position.
A check has been made that no voltage is present.

1. Carry out safety measures as stipulated in relevant regulations (IEC 364, for example or DIN VDE 0100) and in national accident prevention regulations (BGV A3 in Germany). In addition, observe the regulations of the local electricity supplier.
2. Check the permitted disconnect time for the overload protection cut-out if a fault arises.
3. Use wire conductor dimensions and fuse ratings in accordance with local regulations (VDE 0100 parts 430 and 523 in Germany, for example).

**DANGER**

Danger of fatal injury from electric shock!

- Switch off and lock out the power supply disconnecting device and check that no voltage is present.

4. Connect the machine to the power supply.

RAMIRENT

7 Initial Start-up

7.1 Safety

Here you will find instructions for safe initial start-up of the machine.
Warning instructions are located before a potentially dangerous task.

Basic safety instructions

1. Follow the instructions in chapter "Safety and Responsibility".
2. Have the initial start-up carried out by authorized installation personnel only.
3. Before switching on, make sure that:
 - no personnel are working on the machine,
 - all panels are in place and secured.

Working on live components

1. Work on electrical equipment may only be carried out by authorized electricians.
2. Switch off and lock out the power supply disconnecting device and check that no voltage is present.

Working on pressure systems

1. Close shut-off valves or otherwise isolate the machine from the compressed air system to ensure that no compressed air can flow back into the machine.
2. Vent all pressurized components and chambers completely.
3. The pressure gauge on the machine must read 0 bar.

Working on the drive system

1. Switch off and lock out the power supply disconnecting device and check that no voltage is present.
2. Replace and secure all enclosure panels before starting the machine.

Further information See chapter 3.4.2 regarding authorized personnel.
See chapter 3.5 regarding dangers and their avoidance.

7.2 Instructions to be observed before commissioning or recommissioning

Incorrect or improper initial start-up can cause damage to the machine.

7 Initial Start-up

7.3 Checking positioning and operating conditions

- Only a competent technician may carry out initial start-up.

Special measures for start-up after storage

Storage period longer than	Action
12 months	<ul style="list-style-type: none"> ➤ Change the Compressor Oil ➤ Have the motor bearings checked by an authorized KAESER Service Technician.
36 months	<ul style="list-style-type: none"> ➤ Have the overall technical condition checked by an authorized KAESER Service Technician.

Tab. 21 Re-commissioning after storage

7.3 Checking positioning and operating conditions

- Check and confirm all the items in the checklist before first start-up of the machine.

To be checked	See chapter	Confirmed?
➤ Are the operators fully conversant with safety regulations?	–	
➤ Have all the positioning conditions been fulfilled?	5	
➤ Does the power supply conform to the specifications on the name-plate?	2.1	
➤ Are the power supply cable conductor cross-sections and fuse ratings adequate?	2.10	
<ul style="list-style-type: none"> ➤ Have all electrical connections been checked for tightness? ➤ (The check must be repeated after 50 operating hours). 	–	
➤ Is the connection to the air main made with a flexible hose?	6.4	
<ul style="list-style-type: none"> ➤ Is there sufficient oil in the crankcase? (oil level in the red zone of the sight glass) ➤ (The oil must be changed after 50 operating hours) 	10.6	
➤ Motor protection device adjusted correctly with regard to the power supply?	7.4	

Tab. 22 Checklist of installation conditions

7.4 Motor overload protection

The machine should only be operated with a correctly adjusted motor overload protection switch to protect the motor from overloading.

A motor overload protection switch that is set too high provides no protection. Incorrect setting can lead to irreparable damage.

7.4.1 Motor protection setting with direct online starting

The machine starts directly and is controlled by a pressure switch. The pressure switch switches the machine on and off as necessary to hold pressure within the set limits.



The motor overload protection switch setting can be 10 % higher than the rated motor current to prevent it from being triggered by voltage fluctuations, temperature influences or component tolerances.

1. Read the rated motor current from the nameplate and calculate the correct protection setting.
2. Check the motor overload protection switch setting.
3. Adjust the protection setting, if necessary.
4. Switch on the compressor at the pressure switch.



The machine is shut down by the motor overload protection switch?

- Allow the motor to cool down.
- Switch the machine on again.

Further information See chapter 8.

7.5 Checking direction of rotation

The machine is designed for a clockwise phase sequence.

Ideally, the direction of phase rotation should be measured with a phase sequence meter. Alternatively, start the machine very briefly and observe the direction of rotation of the motor cooling fan.

1. Check the direction of phase rotation with a phase sequence meter.
2. If the direction is incorrect, reverse supply phases L1 and L2.



You have no phase sequence meter?

- Switch the machine on and off again the moment the drive motor begins to turn.
- Check the direction of rotation against the arrow on the fan cowl.
- If the direction is incorrect, reverse L1 and L2.

7.6 Starting the machine for the first time

Precondition No personnel are working on the machine

- Switch on the mains isolating device and the pressure switch.
The machine switches to LOAD and delivers compressed air.



- Keep an eye on the machine during the first few hours of operation to ensure that it is operating correctly.

Carry (or have carried) out the following tasks after the first 50 operating hours:

- Check that all electrical connections are tight.
- Change the compressor oil.

7.7 Measuring the Air Receiver Filling Time

Measuring the time the compressor takes to fill the air receiver when new can be useful in checking the machine's performance at a later date.

Precondition Machine at operating temperature.

1. Disconnect all air consumers.
2. Switch on the power supply disconnecting device.

3. Measure the air receiver filling time.
4. Enter the filling time and machine model in the table.

Machine model	Receiver filling time from 3–8 bar [min/s]

Tab. 23 Air receiver filling time

7.8 Setting network pressure

The network pressure (working pressure) is set at the factory.

A pressure adjustment is possible to suit individual operating conditions.



The pressure setting can only be adjusted if a pressure switch is fitted and under pressure.
Maximum pressure differential: 20% of the maximum operating pressure of the air receiver.




Fig. 5 Setting network pressure

- | | |
|---|---|
| <ol style="list-style-type: none"> ① Canopy ② Screw ③ Adjusting screw for upper pressure (cut-out) | <ol style="list-style-type: none"> ④ Pressure differential adjusting screw ⑤ «ON/OFF»switch for direct online start |
|---|---|



DANGER

Electric shock!

Contact with live components can cause serious injury or death.

- Switch off and lock out the power supply disconnecting device and check that no voltage is present.
- Work carefully.

1. Remove the screws securing the cover.
2. Remove the cover.



WARNING

Compressed air!

- Compressed air and devices under pressure can injure or cause death if the contained energy is released suddenly.
- Do not loosen or open any component that is still under pressure.

3. Adjust the pressure switch setting according to the table.

Adjusting the setting	Function
Cut-out pressure is to be increased.	➤ Turn the adjusting screw ③ clockwise (direction: +).
Cut-out pressure is to be decreased.	➤ Turn the adjusting screw ③ anticlockwise (direction: -).
The pressure differential between cut-in and cut-out pressure is to be increased.	➤ Turn the adjusting screw ④ clockwise (direction: +).
The pressure differential between cut-in and cut-out pressure is to be decreased.	➤ Turn the adjusting screw ④ anticlockwise (direction: -).

Tab. 24 Changing the pressure switch setting

4. Replace the cover.



The motor starting frequency is to be reduced?

- Increase the difference between cut-in and cut-out pressure.
- Add a larger air receiver downstream to increase buffer capacity.

Further information The duty cycle of the machine is given in chapter 2.12.
See table 11 for the machine starting frequency.

7.9 Setting the filter regulator

The working pressure of a compressor fluctuates according to the limits set on the pressure switch. The filter regulator unit reduces this fluctuation to the required pressure and holds it constant.

Precondition The machine is isolated from the air consumers.




Fig. 6 Setting the filter regulator

- | | |
|-------------------|-------------------------------------|
| ① Adjusting screw | ③ Pressure gauge (working pressure) |
| ② Locknut | ④ Compressed air outlet |

1. Start the machine and run it up to cut-out pressure.
2. To relieve the filter regulator, turn the adjusting screw anticlockwise until no more resistance is felt.
3. Turn the adjusting screw clockwise until the pressure gauge reads the required working pressure.
4. Tighten the locknut to fix the adjusting screw in position.

8 Operation

8.1 Switching on and off

Always switch on and off by means of the pressure switch.

Precondition A power supply disconnecting device has been installed by the user.
No personnel are working on the machine.
All panels are in place and secured.
The machine temperature is at least +3° C.




DANGER

Automatic restart!

Serious injury is possible. The machine restarts automatically when power is restored after a power cut.

- Make sure that no one is working on the machine.



08-P0093

Fig. 7 Switching on and off
① «ON/OFF» switch

Switching on



WARNING

Compressed air!

Serious injury is possible.

- Never direct compressed air at persons or animals.
- Make sure that no one is working on the machine.

1. Switch on the power supply isolating device.
2. Switch on the compressor at the pressure switch.

Result The machine starts as soon as network pressure is lower than the cut-out pressure.

Switching off

1. Switch the machine off at the pressure switch.
2. Switch off and lock out the main supply isolator.

9 Fault Recognition and Rectification

9.1 Basic Information

The alarm indications valid for your machine are dependent on the individual equipment.

1. Do not attempt fault rectification measures other than those given in this manual.
2. Inform KAESER Service if the fault cannot be rectified by the measures suggested.

9.2 Alarms

Fault	Possible cause	Action
Machine does not start.	Fuse blown or circuit breaker tripped.	Check motor connections and fuses (circuit breakers).
	Defective pressure switch contact.	Replace pressure switch.
	Motor overload protection has tripped.	Allow the motor to cool down.
	Compressor motor defective: bearing damage or winding short-circuit.	Contact KAESERservice.
	Compressor block defective.	Contact KAESERservice.
Machine starts with difficulty.	Venting valve on the pressure switch not opening.	Clean or replace the venting valve.
	Bearing damage.	Contact KAESERservice.
	Piston seized due to insufficient or incorrect oil.	Contact KAESERservice.
	Fault in the power supply.	Check power supply.
	Oil level too high.	Drain out some oil.
Machine runs hot.	Ambient temperature too high.	Reduce the ambient temperature.
	Wrong direction of rotation.	Swap the L1 and L2 connections to the drive motor.
	Fan cannot draw air freely.	Ensure unrestricted flow of air to the fan.
	Valve plate leaking air or coked.	Check or clean the valve plate.
	Outlet valve reed broken.	Replace valve plate.
Motor overload protection trips out after a short time.	Fault in the power supply.	Check power supply.
	Motor fault.	Contact KAESERservice.
Motor overload protection trips out after a long time.	Current too high because of low supply voltage.	Check power supply cable conductor cross-sections. Check and tighten connection terminals.

Fault	Possible cause	Action
The machine runs continuously but maximum pressure is not reached.	Air filter clogged.	Clean or change the air filter.
	Valve plate leaking air or coked.	Check or clean the valve plate.
	Outlet valve reed broken.	Replace valve plate.
	Machine leaks air.	Seal leak or replace leaking part.
	Leakage from an air consumer connected to the air system.	Check possible leakage points.
	The air demand is greater than the machine's air delivery capacity.	Use a larger machine.
Machine cuts in and out too often.	Air receiver filled with condensate.	Drain condensate.
The machine switches off and air escapes from the venting valve.	Check valve is defective.	Replace the check valve.
The venting valve loses air while the machine is running.	The venting valve is not closing.	Clean or replace the venting valve.
The pressure switch does not vent after switching off.	Venting valve dirty.	Clean or replace the venting valve.
Air leaks from the pressure switch while the machine is running.	Defective switch diaphragm.	Replace the pressure switch.
	The venting valve is not closing.	Clean or replace the venting valve.
Whistling sound from the cylinder head.	Cylinder head fixing screws loose. Gasket defective.	Tighten the cylinder head fixing screws. Replace gasket.
The pressure relief valve blows off before the cut-out pressure is reached.	Pressure switch incorrectly set.	Check pressure switch setting.
	Valve spring defective.	Replace the pressure relief valve.
	Dirt or foreign bodies on the valve seat.	Let the pressure relief valve blow off briefly.
Pressure relief valve on the air cooler blows off prematurely.	Cooler clogged. Cooler pipe coked.	Clean the radiator.
Machine uses too much oil.	Viscosity too low.	Fill with oil specified in the service manual.
	Crankcase venting defective.	Clean or renew the crankcase vent.
	Piston rings worn or broken.	Contact KAESERservice.
Piston rings already worn or damaged after only a short operating period.	Dirty oil.	Fit finer air inlet filter.

Tab. 25 Faults and remedies

10 Maintenance

10.1 Safety

Follow the instructions below to ensure safe machine maintenance.

Warning instructions are located before a potentially dangerous task.

Basic safety instructions

1. Follow the instructions in chapter "Safety and Responsibility".
2. Maintenance work may only be carried out by authorized personnel.
3. Before switching on, make sure that:
 - no personnel are working on the machine,
 - all panels are in place and secured.

Working on live components

1. Work on electrical equipment may only be carried out by authorized electricians.
2. Switch off and lock out the power supply disconnecting (isolating) device and check that no voltage is present.

Working on pressure systems

1. Close shut-off valves or otherwise isolate the machine from the compressed air system to ensure that no compressed air can flow back into the machine.
2. Vent all pressurized components and chambers completely.
3. The pressure gauge on the machine must read 0 bar.

Working on the drive system

1. Switch off and lock out the power supply disconnecting (isolating) device and check that no voltage is present.
2. Replace and secure all enclosure panels before starting the machine.

Further information See chapter 3.4.2 regarding authorized personnel.
See chapter 3.5 regarding dangers and their avoidance.

10.2 Maintenance Schedule

10.2.1 Logging maintenance work



- The maintenance intervals given are those recommended for average operating conditions.
- Adjust the maintenance intervals with regard to local installation and operating conditions.
 - Keep a log of all maintenance and service work.
This enables the frequency of individual maintenance tasks and deviations from our recommendations to be determined.

Further information A prepared list is provided in chapter 10.16.

10.2.2 Regular maintenance tasks

- When operating conditions are unfavourable (e.g. dusty atmosphere) or when the equipment is in constant use, maintenance tasks must be carried out more frequently (shorter intervals).

Interval	Maintenance task	See chapter
Daily or every 24 operating hours	Check the oil level.	10.6
	Drain off condensate from the receiver.	10.10
	Drain condensate from the filter regulator.	10.14
Annually	Carry out air filter maintenance	10.4
	Maintain the check valve	10.12
	Check that all electrical connections are tight.	–
	Check the pressure relief valve	10.9
Variable, see table 27	Change the oil.	10.8

h = operating hours

Tab. 26 Regular maintenance tasks

10.2.3 Oil change interval

Duty cycles and ambient conditions are important criteria for the number and length of the oil change intervals.



Advice can be obtained from KAESER Service on determining suitable changing intervals.

- Check operating conditions and adjust intervals as necessary; log the results in table 27 for future reference.

Compressor oil	Maximum permissible oil change interval [operating hours/years]	
	Favourable operating conditions*	My operating conditions
VDL 150	1000/1	
FGP	1000/2	

* Cool to moderate ambient temperatures, low humidity, low to average duty cycle.

Tab. 27 Oil change intervals

10.2.4 Regular service tasks

- Only an authorised KAESER Service Technician should carry out service work.
- When operating conditions are unfavourable (e.g. dusty or humid atmosphere) or when the equipment is in constant use, have the service work carried out more frequently (shorter intervals).

Interval	Service task
Every 2 years at least	Change the air filter element
Up to 3000 h	Have cylinder head and valves checked.

h = operating hours

Interval	Service task
Up to 12,000 h	Have the machine generally overhauled.
up to 12,000 h, every three years at the latest	Have motor bearings checked.

h = operating hours

Tab. 28 Regular service tasks

10.3 Air cooler maintenance




Clogging causes overheating and machine damage.

Regular cleaning ensures reliable cooling of the machine and the compressed air. The frequency is mainly dependent on local operating conditions.

Material Brush
Vacuum cleaner
Face mask (as required)

Precondition The supply disconnecting device is switched off, the device is locked off, a check has been made that no voltage is present. The machine has cooled down.



10-P0091

Fig. 8 Cleaning the air cooler

- ① Compressed air cooler
- ② Brush

10.3.1 Cleaning the air cooler

Do not use sharp objects to clean the air cooler. It could cause damage.

Avoid creating clouds of dust.

- Dry brush the air cooler and safety screen using a vacuum cleaner to suck up the dirt.



The air cooler can't be cleaned thoroughly?

- Have stubborn clogging removed by an authorized KAESER Service Technician.

10.4 Air filter maintenance

The air filter contains a filter element that can be washed but not removed.

Material Compressed air for blowing out
Solvent cleaner
Cleaning cloths
Spares as required

Precondition The supply disconnecting device is switched off,
the device is locked off,
a check has been made that no voltage is present.
The machine has cooled down.




Fig. 9 Air filter maintenance

- | | |
|---------------------|------------------|
| ① Air filter | ④ Retaining clip |
| ② Inlet air opening | ⑤ Cover |
| ③ Filter element | |

1. Unscrew the air filter.
2. Release the retaining clip and take off the cover.
3. Blow out the cover and filter element with dry compressed air (< 5 bar).
4. Clean the housing and sealing faces.
5. Wet the filter element lightly with oil after cleaning.



If the filter element is heavily clogged, clean with a solvent-based fluid or steam blaster. Observe safety regulations.

Replace the air filter if it has already been cleaned a number of times.

6. Position the cover over the element and close the retaining clips.
7. Mount the air filter again.



The filter air inlet must face downwards.

8. Switch on the power supply disconnecting device.

10.5 Drive Motor Maintenance

The drive motor bearings are permanently greased and need no re-greasing.

- Have the motor bearings checked during service.

10.6 Checking the Oil Level

The oil level can be read off on the oil sight glass.

Precondition The machine is shut down.




Fig. 10 Checking the Oil Level

- ① Oil filler and crankcase vent
- ② Oil sight glass

- Read off the oil level daily and before each start-up.

Result Top up when the compressor oil level falls to the minimum mark.

10.7 Topping up the compressor oil

Material Compressor oil

Precondition The supply disconnecting device is switched off, the device is locked off, a check has been made that no voltage is present. The machine has cooled down.



CAUTION

The machine can be damaged by unsuitable oil.

- Never mix different types of oil.
- Never top up with a different type of oil to that already used in the machine.

The type of compressor oil used is listed in table 12.

1. Remove the crankcase vent from the oil filler.
2. Top up to bring the oil to the correct level.

3. Replace the crankcase vent.
4. Start the machine and check the oil level again after about 2 minutes, topping up again, if necessary.
5. Switch off the machine and check visually for leaks.

10.8 Changing the Compressor Oil

The initial charge of oil should be changed as specified in the table 26. Drain the oil completely from the compressor block.



Change the oil immediately if it becomes milky white. This means there is condensate in it. Contact KAESER Service if condensate is detected in the oil.

Material Compressor oil
Oil receptacle


Precondition Machine at operating temperature.
The power supply disconnecting device is switched off.
The disconnecting device is locked in the off position.
A check has been made that no voltage is present.



CAUTION

Danger of burning from hot components and scalding from escaping oil.

- Wear long-sleeved clothing and gloves.



10-P0096

Fig. 11 Changing the compressor oil

- ① Oil filler port
- ② Oil sight glass
- ③ Oil drain plug

Draining the oil

1. Remove the crankcase vent from the oil filler.
2. Position the oil receptacle.
3. Remove the drain plug and allow oil to drain into the receptacle.
4. Replace the drain plug after making sure the gasket is not damaged.



Dispose of the old oil in accordance with valid environmental protection regulations.

Filling with oil

1. Fill with new oil to the maximum mark on the oil sight glass.
2. Replace the crankcase vent.
3. Start the machine and check the oil level again after about 2 minutes, topping up if necessary.
4. Switch off the machine and visually check for leaks.

10.9 Checking the pressure relief valve

- To check the valve activating pressure, it must be removed from the machine by a KAESER Service Technician and installed in a test rig.

Further information See chapter 2.6 for the activating pressure of the valve.

10.9.1 Pressure relief valve in the collecting pipe


To prevent the relief valve from sticking, activate it at regular intervals or at least once a year.



The valve opens to protect the machine if the maximum permissible working pressure is exceeded.

- Never operate the machine without a correctly functioning pressure relief valve.
- Do **not** adjust the pressure relief valve.

Precondition Machine running under LOAD.



10-P0131

Fig. 12 Checking the collecting pipe relief valve

- ① Pressure relief valve in the collecting pipe
- ② Knurled knob



WARNING

The pressure relief valve may blow off at any time!
Excessive noise is caused when the pressure relief valve blows off!
Injury from flying particles!

- Wear ear and eye protection.
- Work carefully.

1. Turn the knurled knob on the pressure relief valve anticlockwise until air blows off.
2. Then turn the knurled knob back to its original position.

Result The machine can now be started.



Pressure relief valve does not blow off?

- Have the defective relief valve replaced by KAESER Service.

10.9.2 Air receiver pressure relief valve

To prevent the relief valve from sticking, activate it at regular intervals or at least once a year.



The valve opens to protect the machine if the maximum permissible working pressure is exceeded.

- Never operate the machine without a correctly functioning pressure relief valve.
- Do **not** adjust the pressure relief valve.

Precondition The machine is switched off under LOAD, the power supply isolating device is locked off, a check has been made that no voltage is present.



10-P0097

Fig. 13 Checking pressure relief valve on the air receiver

- ① Pressure relief valve
- ② Knurled knob



WARNING

The pressure relief valve may blow off at any time!
Excessive noise is caused when the pressure relief valve blows off!
Injury from flying particles!

- Wear ear and eye protection.
- Work carefully.

1. Close the user's shut-off valve between the machine and the air distribution network.
2. Turn the knurled knob on the pressure relief valve anticlockwise until air blows off.
3. Then turn the knurled knob back to its original position.
4. Open the user's shut-off valve between the machine and the air distribution network.

Result The machine can now be started.



Pressure relief valve does not blow off?

- Have the defective relief valve replaced by KAESER Service.

10.10 Air Receiver

Pressure vessels must be inspected at regular intervals in accordance with legal requirements.

- Observe relevant national regulations.
- Drain the condensate out daily.

10.11 Venting the machine (de-pressurising)

After being switched off, the machine is still under pressure from the air network up to the check valve.



The machine must be isolated from the air network and completely vented before undertaking any maintenance or service work on the pressure system.

Precondition The supply disconnecting device is switched off, the device is locked off, the absence of voltage has been verified. The machine has cooled down.



10-P0086

Fig. 14 Venting the machine

- ① Condensate drain tap



DANGER

Compressed air!

Compressed air and devices under pressure can injure or cause death if the contained energy is released suddenly.

- Isolate the compressor from the air system.

1. Open the condensate drain slowly and release pressure completely.
2. Check that the air receiver pressure gauge reads 0 bar.



After automatic venting the pressure gauge does not read zero?

Shut-off valve still open.

- Defective condensate drain.
- If manual venting does **not** bring the oil separator tank pressure gauge to zero: Contact the authorised KAESER Service.

10.12 Maintaining the check valve

The check valve is installed in the air receiver inlet port. It prevents the compressed air from flowing back from the air receiver to the compressor block.

Material Compressed air for blowing out
Cleaning cloths
Spares as required

Precondition The supply disconnecting device is switched off, the device is locked off, the absence of voltage has been verified.
The machine is completely depressurised (pressure gauge reads 0 bar).
The machine has cooled down.




Fig. 15 Cleaning the check valve

- | | | | |
|---|------------|---|------------|
| ① | Enclosure | ④ | Valve seat |
| ② | Screw plug | ⑤ | Spring |
| ③ | Valve cone | ⑥ | O-ring |



CAUTION

Danger of burns from hot components!

- Wear long-sleeved clothing and gloves.
- Work carefully.

1. Remove the plug.
2. Clean the valve cone and seat.



The complete valve must be replaced if the valve seat is badly worn or damaged.

3. Insert the valve cone and spring in the housing.
4. Reseal the housing with the plug and O-ring.

10.13 Maintenance of the pressure switch unloading valve

The unloading valve must be cleaned in the following circumstances:

- Machine starts with difficulty.
- The machine does not vent after switching off.

Material Compressed air for blowing out
Cleaning cloths
Spares as required

Precondition The supply disconnecting device is switched off,
the device is locked off,
the absence of voltage has been verified.
The machine is completely depressurised (pressure gauge reads 0 bar).
The machine has cooled down.




Fig. 16 Maintenance of the pressure switch unloading valve

- | | |
|-------------------|--------------------|
| ① Unloading valve | ⑤ Spring |
| ② Screw | ⑥ Gasket |
| ③ Screw plug | ⑦ Valve cone |
| ④ Ball | ⑧ Screw connection |



Open the valve carefully.

1. Remove the fitting from the valve.
2. Loosen the securing screws and take off the unloading valve.
3. Remove the screw plug and take out the individual parts.
4. Extract the valve cone and clean it together with the other parts.
5. After reassembly insert the valve and tighten down with the screw.

10.14 Cleaning the filter regulator

Empty accumulating condensate at regular intervals, at least once a day.

Material Compressed air for blowing out
Cleaning rags
Spare parts as required

Precondition The power supply disconnecting device is switched off.
The disconnecting device is locked in the off position.
A check has been made that no voltage is present.
Machine is fully vented (no pressure).

- Drain condensate.



- Collect the condensate in a suitable container and dispose of in accordance with environmental regulations.

Cleaning the filter element




Fig. 17 Cleaning the Filter Regulator

- | | | | |
|---|-------------------|---|------------------------|
| ① | Condensate outlet | ③ | Label (cleaning agent) |
| ② | Housing | ④ | Filter element |

1. Unscrew and clean the housing and filter element.



Refer to the label on the housing for selection of the cleaning agent.

2. Blow out the housing with compressed air (<5 bar).
3. Reassemble the parts and make sure they sit correctly.

10.15 Cylinder Head and Valves

The condition of the valves can be assessed by measuring the receiver charging time and comparing this with the charging time when the machine was new.

10.15.1 Checking the cylinder head and valves

Precondition Machine at operating temperature.

- Start the machine and measure the receiver charging time.

Result If there is a significant difference in the filling time to when the machine was new, have KAESER Service check or replace the valves.

Further information See chapter 7.7 for receiver filling time measurement.

10.16 Document maintenance and service work.

Machine number:

- Enter maintenance and service work carried out in the list.

Date	Maintenance task carried out	Operating hours	Signature

Tab. 29 Logged maintenance tasks

11 Spares, Operating Materials, Service

11.1 Note the Nameplate

The nameplate contains all information to identify your machine. This information is essential to us in order to provide you with optimal service.

- Please give the information from the nameplate with every enquiry and order for spares.

11.2 Ordering consumable parts and operating fluids/materials

KAESER consumable parts and operating materials are original Kaeser products. They are specifically selected for use in KAESER machines.



WARNING

There is risk of personal injury or damage to the machine resulting from the use of unsuitable spares or operating fluids/materials.

Unsuitable or poor quality consumable parts and operating fluids/materials may damage the machine or impair its proper function.

Damage to the machine can also result in personal injury.

- Use only original KAESER parts and operating fluids/materials.
- Have an authorised KAESER Service Technician carry out regular maintenance.



11-P0085

Fig. 18 Consumable parts

- 10 Air filter
- 20 Check valve

Machine

Name	Quantity	Number
Air filter	2	10
Check valve	1	20
Compressor oil VDL 150	1,0l	9.0894.0
Compressor oil FGP	1,0l	9.0874.0

Tab. 30 Consumable parts

11.3 KAESER AIR SERVICE

KAESER AIR SERVICE offers:

- authorised service technicians with KAESER factory training,
- increased operational reliability ensured by preventive maintenance,

- energy savings achieved by avoidance of pressure losses,
 - optimum conditions for operation of the compressed air system,
 - the security of genuine KAESER spare parts,
 - increased legal certainty as all regulations are kept to.
- Why not sign a KAESER AIR SERVICE maintenance agreement!

Result Your advantage:
lower costs and higher compressed air availability.

11.4 Service Addresses

Addresses of KAESER agents are given at the end of this manual.

11.5 Spare Parts for Service and Repair



- Make sure that any service or repair tasks not described in this manual are carried out by an authorized KAESER Service Technician.

12 Decommissioning, Storage and Transport

12.1 De-commissioning

De-commissioning is necessary, for example, under the following circumstances:

- the machine is temporarily not needed,
- the machine is to be moved to another location,
- the machine is to be scrapped.

Temporary de-commissioning

Precondition The machine can be started at regular intervals.

- Run the machine once a week under load for at least 30 minutes to ensure corrosion protection.

Long-term de-commissioning

Precondition The machine must have run for at least 30 minutes before before long-term de-commissioning.

The mains disconnecting device is switched off.
The disconnecting device is locked in the off position.
A check has been made that no voltage is present.
Machine fully vented (no pressure).

1. Allow the machine to cool down completely.
2. Spray the valves and cylinder bore with Shell Ensis 20 preserving oil.



The preserving oil does not need to be removed when re-commissioning.

3. Drain condensate.
4. Disconnect all air and electrical connections.
5. Spray all contacts and terminals with a preservative (e.g. Rivalto, W.S.X.).

12.2 Packing

A wooden crate is required for overland transport to protect the machine from mechanical damage.
Consult KAESER Service for advice on packing for sea or air transport.

Material Desiccant
Plastic sheeting
Wooden transport crate

Precondition The machine is decommissioned.
Machine is dry and cooled down.

1. Wrap the machine in plastic sheeting.
2. Place sufficient desiccant (e.g. silica gel) inside the plastic sheeting.

12.3 Storage

Moisture can lead to corrosion, particularly on the surfaces of the compressor block.

Frozen moisture can damage components, diaphragms, valves and gaskets.



Advice can be obtained from KAESER on storage and commissioning.



CAUTION

Moisture and frost can damage the machine.

- Prevent ingress of moisture and formation of condensation.
- Maintain a storage temperature of $>0\text{ }^{\circ}\text{C}$.

- Store the machine in a dry, frost-proof room.

12.4 Transporting

12.4.1 Safety

Avoid damaging the machine.

- Transport only with the enclosure fully closed.

12.5 Disposal

When disposing of a machine, drain out all liquids and remove dirty filters.

Precondition The machine is decommissioned.

1. Completely drain the oil from the machine.
2. Remove old filters.
3. Hand the machine over to an authorized disposal expert.







- Components contaminated with oil must be disposed of in accordance with local environment protection regulations.

13 Annex

13.1 Dimensional Drawing

RAMIRENT




<p>KAESER KOMPRESSOREN</p> <p>K1-1830_0 10024673 D 02</p>	
<p>Premium car 660-70</p>	
Titel	Name
Dat.	02.10.2008
Zeichn.	Behr1
Proj.	06.10.2008
Freigegeben	Schneefl
Maßstab	1:5
<p>Erstellt für</p>	

Die Zeichnung bleibt unser ausschließliches Eigentum. Sie wird nur zu dem vereinbarten Zweck anvertraut und darf zu keinem anderen Zweck verwendet werden. Kopien oder sonstige Verwertigungen einschließlich Speicherung, Vervielfältigung oder Verbreitung unter Verwendung elektronischer Systeme dürfen nur zu dem vereinbarten Zweck angefertigt werden. Weder Original noch Vervielfältigungen dürfen Dritten ausgehändigt oder in sonstiger Weise zugänglich gemacht werden. Entwicklungsbedingte Änderungen vorbehalten. Zeichnung darf nur über CAD geändert werden.

Service Manual Reciprocating compressor

13.2 Electrical Diagram

RAMIRENT



- 1) See service manual, Technical specification: Electrical connection
2) See service manual, Technical specification: Drive motor

c		Datum	12.04.1996	E	Circuit diagram Reciprocating compressor-unit Three-phase	SKK.D-04.96/00400 Blatt 1
b		Bearb.	Reuß			
a		Gepr.				
d	Änderung	Datum	Name	Norm	Ersatz durch:	Ursprung: